



# EtherNet/IP Explicit Messaging Driver

1	System Configuration.....	3
2	External Device Selection .....	6
3	Communication Settings .....	7
4	Setup Items .....	15
5	Supported Device Addresses.....	26
6	Device Code and Address Code .....	36
7	Error Messages.....	40


**IMPORTANT**

- The below Displays are no longer sold nor maintained by Pro-face. To reduce unplanned downtime due to aged hardware and to maximize your cyber security environment we recommend replacing your devices with a new, successor model. For details, please visit our homepage for "Recommended Substitution". Discontinued from GP-Pro EX 5.00 onwards: GP3000 Series, LT3000 Series, ST3000 Series, GP-4100 Series (Monochrome model), PL Series, PS3000/4000 Series, PE4000 Series.
- For details on the Displays supported by the driver, please check the "Connectable Devices" on our website.  
<http://www.pro-face.com/trans/en/manual/1064.html>

**Introduction**

This manual describes how to connect the Display and the External Device (target PLC).

In this manual, the connection procedure is described in the sections identified below:



# 1 System Configuration

The following table lists system configurations for connecting External Devices and the Display.

Driver	CPU	Link I/F	SIO Type	Setting Example
EtherNet/IP	Explicit message server	Ethernet port on the External Device	Ethernet (TCP)	Setting Example 1 (page 7)

## NOTE

- The display unit operates as the Originator.

- External Device used to confirm connection

Driver	CPU	Link I/F	SIO Type	Setting Example
IAI CORPORATION. RCON	RCON-GW-EP-ET RCON-GW-EP	EtherNet/IP port on CPU	Ethernet (TCP)	Setting Example 2 (page 9)
FANUC CORPORATION CNC	FANUC Series 0i-MODEL F Plus	CD38R port on Fast Ethernet board of slot 1	Ethernet (TCP)	Setting Example 3 (page 11)

This driver is not certified by ODVA. Check the following when working with the driver.

- Implicit Messaging

The equipment listed below has been tested and confirmed to operate. For the latest list, refer to our home page (<http://www.pro-face.com/trans/en/manual/1056.html>). If you use equipment that is not listed, fully test the equipment in an operation environment.

CPU	Link I/F
WAGO Corporation Model: 750-352	Model: 750-402 Model: 750-467 Model: 750-504 Model: 750-550
Phoenix Contact Model: IL EIP BK DI8 DO4 2TX-PAC	Ethernet/IP Bus Coupler's Ethernet/IP connector
SMC Model: EX600-8EN1	SI unit's BUS connector
Applied Motion Products Model: ST10-IP-EE	-
Schneider Electric Model: LMDCE571	-
Schneider Electric ATV320 Model: ATV320U04M3C	-

- Explicit Messaging


The service codes and data sizes you can use are as follows.

- Service code: Get\_Attribute\_Single, Set\_Attribute\_Single
- Data size: 16-Bit, 32-Bit


Use Custom Explicit Message to implement different service codes or data sizes.

## Connection Configuration


- 1:n Connection



- n:1 Connection



- n:m Connection



\*1 When 33 or more External Devices are connected, it is necessary to check [Increase allowable number of Devices/PLCs].

☞ "4.1 Setup Items in GP-Pro EX" (page 15)


\*2 The maximum number of connectable units varies depending on the External Device. Refer to your External Device manual for details.

**NOTE**

- Increasing the number of External Devices increases the communication load. If you use Implicit Messaging and the communication load is too high, you may not be able to get data. When that happens, to reduce the communication load, either increase the length of the Requested Packet Interval (RPI) or reduce the number of connected devices.  
Posted on the "Otasuke Pro!" (<http://www.pro-face.com/trans/en/manual/1001.html>) support site's download page for the ODVA EtherNet/IP Explicit Messaging driver is the configuration that worked in our test environment.
  - For Implicit Messaging multicast communication, use communication speeds of 100BASE-TX or faster.
  - When using this driver and the ODVA EtherNet/IP Target driver at the same time, the following restrictions apply.
    - Use ODVA EtherNet/IP Target driver version 1.13.04 or later.
-

## 2 External Device Selection

Select the External Device to be connected to the Display.



Setup Items	Setup Description
Number of Devices/PLCs	Enter an integer from 1 to 4 to define the number of Devices/PLCs to connect to the display.
Manufacturer	Select the manufacturer of the External Device to connect. Select "ODVA".
Series	Select the External Device model (series) and the connection method. Select "EtherNet/IP Explicit Messaging". In System configuration, make sure the External Device you are connecting is supported by "EtherNet/IP Explicit Messaging". ☞ "1 System Configuration" (page 3)
Port	Select the Display port to connect to the External Device.
Use System Area	Check this option to synchronize the system data area of the Display and the device (memory) of the External Device. When synchronized, you can use the External Device's ladder program to switch the display or display the window on the Display. Cf. GP-Pro EX Reference Manual "LS Area (Direct Access Method Area)" This feature can also be set in GP-Pro EX or in the Display's offline mode. Cf. GP-Pro EX Reference Manual "System Settings [Display Unit] - [System Area] Settings Guide" Cf. Maintenance/Troubleshooting Guide "Main Unit - System Area Settings"

### 3 Communication Settings

This section provides examples of communication settings recommended by Pro-face for the Display and the External Device.

#### 3.1 Setting Example 1

##### ■ GP-Pro EX Settings

##### ◆ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1

Summary

Manufacturer: ODVA Series: EtherNet/IP Explicit Messaging Port: Ethernet (TCP) [Change Device/PLC](#)

Text Data Mode: 2 [Change](#)

Communication Settings

Port No.: 1024 ☒ Auto

Timeout: 3 (sec)

Retry: 0

Wait To Send: 0 (ms) [Default](#)

Device-Specific Settings

Allowable Number of Devices/PLCs: 32 [Add Device](#) [Increase Allowable Number of Devices/PLCs](#)

No.	Device Name	Settings
1	PLC1	IP Address=192.168.0.001, Enable Implicit Messaging

[Add Indirect Device](#)

##### ◆ Device Setting

To display the [Individual Device Settings] dialog box, select the External Device and click [Settings] from [Device-Specific Settings] in the [Device/PLC] window.

Individual Device Settings

PLC1

Configuration

IP Address: 192.168.0.1

☐ Enable Implicit Messaging

Control / Status Address: USR 0

+0 Control Word  
+1 Status Word  
+2 Scan Count

☐ Enable Custom Explicit Message

[Default](#)

OK (O) Cancel

**◆ Notes**

- Check with your network administrator about the IP address you want to use. Do not duplicate IP addresses on the same network.
- In [Individual Device Settings], set the IP address of the External Device.
- Set the Display's IP address in offline mode.

**■ External Device Settings**

The communication settings vary depending on the External Device.

Refer to your External Device manual for details.

## 3.2 Setting Example 2

### ■ GP-Pro EX Settings

#### ◆ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1

Summary

Manufacturer: ODVA Series: EtherNet/IP Explicit Messaging Port: Ethernet (TCP) [Change Device/PLC](#)

Text Data Mode: 2 [Change](#)

Communication Settings

Port No.: 1024 ☒ Auto

Timeout: 3 (sec)

Retry: 0

Wait To Send: 0 (ms) [Default](#)

Device-Specific Settings

Allowable Number of Devices/PLCs: 32 [Add Device](#) [Increase Allowable Number of Devices/PLCs](#)

No. Device Name Settings

No.	Device Name	Settings
1	PLC1	IP Address=192.168.250.003, Enable Implicit Messagin

[Add Indirect Device](#)

#### ◆ Device Setting

To display the [Individual Device Settings] dialog box, select the External Device and click [Settings] from [Device-Specific Settings] in the [Device/PLC] window.

For periodic communication between the External Device and Display: Click the [Implicit Messaging] tab, select either [Input/Output] or [Input Only] for the connection mode, and specify values for associated settings.

Individual Device Settings

PLC1

Configuration

IP Address: 192.168.250.3

☒ Enable Implicit Messaging

Control / Status Address: USR 10000

☐ Enable Custom Explicit Message

[Default](#)

[OK \(O\)](#) [Cancel](#)

Individual Device Settings

PLC1

Configuration

Implicit Messaging

Connection: Input/Output

	Size (8-Bit)	Assembly Instance	Address
Input (T->O)	64	100	USR 11000
Output (O->T)	64	150	USR 12000
Configuration (O->T)	0	1	USR 0

Requested Packet Interval: 50 10ms - 10000ms

Byte Order in 16-Bit Word: L/H

☐ Use Unicast Connection

O->T Format: 32-bit Header

T->O Format: Modeless

[Import from EDS File](#)

[OK \(O\)](#) [Cancel](#)

## ◆ Notes

- Check with your network administrator about the IP address you want to use. Do not duplicate IP addresses on the same network.
- In [Individual Device Settings], set the IP address of the External Device.
- Set the Display's IP address in offline mode.

## ■ External Device Settings

Use the MODE selector switch and the Parameter Configuration Tool in the IAI GateWay Unit Software, or IAI-OS Software, for defining communication settings. Please refer to the manual of the External Device for more details.

When using the Parameter Configuration Tool in the IAI GateWay Unit Software

- (1) Set the MODE selector switch to "MANU".
- (2) Select [EthernetIP setting(I)] from [Setting].
- (3) Set the IP address, subnet mask, and default gateway.

---

**IMPORTANT** • Set the External Device and Display to the same IP address.

---

When using IAI-OS Software

- (1) Set the MODE selector switch to "MANU".
- (2) Click the status tab.
- (3) Select [PC] -> [COM10] -> [GW No.0 RCON-GW] -> [Parameter edit].
- (4) Click [Network setting] tab.
- (5) Set the IP address, subnet mask, and default gateway.

---

**IMPORTANT** • Set the External Device and Display to the same IP address.

---

## ◆ About O-&gt;T Format and T-&gt;O Format

To use Advanced Configuration, set the [O->T Format] and [T->O Format] shown on the [Implicit Messaging] tab as below.

Setup Items	Setting Value
O->T Format	32-bit header
T->O Format	Modeless

---

**IMPORTANT** • Set the External Device and the Display to the same setting.

---

### 3.3 Setting Example 3

#### ■ GP-Pro EX Settings

##### ◆ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1

Summary

Manufacturer: ODVA Series: EtherNet/IP Explicit Messaging Port: Ethernet (TCP) [Change Device/PLC](#)

Text Data Mode: 2 [Change](#)

Communication Settings

Port No.: 1024 ☒ Auto

Timeout: 3 (sec)

Retry: 0

Wait To Send: 0 (ms) [Default](#)

Device-Specific Settings

Allowable Number of Devices/PLCs: 32 [Add Device](#) [Increase Allowable Number of Devices/PLCs](#)

No. Device Name Settings

No.	Device Name	Settings
1	PLC1	IP Address=192.168.001.001, Enable Implicit Messagin

[Add Indirect Device](#)

##### ◆ Device Setting

To display the [Individual Device Settings] dialog box, select the External Device and click [Settings] from [Device-Specific Settings] in the [Device/PLC] window.

For periodic communication between the External Device and Display: Click the [Implicit Messaging] tab, select either [Input/Output] or [Input Only] for the connection mode, and specify values for associated settings.

Individual Device Settings

PLC1

Configuration [Implicit Messaging](#)

IP Address: 192.168.1.1

☒ Enable Implicit Messaging

Control / Status Address: USR 0

+0 Control Word  
+1 Status Word  
+2 Scan Count

☐ Enable Custom Explicit Message

[Default](#)

[OK \(O\)](#) [Cancel](#)

Individual Device Settings

PLC1

Configuration [Implicit Messaging](#)

Connection: [Input/Output](#)

	Size (8-Bit)	Assembly Instance	Address
Input (T->O)	500	101	USR 100
Output (O->T)	500	151	USR 500
Configuration (O->T)	0	100	USR 900

Requested Packet Interval: 100 10ms - 10000ms

Byte Order in 16-Bit Word: L/H

☐ Use Unicast Connection

O->T Format: 32-bit Header

T->O Format: Modeless

[Import from EDS File](#)

[OK \(O\)](#) [Cancel](#)

## ◆ Notes

- Check with your network administrator about the IP address you want to use.
- Do not duplicate IP addresses on the same network.
- In [Individual Device Settings], set the IP address of the External Device.
- Set the Display's IP address in offline mode.
- Be sure to configure the External Device setting.

## ■ External Device Settings

Set the communication settings for the External Device on the CNC screen.

Please refer to the manual of the External Device for more details.

## ◆ Procedure

- 1 Turn on the power of CNC.
- 2 Press the function key [SYSTEM] to display the parameter setting screen.
- 3 Enter "9", "7", and "0" using the numeric keys.
- 4 Enter the following values for each parameter and press the [INPUT] key.

Parameter No.	Setting	Remarks
970	-1	Does not use the Ethernet function, data server function, or Modbus/TCP server function.
971	-1	Does not use the FL-net function.
972	-1	Does not use the FL-net PORT2 function.
973	-1	Does not use the PROFINET IO device function.
974	-1	Does not use the PROFINET IO controller function.
975	-1	Does not run EtherNet/IP functionality on the same hardware option as Ethernet functionality.
976	23 or 33	Select the operating mode for the EtherNet/IP function when it is running on hardware other than the standard Ethernet function. 23: CNC can only operate as an EtherNet/IP adapter. 33: CNC can operate as both an EtherNet/IP adapter and scanner.

- 5 Restart the CNC. If the alarm (PW0050) appears, restart the CNC again.
- 6 After restarting, press the function key [SYSTEM].
- 7 Press the [<] or [>] button on the screen until the soft key [EtherNet/IP] appears.
- 8 Press the soft key [EtherNet/IP].
- 9 Enter the following values for each item and press the [INPUT] key.

Setup Items	Setting	Remarks
IP Address	192.168.1.1	Enter the IP address.
SUBNET MASK	255.255.255.0	Enter the subnet mask.
ROUTER IP ADDRESS	Blank	Enter the router IP address.

**NOTE**

- When EtherNet/IP communications is not running on the same physical hardware as Ethernet communications, DHCP Client setting is not available.  
To use the DHCP client function, set parameter 904#6 to ON.

10 Press the [<] or [>] buttons on the screen until the soft key [EIP A SET] appears.

11 Press the soft key [EIP A SET].

12 Enter the following values for each item and press the [INPUT] key.

Setup Items	Setting	Remarks
PORT NUMBER (TCP)	44818	This item cannot be changed.
PORT NUMBER (UDP)	2222	This item cannot be changed.
DI DATA ON ABNORMAL	Keep	Selects DI work if DI refresh stop occurs. Keep: Holds the DI data value. Clear: Clears the DI data value to 0.
STATUS ADDRESS	Blank	To use status monitoring, set PMC area to this item.
STATUS	0	To enable the status address in the PMC area input, set the data size to 1 or 3.
OPTION 1	00000000	Bit0 to 1: DHCP client. Bit2: Output EDS file format. Bit3 to 7: Reserved (Always 0.)
OPTION 2	00000000	Bit0: Perform initialization setting at CNC boot (0: Disabled, 1: Enabled). Bit1 to 7: Reserved (Always 0.)

13 Press the page change key [PAGE DOWN].

14 Press the soft key [OPRT].

15 Press the soft key [STATE].

16 Press the soft key [DISABLE].

17 Enter the following values for each item and press the [INPUT] key.

Setup Items		Setting	Remarks
DI	TYPE	1	Selects whether to enable or disable the DI setting. 0: Not used 1: Used
	ADDRESS	Any address	Enter the storage address of the PMC area.
	SIZE	500	Enter the size of the DI.

Setup Items		Setting	Remarks														
DO	TYPE	1	Selects whether to enable or disable the DO setting. 0: Not used 1: Used														
	ADDRESS	Any address	Enter the storage address of the PMC area.														
	SIZE	500	Enter the size of the DO.														
	DO TAG	Blank	This setting is required when using EtherNet/IP tag communication. However, the Explicit message driver does not use tag communication.														
	OPTION	00000000	Bit0 to 1: Data size <table border="1"><thead><tr><th>Bit1</th><th>Bit0</th><th>Data size</th></tr></thead><tbody><tr><td>0</td><td>0</td><td>Byte</td></tr><tr><td>0</td><td>1</td><td>Word</td></tr><tr><td>1</td><td>0</td><td>Long</td></tr><tr><td>1</td><td>1</td><td>Not used</td></tr></tbody></table> Bit2: Endian setting. 0: Disable 1: Enable Bit3 to 7: Reserved (Always 0.)	Bit1	Bit0	Data size	0	0	Byte	0	1	Word	1	0	Long	1	1
Bit1	Bit0	Data size															
0	0	Byte															
0	1	Word															
1	0	Long															
1	1	Not used															

18 Press the soft key [OPRT].

19 Press the soft key [STATE].

20 Press the soft key [ENABLE].

21 Restart the CNC.

#### ◆ Notes

- Check with your network administrator about the IP address you want to use.
- Do not duplicate IP addresses on the same network.

## 4 Setup Items

Set up the Display's communication settings in GP Pro-EX or in the Display's offline mode.

The setting of each parameter must match that of the External Device.

☞ "3 Communication Settings" (page 7)

### NOTE

- You need to set the Display's IP address in offline mode.

Cf. Maintenance/Troubleshooting Guide "Ethernet Settings"

### 4.1 Setup Items in GP-Pro EX

#### ■ Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].


Setup Items	Setup Description
Port No.	Use an integer from 1024 to 65535 to enter the port number of the Display. When you check the option of [Auto Assign], the port number will be automatically set.
Timeout	Use an integer from 1 to 127 to enter the time (seconds) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.
Wait To Send	Use an integer from 0 to 255 to enter the amount of standby time (milliseconds) the Display counts from the time it receives a packet to the time it transmits the next command.
Increase Allowable Number of Devices/PLCs	<p>When clicked, the [Increase Allowable Number of Devices/PLCs] dialog box is displayed. When you check [Increase allowable number of Devices/PLCs], the settings for [Allowable Number of Devices/PLCs] can be extended to "64".</p>

**NOTE**


- Refer to the GP-Pro EX Reference Manual for Indirect Device.

Cf. GP-Pro EX Reference Manual "Changing the Device/PLC at Runtime (Indirect Device)"

## ■ Device Settings


To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]  .

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.



Setup Items	Setup Description
IP Address	<p>Set the IP address of the External Device.</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• Check with your network administrator about the IP address you want to use. Do not duplicate IP addresses on the same network.</li> </ul>
Enable Implicit Messaging	To use Implicit Messaging, select the [Enable Implicit Messaging] check box. The [Implicit Messaging] tab will appear.
Enable Custom Explicit Message	To use Custom Explicit Messages, select the [Enable Custom Explicit Message] check box. The [Custom Explicit Message] tab will appear.

- ◆ Implicit Messaging
  - Configuration



Setup Items	Setup Description
Control / Status Address	Set the address for control and status display. Three words from the defined address are used for control and status.

Description of Control / Status Addresses:

Address	Function	Description
+0	Control Word	Bit 0: I/O scanning control (1: Start, 0: Stop) Bit 1 - 15: Unused
+1	Status Word	Bit 0: I/O scanning control (1: Receiving, 0: Default or did not receive) Bit 1 - 15: Unused
+2	Scan Count	Counts up whenever new input data is received from the External Device.

- Implicit Messaging

Individual Device Settings

PLC1

Configuration Implicit Messaging

Connection Input/Output

	Size (8-Bit)	Assembly Instance	Address
Input (T->O)	500	1	USR 0
Output (O->T)	496	1	USR 0
Configuration (O->T)	0	1	USR 0

Requested Packet Interval 100 10ms - 10000ms

Byte Order in 16-Bit Word L/H

☐ Use Unicast Connection


O->T Format 32-bit Header

T->O Format Modeless

Import from EDS File


OK (O) Cancel

Setup Items	Setup Description
Connection	<p>Select the connection type of the External Device. Select from the following items.</p> <ul style="list-style-type: none"> <li>• Input/Output Reads input data from the External Device. And, writes output data to the External Device.</li> <li>• Input Only Reads input data from the External Device. Sends a heartbeat every 250 milliseconds.</li> <li>• Listen Only Reads input data from the External Device. This option is available only when other External Devices are connected using [Input/Output] or [Input Only].</li> <li>• Output Only Writes output data to the External Device.</li> </ul>
Input (T->O)	<ul style="list-style-type: none"> <li>• Size / Assembly Instance Set the output data size and instance from the External Device. The defined values must match the External Device.</li> <li>• Address Set the USR address for storing data output from the External Device. Starting from the defined USR address, stores the number of bytes of data as defined in the [Size (8-bit)] field.</li> </ul>
Output (O->T)	<ul style="list-style-type: none"> <li>• Size / Assembly Instance Set the output data size and instance from the Display. The defined values must match the External Device.</li> <li>• Address Set the USR address for storing output data. Starting from the defined USR address, stores the number of bytes of data as defined in the [Size (8-bit)] field.</li> </ul> <p>Use this setting if you select [Input / Output] from the [Connection] list. Set [Size (8-bit)] to "0" to not use output.</p>
Heartbeat (O->T)	<p>Set the instance of heartbeats.</p> <p>Use this setting if you select [Input Only] or [Listen Only] from the [Connection] list.</p>

Setup Items	Setup Description										
Configuration (O->T)	<ul style="list-style-type: none"> <li>• <b>Size / Assembly Instance</b> Set the Configuration data size and instance. The defined values must match the External Device.</li> <li>• <b>Address</b> Set the address for storing configuration data. Starting from the defined USR address, stores the number of bytes of data as defined in the [Size (8-bit)] field. Before starting communication, set the Configuration data on the Display.</li> </ul> <div style="border: 1px solid black; padding: 2px; margin: 5px 0;"><b>NOTE</b></div> <ul style="list-style-type: none"> <li>• Set [Size (8-bit)] to "0" to not use configuration.</li> <li>• In the command for opening a connection (Forward_Open), if you do not include any parameters of the Configuration Instance in the Connection_Path, set the [Assembly Instance] to 0.</li> </ul>										
Requested Packet Interval	Set the interval of packets sent from the External Device.										
Byte Order in 16-Bit Word	Set the data storage order of 16-bit word units.										
Use Unicast Connection	To use unicast communication, select the [Use Unicast Connection] check box. To use multicast communication, clear the [Use Unicast Connection] check box.										
O->T Format T->O Format	<p>Set the [O-&gt;T Format] and [T-&gt;O Format]. These settings must match the External Device. You can load an EDS file to define these settings.</p> <table border="1" style="margin: 10px auto; border-collapse: collapse;"> <thead> <tr> <th>Setup Items</th><th>Corresponding Format</th></tr> </thead> <tbody> <tr> <td>Modeless</td><td>Modeless format</td></tr> <tr> <td>Zero Idle</td><td>Zero length data format</td></tr> <tr> <td>Heartbeat</td><td>Heartbeat format</td></tr> <tr> <td>32-bit Header</td><td>32-bit header format</td></tr> </tbody> </table> <div style="border: 1px solid black; padding: 2px; margin: 5px 0;"><b>NOTE</b></div> <ul style="list-style-type: none"> <li>• When the [Connection] is either [Input only] or [Listen only], the [O-&gt;T Format] is fixed to Heartbeat.</li> <li>• If loading an EDS file, specify the [Connection] setting beforehand. When you change the [Connection] setting, [O-&gt;T Format] and [T-&gt;O Format] return to their default settings.</li> </ul>	Setup Items	Corresponding Format	Modeless	Modeless format	Zero Idle	Zero length data format	Heartbeat	Heartbeat format	32-bit Header	32-bit header format
Setup Items	Corresponding Format										
Modeless	Modeless format										
Zero Idle	Zero length data format										
Heartbeat	Heartbeat format										
32-bit Header	32-bit header format										
Import from EDS File	<p>Load the EDS file.</p> <p> " ■ Importing EDS File" (page 21)</p>										

## ◆ Custom Explicit Message

- Custom Explicit Message



Setup Items	Setup Description
Message Control Address	Set the address to use for control. Ten words from the defined address are used for control.
Byte Order in 16-Bit Word	Set the data storage order of 16-bit word units.

Description of Message Control Addresses:

Address	Function	Description
+0	Service Code	-
+1	Object Class ID	-
+2	Instance	-
+3	Attribute	-
+4	Source Data Size (0 - 256)	Size of send data
+5	Destination Data Size (0 - 256)	Size of receive data
+6	Control Word	Bit 0: Command to send (data is sent on change from 0 to 1) Bit 1: Define whether to include the attribute in the send data (0: Include, 1: Exclude) Bit 2 - 15: Unused
+7	Status Word	Bit 0: Busy (1: Busy) Bit 1: Completion (1: Message received) Bit 2: Reserved Bit 3: Error flag (1: Error) Bit 4: Parameter error Bit 5: Communication error Bit 6: Timeout error Bit 7: Reserved Bit 8 - 15: Unused
+8	Source Address	Address on the Display that stores transmitted data.
+9	Destination Address	Address on the Display that stores received data.

## ■ Importing EDS File

(1) Click [Import from EDS File] on the Individual Device Settings.

Individual Device Settings

PLC1

Configuration Implicit Messaging

Connection Input/Output

	Size (8-Bit)	Assembly Instance	Address
Input (T->O)	64	100	USR 11000
Output (O->T)	64	150	USR 12000
Configuration (O->T)	0	1	USR 0

Requested Packet Interval 50 10ms - 10000ms

Byte Order in 16-Bit Word L/H

☐ Use Unicast Connection

O->T Format 32-bit Header

T->O Format Modeless

Import from EDS File

OK (O) Cancel

(2) Click [Import connection information from EDS File] on the Import Configuration.

Import Configuration

Import connection information from EDS File

Choose a connection


Connection Name	Connection Type	Input Size (bytes)	Output Size (bytes)	Config Size (bytes)	O->T

Confirm connection information


Connection	Size (8-bit)			Assembly Instance			RPI (ms)	O->T Format	T->O Format
	Input	Output	Config	Input	Output	Config			
Input/Output	64	64	0	100	150	1	50	32-bit Header	Modeless

OK Cancel


(3) Select EDS file and click [Open].



(4) The EDS file is loaded. Select the Connection to use and click [OK].



- (5) The contents of the EDS file are reflected in the Individual Device Settings.



## 4.2 Setup Items in Offline Mode

**NOTE**

- Refer to the Maintenance/Troubleshooting guide for information on how to enter offline mode or about the operation.

Cf. Maintenance/Troubleshooting Guide "Offline Mode"

- The number of the setup items to be displayed for 1 page in the offline mode depends on the Display in use. Please refer to the Reference manual for details.

### ■ Communication Settings

To display the setting screen, touch [Device/PLC Settings] from the [Peripheral Equipment Settings] tab in offline mode. Touch the External Device you want to set from the displayed list.

Comm.	Device			
EtherNet/IP Explicit Messaging [TCP] Page 1/1				
Port No. <input type="radio"/> Fixed <input checked="" type="radio"/> Auto <input type="text" value="1024"/> ▼ ▲				
Timeout(s) <input type="text" value="3"/> ▼ ▲				
Retry <input type="text" value="0"/> ▼ ▲				
Wait To Send(ms) <input type="text" value="0"/> ▼ ▲				
Exit				Back 2002/09/25 00:59:09

Setup Items	Setup Description
Port No.	Set the port number of the Display. Select either "Fixed" or "Auto". If you select [Fixed], use an integer from "1024 to 65535" to enter the port number of the Display. When you select [Auto], the port number will be automatically assigned regardless of the entered value.
Timeout	Use an integer from 1 to 127 to enter the time (seconds) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, use an integer from 0 to 255 to enter how many times the Display retransmits the command.
Wait To Send	Use an integer from 0 to 255 to enter the amount of standby time (milliseconds) the Display counts from the time it receives a packet to the time it transmits the next command.

## ■ Device Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Equipment Settings]. Touch the External Device you want to set from the displayed list, and touch [Device].

Comm.	Device			
EtherNet/IP Explicit Messaging [TCP] Page 1/1				
Device/PLC Name <input type="text" value="PLC1"/>				
IP Address <input type="text" value="192 168 0 1"/>				
Implicit Messaging Off				
Custom Explicit Off				
Exit		Back		2002/09/25 00:59:12

Setup Items	Setup Description
Device/PLC Name	Select the External Device to set. Device/PLC name is the title of the External Device set with GP-Pro EX. (Initial value [PLC1])
IP Address	Set the IP address of the External Device. <b>NOTE</b> Check with your network administrator about the IP address you want to use. Do not duplicate IP addresses on the same network.
Implicit Messaging	Shows the state for Implicit Messaging.
Custom Explicit	Shows the state for Custom Explicit Message.

## 5 Supported Device Addresses

The following section shows the range of supported device addresses. Please note that the actual supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your External Device.

### 5.1 EtherNet/IP, RCON

Enter the External Device address in the dialog box below.

- For word address

Class	Select the object class to which the explicit message is sent. When you select "Vendor defined", use "0000 to 04FF" to enter the class code.
Instance	Use "0000 to 0FFF" to enter the instance number that defines the instance of the class to receive the message.
Attribute	Use "0000 to 1FFF" to enter the value that defines the attribute (value) of the instance to be accessed.
Data Size	Select the data size from 2 or 4. Select "2" when the External Device object data size is 1. When the data is displayed on the Display, the upper 8 bits will be 0.
String Prefix	If the attribute to be accessed is a string, select the size (byte) of the area which stores the string length from 0, 1, 2, or 4. The string length varies depending on the attribute to be accessed. If the attribute to be accessed is other than a string, select "0".

<b>NOTE</b>	• If you check the [Set as Default Value] option, the set value for a new address entry will be displayed as the default value.
-------------	---

- For bit address

The screenshot shows the 'Input Address' dialog box. The 'Device/PLC' dropdown is set to 'PLC1'. The 'Class' dropdown is set to 'Identity', and the adjacent text box contains '1' with '(Hex)' to its right. The 'Instance' text box contains '0' with '(Hex)' to its right. The 'Attribute' text box contains '0' with '(Hex)' to its right. The 'Data Size' dropdown is set to '2' with '(bytes)' to its right. The 'Bit Number' dropdown is set to '0'. An 'Enter' button is located to the right of the 'Bit Number' field. At the bottom left, there is a checked checkbox labeled 'Set as Default Value'.

Class	Select the object class to which the explicit message is sent. When you select "Vendor defined", use "0000 to 04FF" to enter the class code.
Instance	Use "0000 to 0FFF" to enter the instance number that defines the instance of the class to receive the message.
Attribute	Use "0000 to 1FFF" to enter the value that defines the attribute (value) of the instance to be accessed.
Data Size	Select the data size from 2 or 4. Select "2" when the External Device object data size is 1. When the data is displayed on the Display, the upper 8 bits will be 0.
Bit Number	Select the bit number in the word. Select from "0 to 15" when the data size is 2, and from "0 to 31" when it is 4.

**NOTE**

- If you check the [Set as Default Value] option, the set value for a new address entry will be displayed as the default value.

## Communication format

This driver's communication format is as follows. If the communication format does not match the External Device, you cannot read or write data correctly.


- Display Unit input format

The "Sequence No." is added to the data. On data input, the Sequence No is removed.



- Display Unit output format

The Sequence No and Run/Idle Header is added to output data.




## Example communication operation

With Custom Explicit Message, when you read the data of address (0001,0000,0001)2:0, set the following value to Message Control Address (USR0). After set up, if Bit 0 of Control Word (USR00006) changes from 0 to 1, the 2 words of data that were read in are stored in the word address specified as the Destination Address (USR00200).

Address	Setting Value	Setup Description
USR00000	0x0E	Service Code
USR00001	0x01	Object Class
USR00002	0x00	Instance
USR00003	0x01	Attribute
USR00004	0x00	Source Data Size
USR00005	0x02	Destination Data Size
USR00006	0x00	Control Word
USR00007	0x00	Status Word
USR00008	0x64	Source Data
USR00009	0xC8	Destination Address

### NOTE

- Because External Device communication uses binary data, set the Display setting to [Bin] when reading or writing text string data.
- Set the Message Control Address in the [Individual Device Settings] dialog box.  
 " ■ Device Settings" (page 16)

Device	Bit Address	Word address	32 bits	Remarks
Class, Instance, Attribute, Bit Number, String Prefix, Data Size	Class: 0000h - 04FFh Instance: 0000h - 0FFFh Attribute: 0000h - 1FFFh Data Size: 2, 4 Bit Number: 00 - 31	Class: 0000h - 04FFh Instance: 0000h - 0FFFh Attribute: 0000h - 1FFFh Data Size: 2, 4 String Prefix: 0, 1, 2, 4	<div style="border: 1px solid black; padding: 2px; display: inline-block;">L / H</div> or <div style="border: 1px solid black; padding: 2px; display: inline-block;">H / L</div> <small>*1</small>	*2

\*1 The high and low relationship of the stored data varies depending on the External Device. Refer to your External Device manual for details.

\*2 You can set only Read Area Size for the system area available to use in the External Device. The size that can be used for the Read Area varies depending on the object to be specified.

**NOTE**

- Refer to the precautions on manual notation for icons in the table.




"Manual Symbols and Terminology"


- The corresponding service codes are Get\_Attribute\_Single(0x0E) and Set\_Attribute\_Single(0x10).
- The device monitor function on the Display is not supported.
- The first 1 word of each attribute is displayed in map display of the External Device address.
- When the number of the word that is more than the specified attribute size is displayed in data displays, the data value of the exceeded word is "0".
- When using D-Script's "Copy Memory" command to copy multiple word data, set the attribute size so it fits in 128 words or less. If you exceed 128 words, data for excess words become 0. When copying word data exceeding 128 words, split up the word data.
- When the device is monitored using "Device Monitor" of Pro-Server EX, the data values for 128 words are displayed for 1 attribute. However, the actual data value is the same number as set for the attribute. The data value of the exceeded word is "0".

The address input area is shown below.

- For word address



- For bit address



## 5.2 FANUC Series 0i-MODEL F Plus

Data Type	Bit Address	Word Address	32 bit	Remarks
DI (T->O)	DI000.00 - DI249.15	DI000 - DI249	<input type="checkbox"/> L <input type="checkbox"/> H	*1
DO (O->T)	DO000.00 - DO249.15	DO000 - DO249	<input type="checkbox"/> L <input type="checkbox"/> H	*1

\*1 The R, E, and D areas of the PMC address can be assigned. For PMC address ranges, refer to FANUC's PMC Programming Manual (B-64513EN). The range of addresses that can be used should match the data size set in the External Device.

### ■ Specifying Address

To display the value of the PMC address of the External Device in the Display, specify the address in the USR area. The address to be specified depends on the setting.

- Implicit Message

(Example)

Configure the External Device and GP-Pro EX as follows.

EIP adapter settings for External Device (ALLOCATION01)

Setup Items	Setting value
DI	-
TYPE	1
ADDRESS	1:R0000
SIZE	10
DO	-
TYPE	1
ADDRESS	1:E0500
SIZE	10

GP-Pro EX's [Individual Device Settings]

In this case, the PMC address is assigned to the USR area as follows. For example, the value of R0002 is stored in the upper 8 bits of USR0101.

USR Area (16 Bits)	EIP Scanner (16 Bits)	PMC Address (8 Bits)
USR0100	DI000	R0000
		R0001
USR0101	DI001	R0002
		R0003
USR0102	DI002	R0004
		R0005
USR0103	DI003	R0006
		R0007
USR0104	DI004	R0008
		R0009
USR0500	DO000	E0500
		E0501
USR0501	DO001	E0502
		E0503
USR0502	DO002	E0504
		E0505
USR0503	DO003	E0506
		E0507
USR0504	DO004	E0508
		E0509

- Custom Explicit Message


(Example)

Configure the External Device and GP-Pro EX as follows.

EIP adapter settings for External Device (ALLOCATION01)

Setup Items	Setting value
DI	-
TYPE	1
ADDRESS	1:R0000
SIZE	10
DO	-
TYPE	1
ADDRESS	1:E0500
SIZE	10

## GP-Pro EX's [Individual Device Settings]



To read the value of the PMC address, write the following value to the [Message Control Address] set in the [Custom Explicit Message] tab. Then write “1” to USR0016, and the PMC address value will be written to USR0200 to USR0209.

**NOTE**

- Class, instance, attribute, and data size values should match the External Device settings.

Address	Setting value	Setting Details
USR0010	0x000E	Service Code 0x000E: Read
USR0011	0x0004	Object Class
USR0012	0x0065	Instance 0x065: DI (T->O)
USR0013	0x0003	Attribute
USR0014	0x0000	Source Data Size
USR0015	0x0005	Destination Data Size (Example) 0x0005: 5 words
USR0016	0x0000	Control Word
USR0017	0x0000	Status Word
USR0018	0x0000	Source Address
USR0019	0x00C8	Destination Address (Example) 0x00C8: USR0200

## Address Mapping

USR Area (16 Bits)	EIP Scanner (16 Bits)	PMC Address (8 Bits)
USR0200	DI000	R0000
		R0001
USR0201	DI001	R0002
		R0003
USR0202	DI002	R0004
		R0005
USR0203	DI003	R0006
		R0007
USR0204	DI004	R0008
		R0009

To write the value to the PMC address, write the following value to [Message Control Address]. Then, write “1” to USR0016, and the values from USR0100 to USR0105 will be written to the PMC address.

**NOTE**

- Class, instance, attribute, and data size values should match the External Device settings.

Address	Setting value	Setting Details
USR0010	0x0010	Service Code 0x0010: Write
USR0011	0x0004	Object Class
USR0012	0x0065	Instance 0x0065: DI (T->O) 0x0097: DI (O->T)
USR0013	0x0003	Attribute
USR0014	0x0005	Source Data Size (Example) 0x0005: 5 words
USR0015	0x0000	Destination Data Size
USR0016	0x0000	Control Word
USR0017	0x0000	Status Word
USR0018	0x0064	Source Address (Example) 0x0064: USR0100
USR0019	0x0000	Destination Address

## Address Mapping

USR Area (16 Bits)	EIP Scanner (16 Bits)	PMC Address (8 Bits)
USR0100	DI000	R0000
		R0001

USR Area (16 Bits)	EIP Scanner (16 Bits)	PMC Address (8 Bits)
USR0101	DI001	R0002
		R0003
USR0102	DI002	R0004
		R0005
USR0103	DI003	R0006
		R0007
USR0104	DI004	R0008
		R0009

## 6 Device Code and Address Code

Use device code and address code if you select "Device Type & Address" for the address type in data displays.

**NOTE**

- For device code and address code, the address whose instance number is "0" can be used.

Class Name	Class Code (HEX)	Device Code (HEX)	Address Code
Identity	0001	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Message Router	0002	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
DeviceNet	0003	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Assembly	0004	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Connection	0005	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Connection Manager	0006	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Register	0007	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Discrete Input Point	0008	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Discrete Output Point	0009	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Analog Input Point	000A	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Analog Output Point	000B	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Presence Sensing	000E	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Parameter	000F	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80

Class Name	Class Code (HEX)	Device Code (HEX)	Address Code
Parameter Group	0010	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Group	0012	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Discrete Input Group	001D	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Discrete Output Group	001E	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Discrete Group	001F	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Analog Input Group	0020	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Analog Output Group	0021	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Analog Group	0022	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Position Sensor	0023	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Position Controller Supervisor	0024	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Position Controller	0025	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Block Sequencer	0026	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Command Block	0027	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Motor Data	0028	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Control Supervisor	0029	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80

Class Name	Class Code (HEX)	Device Code (HEX)	Address Code
AC/DC Drive	002A	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Acknowledge Handler	002B	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Overload	002C	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Softstart	002D	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Selection	002E	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
S-Device Supervisor	0030	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
S-Analog Sensor	0031	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
S-Analog Actuator	0032	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
S-Single Stage Controller	0033	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
S-Gas Calibration	0034	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Trip Point	0035	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
File	0037	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
S-Partial Pressure	0038	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Connection Configuration	00F3	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Port	00F4	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80

Class Name	Class Code (HEX)	Device Code (HEX)	Address Code
TCP/IP Interface	00F5	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
EtherNet Link	00F6	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80
Vendor defined	Other class codes than noted above	Value of (Class code $\times$ 0x10) + Set value of the string prefix	Value of Attribute $\times$ 0x80

## 7 Error Messages

Error messages are displayed on the Display screen as follows: "No. : Device Name: Error Message (Error Occurrence Area)". Each description is shown below.

Item	Description
No.	Error number
Device Name	Name of the External Device where an error has occurred. Device/PLC name is the title of the External Device set with GP-Pro EX. (Initial value [PLC1])
Error Message	Displays messages related to an error that has occurred.
Error Occurrence Area	<p>Displays the IP address or device address of the External Device where an error has occurred, or error codes received from the External Device.</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>Received error codes are displayed as "Decimal [Hex]".</li> <li>Device addresses are displayed as "Address: Device address".</li> <li>IP addresses are displayed as "IP address (Decimal): MAC address (Hex)".</li> </ul>

Example of an Error Message

"RHAA035: PLC1: Error has been responded for device write command (Error Code: 1[01H])"

- NOTE**
- Refer to your External Device manual for details on received error codes.
  - Refer to "Display-related errors" in "Maintenance/Troubleshooting Guide" for details on the error messages common to the driver.

### ■ Error Codes Unique to External Device

- NOTE**
- The general status codes and extended status codes are defined in the ODVA document. Refer to your ODVA manual for details.
- The code to be used varies depending on the External Device. Refer to your External Device manual for details.

General status code	Extended status code	Description
0x01	0x0100 - 0xFCFF	Connection failure
0x02		Resource unavailable
0x03		Invalid parameter value
0x04		Path segment error
0x05		Path destination unknown
0x06		Partial transfer
0x07		Connection lost
0x08		Service not supported
0x09	Index to element	Invalid attribute data detected
0x0A		Attribute list error

General status code	Extended status code	Description
0x0B		Already in requested mode/state
0x0C		Object state conflict
0x0D		Object already exists
0x0E		Attribute not settable
0x0F		Privilege violation
0x10		Device state conflict
0x11		Reply data too large
0x12		Fragmentation of a primitive value
0x13		Not enough data
0x14		Attribute not supported
0x15		Too much data
0x16		Object does not exist
0x17		Service fragmentation sequence not in progress
0x18		No stored attribute data
0x19		Store operation failure
0x1A		Routing failure, request packet too large
0x1B		Routing failure, response packet too large
0x1C		Missing attribute list entry data
0x1D		Invalid attribute value list
0x1E		Embedded service error
0x1F		Vendor specific error
0x20		Invalid parameter
0x21		Write-once value or medium already written
0x22		Invalid reply received
0x23		Reserved
0x24		Reserved
0x25		Key failure in path
0x26		Path size invalid
0x27		Unexpected attribute in list
0x28		Invalid member ID
0x29		Member not settable
0x2A		Group 2 only server general failure
0x2B		Reserved
:		
0xCF		
0xD0		Reserved
:		
0xFF		

## ■ Error Messages Unique to External Device

Error No.	Error Message	Description
RHxx130	(Node Name): Error has been responded for device read command (General status: [Hex], Extended status [Hex])	Displayed when error occurs by device read command. Please check the specifications or settings by referring to the External Device manual.
RHxx131	(Node Name): Error has been responded for device write command (General status: [Hex], Extended status [Hex])	Displayed when error occurs by device write command. Please check the specifications or settings by referring to the External Device manual.
RHxx133	(Node Name):Error has been received for Implicit Open command (General status:[(Hex)], Extended status:[(Hex)])	Displays when an error occurs on opening the Implicit I/O connection. Make sure the Implicit I/O settings are correct.
RHxx134	(Node Name):Error has been received for Implicit Close command (General status:[(Hex)], Extended status:[(Hex)])	Displays when an error occurs on closing the Implicit I/O connection. Make sure the Implicit I/O settings are correct.
RHxx135	(Node Name):Illegal Response for Implicit Open Command	Displays when there is a problem with the response for an Implicit open command.
RHxx136	(Node Name):Illegal Response for Implicit Close Command	Displays when there is a problem with the response for an Implicit close command.
RHxx137	(Node Name):Illegal Response for Custom Explicit Message	Displays when there is a problem with the response for a Custom Explicit Message.

### NOTE

- For the error without the Extended Status code, "0" is displayed.
- When using Implicit Messaging, communication errors may occur if processing on the display unit does not occur on time. Adjust the [Requested Packet Interval] to 100 ms or longer. Additionally, you can reduce the load on the display unit by decreasing the logic in the logic program or by decreasing the number of device read/write operations.