

Pro-face

**PS Series Type G
Application Development Kit
(ADK)**

Developer Manual

Preface

Thank you for purchasing Pro-face PS Series Type G Application Development Kit (hereafter referred to as “ADK”). This manual is the Developer Manual for the ADK, which contains the libraries and definition files necessary for developing applications that will run on Pro-face PS Series Type G Programmable Operator Interface (hereafter referred to as “PS-G unit”). Please read this manual thoroughly before using the ADK.

Important

- (1) The copyrights to all programs and manuals included in the “PS Series Type G Application Development Kit (ADK)” (hereafter referred to as “this product”) are reserved by the Digital Electronics Corporation. Digital grants the use of this product to its users as described in the “END-USER LICENSE AGREEMENT” documentation. Any actions violating the above-mentioned agreement is prohibited by both Japanese and foreign regulations.
- (2) The contents of this manual have been thoroughly inspected. However, if you should find any errors or omissions in this manual, please inform your local representative of your findings.
- (3) Regardless of article (2), the Digital Electronics Corporation shall not be held liable by the user for any damages, losses, or third party claims arising from the uses of this product.
- (4) Differences may occur between the descriptions found in this manual and the actual functioning of this product. Therefore, the latest information on this product is provided in data files (i.e. Readme.txt files, etc.) and in separate documents. Please consult these sources as well as this manual prior to using the product.
- (5) The specifications set out in this manual are for overseas products only. As a result, some differences may exist between the specifications given here and for those of the identical Japanese product.
- (6) Even though the information contained in and displayed by this product may be related to intangible or intellectual properties of the Digital Electronics Corporation or third parties, the Digital Electronics Corporation shall not warrant or grant the use of said properties to any users and/or other third parties.

© 2001, Digital Electronics Corporation. All rights reserved.

For details concerning trademarks, please refer to “About Trademarks”.

Documentation Conventions

In this manual the following warning symbols are used to indicate important points concerning safe and proper use of the ADK. Prior to operating the ADK, be sure to read these points carefully.

Warning Symbols

This manual's warning symbols indicate the following levels of danger.

| | |
|--|--|
|  WARNING | Failure to fully comply with points indicated by this symbol may result in death or serious injury. |
|  CAUTION | Failure to fully comply with points indicated by this symbol may result in injury or equipment damage. |
|  | Indicates actions or procedures that should NOT be performed. |
|  | Indicates actions or procedures that MUST be performed to ensure proper operation. |

The following mark is used in this manual in addition to the safety and warning symbols.

| | |
|--|---|
|  MEMO | Refers to related information or an additional explanation. |
|--|---|

About Trademarks

The company names and product names described in this manual are referred to in this manual by their trademarks (including registered trademarks) or service marks. These are abbreviated as follows:

| Trademark | Holder |
|--|---------------------------------|
| Microsoft, MS, Windows, Windows 95, Windows 98, Windows NT, Windows 2000, Windows CE, Windows Explorer, eMbedded Visual C++, eMbedded Visual Basic | Microsoft Corporation |
| Intel, Pentium | Intel Corporation |
| Pro-face | Digital Electronics Corporation |
| IBM, VGA, PC/AT | IBM |
| Adobe, Acrobat | Adobe Systems Incorporated |

The abbreviated trademarks in this manual correspond to the following official trademarks:

| Term used in this manual | Official Trademarks |
|-----------------------------------|---|
| Windows 95 | Microsoft® Windows 95® operating system |
| Windows 98 | Microsoft® Windows® 98 operating system |
| Windows NT | Microsoft® Windows NT® operating system |
| Windows 2000 | Microsoft® Windows® 2000 operating system |
| Windows CE | Microsoft® Windows® CE operating system |
| MS-DOS | Microsoft® MS-DOS® operating system |
| Pentium | Intel® Pentium® processors |
| Acrobat Reader 4.0 | Adobe® Acrobat® Reader 4.0 |
| eMbedded Visual Tools | Microsoft® eMbedded™ Visual Tools 3.0 |
| eMbedded Visual C++ | Microsoft® eMbedded™ Visual C++® 3.0 |
| eMbedded Visual Basic | Microsoft® eMbedded™ Visual Basic® 3.0 |
| ActiveSync 3.1 | Microsoft® ActiveSync® 3.1 |
| Microsoft Custom SDK | Microsoft® Custom Software Development Kit for Windows® CE, Version 3.0 |
| Windows CE Platform SDK (HPC Pro) | Microsoft® Software Development Kit for Windows® CE, Handheld P/C Professional Edition Version 3.01 |

PS Series Type G Model Numbers

The PS Series Type G units consist of the following models.

| Series | Model | Description | International standards |
|---------|------------------|--|--------------------------------------|
| PS-600G | PS600G-T11-J1 | Preinstalled with Windows CE 3.0 (Japanese). Input voltage AC100V | Not supported |
| | PS600G-T41-J124V | Preinstalled with Windows CE 3.0 (Japanese). Input voltage DC24V | CE Marking, UL/c-UL (CSA) compliant. |
| | PS600G-T41-E124V | Preinstalled with Windows CE 3.0 (English). Input voltage DC24V | CE Marking, UL/c-UL (CSA) compliant. |
| PS-400G | PS400G-T41-J124V | Preinstalled with Windows CE 3.0 (Japanese). Input voltage DC24V | CE Marking, UL/c-UL (CSA) compliant. |
| | PS400G-T41-E124V | Preinstalled with Windows CE 3.0 (English). Input voltage DC24V | CE Marking, UL/c-UL (CSA) compliant. |

Please note that the term PS-G in this manual refers only to the PS600G-T41-E124V and the PS400G-T41-E124V.

The Japanese version of the PS Series Type G Application Development Kit should be used to develop applications for PS-G units with preinstalled Japanese Windows CE 3.0. To develop applications for PS-G units with preinstalled English Windows CE 3.0, use the English version of the PS Series Type G Application Development Kit.

CD-ROM Contents

The CD-ROM provided with this ADK package contains the following:

| Item | Description | |
|---|---|---|
| PS Series Type G Application Development Kit (ADK) Developer Manual (This manual) | PDF manual for the PS Series Type G Application Development Kit (ADK) | |
| Acrobat Reader 4.0 | Software for viewing PDF files (Self-extracting file) | |
| PS Series Type G Application Development Kit (ADK) | Microsoft Custom SDK | Standard [Windows CE] library files |
| | PS Series Type G Platform SDK (Platform Developer Components for the Microsoft Custom SDK) | Library and header files that allow programs such as RAS, etc. to access specific PS-G unit hardware. |
| ActiveSync 3.1 | Enables communication between the PS-G unit and the personal computer used for developing applications. | |

Usage Precautions

WARNINGS

During Program Development

-  Do not design emergency stop switches that require activation via the PS-G unit's touch panel. For industrial machinery or equipment, installation of a physically activated mechanical-type emergency switch is likely to be required by law. Also, for devices or equipment other than the above, be sure to install a safety switch that complies with all relevant laws and regulations.

CAUTIONS

Handling of CD-ROM disk

-  Be sure to remove the CD-ROM disk before turning your personal computer's power OFF.
-  Do not attempt to remove the CD-ROM disc while the drive lamp is lit.
-  Do not touch the CD-ROM data surface.
-  Keep this disc away from excessively high or low temperatures, and environments with prolonged high humidity and dust.
-  Do not turn OFF your personal computer's power while a program is running.

Table of Contents

| | |
|--|------|
| Preface | 1 |
| Documentation Conventions | 2 |
| About Trademarks | 3 |
| PS Series Type G Model Numbers | 4 |
| CD-ROM Contents | 5 |
| Usage Precautions | 6 |
| | |
| Chapter 1 Development Environment | |
| 1 Overview | 1-2 |
| 2 Hardware Environment | 1-3 |
| 3 Software Environment | 1-5 |
| 3.1 Development Software | 1-5 |
| 3.2 ADK Files | 1-6 |
| 4 Installing Application Development Tools | 1-8 |
| 5 Remote Connection Procedure | 1-13 |
| 5.1 Personal Computer Settings | 1-13 |
| 5.2 PS-G Unit Settings | 1-16 |
| 5.3 Connection | 1-17 |
| | |
| Chapter 2 Application Development | |
| 1 Development using eMbedded Visual C++ | 2-2 |
| 1.1 Creating a Project | 2-2 |
| 1.2 Building and Downloading a Program | 2-5 |
| 1.3 Running a Program | 2-6 |
| 2 Development using eMbedded Visual Basic | 2-7 |
| 2.1 Creating a Project | 2-7 |
| 2.2 Downloading and Running a Program | 2-9 |
| 3 Debugging Programs Using the Emulator | 2-12 |
| 4 Auto Start | 2-14 |
| | |
| Chapter 3 Library Interface Reference | |
| 1 Backlight Driver | 3-3 |
| 1.1 Backlight Driver APIs | 3-3 |
| 1.2 Function Specifications | 3-4 |
| 2 SRAM Driver | 3-9 |
| 2.1 SRAM Driver APIs | 3-9 |
| 2.2 Function Specifications | 3-9 |

| | | |
|-----|--|------|
| 3 | GMU-BUS Driver | 3-14 |
| 3.1 | GMU-BUS Driver APIs | 3-14 |
| 3.2 | Function Specifications | 3-14 |
| 4 | RAS Driver | 3-20 |
| 4.1 | RAS Driver APIs | 3-20 |
| 4.2 | Details of Function Specifications | 3-22 |
| 4.3 | Register Details | 3-42 |
| 5 | Touch Panel Driver | 3-46 |
| 5.1 | Touch Panel Driver APIs | 3-46 |
| 5.2 | Function Specifications | 3-46 |

Index

1

Development Environment

- 1 Overview
- 2 Hardware Environment
- 3 Software Environment
- 4 Installing Application Development Tools
- 5 Remote Connection Procedure

1 Overview

The Application Development Kit (ADK) containing libraries and definition files used for developing PS-G unit applications.

The new PS-G unit is a high-performance programmable operator interface that uses the Hitachi SH4 RISC CPU (200MHz) and is preinstalled with Windows CE 3.0.

To develop applications that will run on the PS-G unit, you will need both the eMbedded Visual Tools and the ADK-software.

eMbedded Visual Tools offer functionality similar to a regular Win32 application development environment (such as Visual Studio), and allow you to easily create applications for the PS-G unit. Since you can utilize your Win32 application programming knowledge and use familiar debugging tools, you can quickly create Windows CE applications for the PS-G unit. Also, the use of the Windows CE API, a subset of the Win32 API, helps to further improve development efficiency.


MEMO

- Since the eMbedded Visual Tools package is not included in the ADK package, you will need to purchase it separately.
- Certain Win32 APIs cannot be used with Windows CE. For details, please refer to the MSDN and check whether the APIs you intend to use are supported by Windows CE.

2 Hardware Environment

The following describes the hardware configuration required for developing and running PS-G unit applications.

Connect the PS-G unit to a personal computer via the data transfer cable provided with ADK. This allows an application developed on the personal computer to be easily download to the PS-G. If the personal computer you are using has a CF Card adaptor, you can run an application on the PS-G unit after copying it to the CF Card and then loading the card data into the PS-G unit. A CF Card is also required to save applications downloaded to the PS-G unit or data entered via the Control Panel of the PS-G unit.

**MEMO**

- Use only Digital Electronics Corporation CF Cards. Other vendor CF Cards may fail to meet PS-G specifications.
- Be sure to back up your CF Card data regularly.

The following describes the personal computer hardware required to develop applications. Refer to each package’s hardware environment specifications for details.

<Required Personal Computer Hardware>

| | |
|------------------|---|
| Operating System | Windows NT Workstation 4.0 with Service Pack 5 or later, Windows 2000 Professional, or Windows 98 Second Edition. |
| Computer | Windows compatible PC with Pentium processor (Pentium 150MHz or faster processor is recommended) |
| Memory | 32MB for Windows NT 4.0 or Windows 2000 (48MB recommended) 24MB of RAM for Windows 98 (48MB recommended) |
| Hard-disk Space | Installing eMbedded Visual C++ and Windows CE Platform SDK (HPC Pro), or eMbedded Visual Basic and Windows CE Platform SDK (HPC Pro) requires 360MB or more. Installing the ADK software requires free space of 100MB or more. |
| CD-ROM Drive | A CD-ROM drive is required. |

 **CAUTION**

 Windows 98 is not recommended if you want to both develop and debug applications, as problems with emulation functions or remote tools may occur during debugging. When developing applications that require performance of both the build and the debug process, be sure to use a personal computer running Windows NT 4.0 or Windows 2000.

3 Software Environment

To develop applications that will run on the PS-G unit, you need both the eMbedded Visual Tools and the ADK.

The eMbedded Visual Tools contain both eMbedded Visual C++ and eMbedded Visual Basic. ADK supports both of these visual programming tools.

3.1 Development Software

The following software should be installed when developing applications.

| Item | Description | |
|--|---|---|
| eMbedded Visual Tools | Install eMbedded Visual C++ or eMbedded Visual Basic. | |
| | Windows CE Platform SDK (HPC Pro) | This program must be installed to run Windows CE applications under emulation on your computer. |
| PS Series Type G Application Development Kit (ADK) | Microsoft Custom SDK | Standard [Windows CE] library files |
| | PS Series Type G Platform SDK (Platform Developer Components for the Microsoft Custom SDK) | Library and header files that allow programs such as RAS, etc. to access specific PS-G unit hardware. |
| ActiveSync 3.1 | Enables communication between the PS-G unit and the personal computer used for developing applications. (This program is included in the ADK package.) | |
| TCP/IP protocol | TCP/IP protocol must be used to download the applications to the emulator via Ethernet for debugging. (Be sure to set the appropriate network parameters for your development environment.) | |

The eMbedded Visual Tools package contains the following remote tools. These tools allow the personal computer used for development to acquire necessary information from the PS-G unit (connected via Microsoft ActiveSync3.1), debug applications and check program operation.

- **Remote Spy++ (Spy)**
Determines what kind of messages the target device receives or uses to check window handles, classes, and other items.
- **Remote Registry Editor (Registry Editor)**
Used for editing the target device registry.
- **Remote ZoomIn (Zoom)**
Enables you to capture target device screen images and view them on the personal computer used for developing applications.
- **Remote File Viewer (File Viewer)**
Enables you to browse files on the target device.
- **Remote Heap Walker (Heap Walker)**
Checks the heap ID and the current heap.
- **Remote Process Viewer (Process Viewer)**
Enables you to check the processes, threads and modules that are currently being executed on the target device, and check for available memory areas.

3.2 ADK Files

Each ADK contains the following two software development kits: Microsoft Custom SDK and PS Series Type G Platform SDK. After an ADK is installed, individual SDK files are automatically extracted to the following folders.

Microsoft Custom SDK

```
Standard library files for Windows CE
\Windows CE Tools \Wce300\Bin
    \Psgwce30 \Atl
        \Help
        \Include
        \Lib
        \Mfc
        \Target
        \Template
        \Vbsdk
```

PS Series Type G Platform SDK

```
\Windows CE Tools \Wce300\Psgwce30\Include\bldrvapi.h
                                     \sramdrvapi.h
                                     \gmudrvapi.h
                                     \rasdrvapi.h
                                     \tchdrvapi.h

\Windows CE Tools \Wce300\Psgwce30\Lib\Sh4\bldrvif.lib
                                     \sramdrvif.lib
                                     \gmudrvif.lib
                                     \rasdrvif.lib
                                     \touchdrvif.lib
                                     \bldrvif.exp
                                     \sramdrvif.exp
                                     \gmudrvif.exp
                                     \rasdrvif.exp
                                     \touchdrvif.exp

\Windows CE Tools \Wce300\Psgwce30\Vbsdk\Sh4\bldrvif.lib
                                     \sramdrvif.lib
                                     \gmudrvif.lib
                                     \rasdrvif.lib
                                     \touchdrvif.lib
                                     \bldrvif.exp
                                     \sramdrvif.exp
                                     \gmudrvif.exp
                                     \rasdrvif.exp
                                     \touchdrvif.exp
                                     \bldrdef.bas
                                     \sramdrvdef.bas
                                     \gmudrvdef.bas
                                     \rasdrvdef.bas
                                     \touchdrvdef.bas
```

4 Installing Application Development Tools

Before installing an ADK, be sure to check that the personal computer to be used for application development meets the specified requirements by referring to the table <Required Personal Computer Hardware> in "Chapter 1 2. Hardware Environment."

CAUTION

-  Windows 98 is not recommended if you want to both develop and debug applications, as problems with emulation functions or remote tools may occur during debugging. When developing applications that require performance of both the build and the debug process, be sure to use a personal computer running Windows NT 4.0 or Windows 2000.

To install the application development tools, follow the procedure below.

Be sure to follow the procedures given here, in sequence. If you do not, the tools may not operate correctly.

- (1) Install the eMbedded Visual Tools.
- (2) Install the ADK for eMbedded Visual C++ or eMbedded Visual.
- (3) Install ActiveSync 3.1.

Installing the eMbedded Visual Tools

- (1) Install the eMbedded Visual Tools software.
eMbedded Visual Tools contains both eMbedded Visual C++ and eMbedded Visual Basic. Install either or both, depending on your needs.

Installing the ADK

- (1) Insert the ADK CD-ROM into your personal computer's CD-ROM drive and install either the ADK for eMbedded Visual C++ or eMbedded Visual Basic.
 - To install ADK for Visual C++
Install ADK for Visual C++ by double-clicking on the [psg-sdk.exe] file located in the CD-ROM's [\us\psg-adk\vc] folder. After the installation screen appears, follow each screen's instructions.
 - To install ADK for Visual Basic
Install ADK for Visual Basic by double-clicking on the [psg-sdk.exe] file located in the CD-ROM's [\us\psg-adk\vb] folder. After the installation screen appears, follow each screen's instructions.


Installing ActiveSync 3.1 and connecting with the PS-G unit

- Install ActiveSync 3.1 by double-clicking on the [msasync.exe] file located in the ADK CD-ROM's [\us\async] folder, and then follow each screen's instructions. As the installation progresses, the computer enters the PS-G connection standby mode. However, at this stage, do **not** establish the connection. This is done by not clicking the  button until step (11).




- Turn ON the power to the PS-G unit, and connect the data transfer cable (provided with the ADK) from the COM port on the personal computer to the serial I/F (COM1) on the PS-G unit.
- To open the PS-G unit's Control Panel, click the [Start] button and then point to [Settings]. From the menu that appears, click [Control Panel].


- Double click  to open the [Communications Properties] screen.



- (5) Enter a name in the [Device name] field so that the PS-G unit will be recognized by the personal computer.



- (6) Click the [PC Connection] tab, and then the **Change...** button.



- (7) Select the desired baud rate setting.




- (8) Click the **OK** button to register the [Communications Properties] settings.

- (9) In the Control Panel, click on the  icon to save the remote connection settings to the CF Card. Then, reboot the PS-G unit.

- (10) After the PS-G unit is rebooted, open the [Windows] folder, located in My Computer.

- (11) Click the  button on the dialog box that appeared in step (1), and immediately double-click the  icon (connection establishment program).




Personal computer




PS-G unit

The connection with the PS-G unit will not be established if the timing of the double-clicking of  is not correct. If the connection fails, the following screen will appear on both the PC and the PS-G unit. In this case, retry step (11).



Personal computer




PS-G unit


- (12) When the connection is successfully established, the following screen will appear on the PC. Select [No] for [Would you like to set up a partnership?]



- (13) When the connection is completed, the [Microsoft ActiveSync] screen appears on the PC.



Also, an icon signifying a successful connection appears in the PS-G unit's the task bar.



MEMO

Once the connection is established, ActiveSync 3.1 stays resident in the computer memory and the connection settings are stored, allowing the PS-G unit to be connected with the personal computer from next time by

simply double-clicking the PS-G unit's  icon.

repllog

5 Remote Connection Procedure

To transfer a program from the personal computer used for developing applications to the PS-G unit and then debug the program while it is running on the PS-G unit, use ActiveSync 3.1 to establish the connection between the personal computer and the PS-G unit.

MEMO


Transferring a program via an Ethernet network greatly shortens the transfer time. To use an Ethernet network, you should set the parameters appropriate for the development environment.

Turn ON the power to the PS-G unit, and connect the data transfer cable (provided with the ADK) from the COM port on the personal computer to the serial I/F (COM1) on the PS-G unit.

5.1 Personal Computer Settings

ActiveSync 3.1 - Connection Settings


Launch ActiveSync 3.1 and select [Connection Settings] from the [File] menu. In the following screen, designate the data transfer cable port.




eMbedded Visual Tools - Platform Manager Configuration

From the [Platform Manager Configuration] screen, register a device name in your PC for the PS-G unit. This enables you to designate the PS-G unit as the download destination. The device properties should also be set according to the communication settings.

- Call up the [Platform Manager Configuration] screen following either of the procedures below. When you use eMbedded Visual C++, select [Platform Manager Configuration] from the [Tools] menu. When you use eMbedded Visual Basic, select [Project 1 - Properties] from the [Project] menu and then click the **Configure Target** button.



- Select [PSG] and click the **Add Device** button to add its name as a selectable device.




(The unit selected here is the PS-G device name.)

MEMO

The device name you designate should agree with the one set in the PS-G unit. Be sure to designate the same device name as the one you set in the PS-G unit's [Communications Properties] screen. For details, refer to "Chapter 1 5.2 PS-G Unit Settings"



- (3) Click the **Properties...** button to display the [Device Properties] dialog box. From [Available Transport Components], select [Microsoft ActiveSync]. If you intend to use Ethernet, select [TCP/IP Transport for Windows CE].

**MEMO**

Transferring a program via an Ethernet network greatly shortens the transfer time. To use an Ethernet network, you should set the parameters appropriate for the development environment.

- (4) Click the **Advanced** button and the following screen will appear. From [Available Server Components], select "Microsoft ActiveSync".



- (5) Click the **OK** button to register the settings and complete the Platform Manager setup.

5.2 PS-G Unit Settings

Control Panel - Communications Settings

- (1) To open the PS-G unit's Control Panel, click the [Start] button and then point to [Settings]. From the menu that appears, click [Control Panel].


- (2) Double Click  to open the [Communications Properties] screen.

- (3) Enter a name in the [Device name] field so that the PS-G unit will be recognized by the personal computer it is connected to.




MEMO

The device name you enter here should agree with the one set on the personal computer. Be sure to enter the same device name as the one you set in the [Platform Manager Configuration] screen on the personal computer. For details, refer to "Chapter 1 5.1 Personal Computer Settings"



- (4) Click the [PC Connection] tab, and then the  button.



- (5) Select the desired baud rate setting.



- (6) Click the  button to register and complete the [Communications Properties] settings.

- (7) In the Control Panel, click on the  icon to save the remote connection settings to the CF Card. Then, reboot the PS-G unit.

5.3 Connection

If you have already connected a personal computer to the PS-G unit prior installing ActiveSync 3.1, the connection settings for the personal computer and the PS-G unit can be established by

simply double-clicking  and following the procedures from step 12 in "Chapter 1 4.

Installing Application Development Tools." If the connection settings have not yet been established, launch ActiveSync 3.1 and then select [Connection] from the [File] menu. The personal computer will go into PS-G connection standby mode. You can then establish the connection settings by following the procedures in "Chapter 1 4. Installing the Application Development Tools."

2

Application Development

- 1 Development using eMbedded Visual C++
- 2 Development using eMbedded Visual Basic
- 3 Debugging Programs Using the Emulator
- 4 Auto Start


1 Development using eMbedded Visual C++

The following explains the procedure for using eMbedded Visual C++ to create a simple application to display an on-screen window.


1.1 Creating a Project

- (1) Start eMbedded Visual C++ and select [New] from the [File] menu. In the [Projects] tab, select the type of program you want to create and input a project name. Select "Win32 [WCE SH4]" for "CPUs". If you intend to debug the program by running it using the emulator, also select "Win32 [WCE x86em]".


Click the **OK** button to proceed to the next step.




- (2) Select the necessary items and click the **Next >** button. To create a program using a dialog-based interface, select the [Dialog based] option.




- (3) Select the necessary items and click the **Next >** button to proceed to the next step.




- (4) Again, select the necessary items and click the **Next >** button to proceed to the next step.



- (5) Click the **Finish** button, and the following page's [New Project Information] screen will appear.






(6) Click the  button and your new project creation is completed.

1.2 Building and Downloading a Program

Here, as an example we will create a program to display the text "Hello PS Series Type G" in the center of a window.



Add the following description to the OnDraw view class.

```
pDC->ExtTextOut (350, 300, NULL, NULL, TEXT ("Hello PS Series Type G"), NULL);
```

When you Build the program, it is automatically downloaded to the designated device. Before executing the build process, from the [WCE Configuration] tool bar, designate the SDK and other environment to be used in this process via the options displayed in the "Select Active WCE Configuration", "Select Active Configuration" and "Select Default Device" pop-up menus. Depending on the program's intended use, the setting of the [WCE Configuration] tool bar will differ. The following three types of program build methods are explained below.

- Programs debugged using the emulator
- Programs debugged using the PS-G unit
- Programs released for the PS-G unit

Program debugged using the emulator

To debug a program by running it using the emulator, the Windows CE Platform SDK (HPC Pro) is necessary. For details, refer to "Chapter 1 3.1 Development Software."

- (1) Set the tool bar as follows and then execute the build.



- (2) When the build completes successfully, the program is automatically downloaded to the emulator. If the emulator is not already running, it will be launched and then it will load the program automatically.
- (3) After downloading is completed, the program is saved in the [My Handheld PC] folder. Run the program by double-clicking on the program file's icon. To debug this program, start the debugger. For details, refer to "Chapter 2 3 Debugging Programs Using the Emulator."

Program debugged using the PS-G unit

- (1) Connect the personal computer to be used for development and the PS-G unit via ActiveSync3.1. For details, refer to "Chapter 1 5 Remote Connection Procedure."
- (2) Set the [WCE Configuration] tool bar as follows, and execute the build.



- (3) When the build completes successfully, program downloading to the PS-G unit starts automatically.
- (4) After downloading is completed, the program is saved in the PS-G unit's [My Computer] folder. Run the program by double-clicking on the program file's icon. To debug this program, start the PC's debugger.

Programs released for the PS-G unit

- (1) Connect the personal computer to be used for development and the PS-G unit via ActiveSync3.1. For details, refer to "Chapter 1 5 Remote Connection Procedure."
- (2) Set the [WCE Configuration] tool bar as follows, and execute the build.



- (3) When the build completes successfully, program downloading to the PS-G unit starts automatically.
- (4) After downloading is completed, the program is saved in the PS-G unit's [My Computer] folder. Run the program by double-clicking on the program file's icon.

1.3 Running a Program


The program is downloaded to the specified target device. Run the downloaded program by double-clicking on the program file's icon. To debug this program, start the PC's debugger. It is also possible to run a program that has been copied to a CF Card. To run a program from a CF Card, a backup copy of the PS-G's environment settings for running applications should also be saved on the CF-Card. Insert the CF Card into the PS-G unit and double-click  in the Control Panel. Then, double-click the program file's icon located in the [My Computer\Storage Card1] folder to run the program.

2 Development using eMbedded Visual Basic


The following explains the procedure for using eMbedded Visual Basic to create a simple application to display an on-screen window.

2.1 Creating a Project

- (1) After starting Visual Basic, the following [New Project] dialog box appears.



You can also select [New Project] from the [File] menu to display the [New Project] dialog box.




- (2) Select [Windows CE PSGWCE30 Project] to create a PS-G program. If you want to create a program that will run using the emulator, select [Windows CE HPC PRO Project].


MEMO

To run a program (debugged using the emulator) on the PS-G, be sure to add the forms and modules that were created for the Windows CE HPC Pro project to the Windows CE PSGWCE30 project.

- (3) After the project type is selected, the following screen will appear.




- (4) Select [Project 1 - Properties] from the [Project] menu, and the [Project Properties] dialog box will appear.




(Here, the project type has been set to "Windows CE PSGWCE30".)

- (5) Change the name of the project, if necessary.




2.2 Downloading and Running a Program

Here, we will create a program to display the text "Hello PS Series Type G" in the center of a window.




- (1) Select a label from the toolbox, and paste it on the form. Input "Hello PS Series Type G" into the "Caption" property.




- (2) Select [Project 1 - Properties] from [Project]. In the [Project Properties] screen that appears, designate a target device from the [Run on Target] pull-down menu.

If you intend to debug a program (Windows CE HPC Pro project) by running it using the emulator, select [Handheld PC Pro Emulation].



If you intend to debug a program (Windows CE PSGWCE30 project) by running it on the PS-G unit, select the device name for the PS-G that was registered using the Platform Manager. For details, refer to "Chapter 1 4.1 Settings on the Personal Computer."



- (3) When you designate the PS-G unit as the data download target device, connect your PC to the PS-G unit using the data transfer cable.
- (4) Selecting [Start Debug] or [Execute] from the [Run] menu initiates downloading of the program to the designated target device. After downloading of the program completes, the debugging will start.

If a program (Windows CE HPC Pro project) is to be debugged using the emulator, the program is downloaded to the [\My Handheld PC] folder.

If a program (Windows CE PSGWCE30 project) is to be run on the PS-G unit, the program is downloaded to the [My Computer] folder of the PS-G unit.

- (5) After program download is completed, you can run the program by simply double-clicking the program file's icon. To debug the program, execute the PC's debugger. For details, refer to "Chapter 2 3. Debugging Programs Using the Emulator."


It is also possible to run a program that has been copied to a CF Card on the PS-G unit. To run a program from a CF Card, a backup copy of the PS-G's environment settings for running applications should also be saved on the CF-Card. Insert the CF Card into the PS-G

unit and double-click  in the Control Panel. Then, double-click the program file's icon located in the [\\My Computer\\Storage Card1] folder to run the program.


3 Debugging Programs Using the Emulator

If you intend to debug a program without using the PS-G unit’s special hardware interfaces (such as RAS or the touch panel), you can effectively debug the program using the emulator included in the Windows CE Platform SDK (HPC Pro) in your PC. Please note, however, that the Windows CE Platform SDK (HPC Pro) only runs under Windows NT or Windows 2000.


- Start the emulator and the following screen will appear.



- After the program is loaded to the emulator, the executable file is saved in the [\\My Handheld PC] folder.



- Debugging can be started by simply clicking the saved exec file. You can also debug the program by running it to a specified break point, set earlier via the emBEDded Visual Tools debug feature.



- To close the emulator, click [Suspend] in the [Start] menu.



4 Auto Start

An application can be automatically started when the PS-G unit is turned ON. The following explanation describes this procedure.


To automatically start an application in object store memory

- (1) Create a shortcut for the application and place it in the PS-G's [\\Windows\\Startup] folder, or place a copy of the application there.
- (2) Insert a CF Card into the PS-G, and click the  icon in the Control Panel.
Backup
- (3) Reboot the PS-G unit with the CF Card inserted.
- (4) Once Windows CE starts, the PS-G unit will read the environment data from the CF Card and launch the application registered in the [\\Windows\\Startup] folder.

To automatically start a CF Card application

- (1) Create a shortcut in the [\\Windows\\Startup] folder pointing to [AutoRun.exe] in the PS-G unit's [\\Windows] folder.
- (2) Open the Properties of the shortcut created in step (1), open the [Shortcut] tab and set the application to run automatically by changing the link destination in the "Target" field as follows.

Target: "\\Windows\\AutoRun.exe"_"Storage_Card1\\Application name"



MEMO

If "/F" is added to the link destination setting, e.g., "\\Windows\\AutoRun.exe"_/F_"Storage_Card1\\application name", an application can be launched without showing the task bar at the bottom of the screen display. Use this feature to disable the Explorer Shell of Windows CE in the user application.

- (3) Click the  button.
- (4) Insert a CF Card into the PS-G, and click the  icon in the Control Panel.
Backup
- (5) Reboot the PS-G with the CF Card inserted.
- (6) Once Windows CE starts, the PS-G unit will read the environment data from the CF Card and launch the application registered in the [\\Windows\\Startup] folder.

3

Library Interface Reference

- 1 Backlight Driver
- 2 SRAM Driver
- 3 GMU-BUS Driver
- 4 RAS Driver
- 5 Touch Panel Driver

To use the PS-G unit’s special hardware interfaces in your applications, the required header file(s) should be included in the application’s source file so that the necessary interface library files can be linked to the object file.

- Backlight driver
- SRAM driver
- GMU-BUS driver
- RAS driver
- Touch panel driver

| Driver Name | Library file | eMbedded Visual C++ header file | eMbedded Visual Basic header file |
|--------------------|----------------|---------------------------------|-----------------------------------|
| Backlight driver | BIDrvlf.lib | BIDrvApi.h | BIDrvDef.bas |
| SRAM driver | SramDrvlf.lib | SramDrvApi.h | SramDrvDef.bas |
| GMU-BUS driver | GmuDrvlf.lib | GmuDrvApi.h | GmuDrvDef.bas |
| RAS driver | RasDrvlf.lib | RasDrvApi.h | RasDrvDef.bas |
| Touch panel driver | TouchDrvlf.lib | TchDrvApi.h | TchDrvDef.bas |

MEMO Detailed interface specifications for eMbedded Visual C++ are given in the following pages. When developing applications using eMbedded Visual Basic, although the application APIs are common to eMbedded Visual C++ APIs, the arguments will differ. For more information, refer to the available eMbedded Visual Basic header files.

To use an individual API contained in the ADK, it is necessary to set the drivers to Open before using the API and to change the setting back to Close after the API is used. Use the following example as a reference when creating a program.

```

Example) // Example of the settings for drivers
        // Not only the SRAM but also other drivers need the Open/Close settings.
        // Declaration for variables
        BOOL Ret;
        DWORD SramOffset;
        BYTE SramData;
        // Application reinstate processing
        // Before using the drivers, each driver should be set to Open.
        // Call up the corresponding "xxx DriverOpen( )" setting for each driver.
        Ret = SramDriverOpen();           // SRAM driver Open
        :
        // Access to the SRAM
        Ret = SramByteRead(SramOffset, &SramData); // Reads data from the SRAM.
        :
        Ret = SramByteWrite(SramOffset, SramData); // Writes data into the SRAM.
        :
        // Application exit processing
        // After the drivers are used, each driver should be set to Close.
        // Call up the corresponding "xxx DriverOpen( )" setting for each driver.
        Ret = SramDriverClose();
    
```

1 Backlight Driver

The function of this driver is to set and control the backlight status. This driver's functionality is equivalent to the control panel icon.

1.1 Backlight Driver APIs

| API name | Description |
|--------------------|---|
| GetBLDriverVersion | Retrieves driver version information |
| BLDriverOpen | Opens the backlight driver |
| BLDriverClose | Closes the backlight driver |
| GetBLStatus | Retrieves the backlight status |
| SetBLOnOff | Turns the backlight ON/OFF |
| SetBLBright | Sets the brightness of the backlight |
| SetBLAction | Enables/disables input in the case of backlight burnout. |
| GetBLAction | Retrieves backlight burnout settings. |
| SetBLTmOut | Sets the timer value used for turning the backlight OFF when the PS-G is idle. |
| GetBLTmOut | Retrieves the timer value used for turning the backlight OFF when the PS-G is idle. |

1.2 Function Specifications

GetBLDriverVersion

Call format

BOOL WINAPI GetBLDriverVersion (WORD *pMajor, WORD *pMinor)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD *pMajor Pointer to the version information (Major, 0 to 99)

WORD *pMinor Pointer to the version information (Minor, 0 to 99)

Processing performed

Retrieves information on the driver version.

E.g.) BOOL ret = GetBLDriverVersion (WORD &Major, WORD &Minor);

Note

When the driver version is 1.10,

Major is 1 (in decimal) and;

Minor is 10 (in decimal).

BLDriverOpen

Call format

BOOL WINAPI BLDriverOpen (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Opens the backlight driver, enabling features to be set.

E.g.) BOOL ret = BLDriverOpen ();

BLDriverClose

Call format

BOOL WINAPI BLDriverClose (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Closes the backlight driver, disabling setting operations. However, the thread operation of the driver continues.

E.g.) `BOOL ret = BLDriverClose ();`

GetBLStatus

Call format

BOOL WINAPI GetBLStatus (BYTE *pStatus)

Return value

TRUE: Normal

FALSE: Error

Argument

BYTE *pStatus Pointer to address where Backlight Status data is stored.

Backlight status

D7: Error

D4: Backlight burnout 1: Burnout 0: Normal

D3: Backlight status 1: ON 0: OFF

D2 to D0: Backlight brightness

Processing performed

Retrieves the ON/OFF status and brightness of the backlight.

E.g.) // Retrieves the backlight status.

`BYTE Status;`

`BOOL ret = GetBLStatus (&Status);`

SetBLOnOff

Call format

BOOL WINAPI SetBLOnOff (BOOL bSwitch)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bSwitch TRUE: Turns the backlight ON.
 FALSE: Turns the backlight OFF.

Processing performed

Controls the backlight.

E.g.) // Turns the backlight OFF.

```
    BOOL ret = GetBLOnOff (FALSE);
```

SetBLBright

Call format

BOOL WINAPI SetBLBright (BYTE Bright)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL Bright 0 to 3: 0 (darkest) to 3 (brightest)

Processing performed

Controls the brightness of the backlight.

E.g.) // Sets the backlight to its brightest level.

```
    BOOL ret = SetBLBright (3);
```

SetBLAction

Call format

BOOL WINAPI SetBLAction (BYTE Action)

Return value

TRUE: Normal

FALSE: Error

Argument

BYTE Action

D2: Input from touch panel 1: Enabled 0: Disabled

D1: Input from keyboard 1: Enabled 0: Disabled

D0: Input from mouse 1: Enabled 0: Disabled

Processing performed

Enables/disables input from the touch panel, keyboard, and mouse when backlight burnout is detected.

The data for this setting will be stored in the registry.

E.g.) // Disables input from the touch panel, keyboard, and mouse in the case of backlight burnout.

```
BOOL ret = SetBLAction (0);
```

GetBLAction

Call format

BOOL WINAPI GetBLAction (BYTE *pAction)

Return value

TRUE: Normal

FALSE: Error

Argument

BYTE *pAction Pointer to the setting for whether or not input is enabled in the case of backlight burnout.

BYTE Action

D2: Input from touch panel 1: Enabled 0: Disabled

D1: Input from keyboard 1: Enabled 0: Disabled

D0: Input from mouse 1: Enabled 0: Disabled

Processing performed

Retrieves the setting for whether or not input from the touch panel, keyboard, and mouse is enabled when backlight burnout is detected.

E.g.) // Retrieves the setting for input from the touch panel, keyboard, and mouse in the case of backlight burnout.

```
BYTE Action;
```

```
BOOL ret = GetBLAction (&Action);
```

SetBLTmOut

Call format

BOOL WINAPI SetBLTmOut (DWORD TmOut)

Return value

TRUE: Normal

FALSE: Error

Argument

DWORD TmOut Specified timer value for turning the backlight OFF in the case of idle time
(0, 15, 30, 60, 120, 300, 600, 900, or 1800)

Processing performed

Sets the timer value used for turning the backlight OFF when there is no input via the touch panel, keyboard, or mouse.

E.g.) DWORD TmOut = 120;

 BOOL ret = SetBLTmOut (TmOut);

GetBLTmOut

Call format

BOOL WINAPI GetBLTmOut (DWORD *pTmOut)

Return value

TRUE: Normal

FALSE: Error

Argument

DWORD *pTmOut Pointer to the specified timer value for turning the backlight OFF in the
 case of idle time

Processing performed

Retrieves the timer value used for turning the backlight OFF when there is no input via the touch panel, keyboard, or mouse.

E.g.) DWORD TmOut;

 BOOL ret = GetBLTmOut (&TmOut);

2 SRAM Driver

The function of this driver is to read/write data from/to SRAM.

Up to 256KB is available. If a function's return value exceeds 256KB during access, an error will occur.

2.1 SRAM Driver APIs

| API name | Description |
|----------------------|--|
| GetSramDriverVersion | Retrieves information on the driver version. |
| SramDriverOpen | Opens the SRAM driver. |
| SramDriverClose | Closes the SRAM driver. |
| SramByteRead | Reads data from the SRAM. (Byte) |
| SramWordRead | Reads data from the SRAM. (Word) |
| SramLongRead | Reads data from the SRAM. (Long) |
| SramByteWrite | Writes data into the SRAM. (Byte) |
| SramWordWrite | Writes data into the SRAM. (Word) |
| SramLongWrite | Writes data into the SRAM. (Long) |

2.2 Function Specifications

GetSramDriverVersion

Call format

BOOL WINAPI GetSramDriverVersion (WORD *pMajor, WORD *pMinor)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD *pMajor Pointer to the version information (Major, 0 to 99)

WORD *pMinor Pointer to the version information (Minor, 0 to 99)

Processing performed

Retrieves the driver version.

E.g.) BOOL ret = GetSramDriverVersion (WORD &Major, WORD &Minor);

Note

When the driver version is 1.10,

Major is 1 (in decimal) and;

Minor is 10 (in decimal).

SramDriverOpen

Call format

BOOL WINAPI SramDriverOpen (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Opens SRAM driver, enabling driver operations.

E.g.) BOOL ret = SramDriverOpen ();

SramDriverClose

Call format

BOOL WINAPI SramDriverClose (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Closes SRAM driver, disabling driver operations. However, driver thread operation continues.

E.g.) BOOL ret = SramDriverClose ();

3 GMU-BUS Driver

This driver provides GMU-BUS control. Interrupt support is provided via registration of the user callback routine.

3.1 GMU-BUS Driver APIs

| API name | Description |
|---------------------|----------------------------------|
| GetGmuDriverVersion | Retrieves the driver version. |
| GmuDriverOpen | Opens the GMU-BUS driver. |
| GmuDriverClose | Closes the GMU-BUS driver. |
| GmuByteRead | Reads data from the GMU. (Byte) |
| GmuWordRead | Reads data from the GMU. (Word) |
| GmuLongRead | Reads data from the GMU. (Long) |
| GmuByteWrite | Writes data to the GMU. (Byte) |
| GmuWordWrite | Writes data to the GMU. (Word) |
| GmuLongWrite | Writes data to the GMU. (Long) |
| SetGmuCallbackIntA | Registers the GMU IntA Callback. |
| SetGmuCallbackIntB | Registers the GMU IntB Callback. |

3.2 Function Specifications

GetGmuDriverVersion

Call format

BOOL WINAPI GetGmuDriverVersion (WORD *pMajor, WORD *pMinor)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD *pMajor Pointer to version information (Major, 0 to 99)

WORD *pMinor Pointer to version information (Minor, 0 to 99)

Processing performed

Retrieves information on the driver version.

E.g.) BOOL ret = GetGmuDriverVersion (WORD &Major, WORD &Minor);

Note

When the driver version is 1.10,

Major is 1 (in decimal) and;

Minor is 10 (in decimal).

GmuDriverOpen

Call format

BOOL WINAPI GmuDriverOpen (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Opens the GMU-BUS driver, enabling driver operations.

E.g.) BOOL ret = GmuDriverOpen ();

GmuDriverClose

Call format

BOOL WINAPI GmuDriverClose (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Closes the GMU-BUS driver, disabling driver operations. However, driver thread operation continues.

E.g.) BOOL ret = GmuDriverClose ();

GmuByteRead

Call format

BOOL WINAPI GmuByteRead (DWORD Offset, BYTE *pData)

Return value

TRUE: Normal

FALSE: Error

Argument

DWORD Offset Offset from the beginning of the GMU to the data to be read (in byte units)

BYTE *pData Pointer to the address where readout will be stored

Processing performed

Reads data from the specified address of the GMU.

E.g.) // Reads data of the byte 16th from the beginning of the GMU.

```
BYTE Data;
```

```
BOOL ret = GmuByteRead (0x10, &Data);
```

GmuWordRead

Call format

BOOL WINAPI GmuWordRead (DWORD Offset, WORD *pData)

Return value

TRUE: Normal

FALSE: Error

Argument

DWORD Offset Offset from the beginning of the GMU to the data to be read (in word units)

WORD *pData Pointer to the address in which the readout will be stored

Processing performed

Reads data from the specified address of the GMU.

E.g.) // Reads data of the word 16th from the beginning of the GMU.

```
WORD Data;
```

```
BOOL ret = GmuWordRead (0x10, &Data);
```

GmuLongRead

Call format

BOOL WINAPI GmuLongRead (DWORD Offset, DWORD *pData)

Return value

TRUE: Normal

FALSE: Error

Argument

DWORD Offset Offset from the beginning of the GMU to the data to be read (in double word units)

DWORD *pData Pointer to the address where readout will be stored

Processing performed

Reads data from the specified GMU address.

E.g.) // Reads data of the double word 16th from the beginning of the GMU.

```
DWORD Data;
```

```
BOOL ret = GmuLongRead (0x10, &Data);
```

GmuByteWrite

Call format

BOOL WINAPI GmuByteWrite (DWORD Offset, BYTE Data)

Return value

TRUE: Normal

FALSE: Error

Argument

DWORD Offset Offset from the beginning of the GMU to the destination of the data to be written (in byte units)

BYTE Data Data to be written

Processing performed

Writes the specified data into the specified GMU address.

E.g.) // Writes data (aah) to the byte 16th from the beginning of the GMU.

```
BOOL ret = GmuByteWrite (0x10, 0xaa);
```

GmuWordWrite

Call format

BOOL WINAPI GmuWordWrite (DWORD Offset, WORD Data)

Return value

TRUE: Normal

FALSE: Error

Argument

DWORD Offset Offset from the beginning of the GMU to the destination of the data to be written (in word units)

WORD Data Data to be written

Processing performed

Writes the designated data to the specified GMU address.

E.g.) // Writes the data (55aah) into the word 16th from the beginning of the GMU.

```
    BOOL ret = GmuWordWrite (0x10, 0x55aa);
```

GmuLongWrite

Call format

BOOL WINAPI GmuLongWrite (DWORD Offset, DWORD Data)

Return value

TRUE: Normal

FALSE: Error

Argument

DWORD Offset Offset from the beginning of the GMU to the destination of the data to be written (in double word units)

DWORD Data Data to be written

Processing performed

Writes the designated data into the specified GMU address.

E.g.) // Writes data (55aa55aah) to the double word 16th from the beginning of the GMU.

```
    BOOL ret = GmuLongWrite (0x10, 0x55aa55aa);
```

SetGmuCallbackIntA

Call format

BOOL WINAPI SetGmuCallbackIntA (GMUPROC lpCallbackFunc)

Return value

TRUE: Normal

FALSE: Error

Argument

GMUPROC lpCallbackFunc Long pointer to the interrupt processing function
When set to NULL, cancels the registration of the function selected for interrupt processing.

Processing performed

Registers the function used for interrupt processing when a GMU IntA occurs.

SetGmuCallbackIntB

Call format

BOOL WINAPI SetGmuCallbackIntB (GMUPROC lpCallbackFunc)

Return value

TRUE: Normal

FALSE: Error

Argument

GMUPROC lpCallbackFunc Long pointer to the interrupt processing function
When set to NULL, cancels the registration of the function selected for interrupt processing.

Processing performed

Registers the function used for interrupt processing when a GMU IntB occurs.

4 RAS Driver

This driver provides RAS function control. It supports the watchdog timer, remote reset input, standard signal inputs (two), standard signal output (one), and alarm output (one). Each of the actions to be performed can also be designated from the control panel. This driver provides functions equivalent to the control panel.

4.1 RAS Driver APIs

<Common functions>

| | Setting/display dialog control | API name | Description | H/W resister/registry |
|--------|--------------------------------|---------------------|--|-----------------------|
| Common | / | GetRasDriverVersion | Retrieves information on the driver version. | |
| | | RasDriverOpen | Opens the RAS driver. | |
| | | RasDriverClose | Closes the RAS driver. | |
| | | BuzzerControl | Controls ON/OFF of the buzzer. | |
| | | AlarmControl | Controls ON/OFF of the ALARMOUT. | RAS IN/OUT |
| | | DoutControl | Controls ON/OFF of the DOUT. | RAS IN/OUT |
| | | SetRasRegister | Writes data into the RAS resister. | |
| | | GetRasRegister | Reads data from the RAS resister. | |

<Watchdog timer functions>

| | Setting/display dialog control | API name | Description | H/W resister/registry |
|-----|--------------------------------|---------------|--|-----------------------|
| WDT | Enable | SetWdtEnable | Enables/disables the watchdog timer. | Registry W |
| | | GetWdtEnable | Retrieves the setting for whether the watchdog timer is enabled. | Registry R |
| | Counter | SetWdtCounter | Sets the counter value. | Registry W |
| | | GetWdtCounter | Retrieves the counter value setting. | Registry R |
| | Alarm | SetWdtMask | Sets the alarm mask. | Registry W |
| | | GetWdtMask | Retrieves the alarm mask setting. | Registry R |
| | Buzzer | SetWdtBuzzer | Enables/disables the buzzer activation. | Registry W |
| | | GetWdtBuzzer | Retrieves the buzzer activation setting. | Registry R |
| | Reset | SetWdtReboot | Enables/disables reboot. | Registry W |
| | | GetWdtReboot | Retrieves the reboot setting. | Registry R |
| | Popup Enable | SetWdtPopup | Enables/disables the pop-up message. | Registry W |
| | | GetWdtPopup | Retrieves the setting for whether the pop-up message is enabled. | Registry R |
| | Popup Message | SetWdtMessage | Sets the pop-up message. | Registry W |
| | | GetWdtMessage | Retrieves the pop-up message setting. | Registry R |

<Watchdog timer functions>

| | Setting/display dialog control | API name | Description | H/W resister/registry |
|-----|--------------------------------|-----------------|---|-----------------------|
| WDT | User application | SetWdtControl | Starts/stops the watchdog timer. | WDT_CNTL |
| | | GetWdtControl | Retrieves the start/stop setting for the watchdog timer. | WDT_CNTL |
| | | GetWdtTimeout | Retrieves the information on occurrence of the watchdog timer time-out. | WDT_STT |
| | | ClearWdtTimeout | Clears the watchdog timer time-out state. | WDT_STT |
| | | RefreshWdtTime | Resets the watchdog timer. | WDT_COUNT |

<DIN functions>

| | Setting/display dialog control | API name | Description | H/W resister/registry |
|-----|--------------------------------|----------------|---|-----------------------|
| DIN | Enable | SetDinEnable | Enables/disables DIN port input. | Registry W |
| | | GetDinEnable | Retrieves the setting for whether DIN port input is enabled. | Registry R |
| | Alarm | SetDinAlarmOut | Enables/disables alarm output. | Registry W |
| | | GetDinAlarmOut | Retrieves the setting for whether alarm output is enabled. | Registry R |
| | Buzzer | SetDinBuzzer | Enables/disables buzzer output. | Registry W |
| | | GetDinBuzzer | Retrieves the setting for whether buzzer output is enabled. | Registry R |
| | RAS Output | SetDinDout | Enables/disables DOUT output. | Registry W |
| | | GetDinDout | Retrieves the setting for whether DOUT output is enabled. | Registry R |
| | Popup Enable | SetDinPopup | Enables/disables pop-up message output. | Registry W |
| | | GetDinPopup | Retrieves the setting for whether pop-up message output is enabled. | Registry R |
| | Popup Message | SetDinMessage | Sets the pop-up message. | Registry W |
| | | GetDinMessage | Retrieves the pop-up message setting. | Registry R |

<Remote reset functions>

| | Setting/display dialog control | API name | Description | H/W resister/registry |
|--------------|--------------------------------|--------------|--|-----------------------|
| Remote Reset | Enable | SetRstEnable | Enables/disables remote reset. | Registry W |
| | | GetRstEnable | Retrieves the setting for whether remote reset is enabled. | Registry R |

4.2 Details of Function Specifications

<Common functions>

GetRasDriverVersion

Call format

BOOL WINAPI GetRasDriverVersion (WORD *pMajor, WORD *pMinor)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD *pMajor Pointer to the version information (Major, 0 to 99)

WORD *pMinor Pointer to the version information (Minor, 0 to 99)

Processing performed

Retrieves driver version information.

E.g.) BOOL ret = GetRasDriverVersion (WORD &Major, WORD &Minor);

Note

When the driver version is 1.10,

Major is 1 (in decimal) and;

Minor is 10 (in decimal).

RasDriverOpen

Call format

BOOL WINAPI RasDriverOpen (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Opens the RAS driver, enabling setting operations.

E.g.) BOOL ret = RasDriverOpen ();

RasDriverClose

Call format

BOOL WINAPI RasDriverClose (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Closes the RAS driver, disabling setting operations. However, driver thread operation continues.

E.g.) `BOOL ret = RasDriverClose ();`

BuzzerControl

Call format

BOOL WINAPI BuzzerControl (short length)

Return value

TRUE: Normal

FALSE: Error

Argument

Short length ON (-1): Buzzer is ON.
 OFF (0): Buzzer is OFF.
 1 to 32767: Buzzer length (in ms)

Processing performed

Controls ON/OFF of the buzzer.

E.g.) `// Sounds the buzzer for 100 ms.`

`BOOL ret = BuzzerControl (100);`

AlarmControl

Call format

BOOL WINAPI AlarmControl (BOOL bSwitch)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bSwitch TRUE: ALARMOUT output
 FALSE: Stops ALARMOUT output

Processing performed

Controls the ALARMOUT port.

E.g.) // Turns the ALARMOUT OFF.

```
    BOOL ret = AlarmControl (FALSE);
```

DoutControl

Call format

BOOL WINAPI DoutControl (BOOL bSwitch)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bSwitch TRUE: DOUT output
 FALSE: Stops DOUT output

Processing performed

Controls the DOUT port.

E.g.) // Turns the DOUT ON.

```
    BOOL ret = DoutControl (TRUE);
```

SetRasRegister

Call format

BOOL WINAPI SetRasRegister (WORD RegNo, BYTE Data)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD RegNo Register designation *1

BYTE Data Data to be set in the register

Register designation

```
#define RAS_IN_MASK 0
```

```
#define RAS_IN_OUT 1
```

```
#define WDT_CR 2
```

```
#define WDT_COUNT 3
```

Processing performed

Sets the application's designated data to the designated port.

E.g.) // Sets 0 in the RAS_IN_MASK register.

```
BOOL ret = SetRasRegister (RAS_IN_MASK, 0);
```

GetRasRegister

Call format

BOOL WINAPI GetRasRegister (WORD RegNo, BYTE *pData)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD RegNo Number of the register to be read

BYTE *pData Pointer to the data to be read

Processing performed

Reads the port specified by the application.

E.g.) // Reads the RAS_IN_MASK register.

```
BYTE Data;
```

```
BYTE ret = GetRasRegister (RAS_IN_MASK, &Data);
```

*1: For details on the registers, refer to "4.3 Details of the Registers" in Chapter 3.

<Watchdog timer functions>

SetWdtEnable

Call format

BOOL WINAPI SetWdtEnable (BOOL bEnable)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bEnable TRUE: Enables the watchdog timer.
 FALSE: Disables the watchdog timer.

Processing performed

Enables/disables the watchdog timer.

E.g.) BOOL ret = SetWdtEnable(TRUE);

GetWdtEnable

Call format

BOOL WINAPI GetWdtEnable (BOOL *pEnable)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *pEnable Pointer to the watchdog timer setting

Processing performed

Retrieves the setting for whether or not the watchdog timer is enabled.

E.g.) BOOL Enable;

 BOOL ret = GetWdtEnable(&Enable);

SetWdtCounter

Call format

BOOL WINAPI SetWdtCounter (BYTE Counter)

Return value

TRUE: Normal

FALSE: Error

Argument

BYTE Counter Initial counter value (5 to 255) for the watchdog timer (in sec.)

Processing performed

Sets the initial counter value for the watchdog timer. (WDT COUNT)

E.g.) // Sets 10 seconds as the initial counter value for the watchdog timer.

```
    BOOL ret = SetWdtCounter (10);
```

GetWdtCounter

Call format

BOOL WINAPI GetWdtCounter (BYTE *pCounter)

Return value

TRUE: Normal

FALSE: Error

Argument

BYTE *pCounter Pointer to the initial counter value (in sec.) for the watchdog timer

Processing performed

Retrieves the initial counter value currently set for the watchdog timer. (WDT COUNT)

E.g.) Byte Counter;

```
    BOOL ret = GetWdtCounter (&Counter);
```

SetWdtMask

Call format

BOOL WINAPI SetWdtMask (BOOL bMask)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bMask TRUE: Sets the mask for the watchdog timer alarm.
 FALSE: Removes the mask for the watchdog timer alarm.

Processing performed

Sets/removes the mask for the front LED control and the alarm to be output in the event of watchdog timer time-out.

E.g.) // Removes the mask for the ALARM output.

```
    BOOL ret = SetWdtMask (FALSE);
```

GetWdtMask

Call format

BOOL WINAPI GetWdtMask (BOOL *pMask)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *pMask Pointer to the mask setting for the watchdog timer

Processing performed

Retrieves the mask setting for the front LED control and the alarm to be output in the event of watchdog timer time-out.

E.g.) // Retrieves the mask setting for the ALARM.

```
    BOOL Mask;
```

```
    BOOL ret = GetWdtMask (&Mask);
```

SetWdtBuzzer

Call format

BOOL WINAPI SetWdtBuzzer (BOOL bBuzzer)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bBuzzer TRUE: Enables the buzzer.
 FALSE: Disables the buzzer.

Processing performed

Enables/disables the buzzer to operate in the event of watchdog timer time-out.

E.g.) BOOL ret = SetWdtBuzzer (TRUE);

GetWdtBuzzer

Call format

BOOL WINAPI GetWdtBuzzer (BOOL *pBuzzer)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *pBuzzer Pointer to the buzzer activation setting

Processing performed

Retrieves the setting for whether or not the buzzer is enabled to operate in the event of watchdog timer time-out.

E.g.) BOOL Buzzer;

 BOOL ret = GetWdtBuzzer (&Buzzer);

SetWdtReboot

Call format

BOOL WINAPI SetWdtReboot (BOOL bReboot)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bReboot TRUE: Enables reboot.
 FALSE: Disables reboot.

Processing performed

Enables/disables reboot in the event of watchdog timer time-out.

E.g.) BOOL ret = SetWdtReboot (TRUE);

GetWdtReboot

Call format

BOOL WINAPI GetWdtReboot (BOOL *pReboot)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *pReboot Pointer to the reboot setting

Processing performed

Retrieves the setting for whether or not reboot is enabled in the event of watchdog timer time-out.

E.g.) BOOL Reboot;

 BOOL ret = GetWdtReboot (&Reboot);

SetWdtPopup

Call format

BOOL WINAPI SetWdtPopup (BOOL bPopup)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bPopup TRUE: Enables the pop-up message.
 FALSE: Disables the pop-up message.

Processing performed

Enables/disables the pop-up message to appear in the event of watchdog timer time-out.

E.g.) BOOL ret = SetWdtPopup (TRUE);

GetWdtPopup

Call format

BOOL WINAPI GetWdtPopup (BOOL *pPopup)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *pPopup Pointer to the pop-up message setting

Processing performed

Retrieves the setting for whether or not the pop-up message is enabled to appear in the event of watchdog timer time-out.

E.g.) BOOL Popup;

 BOOL ret = GetWdtPopup (&Popup);

SetWdtMessage

Call format

BOOL WINAPI SetWdtMessage (wchar_t *pMessage)

Return value

TRUE: Normal

FALSE: Error

Argument

wchar_t *pMessage Pointer to the pop-up message

Processing performed

Sets the pop-up message which appears in the event of watchdog timer time-out.

E.g.) BOOL ret = SetWdtMessage (L" Watchdog timer time-out");

GetWdtMessage

Call format

BOOL WINAPI GetWdtMessage (wchar_t *pMessage)

Return value

TRUE: Normal

FALSE: Error

Argument

wchar_t *pMessage Pointer to the pop-up message storage area

Processing performed

Retrieves the pop-up message which appears in the event of watchdog timer time-out.

E.g.) wchar_t msg[32];

 BOOL ret = GetWdtMessage (msg);

SetWdtControl

Call format

BOOL WINAPI SetWdtControl (BOOL bCont)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bCont TRUE: Starts the watchdog timer.

 FALSE: Stops the watchdog timer.

Processing performed

Starts/stops the watchdog timer. Start, stop and refresh of the watchdog timer are not triggered via the driver. They are performed via the application's timing of the driver function call. As soon as the driver detects the time-out, it takes the specified action(s).

E.g.) BOOL ret = SetWdtControl (TRUE);

GetWdtControl

Call format

BOOL WINAPI GetWdtControl (BOOL *bCont)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *bCont Pointer to the start/stop setting of the watchdog timer
TRUE: The watchdog timer has been started.
FALSE: The watchdog timer has been stopped.

Processing performed

Retrieves the start/stop setting of the watchdog timer.

E.g.) BOOL Cont;

 BOOL ret = GetWdtControl (&Cont);

GetWdtTimeout

Call format

BOOL WINAPI GetWdtTimeout (BOOL *pTOut)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *pTOut Pointer to the watchdog timer time-out information
TRUE: The watchdog timer time-out has occurred.
FALSE: The watchdog timer time-out has not occurred.

Processing performed

After reading the WDT_STT, this function retrieves the information on whether or not the watchdog timer time-out has occurred.

E.g.) BOOL TOut;

 BOOL ret = GetWdtTimeOut (&TOut);

ClearWdtTimeout

Call format

BOOL WINAPI ClearWdtTimeout (void);

Return value

TRUE: Normal

FALSE: Error

Argument

Nothing

Processing performed

Clears the watchdog timer time-out state. (WDT_STT)

E.g.) // Clears the watchdog timer time-out state.

```
    BOOL ret = CleanWdtTimeout ( );
```

RefreshWdtTime

Call format

BOOL WINAPI RefreshWdtTime (void);

Return value

TRUE: Normal

FALSE: Error

Argument

Nothing

Processing performed

Resets the watchdog timer counter (WDT_STT) to the initial counter value preset by the SetWdtCounter.

E.g.) // Refreshes the watchdog timer.

```
    BOOL ret = RefreshWdtTime ( );
```

<DIN functions>

SetDinEnable

Call format

BOOL WINAPI SetDinEnable (WORD inp, BOOL bEnable)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL bEnable TRUE: Enables DIN port input.

FALSE: Disables DIN port input.

Processing performed

Enables/disables DIN0/DIN1 port input.

E.g.) BOOL ret = SetDinEnable (0, TRUE);

GetDinEnable

Call format

BOOL WINAPI GetDinEnable (WORD inp, BOOL *pEnable)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL *pEnable Pointer to the DIN port setting

Processing performed

Retrieves the setting for whether or not DIN0/DIN1 port input is enabled.

E.g.) // Retrieves the DIN port setting.

 BOOL Enable;

 BOOL ret = GetDinEnable (0, &Enable);

SetDinAlarmOut

Call format

BOOL WINAPI SetDinAlarmOut (WORD inp, BOOL bAlm)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL bAlm TRUE: Enables alarm output.

 FALSE: Disables alarm output.

Processing performed

Enables/disables alarm output.

E.g.) BOOL ret = SetDinAlarmOut (0, TRUE);

GetDinAlarmOut

Call format

BOOL WINAPI GetDinAlarmOut (WORD inp, BOOL *pAlm)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL *pAlm Pointer to the setting for whether or not alarm output is enabled while the
 DIN0/DIN1 port is active

Processing performed

Retrieves the setting for whether or not alarm output is enabled while the DIN0/DIN1 port is active.

E.g.) // Retrieves the setting for alarm output through the DIN port.

 BOOL Alm;

 BOOL ret = GetDinAlarmOut (0, &Alm);

SetDinBuzzer

Call format

BOOL WINAPI SetDinBuzzer (WORD inp, BOOL bBuzzer);

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL bBuzzer Enables/disables buzzer output.

Processing performed

Enables/disables buzzer output while the DIN0/DIN1 port is active.

E.g.) // Disables buzzer output through the DIN port.

```
    BOOL ret = SetDinBuzzer (0, FALSE);
```

GetDinBuzzer

Call format

BOOL WINAPI GetDinBuzzer (WORD inp, BOOL *pBuzzer);

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL *pBuzzer Pointer to the setting for whether or not buzzer output is enabled.

Processing performed

Retrieves the setting for whether or not buzzer output is enabled while the DIN0/DIN1 port is active.

E.g.) // Retrieves the setting for buzzer output through the DIN port.

```
    BOOL Buzzer;
```

```
    BOOL ret = GetDinBuzzer (0, &Buzzer);
```

SetDinDout

Call format

BOOL WINAPI SetDinDout (WORD inp, BOOL bRasout);

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL bRasout Enables/disables DOUT output.

Processing performed

Enables/disables DOUT output while the DIN0/DIN1 port is active.

E.g.) // Disables DOUT output.

```
    BOOL ret = SetDinDout (0, TRUE);
```

GetDinDout

Call format

BOOL WINAPI GetDinDout (WORD inp, BOOL *pRasOut);

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL *pRasOut Pointer to the setting for whether or not DOUT output is enabled.

Processing performed

Retrieves the setting for whether or not DOUT output is enabled while the DIN0/DIN1 port is active.

E.g.) // Retrieves the DOUT output setting.

```
    BOOL RasOut;
```

```
    BOOL ret = GetDinDout (0, &RasOut);
```

SetDinPopup

Call format

BOOL WINAPI SetDinPopup (WORD inp, BOOL bPopup);

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL bPopup Enables/disables pop-up message output.

Processing performed

Enables/disables pop-up message output while the DIN0/DIN1 port is active.

E.g.) // Enables pop-up message output.

```
    BOOL ret = SetDinPopup (0, TRUE);
```

GetDinPopup

Call format

BOOL WINAPI GetDinPopup (WORD inp, BOOL *pPopup);

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

BOOL *pPopup Pointer to the setting for whether or not pop-up message output is enabled.

Processing performed

Retrieves the setting for whether or not pop-up message output is enabled while the DIN0/DIN1 port is active.

E.g.) // Retrieves the pop-up message output setting.

```
    BOOL Popup;
```

```
    BOOL ret = GetDinPopup (0, &Popup);
```

SetDinMessage

Call format

BOOL WINAPI SetDinMessage (WORD inp, wchar_t *pMessage);

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

wchar_t *pMessage Pointer to the pop-up message.

Processing performed

Sets the pop-up message while the DIN0/DIN1 port is active.

E.g.) BOOL ret = SetDinMessage (1, L" Universal Input Active");

GetDinMessage

Call format

BOOL WINAPI GetDinMessage (WORD inp, wchar_t *pMessage);

Return value

TRUE: Normal

FALSE: Error

Argument

WORD inp 0 or 1: DIN port number

wchar_t *pMessage Pointer to the pop-up message

Processing performed

Retrieves the pop-up message while the DIN0/DIN1 port is active.

E.g.) wchar_t msg [32];

 BOOL ret = GetDinMessage (1, msg);

<Remote reset functions>

SetRstEnable

Call format

BOOL WINAPI SetRstEnable (BOOL bEnable)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bEnable TRUE: Enables remote reset input.
 FALSE: Disables remote reset input.

Processing performed

Enables/disables remote reset input.

E.g.) `BOOL ret = SetRstEnable (TRUE);`

GetRstEnable

Call format

BOOL WINAPI GetUniEnable (BOOL *pEnable)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *pEnable Pointer to the setting for whether or not remote reset input is enabled.

Processing performed

Retrieves the setting for whether or not remote reset input is enabled.

E.g.) `// Retrieves the remote reset input setting.`

`BOOL Enable;`

`BOOL ret = GetRstEnable (&Enable);`

4.3 Register Details

RAS_IN_MASK

RAS IN MASK register
Read/Write

| Register | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | Note |
|-------------|----|----|----------------------|----|----|----|--------------|--------------|-------------------------------|
| RAS IN MASK | -- | -- | RMT_ RST_ MASK | -- | -- | -- | IN1_ MASK | IN0_ MASK | 8th to 15th bits invalid "0". |

RMT_RST_MASK Remote reset mask
1: External remote reset input is enabled. (Default)
0: External remote reset input is disabled.

IN1_MASK DIN1 input mask
1: DIN1 input is enabled.
0: DIN1 input is disabled. (Default)

IN0_MASK DIN0 input mask
1: DIN0 input is enabled.
0: DIN0 input is disabled. (Default)

RAS_IN_OUT

RAS IN/OUT register
Read/Write

| Register | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | Note |
|------------|------|------|----|----|-------------|--------------|-------------|-------------|-------------------------------|
| RAS IN/OUT | LEDR | LEDG | -- | | RAS_ ALM | RAS_ OUT0 | RAS_ IN1 | RAS_ IN0 | 8th to 15th bits invalid "0". |

LEDR Front red LED control (Independent functioning of Alarm Output)
When the RAS_ALM register is 0 and the WDT_ALM_MSK register is 1 (independent of the WDT_STT register), the control is enabled.
When the RAS_ALM register is 1 or the WDT_ALM_MSK register is 0, and the WDT_STT register is 1 (WDT error status), the red LED is ON as priority is given to the latter status.
1: The front red LED is ON. (Default)
0: The front red LED is OFF.

LEDG Front green LED control

- 1: The front green LED is ON.
- 0: The front green LED is OFF. (Default)

RAS_ALM Control of Alarm Output and front bezel LED

When the WDT_ALM_MASK register is 0 and the WDT_STT register is 1, Alarm Output is ON and the orange LED is ON (the red LED is also ON), regardless of the RAS_ALM register status.

- 1: Alarm Output is ON.
 - Front LED: The orange LED is ON. (The red LED is ON.)
- 2: Alarm Output is OFF. (Default)
 - Front LED: The green LED is ON. (The red LED is OFF.)

RAS_OUT0 DOUT control

- 1: DOUT0 is ON.
- 2: DOUT0 is OFF. (Default)

RAS_IN1 DIN1 control

When DIN1 is not masked, the DIN1 status is retained until 1 is written in this bit.

DIN1 input is accepted as soon as the signal changes from 0 to 1.

- 1: There is a DIN1 input. (Read) / Status clear (Write)
- 0: There is no DIN1 input. (Read) (Default)

RAS_IN0 DIN0 control

When DIN0 is not masked, the DIN0 status is retained until 1 is written in this bit.

DIN0 input is accepted as soon as the signal changes from 0 to 1.

- 1: There is a DIN0 input. (Read) / Status clear (Write)
- 0: There is no DIN0 input. (Read) (Default)

WDT_CR

Watchdog timer control register
Read/Write

| Register | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | Note |
|----------|---------|----|----|---------|--------------|----|----|----------|-------------------------------|
| WDT_CR | WDT_ALD | -- | -- | WDT_STT | WDT_ALM_MASK | -- | -- | WDT_CNTL | 8th to 15th bits invalid "0". |

WDT_ALD Watchdog timer automatic load

The data in the counter register is loaded into the watchdog timer as the initial value.

1: The initial value for the counter is loaded. (Write)

0: This bit remains set to 0 at the time of reading. (Read) (Default)

WDT_STT Watchdog timer time-out status

1: The watchdog timer time-out has occurred. (Read)

The time-out state is cleared. (Write)

0: The watchdog timer time-out has not occurred. (Read) (Default)

WDT_ALM_MASK Watchdog timer alarm mask

1: The mask is enabled. (Default)

0: The alarm is output to the RAS connector in the event of time-out.

WDT_CNTL Watchdog timer counter control

The operation of the watchdog timer is supported by repeated start and stop before the specified time-out limit passes. If the counter is not stopped before the specified time-out limit passes, Alarm/Lamp Out is output and 1 is set in the WDT_STT.

1: The counter is started.

2: The counter is stopped./The time-out status is cleared./The initial value is loaded. (Default)

WDT_COUNT

Watchdog timer counter register
Read/Write

| Register | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | Note |
|-----------|-------------------------|----------------|----------------|----------------|----------------|----------------|----------------|-------------------------|----------------------------------|
| WDT_COUNT | WDT_COUNT 7 (MSB) | WDT_COUNT 6 | WDT_COUNT 5 | WDT_COUNT 4 | WDT_COUNT 3 | WDT_COUNT 2 | WDT_COUNT 1 | WDT_COUNT 0 (LSB) | 8th to 15th bits invalid "0". |

WDT_COUNT 0 to 7 Initial value for the timer. One count is approximately equal to one second.

(Default: FF)

Sets the initial value to be loaded into the watchdog timer.

5 Touch Panel Driver

The function of this driver is to enable/disable buzzer activation and input when the touch panel is touched.

5.1 Touch Panel Driver APIs

| API name | Description |
|-----------------------|--|
| GetTouchDriverVersion | Retrieves information on the driver version. |
| TouchDriverOpen | Opens the touch panel driver. |
| TouchDriverClose | Closes the touch panel driver. |
| SetTouchClickBuzzer | Enables/disables the buzzer when the touch panel is touched. |
| GetTouchClickBuzzer | Retrieves the setting for buzzer activation when the touch panel is touched. |
| SetTouchInput | Enables/disables input when the touch panel is touched. |
| GetTouchInput | Retrieves the setting for input when the touch panel is touched. |

5.2 Function Specifications

GetTouchDriverVersion

Call format

BOOL WINAPI GetTouchDriverVersion (WORD *pMajor, WORD *pMinor)

Return value

TRUE: Normal

FALSE: Error

Argument

WORD *pMajor Pointer to the version information (Major, 0 to 99)

WORD *pMinor Pointer to the version information (Minor, 0 to 99)

Processing performed

Retrieves information on the driver version.

E.g.) BOOL ret = GetTouchDriverVersion (WORD &Major, WORD &Minor);

Note

When the driver version is 1.10,

Major is 1 (in decimal) and;

Minor is 10 (in decimal).

TouchDriverOpen

Call format

BOOL WINAPI TouchDriverOpen (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Opens the touch panel driver, enabling setting operations.

E.g.) BOOL ret = TouchDriverOpen ();

TouchDriverClose

Call format

BOOL WINAPI TouchDriverClose (void)

Return value

TRUE: Normal

FALSE: Error

Argument

None

Processing performed

Closes the touch panel driver, disabling setting operations. However, the thread operation of the driver continues.

E.g.) BOOL ret = TouchDriverClose ();

SetTouchClickBuzzer (BOOL bState)

Call format

BOOL WINAPI SetTouchClickBuzzer (BOOL bState)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bState TRUE: Turns the buzzer ON.
 FALSE: Turns the buzzer OFF.

Processing performed

Enables/disables the buzzer to activate when the touch panel is clicked.

E.g.) // Enables the buzzer to operate when the touch panel is clicked.

```
    BOOL ret = SetTouchClickBuzzer (TRUE);
```

GetTouchClickBuzzer (BOOL *bState)

Call format

BOOL WINAPI GetTouchClickBuzzer (BOOL *bState)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *bState Pointer to the buzzer activation setting when the touch panel is clicked

Processing performed

Retrieves the setting for whether or not the buzzer is enabled when the touch panel is clicked.

E.g.) // Retrieves the buzzer activation setting when the touch panel is clicked.

```
    BOOL State;
```

```
    BOOL ret = GetTouchClickBuzzer (&State);
```

SetTouchInput (BOOL bState)

Call format

BOOL WINAPI SetTouchInput (BOOL bState)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL bState TRUE: Enables input.
 FALSE: Disables input.

Processing performed

Enables/disables input when the touch panel is touched.

E.g.) // Enables input when the touch panel is touched.

```
    BOOL ret = SetTouchInput (TRUE);
```

GetTouchInput (BOOL *bState)

Call format

BOOL WINAPI GetTouchInput (BOOL *bState)

Return value

TRUE: Normal

FALSE: Error

Argument

BOOL *bState Pointer to the setting for input when the touch panel is touched.

Processing performed

Retrieves the setting for whether or not input is enabled when the touch panel is touched.

E.g.) // Retrieves the setting for input when the touch panel is touched.

```
    BOOL State;
```

```
    BOOL ret = GetTouchInput (&State);
```


Index

A

About Trademarks 3
ADK Files 1-6
Auto Start 2-14

B

Backlight Driver 3-3
Backlight Driver APIs 3-3
Building and Downloading a Program 2-5

C

CD-ROM Contents 5
Common functions 3-20, 3-22

D

Data Transfer Cable 1-3
Debugging Programs Using the Emulator 2-12
DIN functions 3-21, 3-35

E

emulation 1-4, 1-8

F

Function Specifications 3-4, 3-9, 3-14, 3-22, 3-46

G

GMU-BUS Driver 3-14
GMU-BUS Driver APIs 3-14

H

Hardware Environment 1-3
header file 3-2

I

Installing Application Development Tools 1-8

P

Platform Manager Configuration 1-14

R

RAS Driver 3-20
RAS Driver APIs 3-20
Registers Details 3-42
Remote Connection Procedure 1-6
Remote reset functions 3-21, 3-41
remote tools 1-4, 1-8

S

Software Environment and Installation 1-5
SRAM Driver 3-9
SRAM Driver APIs 3-9

T

Touch Panel Driver 3-46
Touch Panel Driver APIs 3-46

U

Usage Precautions 6

W

Watchdog timer functions 3-20, 3-21, 3-26
Win32 API 1-2

Global Head Office

Digital Electronics Corporation
8-2-52 Nanko-higashi,
Suminoe-ku, Osaka 559-0031 JAPAN
Tel: +81 (0)6 6613 3116 Fax: +81(0)6 6613 5888
<http://www.pro-face.com> support@digital.co.jp

South Korea

Pro-face Korea Co., Ltd.
Room #701, Jaeyoung Building
678-10 Deungchon-dong
Kangseo-Ku, Seoul 157-030 KOREA
Tel: +82 (0)2 658 6835 Fax: +82 (0)2 3664 6839
<http://www.proface.co.kr> proface@proface.co.kr

Taiwan

Pro-face Taiwan Co., Ltd.
2F, No.69, Fushing North Road
Taipei 105 TAIWAN R. O. C.
Tel: +886 (0)2 2772 5208 Fax: +886 (0)2 8773 7892
<http://www.proface.com.tw> proface@proface.com.tw

North/South America

Pro-face America, Inc.
2190-E Gladstone Court
Glendale Heights, IL 60139 U.S.A.
Tel: +1 630 351 1101 Fax: +1 630 351 1102
<http://www.profaceamerica.com>
support@profaceamerica.com

European Head Office

Pro-face HMI B.V.
Amsteldijk 166
1079 LH Amsterdam THE NETHERLANDS
Tel: +31 (0)20 6464 134 Fax: +31(0)20 6464 358
<http://www.proface.com> support@proface.com

Italy

Pro-face HMI B.V. Italy
Via Carcano 44
20033 Desio (MI)
ITALY
Tel: +39 0362 33 71 63 Fax: +39 0362 30 77 25
supporto_tecnico@proface.com

Germany

Pro-face Deutschland GmbH
Albertus-Magnus-Strasse 11
42719 Solingen
GERMANY
Tel: +49 (0)212 258 260 Fax: +49 (0)212 258 2640
<http://www.pro-face.de> support@pro-face.de