


**Operating Instruction Manual**

**DTM for Hilscher DeviceNet Master Devices**

**Configuration of Hilscher Master Devices**

**V1.1000**



**Hilscher Gesellschaft für Systemautomation mbH**

**[www.hilscher.com](http://www.hilscher.com)**

DOC070403OI15EN | Revision 15 | English | 2018-03 | Released | Public

# Table of Contents

1	INTRODUCTION.....	6
1.1	About this Manual .....	6
1.1.1	Descriptions of the Dialog Panes .....	6
1.1.2	Online Help .....	6
1.1.3	List of Revisions .....	7
1.1.4	Conventions in this Manual .....	8
1.2	Legal Notes.....	9
1.3	Registered Trademarks.....	12
1.4	About DeviceNet Master DTM.....	13
1.4.1	Requirements .....	13
1.5	Dialog Structure of the DeviceNet Master DTM.....	15
1.5.1	General Device Information.....	16
1.5.2	Navigation Area .....	16
1.5.3	Dialog Panes .....	17
1.5.4	OK, Cancel, Apply and Help.....	18
1.5.5	Table Lines .....	18
1.5.6	Status Bar .....	19
2	SAFETY .....	20
2.1	General Note.....	20
2.2	Intended Use.....	20
2.3	Personnel Qualification .....	20
2.4	Safety Instructions.....	21
2.4.1	Communication Stop during Firmware or Configuration Download .....	21
2.4.2	Mismatching System Configuration .....	21
2.5	Property Damage .....	22
2.5.1	Power Disconnect while downloading Firmware or Configuration .....	22
2.5.2	Invalid Firmware .....	22
2.6	Labeling of Safety Messages .....	23
2.7	References Safety.....	23
3	GETTING STARTED.....	24
3.1	Configuration Steps.....	24
3.2	Safety Messages on Firmware or Configuration Download .....	28
4	SETTINGS .....	29
4.1	Overview Settings .....	29
4.2	Settings for Driver and Device Assignment .....	30
4.3	Driver .....	32
4.3.1	Verify or adapt Driver Settings .....	32

4.3.2	cifX Device Driver .....	34
4.3.3	netX Driver .....	34
4.3.4	Configuring netX Driver .....	35
4.3.5	netX Driver - USB/RS232 Connection .....	36
4.3.6	netX Driver - TCP/IP Connection .....	38
4.4	Device Assignment .....	41
4.4.1	Scanning for Devices .....	41
4.4.2	Selecting the Device (with or without firmware) .....	44
4.4.3	Selecting the Device once more (with Firmware) .....	45
4.5	Firmware Download .....	47
4.6	Licensing .....	54
5	CONFIGURATION .....	55
5.1	Overview Configuration .....	55
5.2	Configuring Device Parameters .....	56
5.3	Bus Parameters .....	58
5.3.1	General .....	59
5.3.2	Bus Parameters .....	59
5.3.3	Error Handling .....	59
5.4	Server Parameters .....	60
5.5	Process Data .....	61
5.6	Address Table .....	62
5.6.1	Description of the Paramters .....	62
5.6.2	CSV Export .....	62
5.7	MAC ID Table .....	63
5.8	Quick Connect Table .....	64
5.8.1	What is „Quick Connect“? .....	65
5.8.2	How does „Quick Connect“ work? .....	65
5.8.3	Requirements for the use of „Quick Connect“ .....	66
5.8.4	How fast the I/O connection can be established with Quick-Connect? .....	67
5.9	Master Settings .....	68
5.9.1	Start of Bus Communication .....	69
5.9.2	Application Monitoring .....	69
5.9.3	Module Alignment .....	70
5.9.4	Process Data Handshake .....	71
5.9.5	Advanced (For future Application) .....	71
5.9.6	Device Status Offset .....	72
6	ONLINE FUNCTIONS .....	73
6.1	Connecting/Disconnecting Device .....	73
6.2	Debug Mode .....	75
6.2.1	Requirements .....	76
6.2.2	Starting Debug Mode .....	77
6.2.3	Debug Mode Busline Colors and Debug Icons .....	78
6.2.4	Reset of the Diagnosis Information and of the Station Status .....	79
6.2.5	Stopping Debug Mode .....	79

6.3	Set MAC ID .....	80
6.4	Live List.....	81
6.5	'Network Scan' and 'Upload' .....	82
6.5.1	Starting 'Network Scan' .....	83
6.5.2	Settings in the Scan Response Dialog of the Master DTM.....	85
6.5.3	Description on the Scan Response Dialog of the Master DTM.....	86
6.5.4	Creating Devices, Starting ,Upload'.....	88
6.5.5	Download to the DeviceNet Master Device.....	91
6.6	Download Configuration .....	92
6.7	Start /Stop Communication .....	94
6.8	Licensing.....	95
6.8.1	Open License Dialog .....	95
6.8.2	License Dialog .....	96
6.8.3	Which Licenses are present in the Device? .....	97
6.8.4	How to order a License.....	99
6.8.5	Selecting License(s) .....	99
6.8.6	Ordering Data .....	100
6.8.7	Ordering the License .....	102
6.8.8	How to get the License and transfer it to the Device.....	107
7	DIAGNOSIS .....	108
7.1	Overview Diagnosis .....	108
7.2	General Diagnosis.....	109
7.3	Master Diagnosis .....	111
7.4	Bus Diagnosis .....	112
7.4.1	Master Status .....	113
7.4.2	Server Status.....	114
7.4.3	Bus Monitoring.....	114
7.5	Station Diagnosis .....	115
7.6	Firmware Diagnosis .....	116
8	EXTENDED DIAGNOSIS .....	117
8.1	Overview Extended Diagnosis.....	117
8.2	Task Info .....	118
8.3	IniBatch Status.....	119
8.4	CAN_DL.....	120
8.4.1	App Commands.....	120
8.4.2	CAN Driver Status .....	121
8.5	DEVNET_FAL .....	122
8.5.1	Application Diagnosis .....	122
8.5.2	Device Status .....	123
8.5.3	Diagnosis Error.....	124
8.5.4	Timeout Counter.....	124
8.5.5	Reinit Counter.....	125
8.5.6	DeviceNet CAN Diagnosis .....	125

9	TOOLS .....	126
9.1	Overview Tools .....	126
9.2	Packet Monitor .....	127
9.2.1	Sending Packet .....	128
9.2.2	Receiving Packet.....	129
9.2.3	Example – Reading Data via „Get Attribute“ .....	130
9.2.4	Example – Writing Data via „Set Attribute“ .....	137
9.3	IO Monitor .....	144
9.4	Process Image Monitor .....	145
10	ERROR CODES.....	147
10.1	Error Code Definition.....	147
10.2	Overview Error Codes .....	148
10.3	General Hardware Error Codes .....	149
10.3.1	RCX General Task Errors.....	149
10.3.2	RCX Common Status & Errors Codes .....	150
10.3.3	RCX Status & Error Codes .....	151
10.4	ODM Error Codes .....	152
10.4.1	General ODM Error Codes .....	152
10.4.2	General ODM Driver Error Codes .....	153
10.4.3	cifX Driver Specific ODM Error Codes .....	154
10.5	Error Codes cifX Device Driver and netX Driver .....	157
10.5.1	Generic Error Codes.....	157
10.5.2	Generic Driver Error Codes .....	158
10.5.3	Generic Device Error Codes .....	159
10.6	Error Codes netX Driver .....	160
10.6.1	CIFX API Transport Error Codes.....	160
10.6.2	CIFX API Transport Header State Error Codes .....	160
10.7	ODM Error Codes DBM V4 .....	161
11	APPENDIX .....	165
11.1	User Rights .....	165
11.1.1	Settings.....	165
11.1.2	Configuration .....	165
11.2	References.....	166
11.3	List of Figures .....	166
11.4	List of Tables.....	168
11.5	Glossary.....	170
11.6	Contacts.....	172

# 1 Introduction

## 1.1 About this Manual

This manual provides information on how to set and configure the device parameters of a netX based DeviceNet Master device using the DeviceNet Master DTM, and what can be read from the diagnosis panes.

### 1.1.1 Descriptions of the Dialog Panes

The table below gives an overview for the individual dialog panes descriptions:

Section	Subsection	Page
<i>Settings</i>	<i>Overview Settings</i>	29
	<i>Driver</i>	32
	<i>Device Assignment</i>	41
	<i>Firmware Download</i>	47
	<i>Licensing</i>	95
<i>Configuration</i>	<i>Overview Configuration</i>	55
	<i>Bus Parameters</i>	58
	<i>Server Parameters</i>	60
	<i>Process Data</i>	61
	<i>Address Table</i>	62
	<i>MAC ID Table</i>	63
	<i>Quick Connect Table</i>	64
	<i>Master Settings</i>	68
<i>Diagnosis</i>	<i>Overview Diagnosis</i>	108
	<i>General Diagnosis</i>	109
	<b>Fehler! Kein gültiges Resultat für Tabelle.</b>	111
	<i>Bus Diagnosis</i>	112
	<i>Station Diagnosis</i>	115
	<i>Firmware Diagnosis</i>	116
<i>Extended Diagnosis</i>	<i>Overview Extended Diagnosis</i>	117
<i>Tools</i>	<i>Overview Tools</i>	126
	<i>Packet Monitor</i>	127
	<i>IO Monitor</i>	144
	<i>Process Image Monitor</i>	145

Table 1: Descriptions Dialog Panes

### 1.1.2 Online Help

The DeviceNet Master DTM contains an integrated online help facility.

- To open the online help, click on **Help** or press **F1**.

### 1.1.3 List of Revisions

Index	Date	Version	Chapter	Revision
14	17-02-22	1.1000	1.4.1	Section <i>Requirements</i> Internet access added, Windows 8.1 and Windwos 10 added.
15	18-02-14	1.1000	2.5.1, 3.2, 4.5, 6.6	Versioning information revised: Title page and this section Safety Message or warning added: Sections <i>Power Disconnect while downloading Firmware or Configuration</i> , <i>Safety Messages on Firmware or Configuration Download</i> , <i>Firmware Download</i> and <i>Download Configuration</i> . Safety communication in the document revised in general.

Table 2: List of Revisions

## 1.1.4 Conventions in this Manual

Notes, operation instructions and results of operation steps are marked as follows:

### Notes



**Important:** <important note you must follow to avoid malfunction>



**Note:** <general note>



<note, where to find further information>

### Operation Instructions

1. <instruction>

2. <instruction>

or

➤ <instruction>

### Results

↪ <result>

### Positions in Figures

The *Positions* ①, ②, ③ ... or a, b, c ... or A, B, C ... refer to the figure used in that section. If the numbers reference to a section outside the current section then a cross reference to that section and figure is indicated.



## 1.2 Legal Notes

### Copyright

© Hilscher Gesellschaft für Systemautomation mbH

All rights reserved.

The images, photographs and texts in the accompanying materials (in the form of a user's manual, operator's manual, Statement of Work document and all other document types, support texts, documentation, etc.) are protected by German and international copyright and by international trade and protective provisions. Without the prior written consent, you do not have permission to duplicate them either in full or in part using technical or mechanical methods (print, photocopy or any other method), to edit them using electronic systems or to transfer them. You are not permitted to make changes to copyright notices, markings, trademarks or ownership declarations. Illustrations are provided without taking the patent situation into account. Any company names and product designations provided in this document may be brands or trademarks by the corresponding owner and may be protected under trademark, brand or patent law. Any form of further use shall require the express consent from the relevant owner of the rights.

### Important notes

Utmost care was/is given in the preparation of the documentation at hand consisting of a user's manual, operating manual and any other document type and accompanying texts. However, errors cannot be ruled out. Therefore, we cannot assume any guarantee or legal responsibility for erroneous information or liability of any kind. You are hereby made aware that descriptions found in the user's manual, the accompanying texts and the documentation neither represent a guarantee nor any indication on proper use as stipulated in the agreement or a promised attribute. It cannot be ruled out that the user's manual, the accompanying texts and the documentation do not completely match the described attributes, standards or any other data for the delivered product. A warranty or guarantee with respect to the correctness or accuracy of the information is not assumed.

We reserve the right to modify our products and the specifications for such as well as the corresponding documentation in the form of a user's manual, operating manual and/or any other document types and accompanying texts at any time and without notice without being required to notify of said modification. Changes shall be taken into account in future manuals and do not represent an obligation of any kind, in particular there shall be no right to have delivered documents revised. The manual delivered with the product shall apply.

Under no circumstances shall Hilscher Gesellschaft für Systemautomation mbH be liable for direct, indirect, ancillary or subsequent damage, or for any loss of income, which may arise after use of the information contained herein.

### Liability disclaimer

The hardware and/or software was created and tested by Hilscher Gesellschaft für Systemautomation mbH with utmost care and is made available as is. No warranty can be assumed for the performance or flawlessness of the hardware and/or software under all application

conditions and scenarios and the work results achieved by the user when using the hardware and/or software. Liability for any damage that may have occurred as a result of using the hardware and/or software or the corresponding documents shall be limited to an event involving willful intent or a grossly negligent violation of a fundamental contractual obligation. However, the right to assert damages due to a violation of a fundamental contractual obligation shall be limited to contract-typical foreseeable damage.

It is hereby expressly agreed upon in particular that any use or utilization of the hardware and/or software in connection with

- Flight control systems in aviation and aerospace;
- Nuclear fusion processes in nuclear power plants;
- Medical devices used for life support and
- Vehicle control systems used in passenger transport

shall be excluded. Use of the hardware and/or software in any of the following areas is strictly prohibited:

- For military purposes or in weaponry;
- For designing, engineering, maintaining or operating nuclear systems;
- In flight safety systems, aviation and flight telecommunications systems;
- In life-support systems;
- In systems in which any malfunction in the hardware and/or software may result in physical injuries or fatalities.

You are hereby made aware that the hardware and/or software was not created for use in hazardous environments, which require fail-safe control mechanisms. Use of the hardware and/or software in this kind of environment shall be at your own risk; any liability for damage or loss due to impermissible use shall be excluded.

### Warranty

Hilscher Gesellschaft für Systemautomation mbH hereby guarantees that the software shall run without errors in accordance with the requirements listed in the specifications and that there were no defects on the date of acceptance. The warranty period shall be 12 months commencing as of the date of acceptance or purchase (with express declaration or implied, by customer's conclusive behavior, e.g. putting into operation permanently).

The warranty obligation for equipment (hardware) we produce is 36 months, calculated as of the date of delivery ex works. The aforementioned provisions shall not apply if longer warranty periods are mandatory by law pursuant to Section 438 (1.2) BGB, Section 479 (1) BGB and Section 634a (1) BGB [Bürgerliches Gesetzbuch; German Civil Code] If, despite of all due care taken, the delivered product should have a defect, which already existed at the time of the transfer of risk, it shall be at our discretion to either repair the product or to deliver a replacement product, subject to timely notification of defect.

The warranty obligation shall not apply if the notification of defect is not asserted promptly, if the purchaser or third party has tampered with the products, if the defect is the result of natural wear, was caused by unfavorable operating conditions or is due to violations against our operating regulations or against rules of good electrical engineering

practice, or if our request to return the defective object is not promptly complied with.

### **Costs of support, maintenance, customization and product care**

Please be advised that any subsequent improvement shall only be free of charge if a defect is found. Any form of technical support, maintenance and customization is not a warranty service, but instead shall be charged extra.

### **Additional guarantees**

Although the hardware and software was developed and tested in-depth with greatest care, Hilscher Gesellschaft für Systemautomation mbH shall not assume any guarantee for the suitability thereof for any purpose that was not confirmed in writing. No guarantee can be granted whereby the hardware and software satisfies your requirements, or the use of the hardware and/or software is uninterrupted or the hardware and/or software is fault-free.

It cannot be guaranteed that patents and/or ownership privileges have not been infringed upon or violated or that the products are free from third-party influence. No additional guarantees or promises shall be made as to whether the product is market current, free from deficiency in title, or can be integrated or is usable for specific purposes, unless such guarantees or promises are required under existing law and cannot be restricted.

### **Confidentiality**

The customer hereby expressly acknowledges that this document contains trade secrets, information protected by copyright and other patent and ownership privileges as well as any related rights of Hilscher Gesellschaft für Systemautomation mbH. The customer agrees to treat as confidential all of the information made available to customer by Hilscher Gesellschaft für Systemautomation mbH and rights, which were disclosed by Hilscher Gesellschaft für Systemautomation mbH and that were made accessible as well as the terms and conditions of this agreement itself.

The parties hereby agree to one another that the information that each party receives from the other party respectively is and shall remain the intellectual property of said other party, unless provided for otherwise in a contractual agreement.

The customer must not allow any third party to become knowledgeable of this expertise and shall only provide knowledge thereof to authorized users as appropriate and necessary. Companies associated with the customer shall not be deemed third parties. The customer must obligate authorized users to confidentiality. The customer should only use the confidential information in connection with the performances specified in this agreement.

The customer must not use this confidential information to his own advantage or for his own purposes or rather to the advantage or for the purpose of a third party, nor must it be used for commercial purposes and this confidential information must only be used to the extent provided for in this agreement or otherwise to the extent as expressly authorized by the disclosing party in written form. The customer has the right, subject to the obligation to confidentiality, to disclose the terms and conditions of this agreement directly to his legal and financial consultants as would be required for the customer's normal business operation.

**Export provisions**

The delivered product (including technical data) is subject to the legal export and/or import laws as well as any associated regulations of various countries, especially such laws applicable in Germany and in the United States. The products / hardware / software must not be exported into such countries for which export is prohibited under US American export control laws and its supplementary provisions. You hereby agree to strictly follow the regulations and to yourself be responsible for observing them. You are hereby made aware that you may be required to obtain governmental approval to export, reexport or import the product.

## 1.3 Registered Trademarks

Windows® XP, Windows® Vista, Windows® 7, Windows® 8, Windows® 8.1 and Windows® 10 are registered trademarks of Microsoft Corporation.

DeviceNet™ is a trademark of ODVA (Open DeviceNet Vendor Association, Inc).

CODESYS® is a registered trademark of 3S-Smart Software Solutions GmbH, Deutschland.

All other mentioned trademarks are property of their respective legal owners.

## 1.4 About DeviceNet Master DTM

You can use the DeviceNet Master DTM to configure the DeviceNet Master device within a FDT Framework.



**Important:** For a 2-channel device consecutively channel 1 or channel 2 must be assigned to the DTM and each must be configured individually.

### 1.4.1 Requirements

#### System Requirements

- PC with 1 GHz processor or higher
- Windows® XP SP3,  
Windows® Vista (32-Bit) SP2,  
Windows® 7 (32-Bit and 64-Bit) SP1,  
Windows® 8 (32-Bit and 64-Bit),  
Windows® 8.1 (32-Bit and 64-Bit),  
Windows® 10 (32-Bit and 64-Bit)
- Administrator privilege required for installation
- Internet Explorer 5.5 or higher
- RAM: min. 512 MByte, recommended 1024 MByte
- Graphic resolution: min. 1024 x 768 pixel
- Keyboard and Mouse
- Restriction: Touch screen is not supported.



**Note:** If the project file is used on a further PC,

- this PC must also comply with the above system requirements,
- the device description files of the devices used in the project must be imported into the configuration software SYCON.net on the new PC,
- and the DTMs of the devices used in the project must also be installed on that further PC.

#### Requirements DeviceNet Master DTM

To configure the DeviceNet Master device with the DeviceNet Master DTM the following requirements have to be accomplished:

- Completed hardware installation of a netX based DTM-compatible DeviceNet Master device, inclusive loaded firmware, license and loaded cifX configuration file
- Installed FDT/DTM V 1.2 compliant frame application
- Loaded DTM in the Device Catalog of the FTD Framework



**Note:** If the DeviceNet Master DTM and the DeviceNet Master device are installed on the same PC, the **cifX Device Driver** must be installed on that PC, as you can connect the DTM to the device.



For more information to the hardware installation, please refer to the corresponding **User Manual** of your device.

To get information on how to order and to download the license to the device, please refer to section *Licensing* on page 95.

## 1.5 Dialog Structure of the DeviceNet Master DTM

The graphical user interface of the DTM is composed of different areas and elements listed hereafter:

1. A header area containing the **General Device Information**,
2. The **Navigation Area** (area on the left side),
3. The **Dialog Pane** (main area on the right side),
4. **OK, Cancel, Apply, Help**,
5. The **Status Line** containing information e. g. the online-state of the DTM.




Figure 1: Dialog Structure of the DeviceNet Master DTM

## 1.5.1 General Device Information

Parameter	Meaning
IO Device	Name of the device
Vendor	Vendor name of the device
Device ID	Identification number of the device
Vendor ID	Identification number of the vendor

Table 3: General Device Information

## 1.5.2 Navigation Area

The **Navigation Area** contains folders and subfolders to open the dialog panes of the DTM.






Figure 2: Navigation Area

- Select the required folder and subfolder.
- The corresponding Dialog pane is displayed.

### Hide / display Navigation

	Hiding the navigation area (above right side).
 Show navigation area	Opening the navigation area (below left side).



### 1.5.3 Dialog Panes

At the dialog pane the **Settings**, **Configuration**, **Diagnosis/Extended Diagnosis** or the **Tools** panes are opened via the corresponding folder in the navigation area.

Settings	
Driver	To establish a connection from the DeviceNet Master DTM to the DeviceNet Master device, on the pane <b>Driver</b> you can verify if the default driver is checked and respectively check another driver or multiple drivers. For further information, refer to section <i>Driver</i> on page 32.
Device Assignment	On the pane <b>Device Assignment</b> you select the device and assign the device to the driver. For further information, refer to section <i>Device Assignment</i> on page 41.
Firmware Download	The dialog on the pane <b>Firmware Download</b> is used to load a new firmware into the device. A detailed description can be found in section <i>Firmware Download</i> on page 47.
Licensing	Using the license dialog, you can order licenses for Master protocols or Utilities and download them to your device. A detailed description can be found in section <i>Licensing</i> on page 95.
Configuration	
Bus Parameter	The <b>Bus Parameters</b> are the basis of an operating data exchange. For further information refer to section <i>Bus Parameters</i> on page 58.
Server Parameters	The <b>Server Parameters</b> contain DeviceNet specific server parameters with which the device is able to be a server at the same time being a Master. Further information can be found in section <i>Server Parameters</i> on page 60.
Process Data	The <b>Process Data</b> pane serves for the DeviceNet Master DTM as an external process data interface. For further information, refer to section <i>Process Data</i> on page 61.
Address Table	The <b>Address Table</b> shows a list of all dpram addresses used in the process data image. For further information, refer to section <i>Address Table</i> on page 62.
MAC ID Table	The MAC ID Table, also called device table, shows the MAC IDs, Device Names and Device Descriptions of the configured slaves. Further information can be found in section <i>MAC ID Table</i> on page 63.
Quick Connect Table	In the <b>Quick Connect Table</b> pane you need to define for every DeviceNet Slave device whether the Master Device shall accelerate connection establishment to this Slave by using the „Quick Connect“ option. Further information can be found in section <i>Quick Connect Table</i> on page 64.
Master Settings	At the <b>Master Settings</b> pane device related settings can be made. For further information, refer to section <i>Master Settings</i> on page 68.
Diagnosis	
Diagnosis/ Extended Diagnosis	At the <b>Diagnosis</b> panes information can be read for troubleshooting. For further information, refer to section <i>Overview Diagnosis</i> on page 108 or section <i>Overview Extended Diagnosis</i> on page 117.
Tools	
Packet Monitor/ IO Monitor/ Process Image Monitor	Under <b>Tools</b> the Packet Monitor and the IO Monitor are provided for test and diagnosis purposes. For further information, refer to section <i>Packet Monitor</i> on page 127, section <i>IO Monitor</i> on page 144, section <i>Process Image Monitor</i> on page 145 or section <i>Process Image Monitor</i> on page 145.

Table 4: Overview Dialog Panes



**Note:** Accessing the **Diagnosis** panes of the DeviceNet Master DTM requires an online connection from the DeviceNet Master DTM to the DeviceNet Master device.



For further information, refer to section *Connecting/Disconnecting Device* on page 73.

## 1.5.4 OK, Cancel, Apply and Help

**OK, Cancel, Apply and Help** you can use as described hereafter.

	Meaning
<b>OK</b>	To confirm your latest settings, click <b>OK</b> . All changed values will be applied on the frame application database. <i>The dialog then closes.</i>
<b>Cancel</b>	To cancel your latest changes, click <b>Cancel</b> . Answer to the safety query <b>Configuration data has been changed. Do you want to save the data?</b> by <b>Yes</b> , <b>No</b> or <b>Cancel</b> . <b>Yes:</b> The changes are saved or the changed values are applied on the frame application database. <i>The dialog then closes.</i> <b>No:</b> The changes are <u>not</u> saved or the changed values are not applied on the frame application database. <i>The dialog then closes.</i> <b>Cancel:</b> <i>Back to the DTM.</i>
<b>Apply</b>	To confirm your latest settings, click <b>Apply</b> . All changed values will be applied on the frame application database. <i>The dialog remains opened.</i>
<b>Help</b>	To open the DTM online help, click <b>Help</b> .

Table 5: OK, Cancel, Apply and Help

## 1.5.5 Table Lines

In the DTM dialog pane table lines can be selected, inserted or deleted.







	Meaning
	To select the first line of a table use <b>First Line</b> .
	To select the previous line of a table use <b>Previous Line</b> .
	To select the next line of a table use <b>Next Line</b> .
	To select the last line of a table use <b>Last Line</b> .
	<b>Create a new Line</b> inserts new lines into the table.
	<b>Delete selected Line</b> deletes the selected line from the table.

Table 6: Selecting, inserting, deleting Table Line

## 1.5.6 Status Bar

The **Status Bar** displays information about the current state of the DTM. The current activity, e.g. download, is signaled graphically via icons in the status bar.





Figure 3: Status Bar – Status Fields 1 to 6


Status Field	Icon / Meaning	
1	<b>DTM Connection States</b>	
		<b>Connected:</b> Icon closed = Device is online
		<b>Disconnected:</b> Icon opened = Device is offline
2	<b>Data Source States</b>	
		<b>Data set:</b> The displayed data are read out from the instance data set (database).
		<b>Device:</b> The displayed data are read out from the device.
3	<b>States of the instance Date Set</b>	
		<b>Valid Modified:</b> Parameter is changed (not equal to data source).
4	<b>Changes directly made on the Device</b>	
		Load/configure diagnosis parameters: Diagnosis is activated.
6	<b>Device Diagnosis Status</b>	
		<b>Save operation succeeded:</b> The save operation has been successful. Further messages due to successful handling of device data.
		<b>Firmware Download:</b> Firmware Download is running
		<b>Save operation failed:</b> The save operation has failed. Further fail operation messages due to incorrect communication due to malfunction in the field device or its peripherals.

Table 7: Status Bar Icons [1]


Offline State



Save operation succeeded



Firmware Download



Firmware Download successful



Online State and Diagnosis




Figure 4: Status Bar Display Examples

## **2 Safety**

### **2.1 General Note**

The documentation in the form of a user manual, an operating instruction manual or other manual types, as well as the accompanying texts have been created for the use of the products by educated personnel. When using the products, all Safety Messages, Integrated Safety Messages, Property Damage Messages and all valid legal regulations must be obeyed. Technical knowledge is presumed. The user has to assure that all legal regulations are obeyed.

### **2.2 Intended Use**

The DeviceNet Master DTM serves for configuration and diagnosis of DeviceNet Master devices.

### **2.3 Personnel Qualification**

Personnel responsible for the application of the network system shall be aware of the system behavior and shall be trained in using the system.

## 2.4 Safety Instructions

To ensure your own personal safety and to avoid personal injury, you necessarily must read, understand, and comply with the safety instructions and safety messages in this manual before you install and operate your system.

For cases if both, personal injury as well as property damage (damage of equipment or device) may occur together, you find the safety instructions in this section.

### 2.4.1 Communication Stop during Firmware or Configuration Download

If you want to perform either a firmware update (as a download) or a configuration download, both via the DeviceNet Master DTM, be aware of the following:

- Together with the firmware download, an automated reset to the device is performed that will interrupt all network communication and all established connections will drop.
- If you download the configuration during bus operation, the communication between master and slaves is stopped.

#### **Possible faulty System Operation**

- An unpredictable and unexpected behavior of machines and plant components may cause personal injury and property damage.
  - Stop the application program, before starting the firmware update or before downloading the configuration.
  - Make sure that your equipment operates under conditions that prevent personal injury or property damage. All network devices should be placed in a fail-safe mode, before starting the firmware update or before downloading a configuration.

#### **Loss of Device Parameters, Overwriting of Firmware**

- Both the firmware download and the configuration download erase the configuration data base. The firmware download overwrites the existing firmware in the network device.
  - To complete the firmware update and to make the device operable again, re-load the configuration after the firmware update has been finished.

### 2.4.2 Mismatching System Configuration

Mismatching system configuration loaded into the device could result in faulty data mapping in the application program and thus unexpected equipment operation may cause personal injury or damage of equipment.

- In the device use only a configuration suitable for the system.

## 2.5 Property Damage

To avoid property damage and damage to your system or to your equipment, you necessarily must read, understand, and comply with the safety instructions and safety messages in this manual before you configure your system.

### 2.5.1 Power Disconnect while downloading Firmware or Configuration

If during the process of downloading a firmware or configuration

- the power supply to a PC with the software application is interrupted,
- or the power supply to the DeviceNet Master device is interrupted,
- or a reset to the device is performed,

this may lead to the following consequences:

#### **Loss of Device Parameters, Firmware Corruption**

- The firmware download or the configuration download will be interrupted and remains incomplete.
- The firmware or the configuration database will be corrupted and device parameters will be lost.
- Device damage may occur as the device cannot be rebooted.

Whether these consequences occur depends on when the power disconnect occurs during the download.

- During configuration download process, do not interrupt the power supply to the PC, or to the device and do not perform a reset!

Otherwise you might be forced to return your device for repair.

#### **Power Drop during Write and Delete Accesses in the File System**

The FAT file system in the netX firmware is subject to certain limitations in its operation. Write and delete accesses in the file system (firmware update, configuration download etc.) can destroy the FAT (File Allocation Table) if the accesses cannot be completed if the power drops. Without a proper FAT, a firmware may not be found and cannot be started.

Make sure that the power supply to the device is not interrupted during write and delete accesses in the file system (firmware update, configuration download, etc.).

### 2.5.2 Invalid Firmware

Loading invalid firmware files could render your device unusable.

- Only download firmware files to the device that are valid for this device.

Otherwise you might be forced to return your device for repair.

## 2.6 Labeling of Safety Messages

- The **Section Safety Messages** at the beginning of a chapter are pinpointed particularly and highlighted by a signal word according to the degree of endangerment. The type of danger is specified by the safety message text
- The **Integrated Safety Messages** within an instruction description are highlighted with a signal word according to the degree of endangerment. The kind of danger is specified exactly by the safety message text.





Signal Word	Meaning (International)	Meaning (USA)
 <b>DANGER</b>	Indicates a direct hazard with high risk, which will have a consequence of death or grievous bodily harm if it is not avoided.	Indicates a hazardous situation which if not avoided, will result in death or serious injury.
 <b>WARNING</b>	Indicates a possible hazard with medium risk, which will have a consequence of death or (grievous) bodily harm if it is not avoided.	Indicates a hazardous situation which if not avoided, could result in death or serious injury.
 <b>CAUTION</b>	Indicates a minor hazard with medium risk, which could have a consequence of minor or moderate bodily harm if it is not avoided.	Indicates a hazardous situation which if not avoided, may result in minor or moderate injury.
 <b>NOTICE</b>	Indicates a property damage message.	Indicates a property damage message.

Table 8: Signal Words



**Note:** The ANSI Z535.6 standard specifies in section 4.8: "Messages about hazards that could result in both, physical injury and property damage are considered safety messages, not property damage messages." Thus depending of the type of danger and its consequences, warning messages marked by a signal word DANGER, WARNING or CAUTION may include both, messages on physical injury and property damage.

In this document all Safety Instructions and Safety Messages are designed according both to the international used safety conventions as well as to the ANSI Z535.6 standard, refer to safety reference [S1].

In this document the signal words 'WARNING', 'CAUTION' and 'NOTICE' are used according to ANSI Z535.6 standard. The meaning given in ISO/IEC 26514 [S4] section '11.11 Contents of warnings and cautions' is not relevant in this manual.

## 2.7 References Safety

- [S1] ANSI Z535.6-2011 American National Standard for Product Safety Information in Product Manuals, Instructions, and Other Collateral Materials
- [S4] 26514-2010 - IEEE Standard for Adoption of ISO/IEC 26514:2008 Systems and Software Engineering--Requirements for Designers and Developers of User Documentation

## 3 Getting started


### 3.1 Configuration Steps

The following overview provides to you the step sequence on how to configure a netX based DeviceNet Master device with DeviceNet Master DTM as it is typical for many cases. At this time it is presupposed that the hardware installation was done.




The overview lists all the steps in a compressed form. For detailed descriptions of each step refer to the sections noted in the column *For detailed information see section*.



**Important:** For a 2-channel device consecutively channel 1 or channel 2 must be assigned to the DTM and each must be configured individually.

#	Step	Short Description	For detailed information see section	Page
1	Add DeviceNet Slave in the Device Catalog	Add the Slave in the Device Catalog by importing the device description file to the Device Catalog. Depending of the FDT Container. For netDevice: - <b>Network &gt; Import Device Descriptions.</b>	(See <i>Operating Instruction Manual netDevice and netProject</i> )	-
2	Load device catalog	Depending of the FDT Container: For netDevice: - select <b>Network &gt; Device Catalog</b> , - select <b>Reload Catalog</b> .	(See <i>Operating Instruction Manual netDevice and netProject</i> )	-
3	Create new project / Open existing project	Depending of the frame application. For the configuration software: - select <b>File &gt; New</b> or <b>File &gt; Open</b> .	(See <i>Operating Instruction Manual of the Frame Application</i> )	-
4	Insert Master or Slave into configuration	Depending of the FDT Container: For netDevice:   <b>Important!</b> In order to select the desired device in the device catalog, note the details about the DTM and the device at the bottom of the window. When sorting by <i>Fieldbus</i> multiple devices with identical names by different vendors can be displayed.  - in the Device Catalog click to the Master, - and insert the device via drag and drop <b>to the line</b> in the network view, - in the Device Catalog click to the Slave,* - and insert the device via drag and drop <b>to the Master bus line</b> in the network view.* (*This step won't be necessary if the network structure is scanned automatically. See <i>step 17</i> .)	(See <i>Operating Instruction Manual netDevice and netProject</i> )	-
5	Open the Master DTM configuration dialog	Open the Master DTM configuration dialog. - Double click to the device icon of the Master. - The Master DTM configuration dialog is displayed.	-	-



#	Step	Short Description	For detailed information see section	Page
6	Verify or adapt Driver Settings	<p>In the Master DTM configuration dialog: - select <b>Settings &gt; Driver</b>.</p>  <p><b>Note!</b> For PC cards cifX the <b>cifX Device Driver</b> is preset as a default driver. For all the other Hilscher devices the <b>netX Driver</b> is preset as a default driver.</p> <ul style="list-style-type: none"> <li>• Use the <b>cifX Device Driver</b> if the DeviceNet Master DTM is installed on the same PC as the DeviceNet Master device.</li> <li>• Use the <b>netX Driver</b> to establish a USB, Serial (RS232) or TCP/IP connection from the DeviceNet Master DTM to the DeviceNet Master device.</li> <li>• <b>The 3SGateway Driver for netX (V3.x)</b> is used only in relationship with CODESYS.</li> </ul> <p>To search for devices you can check one or multiple drivers simultaneously.</p>	<p><i>Settings for Driver and Device Assignment and Driver</i></p>	30
		<p>- Verify that the default driver is checked. - If necessary, check another driver or multiple drivers.</p>		32
7	Configure Driver	<p>If you use the <b>netX Driver</b>, you respectively must configure it.</p> <p>For <b>netX Driver and communication via TCP/IP</b> set the IP address of the device: - Select <b>Settings &gt; Driver &gt; netX Driver &gt; TCP Connection</b>. - Via  add an IP range. - Under <b>IP Address</b> enter the IP Address of the device or an IP range. - Click <b>Save</b>.</p> <p>Adjust the driver parameters <b>netX Driver USB/RS232</b> only if they differ from the default settings.</p>  <p><b>Note!</b></p> <ul style="list-style-type: none"> <li>• The <b>cifX Device Driver</b> requires no configuration.</li> <li>• The configuration of the <b>3SGateway Driver for netX (V3.x)</b> is carried out via the CODESYS surface.</li> </ul>	<i>Configuring netX Driver</i>	35
8	Assign Master device (with or without firmware)	<p>Assign the device to this driver.</p> <p>In the Master DTM configuration dialog: - select <b>Settings &gt; Device Assignment</b>, - select a Master device (with or without firmware), - therefore check the appropriate checkbox, - select <b>Apply</b>.</p>	<i>Selecting the Device (with or without firmware)</i>	44
9	Select and download firmware	<p>If not yet a firmware was loaded to the device: - Adhere to the necessary safety precautions to prevent personnel injury and property damage.</p> <p>In the Master DTM configuration dialog: - select <b>Settings &gt; Firmware Download</b>, - select <b>Browse...</b>, - select a firmware file, - select <b>Open</b>, - select <b>Download</b> and <b>Yes</b>.</p>	<p><i>Safety Messages on Firmware or Configuration Download</i></p> <p><i>Firmware Download</i></p>	28
				47

#	Step	Short Description	For detailed information see section	Page
10	Assign Master device once more (with firmware and system channel) <i>For repeated download this step is omitted.</i>	In the Master DTM configuration dialog: - select <b>Settings &gt; Device Assignment</b> , - select <b>Scan</b> , - select the Master device (with loaded and defined system channel), - therefore check the appropriate checkbox, - select <b>Apply</b> , - close the Master DTM configuration dialog via <b>OK</b> .	<i>Selecting the Device once more (with Firmware)</i>	45
11	Configure Slave device* (*This step won't be necessary if the network structure is scanned automatically. See step 17.)	Configure the Slave device. - Double click to the device icon of the Slave. - The Slave DTM configuration dialog is displayed. In the Slave DTM configuration dialog: - select <b>Configuration &gt; General</b> , - set UCMM and Fragmentation Timeout, - select <b>Configuration &gt; Connection</b> , - configure the device connection, - select <b>Configuration &gt; Parameter</b> , - set the parameter data of the device, - close the Slave DTM configuration dialog via <b>OK</b> .	<i>(See Operating Instruction Manual Generic Slave DTM for DeviceNet Slave Devices)</i>	-
12	Configure Master device	Configure the Master device. - Double click to the device icon of the Master. - The Master DTM configuration dialog is displayed. In the Master DTM configuration dialog: - select <b>Configuration &gt; Bus Parameters</b> , - set the bus parameters, - select <b>Configuration &gt; Server Parameter</b> , - set the server parameters, - select <b>Configuration &gt; Process Data</b> , - set symbolic names for the configured modules or signals. - select <b>Configuration &gt; MAC ID Table</b> , - set the MAC ID table options, - select <b>Configuration &gt; Quick Connect Table</b> , - check <b>Quick Connect</b> for the Slave device(s), which shall work as „Quick Connect“ Slave, - select <b>Configuration &gt; Master Settings</b> , - set the Master <b>Settings</b> . - close the Master DTM configuration dialog via <b>OK</b> .	<i>Configuring Device Parameters</i>  <i>Bus Parameters</i> <i>Server Parameters</i> <i>Process Data</i> <i>MAC ID Table</i> <i>Quick Connect Table</i> <i>Master Settings</i>	56  58 60 61 63 64 68
13	Save project	Depending of the frame application. For the configuration software: - select <b>File &gt; Save</b> .	<i>(See Operating Instruction Manual of the Frame Application)</i>	-
14	Connect Master device	Depending of the FDT Container. For netDevice: - right click to the device icon of the Master, - select <b>Connect</b> .	<i>Connecting/Disconnecting Device</i>	73
15	Licensing	How to order licenses later and how to transfer them to the device.	<i>Licensing</i>	95
16	Download Configuration	- Adhere to the necessary safety precautions to prevent personnel injury and property damage. Depending of the FDT Container. For netDevice: - right click to the device icon of the Master, - select <b>Download</b> .	<i>Safety Messages on Firmware or Configuration Download</i>  <i>Download Configuration</i>	28  92

#	Step	Short Description	For detailed information see section	Page
17	Network Scan/	As an alternative to manually configure the Slave device, you can automatically scan the network structure by using the context menu <b>Network Scan</b> . Then confirm the query whether the module configuration of the Slave device shall be generated and download the configuration to the Master device. Therefore proceed the following steps: 1. Start the <b>Network Scan</b> function. 2. Make the settings in the <b>Scan Response</b> dialog of the Master DTM. 3. Click <b>Create devices</b> . 4. <b>Upload</b> of the Device configurations and generate the connection configurations. 5. Download of the Slave device configurations to the Master device ( <b>Download</b> ).	<i>'Network Scan' and 'Upload'</i>	82
	Live List	Via the context menu <b>Additional Functions &gt; Live List</b> you can display the devices present at the bus.	<i>Live List</i>	81
18	Diagnosis	Depending of the FDT Container. For netDevice: - right click to the device icon of the Master, - select <b>Diagnosis</b> . - The Master DTM diagnosis dialog is displayed. (1) Check whether the communication is OK: <b>Diagnosis &gt; General Diagnosis &gt; Device status "Communication"</b> must be green! (2) <b>"Communication"</b> is green: Open the IO Monitor and test the input or output data. (3) <b>"Communication"</b> is not green: Use Diagnosis and Extended diagnosis for troubleshooting. - close the Master DTM diagnosis dialog via <b>OK</b> .	<i>Overview Diagnosis</i>	108
19	IO Monitor	Depending of the FDT Container: For netDevice: - right click to the device icon of the Master, - select <b>Diagnosis</b> , - select <b>Tools &gt; IO Monitor</b> . - Check the input or output data, - close the IO Monitor dialog via <b>OK</b> .	<i>IO Monitor</i>	144
20	Disconnect	Depending of the FDT Container. For netDevice: - right click to the device icon of the Master, - select <b>Disconnect</b> .	<i>Connecting/Disconnecting Device</i>	73

Table 9: Getting started - Configuration Steps

## 3.2 Safety Messages on Firmware or Configuration Download

If you perform a firmware download or a configuration download via the DeviceNet Master DTM be aware of the following:

---

**⚠ WARNING****Communication Stop caused by Firmware or Configuration Download**

Initiating a firmware or configuration download process during bus operation will stop the communication and a subsequent plant stop may cause unpredictable and unexpected behavior of machines and plant components, possibly resulting in personal injury and damage to your equipment.

The firmware download overwrites the existing firmware. The communication stop may cause loss of device parameters and possible device damage may occur.

- Stop the application program, before you start the firmware or configuration download.
  - Make sure that all network devices are placed in a fail-safe condition.
- 


---

**⚠ WARNING****Mismatching System Configuration**

Mismatching system configuration loaded into the device could result in faulty data mapping in the application program and thus unexpected equipment operation may cause personal injury or damage of equipment.

- In the device use only a configuration suitable for the system.
- 


---

**NOTICE****Power Disconnect while downloading Firmware or Configuration**

If the power supply to the PC or device is interrupted while the firmware or configuration is being downloaded, the download will be aborted, the firmware may be corrupted, the device parameters may be lost, and the device may be damaged.

- During firmware or configuration download process do not interrupt the power supply to the PC, or to the device and do not perform a reset to the device!
- 

---

**NOTICE****Invalid Firmware**

Loading invalid firmware files could render your device unusable.

- Only proceed with a firmware version valid for your device.
-

## 4 Settings

### 4.1 Overview Settings

#### Settings Dialog Panes

The table below gives an overview for the individual **Settings** dialog panes descriptions:


DeviceNet Master DTM	Folder Name / Section	Subsection	Manual Page
	Driver		32
		Verify or adapt Driver Settings	32
		cifX Device Driver	34
		netX Driver	34
		Configuring netX Driver	35
	Device Assignment		41
		Scanning for Devices	41
		Scanning for all Devices or for suitable only	43
		Selecting the Device (with or without firmware)	44
		Selecting the Device once more (with Firmware)	45
	Firmware Download		47
	Licensing		95

Table 10: Descriptions of the Dialog Panes Settings



**Note:** To edit the **Settings** dialog panes you need *User Rights* for “Maintenance”.



Notice the descriptions in the section *Settings for Driver and Device Assignment* on page 30.

To access to the online help with the descriptions of the drivers:

- Select **Settings > Driver > [Name of the assigned driver]**.
- Press the **F1** key.

## 4.2 Settings for Driver and Device Assignment



**Important:** For a 2-channel device consecutively channel 1 or channel 2 must be assigned to the DTM.

The following steps are needed to establish a connection from the DeviceNet Master DTM to the DeviceNet Master device:

### Verifying or adapting Driver Settings

Verify the Driver Settings and adapt them if necessary.

1. Open the DTM configuration dialog.
  - In the FDT container **netDevice** double click to the DeviceNet Master device icon.
2. Verify that the default driver is checked and respectively check another or multiple drivers.
  - Select **Settings > Driver**.



**Note!** For PC cards cifX the **cifX Device Driver** is preset as a default driver. For all the other Hilscher devices the **netX Driver** is preset as a default driver.

- Use the **cifX Device Driver** if the DeviceNet Master DTM is installed on the same PC as the DeviceNet Master device.
- Use the **netX Driver** to establish an USB, Serial (RS232) or TCP/IP connection from the DeviceNet Master DTM to the DeviceNet Master device.
- The **3SGateway Driver for netX (V3.x)** is used only in relationship with CODESYS.

To search for devices on the network you can check one or multiple drivers simultaneously.

- Verify that the default driver for your device is checked.
- If necessary, check another driver or multiple drivers.

### Configuring Driver



**Note!**

- The **cifX Device Driver** requires no configuration.
- The configuration of the **3SGateway Driver for netX (V3.x)** is carried out via the CODESYS surface.

If you use the **netX Driver**, you respectively must configure it.

3. Configure the **netX Driver** if necessary.

For the driver **netXDriver** an individual driver dialog window can be opened where you can configure the driver.

- Select **Settings > Driver > netX Driver**.
- For netX Driver and communication via TCP/IP set the IP address of the device.

Adjust the driver parameters **netX Driver USB/RS232** only if they differ from the default settings.

### **Assigning the Master device to the DTM**

4. Scan for and select the devices (with or without firmware).
  - Select **Settings > Device Assignment**.
  - Under **Device selection** select *suitable only* or *all* and then **Scan**.
  - In the table check the required devices.
  - Select **Apply**.

### **Selecting and downloading the Firmware**

5. If not yet a firmware was loaded to the device, select and download the firmware.
  - Select **Settings > Firmware Download**.
  - Select and download the firmware via **Download**.
  - Select **Apply**.
6. Scan for and select the devices (with firmware and defined system channel) once more.

*For repeated download this step is omitted.*

  - Select **Settings > Device Assignment**.
  - Select **Scan**.
  - In the table check the required device.
7. Close the DTM configuration dialog via **OK**.

### **Connecting the Device**

8. In **netDevice** put a right-click on the DeviceNet Master device icon.
9. Select the **Connect** command from the context menu.
- 🔗 In the network view the device description at the device icon of the Master is displayed with a green colored background. The DeviceNet Master device now is connected to the DeviceNet Master DTM via an online connection.

### **Further Information**



For descriptions about these steps refer to the sections following here-after.

## 4.3 Driver

The **Driver** dialog pane displays the drivers to be used for a DeviceNet Master DTM to establish a device communication connection.



**Note!** A **default driver** is set in the configuration software.

Driver			
	Driver	Version	ID
<input checked="" type="checkbox"/>	CIFX Device Driver	1.101.1.9801	{368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}
<input type="checkbox"/>	3SGateway Driver for netX (V3.x)	0.9.1.2	{787CD3A9-4CF6-4259-8E4D-109B6A6BEA91}
<input type="checkbox"/>	netX Driver	1.103.2.5183	{B54C8CC7-F333-4135-8405-6E12FC88EE62}

Figure 5: Default Driver ‚CIFX Device Driver’ for PC cards cifX

Parameter	Meaning
Driver	Name of the driver (for more details see descriptions hereafter)
Version	ODMV3 Version of the respective driver
ID	ID of the driver (driver identification)

Table 11: Driver Selection List Parameters

To establish a connection from the DeviceNet Master DTM to the DeviceNet Master device, verify if the default driver is checked and respectively check another driver or multiple drivers.

### 4.3.1 Verify or adapt Driver Settings

Proceed as follows:

1. Select **Settings > Driver** in the navigation area.
- The **Driver** dialog pane is displayed with the available drivers and the setting for the default driver.

Driver			
	Driver	Version	ID
<input checked="" type="checkbox"/>	CIFX Device Driver	1.101.1.9801	{368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}
<input type="checkbox"/>	3SGateway Driver for netX (V3.x)	0.9.1.2	{787CD3A9-4CF6-4259-8E4D-109B6A6BEA91}
<input type="checkbox"/>	netX Driver	1.103.2.5183	{B54C8CC7-F333-4135-8405-6E12FC88EE62}

Figure 6: Default Driver ‚CIFX Device Driver’ for PC cards cifX (example)

Driver			
	Driver	Version	ID
<input type="checkbox"/>	CIFX Device Driver	1.101.1.9801	{368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}
<input type="checkbox"/>	3SGateway Driver for netX (V3.x)	0.9.1.2	{787CD3A9-4CF6-4259-8E4D-109B6A6BEA91}
<input checked="" type="checkbox"/>	netX Driver	1.103.2.5183	{B54C8CC7-F333-4135-8405-6E12FC88EE62}

Figure 7: Default Driver ‚netX Driver’ for Hilscher devices except for PC cards cifX (example)

2. Verify that the default driver is checked.
- Verify that the default driver for your device is checked.



**Default Driver** (Pre-settings in the Configuration Software): For PC cards cifX the **cifX Device Driver** is preset as a default driver. For all the other Hilscher devices the **netX Driver** is preset as a default driver.

3. Respectively check another driver.



**Note!** The driver used for the connection from the DeviceNet Master DTM to the DeviceNet Master device must be supported by the device and must be available for the device.

- Use the **cifX Device Driver** if the DeviceNet Master DTM is installed on the same PC as the DeviceNet Master device.
- Use the **netX Driver** to establish a USB, Serial (RS232) or TCP/IP connection from the DeviceNet Master DTM to the DeviceNet Master device.
- The **3SGateway Driver for netX (V3.x)** is used only in relationship with CODESYS. The version V3.x refers to the driver version defined by 3S-Smart Software Solutions GmbH.

➤ Check the checkbox for the driver in the selection list.

4. Respectively check multiple drivers.

To search for devices on the network you can check multiple drivers simultaneously.

Driver			
	Driver	Version	ID
<input checked="" type="checkbox"/>	CIFX Device Driver	1.101.1.9801	{368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}
<input type="checkbox"/>	3SGateway Driver for netX (V3.x)	0.9.1.2	{787CD3A9-4CF6-4259-8E4D-109B6A6BEA91}
<input checked="" type="checkbox"/>	netX Driver	1.103.2.5183	{B54C8CC7-F333-4135-8405-6E12FC88EE62}

Figure 8: Manual Selection of multiple drivers (Example)

### 4.3.2 cifX Device Driver

In the DeviceNet Master DTM for the **cifX Device Driver** no driver dialog pane is available, since for the **cifX Device Driver** no driver settings are required.

The **cifX Device Driver** will be used if the DeviceNet Master DTM is installed in the same PC as the DeviceNet Master device.



**Note:** To establish a connection from a DTM to a Master device via the **cifX Device Driver**, the **cifX Device Driver** must be installed and the driver must have access to the Master device.

### 4.3.3 netX Driver

The **netX Driver** is used to connect the DTM to the device via different connection types. The DTM communicates with the device via an USB connection, a serial (RS232) connection or a TCP/IP connection. The **netX Driver** establishes

- via the USB interface of the device and the USB port of the PC an USB connection to the device,
- via the RS232 interface of the device and the COM port of the PC a serial connection (RS232) to the device
- and via Ethernet a TCP/IP connection to the device.

To connect the DTM to the physical layer of the device the **netX Driver** software works in combination with the software components:

- “USB/COM connector” for the USB connection and for the serial connection (RS232) and
- “TCP/IP connector” for the Ethernet connection.

## 4.3.4 Configuring netX Driver

The following steps are required to configure the netX Driver:

### USB/RS232 Connection

To set the driver parameters for an USB/RS232 connection note:




**Note:** Adjust the driver parameters netX Driver USB/RS232 only if they differ from the default settings. After saving the changed driver parameters, these parameters are used for the device assignment when scanning devices.

For setting the driver parameters for an USB connection or a serial connection:

1. Select **Settings > Driver > netX Driver > USB/RS232 Connection**.
  - Set the driver netX Driver USB/RS232 parameters.

### TCP/IP Connection

For setting the driver parameters for a TCP/IP connection:

1. Select **Settings > Driver > netX Driver > TCP Connection**.
2. Set IP Address of the device:
  - Add an IP Range via **Select IP Range** .
3. Under **IP Range Configuration > IP Address** enter the IP Address of the device (**Use IP Range** is unchecked).

Or

4. Set IP Range:
    - Check **Use IP Range**.
    - Under **IP Range Configuration > IP Address** enter the start address (left side) and the ending address of the IP scanning range (right side).
  5. Click **Save**, to save the IP address or the IP range.
- After saving the changed driver parameters, these parameters are used for the device assignment when scanning devices.

### 4.3.5 netX Driver - USB/RS232 Connection

The communication from the DTM to the device via an **USB/RS232 Connection** is used when the DTM is installed on a PC and between the PC and the device

- an USB connection
- or a serial connection (RS232) exists.

The DTM accesses the device via the USB interface or via the RS232 interface. This requires either to connect an USB port of the PC to the USB interface of the device using an USB cable or to connect a physical COM port of the PC to the RS232 interface of the device via a serial cable.

The **netX Driver / USB/RS232 Connection** supports all physical and virtual COM ports available on the PC.

Via the RS232 interface or USB interface, the device is configured or diagnosis is performed.

#### 4.3.5.1 Driver Parameters for netX Driver - USB/RS232 Connection

The settings of the driver parameters for the USB/RS232 connection are made via the **netX Driver / USB/RS232 Connection** configuration dialog.

- Open the **USB/RS232 Connection** dialog via navigation area **Settings > Driver > netX Driver**.

- The **USB/RS232 Connection** dialog is displayed:

The screenshot shows the 'netX Driver' configuration window with the 'USB/RS232 Connection' tab selected. The 'TCP Connection' tab is also visible. The 'Enable USB/RS232 Connector (Restart of ODM required)' checkbox is checked. The 'Select Port:' dropdown menu is set to 'COM1'. The 'Port Configuration' section contains several settings: 'Disable Port' is unchecked, 'Baud rate' is set to '115.2 kBit/s', 'Byte size' is '8 Byte', 'Stop bits' is '1 Stopbit', 'Parity' is 'No Parity', 'Send Timeout [ms]' is '1000', 'Reset Timeout [ms]' is '5000', and 'Keep Alive Timeout [ms]' is '2000'. At the bottom right, there are three buttons: 'Restore', 'Save', and 'Save All'.

Figure 9: netX Driver > USB/RS232 Connection


Parameter	Meaning	Range of Value / Default Value
<b>Enable USB/RS232 Connector (Restart of ODM required)</b>	<p>checked: The netX Driver can communicate via the USB/RS232 interface.</p> <p>unchecked: The netX Driver can <u>not</u> communicate via the USB/RS232 interface.</p> <p>If the check mark for <b>Enable USB/RS232 Connector</b> is set or removed, then the ODM server must be restarted<sup>1</sup>, to make the new setting valid.</p> <p><sup>1</sup> Restart the ODM server via the <b>ODMV3 Tray Application</b>:</p> <p>- In the foot line click on  using the right mouse key.</p> <p>- In the context menu select <b>Service &gt; Start</b>.</p>	checked, unchecked; Default: unchecked
<b>Select Port</b>	Depending on the COM ports (interfaces) available on the PC, they will be listed under <b>Select Port</b> .	COM 1 to COM N
<b>Port Configuration</b>		
<b>Disable Port</b>	<p>checked: No connection.</p> <p>unchecked: The netX Driver tries to establish a connection using the configured USB/RS232 interface.</p>	checked, unchecked (Default)
<b>Baud rate</b>	<p>Transfer rate: number of bits per second.</p> <p>The device must support the baud rate.</p>	9.6, 19.2, 38.4, 57.6 or 115.2 [kBit/s]; Default (RS232): 115.2 [kBit/s]
<b>Stop bits</b>	Number of stop bits sent after the transfer of the send data for synchronization purposes to the receiver.	Stop bit: 1, 1.5, 2; Default (RS232): 1
<b>Send Timeout</b>	Maximum time before the transfer of the transmission data is canceled, when the send process fails, for example, because of the transfer buffer is full.	100 ... 60.000 [ms]; Default (RS232 and USB): 1000 ms
<b>Reset Timeout</b>	Maximum time for a device reset, including the re-initialization of the physical interface used for the communication.	100 ... 60.000 [ms]; Default (RS232 and USB): 5000 ms
<b>Byte size</b>	Number of bits per byte by byte specification	7 Bit, 8 Bit; Default (RS232): 8 Bit
<b>Parity</b>	<p>In the error detection in data transmission using parity bits, "parity" describes the number of bits occupied with 1 in the transmitted information word.</p> <p>No Parity: no parity bit</p> <p>Odd Parity: The parity is "odd" if the number of bits occupied with 1 in the transmitted information word will be odd.</p> <p>Even parity: The parity is "even" if the number of bits occupied with 1 in the transmitted information word will be even.</p> <p>Mark Parity: if the parity bit is always 1, this will be named mark-parity (the bit does not contain any information).</p> <p>Space Parity: if the parity bit always 0, this will be named space-parity (the bit represents an empty space).</p>	No Parity, Odd Parity, Even Parity, Mark Parity, Space Parity; Default (RS232): No Parity
<b>Keep Alive Timeout</b>	The "Keep Alive" mechanism is used to monitor whether the connection to the device is active. Connection errors are detected using a periodic heartbeat mechanism. The heartbeat mechanism will be initiated after the set time has elapsed if the communication has failed.	100 ... 60.000 [ms]; Default (RS232 and USB): 2000 ms
<b>Restore</b>	Resets all settings in the configuration dialog to the default values.	
<b>Save</b>	Saving all settings made in the configuration dialog <b>netX Driver &gt; Save USB/RS232 Connection</b> , i. e. only for the selected connection type.	
<b>Save All</b>	Saving all settings made in the configuration dialog <b>netX Driver</b> , i. e. for all connection types.	

Table 12: Parameters netX Driver &gt; USB/RS232 Connection

### 4.3.6 netX Driver - TCP/IP Connection

The communication from the DTM to the device via a **TCP/IP Connection** is used in the following two typical applications:

Application 1: The device has its own Ethernet interface. The DTM is installed on a PC and the TCP/IP connection is established from this PC to the stand-alone device. The IP address of the device is used.

Application 2: The device is installed in a remote PC. The DTM is installed on an additional PC and the TCP/IP connection is established from this PC to the remote PC. The IP address of the remote PC is used. For the TCP/IP connection is made, on the remote PC the cifX TCP/IP server must be started. The cifX TCP/IP server allows the remote access to the device via a TCP/IP connection.



---

**Note:** An exe file for the cifXTCP/IP server is provided on the product CD in the *Tools* directory.

---




Via the TCP/IP interface of the device or of the remote PC, the device is configured or diagnosis is performed.

#### 4.3.6.1 Driver Parameters for netX Driver - TCP/IP Connection

The settings of the driver parameters for the TCP/IP connection are made via the **netX Driver / TCP Connection** configuration dialog.

- Open the **TCP Connection** dialog via navigation area **Settings > Driver > netX Driver**.
- The dialog **netX Driver** is displayed:
- Select **TCP Connection**.

Figure 10: netX Driver > TCP Connection

Parameter	Meaning	Range of Value / Default Value
<b>Enable TCP Connector (Restart of ODM required)</b>	<p>checked: The netX Driver can communicate via the TCP/IP interface.</p> <p>unchecked: The netX Driver can <u>not</u> communicate via the TCP/IP interface.</p> <p>If the check mark for <b>Enable TCP Connector</b> is set or removed, then the ODM server must be restarted<sup>1</sup>, to make the new setting valid.</p> <p><sup>1</sup> Restart the ODM server via the <b>ODMV3 Tray Application</b>:</p> <ul style="list-style-type: none"> <li>- In the foot line click on  using the right mouse key.</li> <li>- In the context menu select <b>Service &gt; Start</b>.</li> </ul>	checked, unchecked; Default: unchecked
<b>Select IP Range</b>	<p>Via <b>Select IP Range</b> already created IP ranges can be selected.</p> <p>Via  an additional IP range can be added.</p> <p>Via  an IP range can be deleted.</p>	

Parameter	Meaning	Range of Value / Default Value
<b>Scan Timeout [ms]</b>	With <b>Scan Timeout</b> can be set, how long to wait for a response while a connection is established.	10 ... 10000 [ms]; Default: 100 ms
<b>IP Range Configuration</b>		
<b>Disable IP Range</b>	checked: No connection. unchecked: The netX Driver tries to establish a connection using the configured TCP/IP interface.	checked, unchecked (Default)
<b>IP Address (left)</b>	Enter the IP address of the device, (if <b>Use IP Range</b> is not checked). Enter the start address of the IP scanning range, (if <b>Use IP Range</b> is checked).	valid IP address; Default: 192.168.1.1
<b>Use IP Range</b>	checked: An IP address range is used. unchecked: Only one IP address is used.	checked, unchecked; Default: unchecked
<b>IP Address (right)</b>	Enter the ending address of the IP scanning range, (only if <b>Use IP Range</b> is checked).	valid IP address; Default: 0.0.0.0
<b>Address Count</b>	Displays the scanning range address count, depending on the selected IP-start or IP-end address. (For this read the note given below.)	recommended: 10
<b>TCP Port</b>	Identifies the endpoint of a logical connection or addresses a specific endpoint on the device or PC.	0 - 65535; Default Hilscher device: 50111
<b>Send Timeout [ms]</b>	Maximum time before the transfer of the transmission data is canceled, when the send process fails, for example, because of the transfer buffer is full.	100 ... 60.000 [ms]; Default (TCP/IP): 1000 ms
<b>Reset Timeout [ms]</b>	Maximum time for a device reset, including the re-initialization of the physical interface used for the communication.	100 ... 60.000 [ms]; Default (TCP/IP): 2000 ms
<b>Keep Alive Timeout [ms]</b>	The "Keep Alive" mechanism is used to monitor whether the connection to the device is active. Connection errors are detected using a periodic heartbeat mechanism. The heartbeat mechanism will be initiated after the set time has elapsed if the communication has failed.	100 ... 60.000 [ms]; Default (TCP/IP): 2000 ms
<b>Restore</b>	Resets all settings in the configuration dialog to the default values.	
<b>Save</b>	Saving all settings made in the configuration dialog <b>netX Driver &gt; Save TCP/IP Connection</b> , i. e. only for the selected connection type.	
<b>Save All</b>	Saving all settings made in the configuration dialog <b>netX Driver</b> , i. e. for all connection types.	

Table 13: Parameters netX Driver &gt; TCP Connection



**Note:** Do not use large IP ranges in combination with a low scan timeout. Microsoft introduced in Windows® XP SP2 a limit of concurrent half-open outbound TCP/IP connections (connection attempts) to slow the spread of virus and malware from system to system. This limit makes it impossible to have more than 10 concurrent half-open outbound connections. Every further connection attempt is put in a queue and forced to wait. Due to this limitation a large IP range used in combination with a low scan timeout could prevent the connection establishment to a device.



## 4.4 Device Assignment



**Note:** In the **Device Assignment** dialog pane you first must assign the DeviceNet Master device to the DeviceNet Master DTM by checking the check box. This is essential to establish an online connection from the DeviceNet Master DTM to the DeviceNet Master device later, as described in section *Connecting/Disconnecting Device* on page 73.

Therefore in the **Device Assignment** dialog pane you scan for the DeviceNet Master device and select it.

If the device did not get a firmware or shall get a new firmware:

1. first you scan for the device (with or without firmware) and select the device,
2. then you download a firmware to the device and
3. subsequently you scan for the device (with firmware) once more and select the device again.



**Important:** For a 2-channel device consecutively channel 1 or channel 2 must be assigned to the DTM.

### 4.4.1 Scanning for Devices

1. Select **Settings > Device Assignment** in the navigation area.

➤ The dialog pane **Device Assignment** is displayed.

Device	Hardware Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input type="checkbox"/> Device Cl*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	Undefined Undefined	...\cifX3_SYS

Figure 11: Device Assignment - detected Devices (\* The name of the device class is displayed.) – Example for a device without firmware

2. Under **Device Selection** select *suitable only*.
3. Select **Scan**, to start the scanning process.

➤ In the table all devices are displayed, which can be connected to the DeviceNet Master DTM via the preselected driver.



**Note:** For devices, which have been found via the **cifX Device Driver** in the column **Access path** the indication **...\cifX[0toM]\_SYS** is displayed. This is correct, as long as a device did not get a firmware. After the firmware download has been completed, in the column **Access path** the indication **...\cifX[0toM]\_Ch[0to3]** is displayed.


Parameter	Meaning	Range of Value / Default Value
Device selection	Selecting <b>suitable only</b> or <b>all</b> devices.	suitable only, all
Device	Device class of the DeviceNet Master Devices.	
Hardware Port 0/1/2/3	Shows, which hardware is assigned to which communication interface.	
Slot number	Shows the <b>Slot Number (Card ID)</b> preset at the PC card cifX via the <b>Rotary Switch Slot Number (Card ID)</b> .  The indication <b>n/a</b> means, that no <b>Slot-Nummer (Card ID)</b> exists. This will occur if the PC card cifX is not equipped with a <b>Rotary Switch Slot Number (Card ID)</b> or for PC cards cifX equipped with a <b>Rotary Switch Slot Number (Card ID)</b> if the rotary switch is set to the value 0 (zero).	1 to 9, n/a
Serial number	Serial number of the device	
Driver	Name of the driver	
Channel Protocol	Shows, which firmware is loaded to which device channel.  The data for the used channel consists of the protocol class and the communication class.  a.) For devices without firmware: Undefined Undefined, b.) For devices with firmware: Protocol name corresponding to the used Firmware	
Access path (last column on the right)	Depending on the used driver in the column <b>Access path</b> different data to the device are displayed.  For the <b>cifX Device Driver</b> the following data are displayed: a.) For devices without firmware: ...cifX[0toN]_SYS, b.) For devices with firmware: ...cifX[0toN]_Ch[0to3].  cifX[0toN] = Board number 0 to N Ch[0to3] = Channel number 0 to 3	Depending on the device and on the driver: board or channel number, IP address or COM interface
Access path (at the lower side of the dialog pane)	If in the table a device is checked, under <b>Access path</b> (at the lower side of the dialog pane) the driver identification or depending on the used driver additional data to the device will be displayed.  For the <b>cifX Device Driver</b> the following data are displayed: a.) For devices without firmware: ...cifX[0toN]_SYS, b.) For devices with firmware: ...cifX[0toN]_Ch[0to3].  cifX[0toN] = Board number 0 to N Ch[0to3] = Channel number 0 to 3	driver identification (ID)  depending on the device and on the driver: board or channel number, IP address or COM interface

Table 14: Parameters of the Device Assignment

#### 4.4.1.1 Scanning for all Devices or for suitable only

##### all

1. Under **Device Selection** select *all*.
2. Select **Scan**.



Device Assignment

Scan progress: 5/5 Devices (Current device: -)

Device selection: all

	Device	Hardware-Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input type="checkbox"/>	Device Cl.*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	Undefined Undefined	...\cifX3_SYS
<input type="checkbox"/>	Device Cl.*	-/-/DeviceNet/-	n/a	20027	CIFX Device Driver	Undefined Undefined	...\cifX1_SYS
<input type="checkbox"/>	Device Cl.*	-/-/-/-	n/a	20058	netX Driver	Undefined Undefined	...\192.168.1..
<input type="checkbox"/>	Device Cl.*	Ethernet/Ethernet/-/-	n/a	20288	CIFX Device Driver	Undefined Undefined	...\cifX2_SYS
<input type="checkbox"/>	Device Cl.*	-/-/CANopen/-	n/a	20022	CIFX Device Driver	Undefined Undefined	...\cifX0_SYS

Figure 12: Device Assignment - detected Devices (\* The name of the device class is displayed.) Example for Devices without Firmware

- ⇒ In the table all devices are displayed, which are attainable in the network and which can be connected to a single DTM each via the preselected drivers.



**Note:** During a subsequent firmware download in the selection window **Select Firmware File** all files from the selected folder are displayed, under **Files of Type** „All Files (\*.\*)“ is displayed and the check box **Validate the selected firmware file.** is unchecked.

##### suitable only

1. Under **Device Selection** select *suitable only*.
2. Select **Scan**.

- ⇒ In the table all devices are displayed, which can be connected to the DeviceNet Master DTM via the preselected drivers.



**Note:** During a subsequent firmware download in the selection window **Select Firmware File** only firmware files from the selected folder are displayed, under **Files of Type** „Firmware Files (\*.nxm)“ or „Firmware Files (\*.nxf)“ is displayed and the check box **Validate the selected firmware file.** is checked.

## 4.4.2 Selecting the Device (with or without firmware)



**Note:** A connection with the DeviceNet Master DTM can only be established with one DeviceNet Master device.

To select the physical DeviceNet Master device (with or without firmware):

1. Check the appropriate device.

Device Assignment

Scan progress: 5/5 Devices (Current device: -)

Device selection:

	Device	Hardware Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input checked="" type="checkbox"/>	Device Cl*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	PROFIBUS Master	...\cifX3_SYS

Access path:

Figure 13: Device Assignment - Selecting the Device (\* The name of the device class is displayed.) – Example for a device without firmware / one Device is selected

- Under **Access path** (below in the dialog pane) the access path to the device, e. g. the driver identification, or depending on the used driver additional access data of the device are displayed.

2. Select **Apply**, to apply the selection.



**Note:** Before an online connection from the DeviceNet Master DTM to the DeviceNet Master device can be established, a firmware must be loaded to the device and the device must be selected once more.



For further information refer to section *Firmware Download* on page 47 or to section *Selecting the Device once more (with Firmware)* on page 45.

### 4.4.3 Selecting the Device once more (with Firmware)



**Note:** For repeated download this step is omitted.

To select the DeviceNet Master device (with firmware and defined system channel) once more, proceed as described hereafter:

#### all

1. Under **Device Selection** select *all*.
2. Select **Scan**.
  - In the table all devices are displayed, which are attainable in the network and which can be connected to a DTM via the preselected drivers.
3. Check the appropriate device.

**Device Assignment**

Scan progress: 5/5 Devices (Current device: -)

Device selection: all Scan

	Device	Hardware-Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input checked="" type="checkbox"/>	Device Cl.*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	PROFIBUS-DP Master	...\cifX3_Ch0
<input type="checkbox"/>	Device Cl.*	-/-/DeviceNet/-	n/a	20027	CIFX Device Driver	DeviceNet Master	...\cifX1_Ch0
<input type="checkbox"/>	Device Cl.*	-/-/-/-	n/a	20058	netX Driver	Undefined Undefined	...\192.168....
<input type="checkbox"/>	Device Cl.*	Ethernet/Ethernet/-/-	n/a	20288	CIFX Device Driver	PROFINET IO Device	...\cifX2_Ch0
<input type="checkbox"/>	Device Cl.*	-/-/CANopen/-	n/a	20022	CIFX Device Driver	Undefined Undefined	...\cifX0_SYS

Access path: {368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}\cifX3\_Ch0

Figure 14: Device Assignment - Selecting the Device (\* The name of the device class is displayed.) – Example for Devices with and without Firmware / one Device is selected



**Note:** After the firmware download has been completed, for the devices which have been detected via the **cifX Device Driver** the following data are displayed:

- In the column **Channel Protocol**: the data for the firmware for the used channel
- In the column **Access path** or under **Access path** (below in the dialog pane): the data: ...\\cifX[0toN]\_Ch[0to3].  
     cifX[0toN] = board number 0 to N  
     Ch[0to3] = channel number 0 to 3

4. Select **Apply**, to apply the selection.
5. Or select **OK**, to apply the selection and to close the DTM interface dialog.
6. Connect the DTM to the device using the context menu (right mouse click).

Or:

### suitable only

1. Under **Device Selection** select *suitable only*.
2. Select **Scan**.
- In the table all devices are displayed, which can be connected to the DeviceNet Master DTM via the preselected drivers.
3. Check the appropriate device.

Device Assignment

Scan progress: 5/5 Devices (Current device: -)

Device selection: suitable only Scan

	Device	Hardware Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input checked="" type="checkbox"/>	Device Cl*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	PROFIBUS-DP Master	...\cifX3_Ch0

Access path: {368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}\cifX3\_Ch0

Figure 15: Device Assignment - Selecting the Device (\* The name of the device class is displayed.) – Example for a device with firmware / one Device is selected



**Note:** After the firmware download has been completed, for the devices which have been detected via the **cifX Device Driver** the following data are displayed:

- In the column **Channel Protocol**: the data for the firmware for the used channel
- In the column **Access path** or under **Access path** (below in the dialog pane): the data: ...\\cifX[0toN]\_Ch[0to3].  
cifX[0toN] = board number 0 to N  
Ch[0to3] = channel number 0 to 3

4. Select **Apply**, to apply the selection.
5. Or select **OK**, to apply the selection and to close the DTM interface dialog.
6. Connect the DTM to the device using the context menu (right mouse click).



For further information how to establish an online connection from the DeviceNet Master DTM to the DeviceNet Master device, refer to section *Connecting/Disconnecting Device* on page 73.

## 4.5 Firmware Download

Using the **Firmware Download** dialog a firmware can be transferred to the device.



**Note:** Prior to the firmware download, you must select the driver and the Master device (with or without firmware) and the device must be assigned to the hardware.



For further information refer to section **Overview Settings** on page 29.

To load the firmware to the device:

1. In the navigation area select **Settings > Firmware Download**.

➤ The dialog **Firmware-Download** pane is displayed.

Figure 16: Firmware Download

Element	Meaning
Name	The path and name of the firmware file selected are displayed.
Version	The version and build version of the firmware file selected are displayed.
Browse...	Via 'Browse...' you can select the firmware file for the download.
Download	Via 'Download' you can download the firmware to the device.

Table 15: Parameter Firmware Download

2. Select the firmware file.

➤ Select **Browse**.

### Device is not assigned to the Hardware

If the device is not assigned to the Hardware, the error message 'The device is not assigned to the hardware!' is displayed:




Figure 17: Error Message 'The device is not assigned to the hardware!'

- Click **OK** and select and assign the Master device as described in section *Device Assignment*.

### **Device is assigned to the Hardware**

- The selection window **Select Firmware File** is displayed.
- Enlarge the selection window to view the columns **Hardware** and **Version**.






Figure 18: Window 'Select Firmware File' (Example CIFX)

Parameter	Meaning	Range of Value / Default Value
Column <b>Name</b>	File name of the firmware file To sort the entries of the window <b>Select Firmware File</b> by name click to the column head <b>Name</b> .	nxf, nxm
Column <b>Firmware</b>	Name of the firmware (consisting of the protocol name and protocol class)	
Column <b>Hardware</b>	Device class of the associated hardware	e. g. CIFX, COMX, COMX 51, NETJACK 10, NETJACK 50, NETJACK 51,

		NETJACK 100, NETTAP 50 (Gateway), NETTAP 100 (Gateway), NETBRICK 100 (Gateway)
<b>Column Version</b>	Firmware version	x.x (build x)
<b>Tooltip</b>	To view the tooltip information move with the mouse pointer over the selected firmware line.  <div> Type: Hilscher firmware file for netX-based targets (NXF)  Size: 563 KB  Date of change: 2013/03/26 11:10 </div>	
<b>Files of Type</b>	„All Files (*.*)“ if before in the <b>Device Assignment</b> pane under <b>Device selection</b> <i>all</i> was selected. „Firmware Files (*.nxm)“ or <i>Firmware Files (*.nxf)</i> if before in the <b>Device Assignment</b> pane under <b>Device selection</b> <i>suitable only</i> was selected.	All Files (*.*), Firmware Files (*.nxm), Firmware Files (*.nxf)
<b>Recent folders</b>	Path of the recently opened folder	
<b>Firmware</b>	As soon as the firmware file has been selected, under <b>Firmware</b> the name, the version and the build version as well as the device class for the selected firmware is displayed.	Name, Version, Build Version, Device Class for the selected firmware
<b>Help</b>	Button, to open the online help of the DTM.	

Table 16: Parameters Select Firmware File




Further descriptions to the selection window **Select Firmware File** are included in the context sensitive help (**F1** key) of the Microsoft Corporation.




**Note:** After in the **Device Assignment** pane under **Device selection** *all* or *suitable only* has been set, during a subsequent firmware download in the selection window **Select Firmware File** the following data are displayed or set:

(for list box entry →)	<b>all</b>	<b>suitable only</b>
In the selection window <b>Select Firmware File</b> :	all files from the selected folder	only firmware files from the selected folder
Under <b>Files of Type</b> *:	„All Files (*.*)“	„Firmware Files (*.nxm)“, „Firmware Files (*.nxf)“
Validation:	A restricted validation will be performed if the selected firmware is applied for the download.	A validation is made whether the firmware file is suitable for the DeviceNet Master DTM.

\*These settings in the selection window **Select Firmware File** can also be changed manually.

- In the selection window mark the firmware file to be loaded using the mouse.
-  In the selection window under **Firmware** the name and the version of the firmware are displayed.
- In the selection window select the **Open** button.

### Validation

-  A validation is made, whether the selected firmware file is suitable for the DeviceNet Master device.

## Invalid Firmware

### NOTICE

## Invalid Firmware

Loading invalid firmware files could render your device unusable.

- Only proceed with a firmware version valid for your device.
- If a firmware file is selected, which is not valid for the assigned device, the request **Select Firmware File** will be displayed.

‘Invalid firmware for assigned device!’

[detailed explication]

Shall firmware file nevertheless be applied for the download?’



Figure 19: Request Select Firmware File - Example Invalid Firmware

- Answer to the request with **No** and select a valid firmware.
- The selection window is closed.

### **Valid Firmware**

➤ The selection window is directly closed (without dialog).

5. Start firmware upgrade.

#### **⚠ WARNING**

#### **Communication Stop caused by Firmware Update, faulty System Operation possible, Overwriting of Firmware or Loss of Device Parameters**

Before you initiate a firmware download process, while the bus is still in operation status:

- Stop the application program.
- Make sure that all network devices are placed in a fail-safe condition.

#### **NOTICE**

#### **Firmware Corruption or Loss of Parameters caused by Power Disconnect during Firmware Download**

- During firmware download process, do not interrupt the power supply to the PC, or to the device and do not perform a reset to the device!
- In the dialog pane **Firmware Download** click to the **Download** button, to download the firmware.
- The request **Do you really want to download the firmware?** is displayed.




Figure 20: Request - Do you really want to download the firmware?

6. Click **Yes**.

- If you are sure, that you have selected the appropriate firmware file answer to the request with **Yes** otherwise with **No**.
- During the download a progress bar is displayed ('Download active, device performs initialization...'), in the status line a clock / green hook symbol is displayed and in the dialog pane **Firmware Download** **Download** is grayed out.




Figure 21: Firmware Download - Progress Bar




Figure 22: Clock Symbol and Hook Symbol green

- In the **Firmware-Download** dialog pane the path and name as well as the version of the selected firmware file are displayed.




Figure 23: Firmware Download – Download

## 4.6 Licensing

To open the Licensing pane:

1. In the navigation area select **Settings > Licensing**.
- The dialog **Licensing** pane is displayed.

**Licensing**

License Type

	Existing	Order
<b>Master protocols</b>		
One General Master License	NO	<input type="checkbox"/>
Two General Master Licenses	NO	<input type="checkbox"/>
PROFIBUS Master	YES	<input type="checkbox"/>
CANopen Master	YES	<input type="checkbox"/>
DeviceNet Master	YES	<input type="checkbox"/>
AS-Interface Master	YES	<input type="checkbox"/>
PROFINET IO RT Controller	YES	<input type="checkbox"/>

Request Form, please fill out

Name	Value
License type	User Single Device License
Manufacturer*	00000001
Article number*	01250510
Serial number*	00020086
Chiptype*	00000002
Step*	00000000
Romcode revision*	00000002

Fields marked with "\*" are mandatory.

Hilscher Germany

E-mail... license@hilscher.com

Print Fax Form... +49 6190 9907-50

Telephone... +49 6190 9907-0

Export License Request...

Download License

Figure 24: Licensing



For a detailed description refer to section *Licensing* on page95.

## 5 Configuration

### 5.1 Overview Configuration

#### Configuration Dialog Panes

The table below gives an overview for the **Configuration** dialog panes descriptions:


DeviceNet Master DTM	Folder Name / Section	Subsection	Page
 Navigation Area – Configuration	Bus Parameters	General	59
		Bus Parameters	59
		Error Handling	59
	Server Parameters		60
	Process Data		61
	Address Table		62
	MAC ID Table		63
	Quick Connect Table		64
	Master Settings	Start of Bus Communication	69
		Application Monitoring	69
		Module Alignment	70
		Process Data Handshake	71
		Advanced	71
		Device Status Offset	72

Table 17: Descriptions of the Dialog Panes Configuration



Notice the descriptions in the section *Configuration Steps* on page 24.

## 5.2 Configuring Device Parameters



**Important:** For a 2-channel device consecutively channel 1 or channel 2 each must be configured individually.

The following steps are required to configure the parameters of the DeviceNet Master device using the DeviceNet Master DTM:

### Busparameters

1. Set the bus parameters:
  - Select **Configuration > Bus Parameters** in the navigation area.

### Server Parameter

2. Set the server parameters:
  - Select **Configuration > Server Parameter** in the navigation area.

### Process Data

3. Set the process data:
  - Select **Configuration > Process Data** in the navigation area.
  - Set symbolic names for the configured modules or signals.

### MAC ID Table

4. Activate memory space for the data exchange with the slave or possibly adapt the MAC ID:
  - Select **Configuration > MAC ID Table** in the navigation area.

### Quick Connect Table

5. Set the „Quick Connect“ option:
  - Select **Configuration > Quick Connect Table** in the navigation area.
  - Check **Quick Connect** for the Slave device(s), which shall work as „Quick Connect“ Slave.

### Master Settings

6. Set the Master Settings:
  - Select **Configuration > Master Settings** in the navigation area.
  - Under **Start of Bus Communication** select **Automatically by device** or **Controlled by application** option.
  - Under **Application Monitoring** set the **Watchdog time**.
  - Under **Module Alignment** set the options **Byte boundaries** or **2 Byte boundaries**.
  - Under **Process Data Handshakes** select the **Process Data Handshake** type to be used.
  - Under **Device Status Offset** select **Automatic calculation** or **Static** option.



### **Close Master DTM Configuration Dialog**

7. Click **OK** in order to close the Master DTM configuration dialog and to store your configuration.

### **Configuration Download to the DeviceNet Master Device**

- Adhere to the necessary safety precautions to prevent personnel injury and property damage.



**Note:** In order to transfer the configuration to the DeviceNet Master device, download the data of the configuration parameters in the DeviceNet Master device. See section *Download Configuration* on page 92.


### **Further Information**



For more information refer to the sections *Bus Parameters* on page 58, *Server Parameters* on page 60, *Process Data* on page 61, *MAC ID Table* on page 63, *Quick Connect Table* on page 64 and *Master Settings* on page 68.

## 5.3 Bus Parameters

The **Bus Parameters** are the basis of an operating data exchange. This section contains information for setting the Bus Parameters as well as the description of the individual parameters.



The screenshot shows a configuration window titled "Bus Parameters". It is divided into three sections: "General", "Bus Parameters", and "Error Handling".

- General:** Contains a "Device Description:" label followed by a text input field containing the placeholder text "[Symbolic Name of the Device]".
- Bus Parameters:** Contains two settings:
  - "MAC ID:" with a numeric input field set to "0" and a small up/down arrow button.
  - "Baud Rate:" with a dropdown menu currently showing "125 kBits/s".
- Error Handling:** Contains a checkbox labeled "Auto Clear", which is currently unchecked.

Figure 25: Bus Parameters

### 5.3.1 General




Figure 26: Bus Parameters > General

The symbolic name of the device is displayed in the field **Device Description** and can be changed via entering.

### 5.3.2 Bus Parameters




Figure 27: Bus Parameters > Bus Parameters

Bus Parameter	Meaning
MAC ID	The MAC ID is the device address of the DeviceNet Master. Each device must have an own (unique) MAC ID to distinguish it in the network. Range of value: 0 ... 63
Baud Rate	This value shows the baud rate to be set to the DeviceNet Master. Range of value: <b>125 kBits/s</b> , 250 kBits/s, 500 kBits/s

Table 18: Bus Parameters > Bus Parameters

### 5.3.3 Error Handling



Figure 28: Bus Parameters > Error Handling

The **Auto Clear** feature defines the behavior of the Master if the communication to a Slave device is disturbed or breaks down.


If **Auto Clear** is checked and a communication disturbance to at least one Slave occurs, the Master operation mode will change from **Operate** to Clear and after this into Stop and so the communication to all Slaves is stopped. The Master can leave this state only by a reset.

If the **Auto clear** is not activated and a communication disturbance to one or more Slaves occurs, the Master stays in the operation mode **Operate**. The Master still communicates with the existing devices and tries to build up the communication to the missing or faulty devices.

For further information see section *General Diagnosis* on page 109.

## 5.4 Server Parameters

The **Server Parameters** contain DeviceNet specific Server Parameters with which the device is able to be a server at the same time being a Master. This allows an other Master in the network to exchange I/O data with this device, too.



**Server Parameters**

☒ I/O Connection Consumer  
 Connection size:  Byte(s)

☒ I/O Connection Producer  
 Connection size:  Byte(s)

Figure 29: Server Parameters

Server Parameters	Meaning
I/O Connection Consumer	If checked, the server functionality for the Consume Connection (Receiving data) is enabled and the I/O Consume Connection size can be entered in the field <b>Connection size</b> . Range of value: <u>0</u> ... 255
I/O Connection Producer	If checked, the server functionality for the Produce Connection (Sending data) is enabled and the I/O Produce Connection size can be entered in the field <b>Connection size</b> . Range of value: <u>0</u> ... 255

Table 19: Server Parameters

## 5.5 Process Data

For the DeviceNet Master DTM the **Process Data** pane serves as an external process data interface, e. g. for data transfer to a PLC unit. The process data pane lists the Slave devices connected to the Master, as well as the configured modules or input or output signals of the devices. This makes the fieldbus structure visible.

For the configured modules or signals names can be set (Column *Tag*).

In addition signal data available to the OPC server can be checked (Column *SCADA*).









Process Data				
		Type	Name	SCADA
		Slave Device* <1>	Slave Device*	<input checked="" type="checkbox"/>
		Poll <Slot 0>	Poll	<input checked="" type="checkbox"/>
		structured input	input	<input type="checkbox"/>
		structured output	output	<input checked="" type="checkbox"/>

Figure 30: Process Data (\*The name of the Slave device is displayed.)








Column	Symbol	Meaning
Type	 device	Device labeling* provided by the hardware followed by the device's name of station in pointy brackets
	 module, submodule	Description of the modules or input or output signals configured to the device (not editable)
	 I/O signal	
Tag	 device	Symbolic name* of the device
	 module, submodule	Symbolic name for the modules or for the input or output signals configured to the device (editable)
	 I/O signal	
	 warning	Duplicate Tag at the same level can cause errors by use of OPC!
SCADA	Option which module or signal data shall be provided for the OPC server. „SCADA“ (= Supervisory Control and Data Acquisition), here used with the meaning „to provide for visualizing purposes“.	
*Depending on the protocol, either the device name or the symbolic name can be edited via the device symbol context menu.		

Table 20: Process Data

## 5.6 Address Table

The **Address Table** dialog pane shows a list of all addresses used in the process data image. The displayed addresses refer to the used DeviceNet Master. To configure the address data:

- Select **Configuration > Address Table** in the navigation area.




Figure 31: Configuration > Address Table (In the Figure shown here, in the column Device or Name example devices are displayed.)

### 5.6.1 Description of the Parameters

Parameter	Meaning
MAC-ID	Device Network Address
Device	Device Name of the Slave device
Name	Designation for the Slave device
Connection Mode	Mode of the input or output data
Length	Input data length or output data length
Address	Output data offset address or input data offset address

Table 21: Parameters Address Table Pane - Inputs / Outputs

### 5.6.2 CSV Export

The **CSV Export** option allows to export input- and output addresses as CSV file (CSV = comma separated value). Therefore:

- Click to the **CSV Export** button.
- A file saving dialog opens.
- Save the data as \*.CSV file.

You can open the generated data by means of a spreadsheet application.

#### Sort Addresses

- To sort the address data, click on the respective column header.

## 5.7 MAC ID Table

The MAC ID Table, also called device table, shows the **MAC IDs**, **Device Names** and **Device Descriptions** of the currently existing devices in the configuration.

MAC ID Table				
Activate	MAC ID	Device	Name	Vendor
<input checked="" type="checkbox"/>	1	CIF50-DNS (C50DNS.EDS)	CIF50-DNS (C50DNS.EDS)	[Vendor Name]

Figure 32: Configuration >MAC ID Table (In the Figure shown here, in the column Device or Name example devices are displayed.)

Column	Meaning
Activate	If the field <b>Activate</b> is checked, memory for process data of this Slave is reserved in the Master and the Master makes a data exchange to this Slave on the bus. If this setting is deactivated, the Master reserves memory in the process data image for this Slave, but no data exchange to this Slave is made at the bus.
MAC-ID	Device Network Address The displayed values of the MAC IDs can be changed by editing. The entered MAC ID must be unique; otherwise an error message is displayed.
Device	Device name of the slave device assigned
Name	The symbolic name of the slave device assigned
Vendor	Name of the vendor of the device

Table 22: Parameters of the MAC-ID Table

## 5.8 Quick Connect Table

In the **Quick Connect Table** pane you need to define for every DeviceNet Slave device in the DeviceNet Master configuration whether the Master Device for the cyclic data exchange shall accelerate connection establishment to this Slave by using the „Quick Connect“ option (see also [3] 2-3.4).

Therefore proceed as follows:

- Select **Configuration > Quick Connect Table**.

For every DeviceNet Slave device:

- Check **Quick Connect**, if the connection from the DeviceNet Master device to this Slave device shall be established using the „Quick Connect“ option.
- Uncheck **Quick Connect**, if the connection from the DeviceNet Master device to this Slave device shall be established without using the „Quick Connect“ option.

Quick Connect Table			
Quick Connect	MAC ID	Device	Name
<input checked="" type="checkbox"/>	1	CIFX DN/DNS (CIFX_DN_DNS.EDS)	CIFX DN/DNS (CIFX_DN_DNS.EDS)
<input checked="" type="checkbox"/>	2	CIFX DN/DNS (CIFX_DN_DNS.EDS)	CIFX DN/DNS (CIFX_DN_DNS.EDS)

Figure 33: Configuration > Quick Connect Table

Parameter	Meaning	Range of Value / Value
Quick Connect	If the field <b>Quick Connect</b> is <u>checked</u> for a Slave device, the connection from the DeviceNet Master device to this Slave device is established using the „Quick Connect“ option.  If the field <b>Quick Connect</b> is <u>unchecked</u> for a Slave device, the connection from the DeviceNet Master device to this Slave device is established without using the „Quick Connect“ option.	checked,  unchecked
MAC-ID	Network Address of the Slave device as set in the MAC ID table (compare section <i>MAC ID Table</i> on page 63).  This parameter defines the DeviceNet address of the device within the network.	0 ... 63
Device	Device name of the slave device assigned and of the EDS file	
Name	The symbolic name of the slave device assigned and of the EDS file	

Table 23: Parameters of the Quick Connect Table

For further information on the „Quick Connect“ option, refer to subsections hereafter.



### 5.8.1 What is „Quick Connect“?

The „Quick Connect“ feature allows a reconnected Slave device on a DeviceNet network to quickly go into operation (e. g. after a tool exchange) by shortening the time required to make the logical connection between it and the Master. [5]

### 5.8.2 How does „Quick Connect“ work?

#### DeviceNet Master Device

The „Quick Connect“ feature is activated also in the *DeviceNet Master device*, if in the Master configuration at least for one DeviceNet Slave device is defined, that the Master device shall establish the connection to this Slave device using „Quick Connect“. [6] S. 97.

Specifically, „Quick Connect“ enables a DeviceNet Master device to initiate a connection request as soon as a “dup mac” request is received from a newly connected Slave device. [5]

When a Slave device is defined as „Quick Connect“ Slave, the Master concurrently sends UCMM and Alloc Master/Slave requests. Depending on the response of the Slave, an explicit connection will be established via „UCMM“ or „Group 2 Only Explicit Connection Port“. [6] S. 97.

#### DeviceNet Slave Device

At the *DeviceNet Slave device* the „Quick Connect“ option effects, that the connection request from the Master device will be accepted without waiting for the 2-second delay in its typical power-up sequence. [5]

When „Quick Connect“ is enabled, the Slave device transitions to the OnLine state concurrently with sending the first duplicate MAC ID request message. But the Slave device is still required to execute the network State Transition Diagram ([3] 2-3.1), including going offline anytime a duplicate MAC ID response message is received. [3] 2-3.4

### 5.8.3 Requirements for the use of „Quick Connect“

*Must both, the DeviceNet Master device and the DeviceNet Slave device support „Quick Connect“?*

*What happens, if the Master uses „Quick Connect“ to connect a Slave that does not support „Quick Connect“?*

As prerequisite for the optimal use of „Quick Connect“, the Master device and the Slave device both must support „Quick Connect“. That is, the Slave device must support „UCMM“ or „Predefined Master/Slave Connection“ as a connection type. The Hilscher DeviceNet Slave devices support the connection type „Predefined Master/Slave Connection“.

*What combinations are possible?*

In the following cases, „Quick Connect“ is available:

1. Master supports „Quick Connect“, Slave supports „Quick Connect“

The time to establish the connection until the I/O data exchange starts is reduced optimally.

2. Master supports „Quick Connect“, Slave does not support „Quick Connect“

The time to establish the connection until the I/O data exchange starts is shorter than without „Quick Connect“.

3. Master does not support „Quick Connect“, Slave supports „Quick Connect“

The time to establish the connection until the I/O data exchange starts is shorter than without „Quick Connect“.

In this case, „Quick Connect“ is not possible:

4. Master does not support „Quick Connect“, Slave does not support „Quick Connect“

The time to establish the connection until the I/O data exchange starts is not shorter than without „Quick Connect“.

*What the user needs to observe for „Quick Connect“?*



**Important:** Generally for DeviceNet and specifically for the use of „Quick Connect“ it is left up to the user:

- (1) to guarantee that no Slave exist with the same MAC ID

AND

- (2) that no more than one Master device is configured to access the same Slave device using the "Predefined Master/Slave Connection Set" ([3] section 3-15.1.).

Bus errors may occur if either of these conditions exists. Further details can be found in [3] Section 2-3.4.

## 5.8.4 How fast the I/O connection can be established with Quick-Connect?

If Quick-Connect is supported by both, the Master device and the Slave device, the connection is established faster. The required time to establish the connection is reduced from 3 s (seconds) to less than 200 ms (milliseconds) approximately.

The following times are required to establish the I/O connection. The values are valid for Hilscher Master Devices.

- **below 200 ms**

*If both the Master device and the Slave device support Quick-Connect.*

- Immediately after the Slave device has sent the duplicate MAC ID request, the Master device sends the „Quick Connect“ request.
- Depending on the reaction time of the Slave, the delay time up to the I/O data exchange can be 20 ... 200 milliseconds.

- **Approx. 2 s**

*If only the Master device supports „Quick Connect“ and the Slave device does not support „Quick Connect“.*

- Immediately after the Slave device has sent the duplicate MAC ID request, the Master device sends the „Quick Connect“ request.
- Immediately after the Slave device has sent the second duplicate MAC ID request, the Master device sends the „Quick Connect“ request and the I/O connection is established.

- **Approx. 2... 3 s**

*If the Master device does not support „Quick Connect“ but only the Slave device supports „Quick Connect“.*

In contrary to

- **Approx. 2 ... 5 s**

*If neither the Master device nor the Slave device support „Quick Connect“.*

## 5.9 Master Settings

At the **Master Settings** pane device related settings can be made. These settings only become active after the configuration was downloaded to the device.



Information about the download you find in section *Download Configuration* on page 92).

Figure 34: Configuration > Master Settings



**Note:** The setting options at the dialog pane **Master Settings** for client specific variants of the configuration software can differ from the setting options displayed here.

## 5.9.1 Start of Bus Communication




Figure 35: Master Settings > Start of Bus Communication

If **Automatically by device** is selected, the DeviceNet Master device will start with the data exchange on the bus after the initialization has been ended.

If **Controlled by application** is selected, the application program must activate the data exchange on the bus.



**Note:** The setting options under **Start of Bus Communication** for client specific variants of the configuration software can differ from the setting options displayed here.

## 5.9.2 Application Monitoring




Figure 36: Master Settings > Application Monitoring

The **Watchdog time** determines the time within which the device watchdog must be re-triggered from the application program while the application program monitoring is activated. When the watchdog time value is equal to 0 the watchdog is deactivated and the application program monitoring is deactivated too.

The permissible range of values of the watchdog time is 20 to 65535. By default the watchdog time value equals to 1000 ms.

Watchdog time	Range of Value / Default Value
Permissible range of values	20 ... 65535 ms
Default	1000 ms
The software watchdog is deactivated.	0 ms

Table 24: Range of Value / Value for the Watchdog time



**Note:** The setting options under **Application Monitoring** for client specific variants of the configuration software can differ from the setting options displayed here.

### 5.9.3 Module Alignment




Figure 37: Master Settings > Module Alignment

The **Module Alignment** defines the addressing mode of the process data image. The addresses (offsets) of the process data are always interpreted as byte addresses. The **Module Alignment** then defines the addressing mode, **Byte boundaries** or **2 Byte boundaries**.

Parameter	Meaning
Byte boundaries	The module address can start at any byte offset.
2 Byte boundaries	The module address can only start at even byte offsets.

Table 25: Parameters Master Settings > Module Alignment



**Note:** The setting options under **Module Alignment** for client specific variants of the configuration software can differ from the setting options displayed here.

## 5.9.4 Process Data Handshake




Figure 38: Master Settings > Process Data Handshake

The various types of **Process Data Handshakes** are used for setting the handshake of the process data for the DeviceNet Master device.

The selection of the used process data handshake is important for the correct data exchange between the application program and the device.

The used handshake of the process data needs to be supported by the used application program.

Only the **Buffered, host controlled** handshake mode is supported.



**Note:** The setting options under **Process Data Handshake** for client specific variants of the configuration software can differ from the setting options displayed here.

## 5.9.5 Advanced (For future Application)

The **Enable configuration download during network state “operate”** option for the DeviceNet network allows to change the configuration of a running DeviceNet network without resetting the devices.




Figure 39: Master Settings > Advanced

- Check **Enable configuration download during network state “operate”** to enable configuration download during network state “operate”.
- 🔗 A new configuration is downloaded and the configuration of the DeviceNet network is changed and saved.



**Note:** The setting options under **Advanced** for customer specific variants of the configuration software can differ from the setting options displayed here.

5.9.6 Device Status Offset

**Reference to Firmware:** The option **Device Status Offset** was implemented since DeviceNet Master Firmware CFXDNM.NXF Version 2.2.2.0.

The option **Device Status Offset** allows via **Automatic calculation** to calculate the offset for the start address of the device status in the dual-port memory automatically or via **Static** to preset the offset.




Figure 40: Master Settings > Device Status Offset

Device Status Offset	Meaning
Automatic calculation:	Device status always after the last input byte. If further input data are added in the configuration, then the starting address of the device status in the dual-port memory will move.
Static:	Here, the distance (free buffer) between the last input byte and the start of the device status can be set. If further input data are added in the configuration, then the distance will be reduced, so that the start address of the device status in the dual-port memory remains the same. If more input data are added in the configuration as free buffer exists, then the start address of the device status in the dual-port memory must be moved.

Table 26: Option Master Settings > Device Status Offset



**Note:** The setting options under **Device Status Offset** for customer specific variants of the configuration software can differ from the setting options displayed here.



## 6 Online Functions

### Getting Access to SYCON.net Online Functions



**Note!** If under 'Configuration' > 'Master Settings' > 'Start of bus communication' > 'Controlled by application' is selected, after 'Power on Reset' the Master device is in 'Offline' state! In this state you can not use the SYCON.net online functions 'Debug Mode', 'LifeList' and 'Network Scan'. To get access to the online functions in case the Master device is used together with an application program, you must make sure that the application program will start the communication. Alternatively you can start the communication manually from the context menu 'Start communication' of the the Master device.

### 6.1 Connecting/Disconnecting Device



**Note:** Several DeviceNet Master DTM functions e. g. **Diagnosis** or the configuration download in the FDT Framework require an online connection from the DeviceNet Master DTM to the DeviceNet Master device.

#### Connecting Device

The following steps are needed to establish a connection from the DeviceNet Master DTM to a DeviceNet Master device:

Under **Settings** in the **Driver** pane:

1. Verify that the default driver is checked and respectively check another or multiple drivers.
2. Configure the driver if necessary.

Under **Settings** in the **Device Assignment** pane:

3. Scan for the devices (with or without firmware).
4. Select the device (with or without firmware) and apply the selection.



Before you download the firmware adhere to the necessary safety precautions to prevent personnel injury and property damage. For more refer to section *Safety Messages on Firmware or Configuration Download* on page 28.

Under **Settings** in the **Firmware Download** pane if not yet a firmware was loaded to the device:

5. Select and download the firmware.

Under **Settings** in the **Device Assignment** pane if not yet a firmware was loaded to the device:

6. Scan for the device (with firmware) once more.
7. Select the device (with firmware) once more.



An overview of the descriptions for these steps you find in the section *Overview Settings* on page 29.

8. In the DTM interface dialog select the **OK** button, to apply the selection and to close the DTM interface dialog.
  9. Put a right-click on the DeviceNet Master device icon.
  10. Select the **Connect** command from the context menu.
- ⇒ The DeviceNet Master device now is connected to the DeviceNet Master DTM via an online connection. In the network view the device description at the device icon of the Master is displayed with a green colored background.

### **Disconnecting Device**

To disconnect an online connection from the DeviceNet Master device to a DeviceNet Master DTM take the following steps:

1. In the DTM interface dialog select the **OK** button, to close the DTM interface dialog.
  2. Right-click on the DeviceNet Master device icon.
  3. Select the **Disconnect** command from the context menu.
- ⇒ In the network view the device description at the device icon of the Master is not any more displayed with a green colored background. Now the DeviceNet Master device is disconnected from the DTM.



---

**Important:** For a 2-channel device channel 1 or channel 2 each must be connected to the DTM separately.

---




## 6.2 Debug Mode







**Note:** Depending by the software variant of the frame application the **debug mode** is available or not.

The **debug mode** allows identifying the status of the cyclical communication between a Master device and its Slave devices on a network based on the colors of the bus lines as well as the debug icons.

For the Master device or the Master bus line this is valid:

- Master device in operation, cyclical communication runs. (Bus line **light green**/debug icon „RUN“  next to the Master device icon)
- Master device not operable.  
(Bus line **blue**/debug icon „ATTENTION“  next to the Master device icon)
- Master in STOP state.  
(Bus line **red**/debug icon „STOP“  next to the Master device icon)

For the Slave device or the bus line from the Master bus line to the Slave device this is valid:

- Slave device in operation, cyclical communication to the Master device runs. (Bus line **light green**/debug icon „RUN“  next to the Slave device icon)
- Diagnosis message available at the Master device.  
(Bus line **yellow** (yellow)/debug icon „RUN“  next to the Slave device icon)
- Slave device not found during cyclical communication boot up.  
(Bus line **blue**/ debug icon „ATTENTION“  next to the Slave device icon)
- Error in the Slave-to-Master communication.  
(Bus line **red**/debug icon „STOP“  next to the Slave device icon)
- Slave device is not configured.  
(Bus line **gray**)

## 6.2.1 Requirements



---

**Note:** You first must:

- assign the Master device to the Master DTM,
- configure the Master or the Slave device parameters,
- and download the configuration to the Master.

Only then the debug mode can be used appropriately.

---



---

For details to the device assignment, refer to section *Settings for Driver and Device Assignment* on page 30.

For information on how to configure the Master device or how to download the configuration, refer to this Operating Instruction Manual and to the Operating Instruction Manual for the netDevice.

For information on how to configure the Slave device, refer to the Operating Instruction Manual of the Slave DTM.

---

## 6.2.2 Starting Debug Mode




**Note:** The menu entries for the **debug mode** will be only available if the debug mode is supported by the frame application and the Master DTM.

For a single network:

- Therefore open the context menu of the Master via right mouse click to the device icon.
- Select the **Start Debug Mode** command from the context menu.

For the entire project:

- Click to the menu **Network > Start Project Debug Mode** or in the netDevice toolbar **Debug** to the icon .
- In the debug mode, the bus lines in the network view are displayed depending on the status of the cyclical communications in various colors. Additionally next to the device icon different debug icons are displayed.




Figure 41: Example Debug Mode with pending Diagnosis, Network View of a Project with one Network (Master and Slave)

- **Root Busline:** This busline is displayed always in **gray**.
- **Branch Line of the Master device** (Busline from the Root to the Master Busline): During the debug mode this busline is displayed **light green**, **blue** or **red** colored. If the debug mode is not used, this bus line will be displayed **gray** colored.
- **Master Busline or Branch Line of the Slave device:** During the debug mode these buslines are displayed **light green**, **yellow** (yellow), **blue** or **red** colored. If the debug mode is not used, this bus line will be displayed in the respective *fieldbus* or *protocol specific* color (PROFIBUS: **violet**).

## 6.2.3 Debug Mode Busline Colors and Debug Icons

The following table contains information about the displayed colors of the bus lines and on the icons in the debug mode.








Debug Mode Busline Colors	Debug Icon	Meaning
Master Busline	Next to the Master device icon	
light green		The Master device has cyclic communication
blue		The Master device is not operable. This may have different causes. For example: - There is no valid license in the Master device. - There is no valid firmware in the Master device.
red		The Master device is in STOP state. The cyclic communication has been stopped.
Branch Line of the Slave device	Next to the Slave device icon	Meaning
light green		The Master device has cyclic communication to this Slave device.
yellow (yellow)		The Master device has cyclic communication to this Slave device, but in the diagnostic buffer of the Master device a diagnostic information about this Slave is pending.
blue		The device was not found. This may have different causes. For example: - The configuration download to the Master device is still missing. - The Slave device is not available in the network. - There is no valid firmware in the Master device. - Parameter or configuration error at the Master device. - The cyclic communication to this Slave device has been stopped (without diagnosis information at the Master).
red		Due to a communication error, the cyclic communication from the Master device to this Slave device is not possible. This may have different causes. For example: - The cyclical communication to this Slave device has been stopped. - Parameter or configuration error at the Slave device. - The validation of the manufacturer or device ID shows different values. - The diagnostic buffer of the Master device still a diagnostic information about this Slave is pending and the cyclic communication to this Slave device has been stopped.
gray	-	The Slave device is not configured. I. e., in the configuration of the Master device there are no configuration parameters to this Slave available.

Table 27: Debug Mode Busline Colors and Debug Icons

## 6.2.4 Reset of the Diagnosis Information and of the Station Status

To analyze the diagnosis information:

- Select the diagnosis windows in the Master DTM dialog.
- Therefore select **Diagnosis** > [*diagnosis window*] in the navigation area.

To read the diagnosis buffer of the Master device and thus to reset the device:

- Select **Diagnosis** > **Station diagnosis** in the navigation area.
- In the window **Station diagnosis** click with the right mouse button to the station status LED for the device (yellow).
- From the context menu select **Reset** or **Reset All**.

In the window **Station diagnosis** the station status LED for the device is displayed in green and the network will display the bus line from the Master device icon to the Slave device icon in **light green**.

## 6.2.5 Stopping Debug Mode

For a single network:

- Therefore open the context menu of the Master via right mouse click to the device icon.
- Select the **Stop Debug Mode** command from the context menu.

For the entire project:

- Click to the menu **Network** > **Stop Project Debug Mode** or in the netDevice toolbar **Debug** to the icon .

## 6.3 Set MAC ID

With the dialog **Set MAC ID** the DeviceNet MAC ID of the device can be changed.

To set the MAC ID, proceed as described hereafter:

1. Select and connect the device.
2. Disconnect the device (only if the device is online).



**Note:** The dialog **Set MAC ID** is enabled only during offline mode. The online-connection between the DeviceNet Master DTM and the DeviceNet Master device must be disconnected.



For further information how to establish or how to disconnect an online connection from the DeviceNet Master DTM to the DeviceNet Master device, refer to section *Connecting/Disconnecting Device* on page 73.

3. Select **Additional Functions > Set MAC ID** from the context menu (right mouse click).

Figure 42: Set MAC ID

4. In the **Current MAC ID** list field, select the current MAC ID.
  5. In the field **New MAC ID** enter the new MAC ID and select **Set MAC ID**.
- The new MAC ID of the device is set and in addition it is displayed in the **Current MAC ID** list.



## 6.4 Live List

The **Live List** gives an overview of the devices, which are physically present in the actual DeviceNet network constellation.

The live list works online. Present devices are represented as a **blue circle area**, all other non present devices are displayed in grey, whereby the number indicates the DeviceNet address (MAC ID) of the device.

To work with the **Live List**, proceed as follows:

1. Connecting Device:



**Note:** Accessing the **Live List** display requires an online connection from the DeviceNet Master DTM to the DeviceNet Master device.



For further information refer to section *Connecting/Disconnecting Device* on page 73.

2. Select **Additional Functions > Live List** from the context menu (right mouse click).

Remember that all devices on DeviceNet have to proceed the autobaud detection phase first to get wholly run. This can take up to some milliseconds.




Figure 43: Live List

The display is not updated automatically as this function loads the DeviceNet network. However, the Live List can be renewed with the **Update** button.

## 6.5 'Network Scan' and 'Upload'

**Reference to Firmware:** The option **Network Scan** was implemented since DeviceNet Master Firmware CFXDNM.NXF Version 2.3.11.0.

With the function **Network Scan...** of the DeviceNet Master DTM you can find out automatically which DeviceNet Slaves are attached to the DeviceNet Master device and how these devices are configured. During the network scan the Master device requests the ident codes of the Slave devices found at the bus. For each connected Slave device its ident code is read out.

In the **Scan Response** dialog of the Master DTM the assigned device description files or DTM devices are displayed. Exactly one ident code is assigned to each device description file and to each DTM device. Different versions (also language versions) of the same device description file are defined by the same ident code. For every identified device you can select the assigned DTM device according to the firmware loaded in that Slave device. Via **Create Devices** for each Slave device the selected DTM device is created.

The **Upload** of the configuration is proceeded subsequent to a network scan procedure. The upload function allows to upload connection configuration data from all DeviceNet Slave devices via the DeviceNet Master device and the DeviceNet Master DTM to the DeviceNet Slave DTMs.

### Requirements

The DeviceNet Master device must be configured. Under **Settings > Bus Parameters** you must set the baud rate and the MAC ID of the Master.



**Important:** The configuration of the Master device must be downloaded in the Master device. For more see section *Configuration Steps* on page 24.

### Overview Steps

1. Starting the **Network Scan** function of the Master DTM.

2. Make the settings in the **Scan Response** dialog of the Master DTM.

3. Click **Create Devices**.

For all Slave devices:

4. Via the **Upload** function of the Slave DTMs, upload the configurations of the Slave devices into the Slave DTMs.

5. Via the **Download** function of the Master DTM, download the current configurations of the Slave devices to the Master device.

## 6.5.1 Starting 'Network Scan'

### 1. Starting the **Network Scan** function of the Master DTM.

- In netDevice: right-click on the device symbol of the DeviceNet Master DTM.
- Select **Network Scan...** from the context menu.




Figure 44: Starting 'Network Scan' (Example)

- Wait for a short time.



**Note:** It can last some seconds, until the **Network Scan...** dialog is displayed.

Via **Network Scan...** an online connection from the DeviceNet Master DTM to the DeviceNet Master device is established. The configuration software scans, which DeviceNet Slave devices are attached to the PROFIBUS network or to the DeviceNet Master device.

➤ The **Scan Response** dialog of the Master DTM is displayed.




Figure 45: Scan Response dialog of the Master DTM (Example)

## 6.5.2 Settings in the Scan Response Dialog of the Master DTM

2. Make the settings in the **Scan Response** dialog of the Master DTM.

- In the **DTM to Use** column the DTM devices assigned to the found ident codes appear.




Figure 46: Scan Response dialog of the Master DTM (Example)

- In the **DTM to Use** column select for every identified device the DTM device corresponding to the firmware loaded in this Slave device.
- If in the **DTM to Use** column no DTM device or a DTM device not desired is displayed, add the required DTM devices to the device catalog.
- or adapt the creation mode under **Creation Mode**.
- In the **Action** column select, whether the found DTM device shall be:
  - *added or skipped*  
(if a device is not yet present in the project),
  - *or replaced or skipped*  
(if a device is already present in the project)

### 6.5.3 Description on the Scan Response Dialog of the Master DTM

In the following table you find a description about the **Scan Response** dialog of the Master DTM.

Column	Description
<b>Title Bar</b>	With the text: <i>Symbolic Name of the Master Device [Device Description] &lt;Device Address&gt; (#Network ID) channel//DeviceNet.</i>
<b>Instruction</b>	In the Network Scan window the instruction text is displayed: <b>The following hardware-devices have been found during network scan. Please check automatic selection of corresponding devices found in device catalog in column 'DTM Devices' before creating devices.</b>
<b>Station Address</b>	DeviceNet station address, which displays the logical sequence of the devices within a DeviceNet network. <i>Note:</i> The station address displayed here is not identical to the station address of the device stored in the hardware configuration.
<b>Colors</b>	Meaning of colors in the <b>Scan Response</b> dialog of the Master DTM: <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;"> <div style="background-color: red; width: 20px; height: 15px; display: inline-block;"></div> <b>Red</b>  <div style="background-color: yellow; width: 20px; height: 15px; display: inline-block;"></div> <b>Yellow</b> </div> <div> <p>If a field marked in red appears in column <b>Station address</b>, the respective DTM device is already present on the network.</p> <p>If a field appears marked in yellow, a selection can be made by a combo box.</p> </div> </div>
<b>Device Type ID</b>	Identification (ID): Ident code read out from each device (Unique Identifier)
<b>Sub Device Type</b>	Sub type of the device type if applicable
<b>DTM to Use</b>	<p>Display of the DTM devices, which are assigned to the ident codes found during scanning:</p> <p>If <u>Use Hilscher generic DTMs if available</u> is displayed <i>without color marking</i>, there is no selection possibility.</p> <p>If <u>Use Hilscher generic DTMs if available</u> is displayed <i>marked in yellow</i>, the following selection can be made:</p> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px;"> <div style="background-color: #f0f0f0; padding: 2px;">Use Hilscher generic DTMs if available</div> <div style="background-color: #0000ff; color: white; padding: 2px;">Use Hilscher generic DTMs if available</div> <div style="background-color: #ffffff; padding: 2px;">Use vendors DTMs if available</div> </div> <div style="margin-left: 10px;">(In the figure shown example DTMs are displayed.)</div> </div> <p>A selection will only be displayed if under <b>Creation Mode &gt; Choose for each device</b> was selected and if another DTM has been found for the respective device.</p>
<b>Device Class</b>	Device class of the DeviceNet Slave devices.
<b>DTM Device</b>	<p>Found DTM device (the device name as taken from the DTM)</p> <p>Only the device description files or DTM devices can be displayed within the column <b>DTM Devices</b>:</p> <ul style="list-style-type: none"> <li>• Which are available in the device catalog for the scanned ident code,</li> <li>• Respectively, which belong to the selection made under <b>Creation Mode</b></li> <li>• and which belong to the selection made under <b>Creation Mode &gt; Choose for each device</b> under <b>DTM to create</b>.</li> </ul> <div style="display: flex;"> <div style="flex: 1;"> <p>For each device type ID in the column <b>DTM Device</b> the following is displayed:</p> <ul style="list-style-type: none"> <li>• <u>no</u> device,</li> <li>• <u>one</u> single device</li> <li>• or <u>multiple</u> devices (within a combobox).</li> </ul> </div> <div style="flex: 1;"> <p>This means, within the device catalog of netDevice for the found ident code and the selected <b>Creation Mode</b> these alternatives are available:</p> <ul style="list-style-type: none"> <li>• no DTM</li> <li>• A device description file or a DTM device of a manufacturer</li> <li>• One or more device description files or DTM devices of the manufacturer</li> </ul> </div> </div>
<b>Quality</b>	Associated quality information Display: [1] DTM found, [3] Generic found



Column	Description
<b>ction</b>	<p>The action to be performed with the corresponding device during the process of device creation.</p> <ul style="list-style-type: none"> <li>If no device is present within the current project, the selection <b>Add/Skip</b> will appear.</li> <li>If there is already a device present within the current project, the selection <b>Replace/Skip</b> will appear.</li> </ul> <p><b>Add</b> adds a new instance for the selected DTM during the process of creation of a device.</p> <p><b>Skip</b> skips the process of creation of a device for the respective device address.</p> <p><b>Replace</b> erases the instance of the DTM currently located at this address during the process of creation of a device, and replaces it with the instance of the chosen DTM.</p>
<b>Table below</b>	<p>The lower table in the <b>Scan Response</b> dialog of the Master DTM shows a comparison of possible differences in device information taken from:</p> <ul style="list-style-type: none"> <li>The hardware device (displayed in central column of 3)</li> <li>and the DTM (displayed in right column of 3)</li> </ul> <p>The left column contains which information is compared between the information sources 'Hardware Device' and 'DTM'.</p> <hr/> <p> <b>Note:</b> If a field contains the text 'n/a', the corresponding information is not applicable in the current context (fieldbus).</p>
<b>Creation Mode</b>	<p>Under <b>Creation Mode</b> one of the following options can be selected:</p> <ul style="list-style-type: none"> <li>User Hilscher generic DTM if available</li> <li>Use vendors DTMs if available</li> <li>Choose for each device</li> </ul> <div data-bbox="379 996 861 1124">  </div> <p><i>'Scan Response dialog of the Master DTM &gt; 'Creation Mode'</i></p>
<b>Create Devices</b>	<p>About <b>Create Devices</b> ...</p> <ul style="list-style-type: none"> <li>for each Slave device the previously selected DTM device is created.</li> <li>an upload of the Slave configuration can be proceeded.</li> </ul>
<b>Cancel</b>	Click <b>Cancel</b> to leave the dialog without creating a Device.

Table 28: Description on the Scan Response dialog of the Master DTM

## 6.5.4 Creating Devices, Starting ,Upload'

### 3. Click **Create Devices**

- In the **Scan Response** dialog of the Master DTM click **Create Devices**.
- For each Slave device the previously selected DTM device is created.
- The dialog **Network Scan – Creating Devices** appears.



**Note:** Depending on the manufacturer of the respective device, also a dialog with some slight deviations from this one may be displayed.




Figure 47: DTM device is created (Example)



4. Via the **Upload** function of the Slave DTMs, upload the configurations of the Slave devices into the Slave DTMs.
  - In netDevice: right-click on the device symbol of the DeviceNet Slave DTM.
  - Select **Upload** from the context menu.




Figure 48: 'Upload' the Slave Device Configuration (Example)

- The dialog **Devices Symbolic Name of the Master Device [Device Description] <Device Address> Starting Upload ...** appears. The dialog shows the progress of the upload process.



**Note:** Depending on the manufacturer of the respective device, also a dialog with some slight deviations from this one may be displayed.

- Additionally you are asked whether the module configuration (for DeviceNet this means 'Connection configuration') of the DeviceNet Slave device should be generated.




Figure 49: Query of the Upload Function (Example)

- Answer the query by **Yes**.
- For the Slave device its current configuration is uploaded via the Master device and the Master DTM to the Slave DTM.




Figure 50: Upload succeeded (Example)

- The success of the upload procedure is reported in the output window.

After the connection configuration of the DeviceNet Slave device has been created, you can display the uploaded connection configuration by double-clicking the Slave device symbol.




Figure 51: Uploaded Connection Configuration (Example)

### 6.5.5 Download to the DeviceNet Master Device



Adhere to the necessary safety precautions to prevent personnel injury and property damage. For more refer to section *Safety Messages on Firmware or Configuration Download* on page 28.

5. Via the **Download** function of the Master DTM, download the current configurations of the Slave devices to the Master device.

- In netDevice: right-click on the device symbol of the DeviceNet Master DTM.
- Select **Download** from the context menu.

## 6.6 Download Configuration

The device configuration is created *offline* in the DTM (application program). A download to the device is required, to transfer the configuration with the parameter data to the device.



**Note:** To download configuration parameter data to the DeviceNet Master device an online connection from the DeviceNet Master DTM to the DeviceNet Master device is required. Further information can be found in the *Connecting/Disconnecting Device* section on page 73.

### **Safety Precautions**

If you plan to perform a configuration download via the DeviceNet Master DTM be aware of the following:

#### **⚠ WARNING**

#### **Communication Stop caused by Configuration Download, faulty System Operation possible or Loss of Device Parameters**

Before you initiate a configuration download process, while the bus is still in operation status:

- Stop the application program.
- Make sure that all network devices are placed in a fail-safe condition.

#### **⚠ WARNING**

#### **Mismatching System Configuration, faulty System or Device Operation possible**

- In the device use only a configuration suitable for the system.

#### **NOTICE**

#### **Loss of Parameters caused by Power Disconnect during Configuration Download**

- During configuration download process, do not interrupt the power supply to the PC, or to the device and do not perform a reset to the device!

*For more see next page.*

### **Download Steps**

To transfer the configuration with the corresponding parameter data to the DeviceNet Master device you download the data using the frame application of the configuration software.

For netDevice the download is made via **Device > Download** or use the context menu with **Download**.

1. Select **Download** in the context menu of the device.

⇒ If the download is started as long as the Slave devices are connected to the Master device, the following message is displayed: 'If you attempt to download during bus operation, communication between Master and Slaves is stopped. Do you really want to download?'




Figure 52: netDevice Message: Download



**Important:** If the communication between the Master and the Slave devices is stopped, the data exchange between the Master device and the Slave devices is stopped.

2. Click to **Yes** if you intend to download the configuration.

⇒ Then the current configuration in the application program is downloaded to the device.

3. Otherwise click to **No**.

## 6.7 Start /Stop Communication

You can manually start or stop the communication between a DeviceNet Master device and DeviceNet Slave devices.

- **Start Communication** can be enabled if the communication was stopped before or if the configuration requires this (Controlled release of communication).
  - **Stop Communication** can be enabled if the communication was started.
- To start or to stop the communication, proceed as follows:

### Start Communication

1. Connecting device:



**Note:** To start the communication of the device at the bus manually, an online connection from the DeviceNet Master DTM to the DeviceNet Master device is required. Further information can be found in the *Connecting/Disconnecting Device* section on page 73.

2. Select **Additional Functions > Service > Start Communication** from the context menu (right mouse click).
- The device communicates at the bus.

### Stop Communication



#### **Faulty System Operation possible, Overwriting of Firmware or Loss of Device Parameters**

Before you stop the communication:

- Stop the PLC program.
  - Make sure that all network devices are placed in a fail-safe condition.
1. Select **Additional Functions > Service > Stop Communication** from the context menu (right mouse click).
- The communication of the device at the bus is stopped.

## 6.8 Licensing

Using the license dialog, you can order licenses for **Master protocols** or **Utilities** and download them to your device.

### 6.8.1 Open License Dialog

You first open the **License** window.



**Note:** You first need to assign the Master device to the DTM. Only then, the device data and the licenses already present in the device are displayed in the **License** dialog.

How to proceed:

#### A.) Assigning the Master device to the DTM

1. Open the DTM configuration dialog.
  - In the FDT container **netDevice** double click to the device icon.
2. Select one or several drivers.
  - Select **Settings > Driver**.
  - Check the drivers.
3. Configure the driver if necessary.
  - Select **Settings > Driver > [Name of the assigned driver]**.
  - Configure the driver settings.
4. Scan for and select the devices.
  - Select **Settings > Device Assignment**.
  - Under **Device selection** select *suitable only* or *all* and then **Scan**.
  - In the table, check the required devices.
  - Select **Apply**.
5. Close the DTM configuration dialog via **OK**.



For details to the device assignment, refer to section *Device Assignment* in this manual.

#### B.) Open the License pane

- In the FDT container **netDevice** right click to the device icon.
- From the context menu select **Additional Functions > License**.
- The **License pane** opens.

## 6.8.2 License Dialog

In the **License**<sup>1</sup> pane you can:

- check, which licenses for Master protocols or Utilities are present in the device (Position ① in the figure below),
- order licenses (Positions ② to ⑪),
- transfer licenses to the device ⑫.

License Type

	Existing	Order
<b>Master protocols</b>		
One General Master License	NO	<input type="checkbox"/>
Two General Master Licenses	NO	<input type="checkbox"/>
PROFIBUS Master	YES	<input type="checkbox"/>
CANopen Master	YES	<input type="checkbox"/>
DeviceNet Master	YES	<input type="checkbox"/>
AS-Interface Master	YES	<input type="checkbox"/>
PROFINET IO RT Controller	YES	<input type="checkbox"/>

Request Form, please fill out

Name	Value
License type	User Single Device License
Manufacturer*	0x0001
Article number*	1251100
Serial number*	20007
Chiptype*	0x00000001
Step*	0x00000000
Romcode revision*	0x00000000

Fields marked with "\*" are mandatory.

Buttons: ④, ⑤ E-mail..., ⑥ Print Fax Form..., ⑦ Telephone..., ⑧ Export License Request..., ⑨, ⑩, ⑪, ⑫ Download License, Close, Help

Figure 53: License Pane



**Note:** To display further entries under **License Type**, move the scroll box ① downwards or upwards. To display further entries under **Request Form, please fill out**, move the scroll box ② downwards or upwards.

<sup>1</sup> The title bar contains the notation of the **device description**:  
Symbolic Name [Device Description] <Station Address> (#Network ID).



### 6.8.3 Which Licenses are present in the Device?

Check, which licenses are present in the device.

How to proceed:

- Open the **License** pane as described.




Figure 54: License Pane - License Type

- Under **License Type** click at **Master protocols**.

➤ The **Master protocols** overview opens:

	Existing	Order
One General Master License	NO	<input type="checkbox"/>
Two General Master Licenses	NO	<input type="checkbox"/>
PROFIBUS Master	YES	<input type="checkbox"/>
CANopen Master	YES	<input type="checkbox"/>
DeviceNet Master	YES	<input type="checkbox"/>
AS-Interface Master	YES	<input type="checkbox"/>
PROFINET I/O RT Controller	YES	<input type="checkbox"/>

Figure 55: License Pane – License Type / Master protocols

- Or click at **Utilities**.

➤ The **Utilities** overview opens:

	Existing	Order
OPC Server	NO	<input type="checkbox"/>
SYCON.net	NO	<input type="checkbox"/>
QVis Minimum Size	NO	<input type="checkbox"/>
QVis Standard Size	NO	<input type="checkbox"/>
QVis Maximum Size	NO	<input type="checkbox"/>
CoDeSys Minimum Size	NO	<input type="checkbox"/>

Figure 56: License Pane – License Type / Utilities

➤ The column **Existing** indicates which licenses are present in the device.

**Yes** = License is present in the device.

**No** = License is not present in the device.



**Note:** In newer versions of the present configuration software under **License Type** may be displayed additional licenses or other protocols that can be ordered later.

### 6.8.3.1 License for Master Protocols

*One General Master License:*

On the device maximally 1 communication protocol with master function can be implemented.

*Two General Master Licenses:*

On the device maximally 2 communication protocols with master function can be implemented.

The license includes the following Master protocols:

- AS-Interface Master
- CANopen Master
- DeviceNet Master
- EtherCat Master
- EtherNet/IP Scanner
- PROFIBUS Master
- PROFINET IO RT Controller
- Sercos Master

### 6.8.3.2 License for Utilities

- SYCON.net
- OPC Server
- QVis Minimum Size
- QVis Standard Size
- QVis Maximum Size
- CoDeSys Minimum Size
- CoDeSys Standard Size
- CoDeSys Maximum Size

For the utilities QVis and CoDeSys, only one license each may be chosen alternatively as:

- *Minimum Size,*
- *Standard Size or*
- *Maximum Size.*

## 6.8.4 How to order a License


To order a license, proceed as follows:

	<i>Refer to Section:</i>	<i>Page</i>
1. Open the license dialog.	<i>Open License Dialog</i>	95
2. Select the required licenses.	<i>Selecting License</i>	99
3. Enter the ordering data.	<i>Ordering Data</i>	100
4. Place your order.	<i>Ordering the License</i>	102


## 6.8.5 Selecting License(s)

You can select licenses for Master protocols and / or utilities.

1. Selecting license(s) for Master protocol(s):

- Under **License Type** click  at **Master protocols** in the **License** pane.
- Under **Order** check as many licenses must run simultaneously on your device:  
*One General Master License* or  
*Two General Master Licenses*.

2. And/or select license(s) for utility(utilities):

- In the **License** pane under **License Type** click  at **Utilities**.
- Under **Order** check the required utility(utilities)  
(*single or several*)<sup>2</sup>:
  - SYCON.net
  - OPC Server
  - QVis Minimum Size\*
  - QVis Standard Size\*
  - QVis Maximum Size\*
  - CoDeSys Minimum Size\*\*
  - CoDeSys Standard Size\*\*
  - CoDeSys Maximum Size\*\*

2 For \*) and \*\*) minimum size, standard size or maximum size can be selected only as an alternative.

## 6.8.6 Ordering Data

### 1. Device Information

➤ The *Device Information* required for the order are read from the device and automatically filled in the order.

### 2. Ordering Data

Enter the *Ordering Data* into the **License** pane.

➤ Enter the **Data to manage the Order**.

### 6.8.6.1 Device Information (Ordering data read from the Device)

The following ordering data are read from the device and displayed in the **License** pane:

- Manufacturer
- Device number
- Serial number
- Chiptype
- Step (chip revision)
- Romcode revision
- Checksum (checksum of the device data)

➤ The gray fields under **Request Form, please fill out** contain the ordering data read from the device:

Request Form, please fill out

Name	Value
Manufacturer*	0x0001
Article number*	1251100
Serial number*	20007
Chiptype*	0x00000001
Step*	0x00000000
Romcode revision*	0x00000000
Checksum*	G

Fields marked with "\*" are mandatory.

Figure 57: License Pane - Request Form, please fill out / Device Information

➤ These ordering data read out from the device are displayed automatically from the device.

### 6.8.6.2 Data to manage the Order (License Information)

For your order you must enter the following data to the **License** pane:

1. License Type (User Single Device License).

Name	Value
License type	User Single Device License

Figure 58: License Pane - Request Form, please fill out / License Type

- Select the license type under **Request Form, please fill out > Value**, (for future application, currently only *User Single Device License* can be selected).
- 2. Mandatory data to the order request (editable fields):
  - First Name
  - Surname
  - E Mail (address, to which the license download link shall be send.)
  - Telephone
  - Company
  - Address
  - Country
  - City, State, Zip

Name	Value
First name*	John
Surname*	Doe
E-Mail*	License@doe.com
Telephone*	0011223344-55
Fax	0011223344-100
Customer number	123456789
Company*	Doe Example LTD

Fields marked with '\*' are mandatory.

Figure 59: License Pane - Request Form, please fill out / Mandatory data

- Enter all mandatory fields under **Request Form, please fill out > Value** (marked with\*).
- 3. Additional order data, not mandatory (editable fields):
  - Fax
  - Customer Number
  - Order Number
  - Value added tax identification number
- Under **Request Form, please fill out > Value** enter all fields for the additional data, which are not mandatory.

## 6.8.7 Ordering the License

Place your order in the **License** pane. Therefore:



Figure 60: License Pane – Selecting the Subsidiary / Ordering / Contacts

1. Select the **Subsidiary** (4), to which the order shall be send.
2. Place the order:

	Refer to Section:	Page
• by <b>E-Mail</b> (5),	<i>Ordering the License <u>by E Mail</u></i>	103
• or by <b>Fax</b> (6) or by <b>Telephone</b> (7),	<i>Ordering the License <u>by Fax or by Telephone</u></i>	104
• or in a <b>File</b> (8).	<i><u>Exporting License Request to a File</u></i>	106
➤ The <b>Contact Data</b> of the selected subsidiary are displayed under Position (9), (10) and (11).		

### 6.8.7.1 Ordering the License by E Mail

You can place your order by e-mail.



Figure 61: License Pane – placing the order by E-mail

- Click **E-mail...** 5.
- The order E-mail **License request** opens:




Figure 62: Example: Order E-Mail License request

- The order e-mail **License request** contains:
  - the **E-mail...** of the selected subsidiary a,
  - the automatically generated **XML file** b *EmailOrderRequest\_[Devicenumbr][Serialnumber].xml* with a summary info of the **order information**,
  - the **Order Address** c,
  - the **License Information** d,
  - the **License Type** e,
  - the **Device Data** f,
  - the **ordered Licenses** g.
- Send the order e-mail **License request**.
- The order process is complete.

### 6.8.7.2 Ordering the License by Fax or by Telephone

You can place your order by Fax or by Telephone.



Figure 63: License Pane - placing the order by Fax or by Telephone

- Click **Print Fax Form** ⑥ or **Telephone...** ⑦.
- The summary of the ordering data *PrintOrderRequest\_[Devicenum-ber]\_[Serialnumber].html* is opened in a browser window.



**Note:** If your browser does not display the order data or the window **Move Element** or **Copy Element** are displayed, check the safety settings of your system.

### netX License Order Form

Doe Example LTD  
2000th Rd

NY 11417  
U. S.  
fax: +11223344-100

#### Licensee Information ④

<i>First Name:</i>	John
<i>Surname:</i>	Doe
<i>e-Mail:</i>	License@doe.com
<i>Telephone:</i>	0011223344-55
<i>Fax:</i>	0011223344-100
<i>Customer No:</i>	123456789
<i>Company:</i>	Doe Example LTD
<i>Address:</i>	2000th Rd
<i>Country:</i>	U. S.
<i>City Zip:</i>	NY 11417
<i>Order Number:</i>	987654321
<i>Tax Ident. Number:</i>	test

#### License Type ⑤

User Single Device License

#### Device Information ⑥

<i>Manufacturer:</i>	0x0001
<i>Device Number:</i>	1251100
<i>Serial Number:</i>	20007
<i>Chip Type:</i>	0x00000001
<i>Step:</i>	0x00000000
<i>Romcode Revision:</i>	0x00000000
<i>License Flags 1:</i>	0x7f
<i>License Flags 2:</i>	0x0

#### Ordered Licenses ⑦

*Master Protocols*

- One General Master License
- Sercos III Master

*Utilities*

- SYCON.net

Date: \_\_\_\_\_

Signature: \_\_\_\_\_

Figure 64: Example: Order Data Form *PrintOrderRequest*



- The order data form contains:
- the **Order Address** <sup>c</sup>,
- the **License Information** <sup>d</sup>,
- the **License Type** <sup>e</sup>,
- the **Device Data** <sup>f</sup>,
- the **ordered Licenses** <sup>g</sup>.
- Print the order data form, sign it and send it by Fax.



Figure 65: License Pane – Fax Number of the selected Subsidiary

- Use the Fax number <sup>10</sup>, which is displayed after the subsidiary was selected in the **License** pane.

Or:

- Keep ready the order data form and communicate the order data via telephone.




Figure 66: License Pane – Telephone Number of the selected Subsidiary

- Use the telephone number <sup>11</sup>, which is displayed after the subsidiary was selected in the **License** pane.
- The order process is complete.

### 6.8.7.3 Exporting License Request to a File

If you are working on a process computer without an e-mail client, you can export your order information to a file, save the file to a removable disk and place your order manually via e-mail from a different PC.



Figure 67: License Pane - Ordering by exported File and E-Mail

- Click **Export License Request...** 8.
- The window **Browse For Folder** is displayed.
- Choose for or create a new folder on a removable disk.
- Save the automatically generated **XML file** *EmailOrderRequest\_- [Devicenumbrer]\_[Serialnumber].xml* with a summary info of the **order information** to this folder.
- Send this file from a PC with an e-mail client manually via e-mail.
- Therefore, use an e-mail address, which is displayed after the subsidiary was selected in the **License** pane (see Position 9 Figure *License Pane*).
- The order process is complete.

## 6.8.8 How to get the License and transfer it to the Device



**Note:** License files can only be delivered via e-mail. The e-mail contains a link to download the license file.

According to the license you ordered, you will receive an e-mail containing a **Link to download the License File**. This leads to a server PC on which the license file is provided. Using the received link you will have to save the license file on your PC and then transfer the license to your device. If your e-mail client is on another PC as your device, you must save your license file e. g. to an USB stick.

### Steps how to proceed


1. Save the license file to a PC or a disk.
  - Click to the **Link to download the License File** in the e-mail.
  - Save the license file \*.nxl to a PC or a removable disk.
2. Download the license file to the device.
  - Respectively connect the removable disk with the license file to the PC, which is connected to your device.
  - Click **Download License**  in the **License** pane in the configuration software.



Figure 68: License Pane - Download License

- The File selection window **Open** is displayed.
    - Therein select the license file *netX License Files (\*.nxl)*.
    - Click **Open**.
  - The license file is transferred to the device.
  - After this the license is present in the device and is activated with the next device reset.
3. Activate Device Reset



**Hint:** To activate the license in the first device, a device reset is required.

- To check whether the license has been activated, follow the steps in section *Which Licenses are present in the Device?*

## 7 Diagnosis

### 7.1 Overview Diagnosis

The dialog **Diagnosis** serves to diagnose the device behavior and communication errors. For diagnosis the device must reside in online state.

#### Diagnosis Panes

The table below gives an overview for the individual **Diagnosis** dialog panes descriptions:


DeviceNet Master DTM	Folder Name / Section	Manual Page
	<i>General Diagnosis</i>	109
	<b>Fehler! Kein gültiges Resultat für Tabelle.</b>	111
	<i>Bus Diagnosis</i>	112
	<i>Station Diagnosis</i>	115
	<i>Firmware Diagnosis</i>	116
<i>Navigation Area - Diagnosis</i>		

Table 29: Descriptions of the Diagnosis Panes

#### Online Connection to the Device



**Note:** Accessing the **Diagnosis** panes of the DeviceNet Master DTM requires an online connection from the DeviceNet Master DTM to the DeviceNet Master device. For further information refer to section *Connecting/Disconnecting Device* on page 73.



**Important:** For a 2-channel device channel 1 or channel 2 each must be connected to the DTM separately.

#### How to proceed

1. In the Master DTM diagnosis dialog check whether the communication is OK:

**Diagnosis > General Diagnosis > Device status "Communication"** must be green!

2. **"Communication"** is green: Open the **IO Monitor** and test the input or output data..
3. **"Communication"** is not green: Use **Diagnosis** and **Extended diagnosis** for troubleshooting.

#### Extended Diagnosis

The **Extended Diagnosis** helps to find communication and configuration errors, when default diagnosis fails. For further information refer to section *Overview Extended Diagnosis* on page 117.

## 7.2 General Diagnosis

Information regarding the Device State and other general diagnosis parameters are displayed in the **General Diagnosis** dialog.

**General Diagnosis**

**Device state**

- ☐ Communication
- ☒ Run
- ☐ Ready
- ☐ Error

**Network state**

- ☒ Operate
- ☐ Idle
- ☐ Stop
- ☐ Offline

**Configuration state**













- ☐ Configuration locked
- ☐ New configuration pending
- ☐ Reset required
- ☒ Bus ON

Communication error:

Watchdog time:

Error count:

Figure 69: General Diagnosis

LED	Meaning	Color	State
Device State			
Communication	Shows whether the DeviceNet device executes the network communication.	 (green)	In COMMUNICATION state
		 (gray)	Not in COMMUNICATION state
Run	Shows whether the DeviceNet device has been configured correctly.	 (green)	Configuration OK
		 (gray)	Configuration not OK
Ready	Shows whether the DeviceNet device has been started correctly. The DeviceNet device waits for a configuration.	 (yellow)	Device READY
		 (gray)	Device not READY
Error	Shows whether the DeviceNet device records a device status error. For further information about the error characteristics and the number of counted errors refer to the extended diagnosis.	 (red)	ERROR
		 (gray)	No ERROR
Network State			
Operate	Shows whether the DeviceNet device is in data exchange. In a cyclic data exchange the input data or the output data of the DeviceNet Master are transmitted to the DeviceNet Slave.	 (green)	In OPERATION state
		 (gray)	Not in OPERATION state
Idle	Shows whether the DeviceNet device is in idle state.	 (yellow)	In IDLE state
		 (gray)	Not in IDLE state













LED	Meaning	Color	State
Stop	Shows whether the DeviceNet device is in Stop state: There is no cyclic data exchange at the DeviceNet network. The DeviceNet device was stopped by the application program or it changed to the Stop state because of a bus error.	 (red)	In STOP state
		 (gray)	Not in STOP state
Offline	The DeviceNet Master is offline as long as it does not have a valid configuration.	 (yellow)	In OFFLINE state
		 (gray)	Not in OFFLINE state
Configuration State			
Configuration locked	Shows whether the DeviceNet device configuration is locked, to avoid the configuration data are typed over.	 (yellow)	Configuration LOCKED
		 (gray)	Configuration not LOCKED
New Configuration pending	Shows whether a new DeviceNet device configuration is available.	 (yellow)	New Configuration pending
		 (gray)	No new Configuration pending
Reset required	Shows whether a firmware reset is required as a new DeviceNet device configuration has been loaded into the device.	 (yellow)	RESET required
		 (gray)	No RESET required
Bus ON	Shows whether the bus communication was started or stopped. I. e., whether the device is active on the bus or no bus communication to the device is possible and no response telegrams are sent.	 (green)	Bus ON
		 (gray)	Bus OFF

Table 30: Indication General Diagnosis

Parameter	Meaning
Communication Error	Shows the name of the communication error. If the cause of error is resolved, the value will be set to zero again.
Watchdog time	Shows the watchdog time in ms.
Error Count	This field holds the total number of errors detected since power-up, respectively after reset. The protocol stack counts all sorts of errors in this field no matter whether they were network related or caused internally.

Table 31: Parameter General Diagnosis

## 7.3 Master Diagnosis

Information regarding the Slave State, slave errors and slaves configured, active or in diagnostic are displayed in the **Master Diagnosis** dialog.

Master Diagnosis	
Slave state	failed
Slave error log indicator	available
Configured slaves	2
Active slaves	0
Slaves with diagnostic	2

Figure 70: Master Diagnosis

Parameter	Meaning	Range of Value / Default Value
Slave state	Shows whether slave state is ok or not. The Slave state field for Master diagnosis shows whether the Master is in cyclic data exchange to all configured slaves. In case there is at least one slave missing or if the slave has a diagnostic request pending, the status will be set to FAILED. For protocols that support non-cyclic communication only, the slave state is set to OK as soon as a valid configuration is found.	UNDEFINED, OK, FAILED
Slave error log indicator	Shows whether the Slave Error Log Indicator is available. The error log indicator field holds the number of entries in the internal error log. If all entries are read from the log, the field will be set to zero.	EMPTY, AVAILABLE
Configured slaves	Shows number of configured slaves. Number of configured slaves in the network according to the slave list derived from the configuration database created by the configuration software . The list includes the slaves to which the Master has to open a connection.	
Active slaves	Shows number of active slaves. Number of slaves in data exchange mode. The list includes the slaves to which the Master has successfully opened a connection.	
Slaves with diagnostic	Shows number of slaves with diagnostic. Number of Slaves with diagnosis or error slaves.	

Table 32: Parameter Master Diagnosis

## 7.4 Bus Diagnosis




Figure 71: Bus Diagnosis - Bus Monitoring



## 7.4.1 Master Status




Figure 72: Bus Diagnosis - Master Status

The **Master Status** shows individual bus errors. A pending error is displayed by a red LED. The meaning of the individual errors is described in the following:















LED	Meaning	Color	State
<b>Bus Diagnosis - Master Status</b>			
<b>DMAC</b>	The DUPLICATE-MAC-ID indicates that the Master has found another device in the network which has the same MAC ID.	 (red)	DUPLICATE-MAC-ID found
		 (gray)	no DUPLICATE-MAC-ID found
<b>PDUP</b>	The DUPLICATE-MAC-ID check is performed. As long this bit is set; the Master is involved in handling the duplicate MAC-ID check.	 (red)	DUPLICATE-MAC-ID check is performed
		 (gray)	DUPLICATE-MAC-ID check is not performed
<b>Not Ready</b>	<b>HOST-NOT-READY</b> shows, that the application program has not started or it has stopped the DeviceNet Master.	 (red)	HOST-NOT-READY
		 (gray)	HOST-READY
<b>Auto Clear</b>	The <b>AUTO-CLEAR-ERROR</b> displays, that device has stopped the communication to all Slaves and it has reached the auto-clear end state.	 (red)	AUTO-CLEAR-ERROR
		 (gray)	no AUTO-CLEAR-ERROR
<b>Slave Error</b>	The <b>NON-EXCHANGE-ERROR</b> shows, that at least one Slave is not in the cyclic data exchange with the DeviceNet Master.	 (red)	NON-EXCHANGE-ERROR
		 (gray)	no NON-EXCHANGE-ERROR
<b>Fatal Error</b>	A <b>FATAL-ERROR</b> has occurred. Because of a heavy bus error no further bus communication is possible.	 (red)	FATAL-ERROR
		 (gray)	no FATAL-ERROR
<b>Control Error</b>	The <b>CONTROL-ERROR</b> displays that a parameterization error has occurred.	 (red)	CONTROL-ERROR
		 (gray)	no CONTROL-ERROR

Table 33: Bus Diagnosis - Master Status

## 7.4.2 Server Status




Figure 73: Bus Diagnosis - Server Status





LED	Meaning	Color	State
<b>Bus Diagnosis - Server Status</b>			
<b>Poll I/O Connection</b>	Indicates, that the Master as server has build up a Poll I/O Connection.	 (red)	Poll I/O Connection
		 (gray)	no Poll I/O Connection
<b>Explicit Connection</b>	Indicates, that the Master as server has build up an Explicit Connection.	 (red)	Explicit Connection
		 (gray)	no Explicit Connection

Table 34: Bus Diagnosis - Server Status

## 7.4.3 Bus Monitoring




Figure 74: Bus Diagnosis - Bus Monitoring



LED	Meaning	Color	State
<b>Bus Diagnosis - Bus Monitoring</b>			
<b>Event</b>	The used CAN chip has detected transmission errors. The number of detected events is counted in the CAN bus off counter and the CAN active to passive counter. The bit will be set when the first event was detected and will not be deleted until the Master is reset.	 (red)	EVENT (transmission errors detected)
		 (gray)	no EVENT (no transmission errors detected)
<b>CAN active to passive counter</b>	This value indicates a bad transmission quality at the CAN bus. This counter is based on a Transmission Rejected Error of the CAN chip, which is always reported, whenever an increased number of faulty CAN frames were detected.	-	-
<b>CAN bus off counter</b>	This counter counts the number of reported bus off events. A bus off event occurs whenever the CAN bus was disturbed substantially during the transmission of CAN frames and therefore the communication chip has to withdraw itself from the bus.	-	-

Table 35: Bus Diagnosis - Bus Monitoring

## 7.5 Station Diagnosis




Figure 75: Station Diagnosis - Station Status

Under **Station Status** all disposal station addresses (0-63) and their states are shown as LED. If a connection to the device exists, the DTM updates this display cyclically.

The legend below describes the possible values for the state of a device, which is assigned to a station address.

Color	Name	Meaning
gray	Not configured	This station address is not configured with a device.
green	Running	The device associated with this station address is running.
yellow	Diagnosis	Diagnosis is available for the device associated with this station address.
blue	Not found	The device associated with this station address was parameterized, but not found.
red	Error	An error message is available for the device associated with this station address.

Table 36: Possible Values for the Status

## 7.6 Firmware Diagnosis

In the dialog **Firmware Diagnosis** the current task information of the firmware is displayed.

Under **Firmware** or **Version** the name of the firmware and version (including the date) are indicated.

Firmware Diagnosis					
Firmware:	<b>Firmware Name*</b>				
Version:	2.2.0 (Build 2)				
Date:	1.2.2010				
Task information:					
Task	Name of task	Version	Prio...	Description	State
0	RX_IDLE	1.0	63	RX IDLE Task.	Task Status ok. (0x00000000)
1	RX_TIMER	0.0	1	The task identifie...	Task Status ok. (0x00000000)
2	RX_SYSTEM	1.16	8	Middleware Syste...	Task Status ok. (0x00000000)
3	DPM_COM0...	1.0	50	TLR-Router DPM.	Task Status ok. (0x00000000)
4	DPM_COM0...	1.0	51	TLR-Router DPM.	Task Status ok. (0x00000000)
5	TLR_TIMER	0.0	31	The task identifie...	Task Status ok. (0x00000000)
6	CAN_DL	1.2	28	CAN DL Task (Dat...	Task Status ok. (0x00000000)
7	DEVNET_FAL	1.0	30	DeviceNet FAL Ta...	Task Status ok. (0x00000000)
8	DEVNET_AP	1.1	27	DeviceNet AP Tas...	0xC0000101 (0xC0000101)

Figure 76: Firmware Diagnosis (\*The name of the Firmware is displayed.)

### Task Information:

The table **Task Information** is listing the task information of the single firmware tasks.

Column	Meaning
Task	Task number
Name of task	Name of the task
Version	Version number of the task
Prio	Priority of the task
Description	Description of the task
Status	Current status of the task

Table 37: Description Table Task Information

## 8 Extended Diagnosis

### 8.1 Overview Extended Diagnosis

The **Extended Diagnosis** of the DeviceNet Master DTM helps to find communication and configuration errors. Therefore it contains a list of diagnosis structures as online counter, states and parameters.

#### Dialog Panes “Extended Diagnosis”

The table below gives an overview for the **Extended Diagnosis** dialog panes descriptions:


DeviceNet Master DTM	Folder Name / Section	Subsection	Manual Page
	RX-SYSTEM	Task Info	118
		IniBatch Status	119
	DPM_COM0_SMBX□	Task Info	118
	DPM_COM0_RMBX	Task Info	118
	CAN_DL	Task Info	118
		App Commands	120
		CAN Driver Status	121
	DEVNET_FAL	Task Info	118
		Application Diagnosis	122
		Device Status	123
		Diagnosis Error	124
		Timeout Counter	124
		Reinit Counter	125
		DeviceNet CAN Diagnosis	125
	DEVNET_AP	Task Info	118
	MARSHALLER	Task Info	118
	PACKET_ROUTER	Task Info	118

Table 38: Descriptions of the Dialog Panes Extended Diagnosis

#### Online Connection to the Device



**Note:** Accessing the **Extended Diagnosis** dialog panes of the DeviceNet Master DTM requires an online connection from the DeviceNet Master DTM to the DeviceNet Master device. For further information refer to section *Connecting/Disconnecting Device* on page 73.

## 8.2 Task Info

Task Info	
Task states	
Name	Value
Id	
Major Ver.	<i>[The displayed values depend from the corresponding task]</i>
Minor Ver.	
Max Packet Size	
Default Que	
Unique Id	
Init result	

Figure 77: Extended Diagnosis > [Folder Name] > Task Info, Example Display

Name	Description
Id	Identification number of the task
Major Ver.	Task version, contains incompatible changes
Minor Ver.	Task version, contains compatible changes
Max Packet Size	Maximum packet size, which the task sends
Default Que	Queue handle, which is accessible via DPM by mailbox.
Unique Id	Unique user ID, 16 Byte indicator used for task identification and its affiliation e. g. to a stack (therein different identification data are coded in).
Init result	Error Code, 0= no Error  The description of the error codes can be found in this manual or in the corresponding software reference manuals.

Table 39: Extended Diagnosis > [Folder Name] > Task Info

## 8.3 IniBatch Status

IniBatch-Status	
Task states	
Name	Value
Communication Channel	0
Current State	Error
IniBatch Result	No DBM file
OpenDbm Result	24975
SendPacket Result	0
Confirmation Result	0
Last Packet Number	0
Last Packet Command	0
Last Packet Length	0
Last Packet Destination	0

Figure 78: Extended Diagnosis > [Folder Name] > IniBatch Status Example Display

Name	Description
Communication Channel	Number of the communication channel used by the device.
Current State	Idle; IniBatch packets in progress; Retrying to send last packet; Error
IniBatch Result	Ok; No DBM file; No Packet table; No data set available; Data set is shorter than packet length; Packet Buffer is shorter than Packet length; Invalid packet destination; Logical queue not defined Send packet failed; Too many retries; Error in confirmation packet status
OpenDbm Result	Error when opening the IniBatch data base Under "OpenDbm Result" the error code is typed in, when "IniBatch Result" == "No DBM file" (1) is.
SendPacket Result	Error when sending a packet Under "SendPacket Result" the error code is typed in, when "IniBatch Result" == "send packet failed" (8) is.
Confirmation Result	Confirmation error when sending packets Under "Confirmation Result" the packet specific error code from the ulSta is typed in, when "IniBatch Result" == "Error in confirmation packet status" (10) is.
Last Packet Number	Value depends by the communication system.
Last Packet Command	Value depends by the communication system.
Last Packet Length	Value depends by the communication system.
Last Packet Destination	Value depends by the communication system.

Table 40: Extended Diagnosis > [Folder Name] > IniBatch Status

The task status "Confirmation Result" is bus specific. The other task statuses are rcx-related error codes.

## 8.4 CAN\_DL

### 8.4.1 App Commands

App Commands	
Task states	
Name	Value
Data Req	0
Pos Cnf	0
Neg Cnf	0
Can DL Ind	0
Can DL Res	0
Can DL Start Req	3
Pos Start Cnf	3
Neg Start Cnf	0
Stop Req	9
Pos Stop Cnf	9
Neg Stop Cnf	0
App Reg Req	3
Pos App Reg Cnf	3
Neg App Reg Cnf	0
Set Param Req	3
Pos Set Param Cnf	3
Neg Set Param Cnf	0
Set Filter Req	0
Pos Set Filter Cnf	0
Neg Set Filter Cnf	0
Enable Rx Id Req	13
Pos Enable Rx Id Cnf	13
Neg Enable Rx Id Cnf	0
Event Ind	3
Event Res	3
Event Ack Req	0
Pos Event Cnf	0
Neg Event Cnf	0
TX Abort Req	0
Pos TX Abort Cnf	0
Neg TX Abort Cnf	0
Init Req	4
Pos Init Cnf	4
Neg Init Cnfs	0
Hi Priority Data Req	0
Pos Hi Priority Data Cnf	0
Neg Hi Priority Data Cnf	0

Figure 79: Extended Diagnosis > CAN\_DL > App Commands

Name	Description
[Service]	Diagnosis counter of the CAN layer. Indicates the services processed. (The services of the single packets are described in the API manual.)

Table 41: Extended Diagnosis > CAN\_DL > App Commands



## 8.4.2 CAN Driver Status

CAN Driver Status	
Task states	
Name	Value
Can Status	0x00010000
Bus Off	false
Error Warning	false
Error Passive	false
Reserved	false
Reserved	false
Reserved	false
Reserved	false
Reserved	false
Reserved	false
Reserved	false
Reserved	false
Reserved	false
Reserved	false
Reserved	false
24 Volt Network Error	true
TX Frame OK	0
TX Error Summary	0
RX Frame OK	0
RX Error Summary	0
TX Error Counter	0
RX Error Counter	0
Arbitration Lost	0
Ind Dropped (Fifo full)	0
Cnf Dropped (Fifo full)	0
RX Std Frames Filtered	0
RX Ext Frames Filtered	0
RX Std Frames Passed	0
RX Ext Frames Passed	0

Figure 80: Extended Diagnosis > CAN\_DL > CAN Driver Status

Name	Description	
CAN Status	collection bits for Bus Off, Error Warning and Error Passive	Diagnosis status of CAN specific error levels. Indicates the respective status of the CAN bus. (For further information refer to the API manual.)
Bus Off	true / false CAN status - The CAN is in Bus Off state	
Error Warning	true / false Error Warning - The CAN is in the status Error Warning	
Error Passive	true / false Error Warning - The CAN is in Error Passive	
Reserved	true / false Status or Error message	
24 Volt Network Error	true / false - 24 Volt Network Error - The CAN is in 24 Volt Network Error	
[Service]	Diagnosis counter of CAN errors. Indicates the services processed. (The services of the single packets are described in the API manual.)	

Table 42: Extended Diagnosis > CAN\_DL > CAN Driver Status

## 8.5 DEVNET\_FAL

### 8.5.1 Application Diagnosis


Application Diagnosis	
Task states	
Name	Value
Register Application Request	0
Positive Register Application Confirmation	1
Negative Register Application Confirmation	0
Initialisation Requests	0
Positive Initialisation Confirmation	0
Negative Initialisation Confirmation	0
Download Request	0
Positive Download Confirmation	0
Negative Download Confirmation	0
Clear Configuration Request	0
Positive Clear Configuration Confirmation	0
Negative Clear Configuration Confirmation	0
Mode Change Indication	0
Mode Change Response	0
Set Mode Request	0
Positive Set Mode Confirmation	0
Negative Set Mode Confirmation	0
Set Output Request	0
Positive Set Output Confirmation	0
Negative Set Output Confirmation	0
Get Input Request	0
Positive Get Input Confirmation	0
Negative Get Input Confirmation	0
Slave Diagnosis Response	0
Get Slave Diagnosis Request	0
Positive Get Slave Diagnosis Confirmation	0
Negative Get Slave Diagnosis Confirmation	0
Get Attribute Request	0
Positive Get Attribute Confirmation	0
Negative Get Attribute Confirmation	0
Set Attribute Request	0
Positive Set Attribute Confirmation	0
Negative Set Attribute Confirmation	0
Abort Request	0
Positive Abort Confirmation	0
Negative Abort Confirmation	0
Get Set Attribut Indication	0
Get Set Attribut Resonse	0
Get Set Attribut Response Request	0
Positive Get Set Attribut Resonse Confirmation	0
Negative Get Set Attribut Resonse Confirmation	0
New Input Indication	0
New Input Response	0
End Process Request	0
Unknown Command	0
Last Unknown Command	0

Figure 81: Extended Diagnosis > DEVNET\_FAL > Application Diagnosis

Name	Description
[Service]	Diagnosis counter of the FAL layer. Indicates the services processed. (The services of the single packets are described in the API manual.)

Table 43: Extended Diagnosis > DEVNET\_FAL > Application Diagnosis

## 8.5.2 Device Status



The screenshot shows a window titled 'Device Status'. Inside, there is a section labeled 'Task states' containing a table with two columns: 'Name' and 'Value'. The table lists five device states, each with a value of 'S000'. A vertical scrollbar is visible on the right side of the table.

Name	Value
Device 0 State	S000
Device 1 State	S000
Device 2 State	S000
Device 3 State	S000
Device 4 State	S000

Figure 82: Extended Diagnosis > DEVNET\_FAL > Device Status

Name	Description
[Status]	Diagnosis status of the single devices. Indicates the current status of the single devices. (For further information refer to the API manual.)

Table 44: Extended Diagnosis > DEVNET\_FAL > Device Status

### 8.5.3 Diagnosis Error

Diagnosis Error	
Task states	
Name	Value
Diagnosis Error Device 0	0
Diagnosis Error Device 1	0
Diagnosis Error Device 2	0
Diagnosis Error Device 3	0
Diagnosis Error Device 4	0

Figure 83: Extended Diagnosis > DEVNET\_FAL > Diagnosis Error

Name	Description
[Error Code]	Error codes of the device diagnosis. Indicates the error codes by each device. (For further information refer to the API manual.)

Table 45: Extended Diagnosis > DEVNET\_FAL > Diagnosis Error

### 8.5.4 Timeout Counter

Timeout Counter	
Task states	
Name	Value
Timeout Counter Device 0	0
Timeout Counter Device 1	0
Timeout Counter Device 2	0
Timeout Counter Device 3	0
Timeout Counter Device 4	0

Figure 84: Extended Diagnosis > DEVNET\_FAL > Timeout Counter

Name	Description
[Service]	Diagnosis counter for device timeout. Indicates the number of timeouts for each device. (For further information refer to the API manual.)

Table 46: Extended Diagnosis > DEVNET\_FAL > Timeout Counter

### 8.5.5 Reinit Counter

Reinit Counter	
Task states	
Name	Value
Reinitialisation Counter Device 0	0
Reinitialisation Counter Device 1	0
Reinitialisation Counter Device 2	0
Reinitialisation Counter Device 3	0
Reinitialisation Counter Device 4	0

Figure 85: Extended Diagnosis > DEVNET\_FAL > Reinit Counter

Name	Description
[Service]	Diagnosis counter for device reinitialization. Indicates the number of reinitialization for each device. (For further information refer to the API manual.)

Table 47: Extended Diagnosis > DEVNET\_FAL > Reinit Counter

### 8.5.6 DeviceNet CAN Diagnosis

DeviceNet CAN Diagnosis	
Task states	
Name	Value
Bus State	0
Receive CAN Frame	0
Transmitted CAN Frame	0
Bus Off Counter	0
Error Passive Counter	0
Error Warning Counter	0

Figure 86: Extended Diagnosis > DEVNET\_FAL > DeviceNet CAN Diagnosis

Name	Description
Bus State	Status of the CAN bus
Receive CAN Frame	Counter for received CAN frames
Transmitted CAN Frame	Counter for transmitted CAN frames
Bus Off Counter	Status level error counter for „Off“ [2]
Error Passive Counter	Status level error counter for „Passive“ [2]
Error Warning Counter	Status level error counter for „Warning“ [2]

Table 48: Extended Diagnosis > DEVNET\_FAL > DeviceNet CAN Diagnosis

## 9 Tools

### 9.1 Overview Tools

Under **Tools** the Packet Monitor and the IO Monitor are provided for test and diagnosis purposes.

#### Tools Panes

The table below gives an overview for the individual **Tools** dialog panes descriptions:


DeviceNet Master DTM	Folder Name / Section	Manual Page
 <p>Navigation Area - Tools</p>	Packet Monitor	127
	IO Monitor	144
	Process Image Monitor	145

Table 49: Descriptions of the Diagnosis Panes

#### Online Connection to the Device



**Note:** Accessing the **Tools** dialog panes of the DeviceNet Master DTM requires an online connection from the DeviceNet Master DTM to the DeviceNet Master device. For further information refer to section *Connecting/Disconnecting Device* on page 73.

## 9.2 Packet Monitor

The **Packet Monitor** serves for test and diagnosis purposes.

Data packets, i. e. messages are self-contained blocks of defined data length. The packets are used to communicate with the firmware and they are exchanged between the application (configuration software) and the firmware in the device. Packets can be sent once or cyclically to the connected device controlled by the user and packets received can be displayed.

Data packets comprise from a **Packet Header** and the **Send Data** or from a **Packet Header** and the **Receive Data**. The packet header can be evaluated by the receiver of the packet and contain the sender and receiver address, the data length, an ID number, status and error messages and the command or response code. The minimum packet size amounts 40 Byte for the packet header. The sending and receiving data are added.



For further information to the packet description refer to the *Protocol API Manual*.

- Open the **Packet Monitor** via **Tools > Packet Monitor**.

Figure 87: Packet Monitor

**Display Mode** switches the representation of the send and reception data between decimal and hexadecimal.

- Select **Reset Counter** to reset the packet counter.

## 9.2.1 Sending Packet

The screenshot shows the 'Send' dialog box with two main sections: 'Packet header' and 'Send data'.

**Packet header:**

- Dest: 00000001
- Src: 00000000
- Dest ID: 00000000
- Src ID: 00000000
- Len: 00000012
- ID: 00000001
- State: 00000000
- Cmd: 00002F00
- Ext: 00000000
- Rout: 00000000
- Auto Increment ID: ☒

**Send data:**

Counter: 0

	0	1	2	3	4	5	6	7	8	9
0										
10										
20										
30										
40										
50										
60										

Buttons: Put cyclic, Put packet

Figure 88: Send > Packet Header and Send Data

### Packet Header

Under **Send > Packet Header** the elements of the packet header of the sending packet are displayed, which is transmitted from the application (configuration software) to the device. The packet header of the sending packets contain the elements described in the following table.

Element		Description
<b>Dest</b>	Destination Queue Handle	Contains the identifier of the receiver for the packet (destination task queue of the firmware).
<b>Src</b>	Source Queue Handle	Contains the identifier of the sender of the packet (sending task).
<b>Dest ID</b>	Destination Queue Reference	Contains an identifier for the receiver of unsolicited sent packets from the firmware to the application (configuration software).
<b>Src ID</b>	Source Queue Reference	Contains an identifier of the sender.
<b>Len</b>	Packet Data Length (in Bytes)	Length of the send respectively receive data.
<b>ID</b>	Packet Identification As Unique Number	Identifies identical data packets among each other.
<b>State</b>	Status / Error Code	Transmits status or error codes to the packet sender.
<b>Cmd</b>	Command / Response Code	Command or respond code.
<b>Ext</b>	Extension	Field for extensions (reserved).
<b>Rout</b>	Routing Information	Internal value of the firmware.

Table 50: Descriptions Packet Header

- Under **Dest** select the receiver (*destination task queue*).
- Under **Cmd** select the command identification (*Request*).

**Auto Increment ID** is an increment for the identifier of the data packets and increments the ID by 1 for each newly sent packet.

### Send Data

- Under **Send > Send data** enter the send data of the packet, which shall be transmitted from the application (configuration software) to the mailbox of the device. The meaning of the transmitted data depends on the command or response code.



### **Sending Packets once or cyclic**

- To send packet once, select **Put packet**.
- To send packet cyclic, select **Put cyclic**.

## **9.2.2 Receiving Packet**

The screenshot shows a software interface for receiving packets. On the left, under the 'Receive' tab, is the 'Packet header' section with the following fields:

- Dest: 00000001
- Src: 00000000
- Dest ID: 00000000
- Src ID: 00000000
- Len: 00000012
- ID: 0000003E
- State: 00000000
- Cmd: 00002F01
- Ext: 00000000
- Rout: 00000000

On the right, under 'Receive data:', there is a 'Counter: 0' and a table of data bytes. The table has columns 0 through 9 and rows 0 through 60. The data shown is:

	0	1	2	3	4	5	6	7	8	9
0	00	00	00	00	00	00	00	00	00	04
10	00	00	01	00	01	00	00	00		
20										
30										
40										
50										
60										

Figure 89: Packet Header and Receive Data

### **Packet Header**

Under **Receive > Packet Header** the elements of the packet header of the receiving packet are displayed, which are transmitted back from the device to the application (configuration software). The packet header of the receiving packets contain the elements described in the following table.

Element		Description
<b>Dest</b>	Destination Queue Handle	Contains the identifier of the receiver for the packet (destination task queue of the firmware).
<b>Src</b>	Source Queue Handle	Contains the identifier of the sender of the packet (sending task).
<b>Dest ID</b>	Destination Queue Reference	Contains an identifier for the receiver of unsolicited sent packets from the firmware to the application (configuration software).
<b>Src ID</b>	Source Queue Reference	Contains an identifier of the sender.
<b>Len</b>	Packet Data Length (in Bytes)	Length of the send respectively receive data.
<b>ID</b>	Packet Identification As Unique Number	Identifies identical data packets among each other.
<b>State</b>	Status / Error Code	Transmits status or error codes to the packet sender.
<b>Cmd</b>	Command / Response Code	Command or respond code.
<b>Ext</b>	Extension	Field for extensions (reserved).
<b>Rout</b>	Routing Information	Internal value of the firmware.

Table 51: Descriptions Packet Header

### **Receive Data**

Under **Receive > Receive Data** the receiving data of the packet, which is transmitted back from the device to the application (configuration software) are displayed.

### 9.2.3 Example – Reading Data via „Get Attribute“

To **read** data from a Slave device via „**Get Attribute**“ using the packet monitor, you must proceed as described below. The single steps are explained with help of sample data.



For more information on the steps under **Settings** and **Configuration** refer to the corresponding chapters in this manual. Required information is easy to find via the overview in the section *Configuration Steps* on page 24.

#### **Requirements**

The function **DeviceNet - read data „Get Attribute“** can only be used, if:

- The used Master and Slave devices support the „**Get Attribute**“ function.
- The used Master and Slave devices are configured. I. e., in the Slave configuration under **General Settings** the **UCMM** must be unchecked where required.
- The used Master and Slave devices are operational.

#### **How to proceed**

1. In the Master DTM under **Settings**:

- Select the cifX device driver and assign the Master device.

Alternative to the connection via the cifX device driver via the netX driver an USB, serial or TCP connection can be used.

2. In the Slave DTM **Configuration**:

- In the **General Settings** examine **UCMM** and uncheck when the Slave device does not support UCMM.

The documentation for the device will indicate if **UCMM** can be used or not.

### Packet Description Read Request

structure DN_FAL_PACKET_GET_ATT_REQ_T				
Type: Request				
Area	Variable	Type	Value / Range	Description
tHead	structure TLR_PACKET_HEADER_T			
	(A) ulDest	UINT32		Destination Queue-Handle
	ulSrc	UINT32		Source Queue-Handle of AP-Task Process Queue
	ulDestId	UINT32	0	Destination End Point Identifier, specifying the final receiver of the packet within the Destination Process. Set to 0 for the Initialization Packet
	ulSrcId	UINT32	0 ... $2^{32}-1$	Source End Point Identifier, specifying the origin of the packet inside the Source Process
	ulLen	UINT32	12	DN_FAL_GETSET_ATT_REQ_SIZE
	ulId	UINT32	0 ... $2^{32}-1$	Packet Identification as unique number generated by the Source Process of the Packet
	ulSta	UINT32	0	Set to zero
	(C) ulCmd	UINT32	0x380A	DEVNET_FAL_CMD_GET_ATT_REQ - Command
	ulExt	UINT32	0	Extension not in use, set to zero for compatibility reasons
	ulRout	UINT32	0	Routing, set to zero
tData	structure DN_FAL_SDU_GETSET_ATT_REQ_T			
	(D) bDeviceAddr	UINT8	0-63	Device address, MAC-ID of device to be addressed
	(E) abReserved[3]	UINT8[]	0	Reserved zero
	(F) usClass	UINT16	0 ... $2^{16}-1$	Class ID
	(G) usInstance	UINT16	0 ... $2^{16}-1$	Instance ID
	(H) usAttribute	UINT16	0 ... $2^{16}-1$	Attribute ID
	(I) usReserved	UINT16	0	Set to zero
	abAttData[0 .. 511]	UINT8[]	0	Attribute Data not used in request

Figure 90: Packet Description DEVNET\_FAL\_CMD\_GET\_ATT\_REQ - Get Attribute Request



Further information on the packet description for this example is comprised in the *DeviceNet Master Protocol API Manual*, in section *DEVNET\_FAL\_CMD\_GET\_ATT\_REQ/CNF – Get Attribute Request* (e. g. *Revision 07* of the API manual, in section 5.2.4.).

1. Open Packet Monitor.
- **Tools > Packet Monitor.**
2. Enter data for Packet header.

### **Send > Packet header**

- Under **Dest** enter or select the receiver.
- Under **Cmd** enter the read command identification.

		<i>Sample Data</i>	
<b>(A)</b>	<b>Receiver</b>	0x20	(Destination Queue Handle)
<b>(C)</b>	<b>Read Command identification</b>	0000380A	DN_FAL_PACKET_GET_ATT_REQ_T (Request)

Send

Packet header

Dest: **(A)** 00000020

Src: 00000000 State: 00000000

Dest ID: 00000000 Cmd: **(C)** 0000380A

Src ID: 00000000 Ext: 00000000

Len: 0000000C Rout: 00000000

ID: 00000002 Auto Increment ID ☐

Figure 91: Example - Reading data via „Get Attribute“ – Send > Packet header

## 3. Enter send data.

**Send > Send Data**

	Range of Value	Sample Data	
<b>(D)</b> Device Address	0 ... 63	01	(for MAC ID 1)
<b>(E)</b> Reserved	0	00 00 00	
<b>(F)</b> Class ID	0 ... $2^{16}-1$	01 00*	(for Class-ID 1)
<b>(G)</b> Instance ID	0 ... $2^{16}-1$	01 00*	(for Instance-ID 1)
<b>(H)</b> Attribute ID	0 ... $2^{16}-1$	06 00*	(for Attribute-ID 6)
<b>(I)</b> Reserved	0	00 00	
	(UINT16 = 2 Bytes)	*Intel format, e. g. LSB first;	

Send data: Counter: 1

	00	01	02	03	04	05	06	07	08	09	
0000	01	00	00	00	01	00	01	00	06	00	
0004	00	00									
0014											
001E											
0028											
0032											
003C											

Put cyclic Put packet

Figure 92: Example - Read data via „Get Attribute“ - Send &gt; Send Data

## 4. Sending/Receiving Packets.

- To send packet once, select **Put packet**.
- The entered values are sent from the packet monitor to the connected Slave device and received packets are displayed.

### Packet Description Read Confirmation

structure DN_FAL_PACKET_GET_ATT_CNF_T				
Type: Request				
Area	Variable	Type	Value / Range	Description
tHead	structure TLR_PACKET_HEADER_T			
	<b>(A)</b> ulDest	UINT32		Destination Queue-Handle
	ulSrc	UINT32		Source Queue-Handle of AP-Task Process Queue
	ulDestId	UINT32	0	Destination End Point Identifier, specifying the final receiver of the packet within the Destination Process. Set to 0 for the Initialization Packet
	ulSrcId	UINT32	0 ... $2^{32}-1$	Source End Point Identifier, specifying the origin of the packet inside the Source Process
	ulLen	UINT32	12 + n	DN_FAL_GETSET_ATT_CNF_SIZE + number of attribute data received
	ulId	UINT32	0 ... $2^{32}-1$	Packet Identification as unique number generated by the Source Process of the Packet
	ulSta	UINT32	0	See section 6.2 Status/Error Codes DevNet FAL – Task
	<b>(C)</b> ulCmd	UINT32	0x380B	DEVNET_FAL_CMD_GET_ATT_CNF - Command
	ulExt	UINT32	0	Extension not in use
	ulRout	UINT32	x	Routing
tData	structure DN_FAL_SDU_GETSET_ATT_CNF_T			
	<b>(D)</b> bDeviceAddr	UINT8	0-63	MAC-ID of the device that was addressed
	<b>(E)</b> abReserved[3]	UINT8	0	Reserved zero
	<b>(F)</b> usClass	UINT16	0 ... $2^{16}-1$	Class ID, returned
	<b>(G)</b> usInstance	UINT16	0 ... $2^{16}-1$	Instance ID, returned
	<b>(H)</b> usAttribute	UINT16	0 ... $2^{16}-1$	Attribute ID, returned
	<b>(K)</b> bGenErr	UINT8	0 .. 255	See Table below
	<b>(L)</b> bAddErr	UINT8	0 .. 255	See Table below
	abAttData[0 .. 512]	UINT8 array	xxx	Attribute Data received

Figure 93: Packet Description DEVNET\_FAL\_CMD\_GET\_ATT\_CNF - Confirmation of Get Attribute Request



Further information on the packet description for this example is comprised in the *DeviceNet Master Protocol API Manual*, in section *DEVNET\_FAL\_CMD\_GET\_ATT\_REQ/CNF – Get Attribute Request* (e. g. *Revision 07* of the API manual, in section 5.2.4.).

## 5. Evaluate received packet.

**Receive > Packet header**

Under **Dest** the receiver is displayed.

Under **State** the status code or possibly an error code is displayed.



All status and error codes are either to be found in this manual via the section *Overview Error Codes* on page 148, in the *Dual Port Memory Manual* or in the *DeviceNet Slave Protocol API Manual*.

Under **Cmd** the response identification read request is displayed.

Receive	
Packet header	
Dest: <b>A</b>	00000020
Src:	00000000
State: <b>B</b>	00000000
Dest ID:	00000000
Cmd: <b>C</b>	0000380B
Src ID:	00000000
Ext:	00000000
Len:	00000010
Rout:	00000000
ID:	00000002

Figure 94: Example - Reading data via „Get Attribute“ – Receive > Packet header

	Sample Data	
<b>A Receiver</b>	0x20	(Destination Queue Handle)
<b>B State</b>	00000000	indicates that the read request could be executed without error. If during the execution of the read request an error was detected, an error code is displayed.
<b>C Response Identification Read Request</b>	0000380B	DN_FAL_PACKET_GET_ATT_CNF_T (Confirmation)

## Receive > Receive data

Under **Receive data** the data of the receive packet are displayed.




Figure 95: Example - Reading data via „Get Attribute“ – Receive > Receive data

		Range of Value	Sample Data	
(D)	<b>Device Address</b>	0 ... 63	01	(for MAC ID 1)
(E)	<b>Reserved</b>	0	00 00 00	
(F)	<b>Class ID</b>	0 ... $2^{16}-1$	01 00*	(for Class ID 1)
(G)	<b>Instance ID</b>	0 ... $2^{16}-1$	01 00*	(for Instance ID 1)
(H)	<b>Attribute ID</b>	0 ... $2^{16}-1$	06 00*	(for Attribute ID 6)
(K)	<b>General Errors</b>	0 ... 255	00	Slave device reports OK, no error
(L)	<b>Additional Errors</b>	0 ... 255	00	Slave device reports OK, no error
(M)	<b>Receive Data</b> (in the example =Serial number)	0 ... $2^{32}-1$  (UINT32 = 4 Bytes)	D2 07 00 00* (=2002)	(4 Bytes)
			*Intel format, e. g. LSB first;	



## 9.2.4 Example – Writing Data via „Set Attribute“

To **write** data to a Slave device via „**Set Attribute**“ using the packet monitor, you must proceed as described below. The single steps are explained with the help of sample data.



For more information on the steps under **Settings** and **Configuration** refer to the corresponding chapters in this manual. Required information is easy to find via the overview in the section *Configuration Steps* on page 24.

### Requirements

The function **DeviceNet - write data „Set Attribute“** can only be used, if:

- The used Master and Slave devices support the „**Set Attribute**“ function.
- The used Master and Slave devices are configured. I. e., in the Slave configuration under **General Settings** the **UCMM** must be unchecked where required.
- The used Master and Slave devices are operational.

### How to proceed

1. In the Master DTM under **Settings**:

- Select the cifX device driver and assign the Master device.

Alternative to the connection via the cifX device driver via the netX driver an USB, serial or TCP connection can be used.

2. In the Slave DTM **Configuration**:

- In the **General Settings** examine **UCMM** and uncheck when the Slave device does not support **UCMM**.

The documentation for the device will indicate if **UCMM** can be used or not.

### Packet Description Write Request

structure DN_FAL_PACKET_SET_ATT_REQ_T				
Type: Request				
Area	Variable	Type	Value / Range	Description
tHead	structure TLR_PACKET_HEADER_T			
A	ulDest	UINT32		Destination Queue-Handle
	ulSrc	UINT32		Source Queue-Handle of AP-Task Process Queue
	ulDestId	UINT32	0	Destination End Point Identifier, specifying the final receiver of the packet within the Destination Process. Set to 0 for the Initialization Packet
	ulSrcId	UINT32	0 ... $2^{32}-1$	Source End Point Identifier, specifying the origin of the packet inside the Source Process
	ulLen	UINT32	12 + n	sizeof(DN_FAL_SDU_GETSET_ATT_REQ_T) + number of attribute data to set
	ulId	UINT32	0 ... $2^{32}-1$	Packet Identification as unique number generated by the Source Process of the Packet
	ulSta	UINT32	0	Set to zero
C	ulCmd	UINT32	0x380C	DEVNET_FAL_CMD_SET_ATT_REQ - Command
	ulExt	UINT32	0	Extension not in use, set to zero for compatibility reasons
	ulRout	UINT32	0	Routing, set to zero
tData	structure DN_FAL_SDU_GETSET_ATT_REQ_T			
D	bDeviceAddr	UINT8	0-63	Device address, MAC-ID of device to be addresses
E	abReserved[3]	UINT8	0	Reserved zero
F	usClass	UINT16	0 ... $2^{16}-1$	Class ID
G	usInstance	UINT16	0 ... $2^{16}-1$	Instance ID
H	usAttribute	UINT16	0 ... $2^{16}-1$	Attribute ID
I	usReserved	UINT16	0	Set to zero
	abAttData[0 .. 512 ]	UINT8 array	x	Attribute Data to be set

Figure 96: Packet Description DEVNET\_FAL\_CMD\_SET\_ATT\_REQ - Set Attribute Request



Further information on the packet description for this example is comprised in the *DeviceNet Master Protocol API Manual*, in section *DEVNET\_FAL\_CMD\_SET\_ATT\_REQ/CNF – Set Attribute Request* (e. g. *Revision 07* of the API manual, in section 5.2.5).

1. Open Packet Monitor.
- **Tools > Packet Monitor.**
2. Enter data for Packet header.

### **Send > Packet header**

- Under **Dest** enter or select the receiver.
- Under **Cmd** enter the write command identification.

	<i>Sample Data</i>	
<b>(A) Receiver</b>	<i>0x20</i>	(Destination Queue Handle)
<b>(C) Write Command Identification</b>	<i>0000380C</i>	DN_FAL_PACKET_ SET_ATT_REQ_T (Request)

The screenshot shows the 'Send' dialog box with the 'Packet header' tab selected. The 'Dest' field contains '00000020' and is highlighted with a red circle labeled 'A'. The 'Cmd' field contains '0000380C' and is highlighted with a red circle labeled 'C'. Other fields include 'Src' (00000000), 'State' (00000000), 'Dest ID' (00000000), 'Src ID' (00000000), 'Len' (00000000), 'ID' (00000002), 'Ext' (00000000), 'Rout' (00000000), and an 'Auto Increment ID' checkbox.

Figure 97: Example - Writing data via „Set Attribute“ – Send > Packet header

## 3. Enter send data.

**Send > Send Data**

		Range of Value	Sample Data	
<b>(D)</b>	<b>Device Address</b>	0 ... 63	01	(for MAC ID 1)
<b>(E)</b>	<b>Reserved</b>	0	00 00 00	
<b>(F)</b>	<b>Class ID</b>	0 ... $2^{16}-1$	64 00*	(for Class-ID 100)
<b>(G)</b>	<b>Instance ID</b>	0 ... $2^{16}-1$	01 00*	(for Instance-ID 1)
<b>(H)</b>	<b>Attribute ID</b>	0 ... $2^{16}-1$	02 00*	(for Attribute-ID 2)
<b>(I)</b>	<b>Reserved</b>	0	00 00	
<b>(O)</b>	<b>Data to be sent</b>		FF	(write 1 Byte with the value 255)
		(UINT16 = 2 Bytes)		*Intel format, e. g. LSB first;

Send data: Counter: 1

	00	01	02	03	04	05	06	07	08	09
0000	01	00	00	00	64	00	01	00	02	00
000A	00	00	FF							
0014										
001E										
0028										
0032										
003C										

Put cyclic Put packet

Figure 98: Example - Writing data via „Set Attribute“ – Send &gt; Send Data

## 4. Sending/Receiving Packets.

➤ To send packet once, select **Put packet**.

➤ The entered values are sent from the packet monitor to the connected Slave device and received packets are displayed.

### Packet Description Write Confirmation

structure DN_FAL_PACKET_SET_ATT_CNF_T				
Type: Request				
Area	Variable	Type	Value / Range	Description
tHead	structure TLR_PACKET_HEADER_T			
A	ulDest	UINT32		Destination Queue-Handle
	ulSrc	UINT32		Source Queue-Handle of AP-Task Process Queue
	ulDestId	UINT32	0	Destination End Point Identifier, specifying the final receiver of the packet within the Destination Process. Set to 0 for the Initialization Packet
	ulSrcId	UINT32	0 ... $2^{32}-1$	Source End Point Identifier, specifying the origin of the packet inside the Source Process
	ulLen	UINT32	12	DN_FAL_GETSET_ATT_CNF_SIZE
	ulId	UINT32	0 ... $2^{32}-1$	Packet Identification as unique number generated by the Source Process of the Packet
	ulSta	UINT32	x	See section 6.2 Status/Error Codes DevNet FAL – Task
C	ulCmd	UINT32	0x380D	DEVNET_FAL_CMD_SET_ATT_CNF - Command
	ulExt	UINT32	0	Extension not in use
	ulRout	UINT32	x	Routing, don't touch
tData	structure DN_FAL_SDU_GETSET_ATT_REQ_T			
D	bDeviceAddr	UINT8	0-63	Device address, MAC-ID of device that was addresses
E	abReserved[3]	UINT8	0	Reserved zero
F	usClass	UINT16	0 ... $2^{16}-1$	Class ID, returned
G	usInstance	UINT16	0 ... $2^{16}-1$	Instance ID, returned
H	usAttribute	UINT16	0 ... $2^{16}-1$	Attribute ID, returned
K	bGenErr	UINT8	0 .. 255	See Table below
L	bAddErr	UINT8	0 .. 255	See Table below
	abAttData[0 .. 511]	UINT8 array	0	Unused in confirmation packet

Figure 99: Packet Description DEVNET\_FAL\_CMD\_SET\_ATT\_REQ - Confirmation of Set Attribute Request



Further information on the packet description for this example is comprised in the *DeviceNet Master Protocol API Manual*, in section *DEVNET\_FAL\_CMD\_SET\_ATT\_REQ/CNF – Set Attribute Request* (e. g. *Revision 07* of the API manual, in section 5.2.5).

## 5. Evaluate received packet.

**Receive > Packet header**

Under **Dest** the receiver is displayed.

Under **State** the status code or possibly an error code is displayed.



All status and error codes are either to be found in this manual via the section *Overview Error Codes* on page 148, in the *Dual Port Memory Manual* or in the *DeviceNet Slave Protocol API Manual*.

Under **Cmd** the response identification write request is displayed.

Receive	
Packet header	
Dest:	<b>A</b> 00000020
Src:	00000000
State:	<b>B</b> 00000000
Dest ID:	00000000
Cmd:	<b>C</b> 0000380D
Src ID:	00000000
Ext:	00000000
Len:	0000000C
Rout:	00000000
ID:	00000002

Figure 100: Example - Writing data via „Set Attribute“ – Receive > Packet header

	Sample Data	
<b>A Receiver</b>	0x20	(Destination Queue Handle)
<b>B State</b>	00000000	indicates that the write request could be executed without error. If during the execution of the write request an error was detected, an error code is displayed.
<b>C Response Identification Writing Request</b>	0000380D	DN_FAL_PACKET_SET_ATT_CNF_T (Confirmation)

## Receive > Receive data

Under **Receive data** the data of the receive packet are displayed.




Figure 101: Example – Writing data via „Set Attribute“ – Receive > Receive data

		Range of Value	Sample Data	
<b>(D)</b>	<b>Device Address</b>	0 ... 63	01	(for MAC ID 1)
<b>(E)</b>	<b>Reserved</b>	0	00 00 00	
<b>(F)</b>	<b>Class ID</b>	0 ... $2^{16}-1$	64 00*	(for Class-ID 100)
<b>(G)</b>	<b>Instance ID</b>	0 ... $2^{16}-1$	01 00*	(for Instance-ID 1)
<b>(H)</b>	<b>Attribute ID</b>	0 ... $2^{16}-1$	02 00*	(for Attribute-ID 2)
<b>(K)</b>	<b>General Errors</b>	0 ... 255	00	Slave device reports OK, no error
<b>(L)</b>	<b>Additional Errors</b>	0 ... 255	00	Slave device reports OK, no error
		(UINT16 = 2 Bytes)	*Intel format, e. g. LSB first;	

## 9.3 IO Monitor

The **IO Monitor** serves for test and diagnosis purposes. It provides to view data of the process data image and to change output data easily. The display is always in a Byte manner.



**Note:** Only change and write output data if you know that no plant disturbances are caused by this. All output data written by the IO Monitor are transmitted at the bus and have effect on subordinate drives, IO etc.

**IO Monitor**

Columns: 10 Display mode: Decimal

Input data

Offset: 0 Go

	0	1	2	3	4	5	6	7	8	9
0	227	207	0	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0	0
50	0	0	0	0	0	0	0	0	0	0
60	n	n	n	n	n	n	n	n	n	n

Output data

Offset: 0 Go

	0	1	2	3	4	5	6	7	8	9
0	0	0	0	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0	0
50	0	0	0	0	0	0	0	0	0	0
60	n	n	n	n	n	n	n	n	n	n

Update

Figure 102: IO Monitor

**Columns** switches the number of columns.

**Display mode** switches the representation of the input and output data between decimal and hexadecimal.

**Offset / Go** moves the indication of the data to the entered offset value.

➤ Enter the output value and select **Update**.

⚠ Always the data of the process image are displayed, also when these Bytes have not been reserved by the configuration.



## 9.4 Process Image Monitor

The window **Process Image Monitor** lists the Slave devices connected to the Master, as well as the configured modules or input or output signals of the devices. This makes visible the fieldbus structure and the data structure of the device's input and output data transmitted at the bus. Furthermore the values of the signal data provided to the OPC server are displayed here.

- Open **Tools > Process Image Monitor**.








Figure 103: Window 'Process Image Monitor'

Parameter	Meaning	Range of Value / Value
<b>Display Mode</b>	Display of the values in the column <b>Value</b> in decimal or hexadecimal mode.	Decimal (Default), Hexadecimal
	The tree shows the structure of the devices (1), modules (2) and the input data (3) and output data (4).	
	Display when the input and output data are not completely read and analyzed.	
	Display when the input and output data are not valid.	
	Display when the input and output data are valid.	
<b>Typ</b>	Device labeling provided by the hardware: Also description of the modules or input or output signals configured to the device.	

Parameter	Meaning	Range of Value / Value
<b>TAG</b>	Device name provided by the hardware (not changeable in the FDT container) or symbolic name for the modules configured to the device or for the input or output signals (changeable in the window <b>Configuration &gt; Process Data</b> ).	
<b>Value</b>	Display of the valid input and output data values.	
<b>Last Error</b>	Last occurred error (Description see appropriate Application Programming Manual)	

*Table 52: Notes to the Window 'Process Image Monitor'*

## 10 Error Codes

### 10.1 Error Code Definition

For COM based application, like the ODM Server and ODM drivers, a common error definition is used, similar to the Microsoft Windows® HRESULT definition.

Error Code Structure:

COM Errors are HRESULTs, which are 32 bit values using the following layout:

```

3 3 2 2 2 2 2 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1
1 0 9 8 7 6 5 4 3 2 1 0 9 8 7 6 5 4 3 2 1 0
+---+---+---+---+---+---+---+---+---+---+
|Sev|C|R|      Facility      |      Code      |
+---+---+---+---+---+---+---+---+---+---+

```

where

*Sev* - is the severity code:

00 - Success

01 - Informational

10 - Warning

11 - Error

*C* - is the Customer code flag

*R* - is a reserved bit

*Facility* - is the facility code

*Code* - is the facility's status code

In this common error definition, several error code regions are already reserved by Windows® itself, the ODM and some other modules.

## 10.2 Overview Error Codes

Overview Error Codes	Range
General Hardware Errors RCX Operating System	<i>RCX General Task:</i> 0xC02B0001 to 0xC02B4D52
	<i>RCX Common Status &amp; Errors Codes:</i> 0x00000000 to 0xC002000C
	<i>RCX Status &amp; Error Codes:</i> 0x00000000 to 0xC0000008
ODM Server	<i>General ODM Error Codes:</i> 0x8004C700 to 0x8004C761
	<i>General ODM Driver Error Codes:</i> 0x8004C7A0 to 0x8004C7C2
ODM Drivers	<i>cifX Driver Specific ODM Error:</i> 0x8004C001 to 0x8004C0A4
cifX Device Driver and netX Driver	<i>Generic Error:</i> 0x800A0001 bis 0x800A0017
	<i>Generic Driver Error:</i> 0x800B0001 bis 0x800B0042
	<i>Generic Device Error:</i> 0x800C0010 bis 0x800C0041
netX Driver	<i>CIFX API Transport:</i> 0x800D0001 bis 0x800D0013
	<i>CIFX API Transport Header State Error:</i> 0x800E0001 bis 0x800E000B
DBM	<i>ODM Error Codes:</i> 0xC004C810 to 0xC004C878

Table 53: Overview Error Codes and Ranges



The fieldbus specific error codes are described in the manuals of the corresponding protocol tasks.

## 10.3 General Hardware Error Codes

### 10.3.1 RCX General Task Errors

Error Code (Definition)	Value	Description
RCX_E_QUE_UNKNOWN	0xC02B0001	Unknown Queue
RCX_E_QUE_INDEX_UNKNOWN	0xC02B0002	Unknown Queue Index
RCX_E_TASK_UNKNOWN	0xC02B0003	Unknown Task
RCX_E_TASK_INDEX_UNKNOWN	0xC02B0004	Unknown Task Index
RCX_E_TASK_HANDLE_INVALID	0xC02B0005	Invalid Task Handle
RCX_E_TASK_INFO_IDX_UNKNOWN	0xC02B0006	Unknown Index
RCX_E_FILE_XFR_TYPE_INVALID	0xC02B0007	Invalid Transfer Type
RCX_E_FILE_REQUEST_INCORRECT	0xC02B0008	Invalid File Request
RCX_E_TASK_INVALID	0xC02B000E	Invalid Task
RCX_E_SEC_FAILED	0xC02B001D	Security EEPROM Access Failed
RCX_E_EEPROM_DISABLED	0xC02B001E	EEPROM Disabled
RCX_E_INVALID_EXT	0xC02B001F	Invalid Extension
RCX_E_SIZE_OUT_OF_RANGE	0xC02B0020	Block Size Out Of Range
RCX_E_INVALID_CHANNEL	0xC02B0021	Invalid Channel
RCX_E_INVALID_FILE_LEN	0xC02B0022	Invalid File Length
RCX_E_INVALID_CHAR_FOUND	0xC02B0023	Invalid Character Found
RCX_E_PACKET_OUT_OF_SEQ	0xC02B0024	Packet Out Of Sequence
RCX_E_SEC_NOT_ALLOWED	0xC02B0025	Not Allowed In Current State
RCX_E_SEC_INVALID_ZONE	0xC02B0026	Security EEPROM Invalid Zone
RCX_E_SEC_EEPROM_NOT_AVAIL	0xC02B0028	Security EEPROM Eeprom Not Available
RCX_E_SEC_INVALID_CHECKSUM	0xC02B0029	Security EEPROM Invalid Checksum
RCX_E_SEC_ZONE_NOT_WRITEABLE	0xC02B002A	Security EEPROM Zone Not Writeable
RCX_E_SEC_READ_FAILED	0xC02B002B	Security EEPROM Read Failed
RCX_E_SEC_WRITE_FAILED	0xC02B002C	Security EEPROM Write Failed
RCX_E_SEC_ACCESS_DENIED	0xC02B002D	Security EEPROM Access Denied
RCX_E_SEC_EEPROM_EMULATED	0xC02B002E	Security EEPROM Emulated
RCX_E_INVALID_BLOCK	0xC02B0038	Invalid Block
RCX_E_INVALID_STRUCT_NUMBER	0xC02B0039	Invalid Structure Number
RCX_E_INVALID_CHECKSUM	0xC02B4352	Invalid Checksum
RCX_E_CONFIG_LOCKED	0xC02B4B54	Configuration Locked
RCX_E_SEC_ZONE_NOT_READABLE	0xC02B4D52	Security EEPROM Zone Not Readable

Table 54: RCX General Task Errors

### 10.3.2 RCX Common Status & Errors Codes

Error Code (Definition)	Value	Description
RCX_S_OK	0x00000000	Success, Status Okay
RCX_E_FAIL	0xC0000001	Fail
RCX_E_UNEXPECTED	0xC0000002	Unexpected
RCX_E_OUTOFMEMORY	0xC0000003	Out Of Memory
RCX_E_UNKNOWN_COMMAND	0xC0000004	Unknown Command
RCX_E_UNKNOWN_DESTINATION	0xC0000005	Unknown Destination
RCX_E_UNKNOWN_DESTINATION_ID	0xC0000006	Unknown Destination ID
RCX_E_INVALID_PACKET_LEN	0xC0000007	Invalid Packet Length
RCX_E_INVALID_EXTENSION	0xC0000008	Invalid Extension
RCX_E_INVALID_PARAMETER	0xC0000009	Invalid Parameter
RCX_E_WATCHDOG_TIMEOUT	0xC000000C	Watchdog Timeout
RCX_E_INVALID_LIST_TYPE	0xC000000D	Invalid List Type
RCX_E_UNKNOWN_HANDLE	0xC000000E	Unknown Handle
RCX_E_PACKET_OUT_OF_SEQ	0xC000000F	Out Of Sequence
RCX_E_PACKET_OUT_OF_MEMORY	0xC0000010	Out Of Memory
RCX_E_QUE_PACKETDONE	0xC0000011	Queue Packet Done
RCX_E_QUE_SENDPACKET	0xC0000012	Queue Send Packet
RCX_E_POOL_PACKET_GET	0xC0000013	Pool Packet Get
RCX_E_POOL_GET_LOAD	0xC0000015	Pool Get Load
RCX_E_REQUEST_RUNNING	0xC000001A	Request Already Running
RCX_E_INIT_FAULT	0xC0000100	Initialization Fault
RCX_E_DATABASE_ACCESS_FAILED	0xC0000101	Database Access Failed
RCX_E_NOT_CONFIGURED	0xC0000119	Not Configured
RCX_E_CONFIGURATION_FAULT	0xC0000120	Configuration Fault
RCX_E_INCONSISTENT_DATA_SET	0xC0000121	Inconsistent Data Set
RCX_E_DATA_SET_MISMATCH	0xC0000122	Data Set Mismatch
RCX_E_INSUFFICIENT_LICENSE	0xC0000123	Insufficient License
RCX_E_PARAMETER_ERROR	0xC0000124	Parameter Error
RCX_E_INVALID_NETWORK_ADDRESS	0xC0000125	Invalid Network Address
RCX_E_NO_SECURITY_MEMORY	0xC0000126	No Security Memory
RCX_E_NETWORK_FAULT	0xC0000140	Network Fault
RCX_E_CONNECTION_CLOSED	0xC0000141	Connection Closed
RCX_E_CONNECTION_TIMEOUT	0xC0000142	Connection Timeout
RCX_E_LONELY_NETWORK	0xC0000143	Lonely Network
RCX_E_DUPLICATE_NODE	0xC0000144	Duplicate Node
RCX_E_CABLE_DISCONNECT	0xC0000145	Cable Disconnected
RCX_E_BUS_OFF	0xC0000180	Network Node Bus Off
RCX_E_CONFIG_LOCKED	0xC0000181	Configuration Locked
RCX_E_APPLICATION_NOT_READY	0xC0000182	Application Not Ready
RCX_E_TIMER_APPL_PACKET_SENT	0xC002000C	Timer App Packet Sent

Table 55: RCX Common Status & Errors Codes

### 10.3.3 RCX Status & Error Codes

Error Code (Definition)	Value	Description
RCX_S_OK	0x00000000	SUCCESS, STATUS OKAY
RCX_S_QUE_UNKNOWN	0xC02B0001	UNKNOWN QUEUE
RCX_S_QUE_INDEX_UNKNOWN	0xC02B0002	UNKNOWN QUEUE INDEX
RCX_S_TASK_UNKNOWN	0xC02B0003	UNKNOWN TASK
RCX_S_TASK_INDEX_UNKNOWN	0xC02B0004	UNKNOWN TASK INDEX
RCX_S_TASK_HANDLE_INVALID	0xC02B0005	INVALID TASK HANDLE
RCX_S_TASK_INFO_IDX_UNKNOWN	0xC02B0006	UNKNOWN INDEX
RCX_S_FILE_XFR_TYPE_INVALID	0xC02B0007	INVALID TRANSFER TYPE
RCX_S_FILE_REQUEST_INCORRECT	0xC02B0008	INVALID FILE REQUEST
RCX_S_UNKNOWN_DESTINATION	0xC0000005	UNKNOWN DESTINATION
RCX_S_UNKNOWN_DESTINATION_ID	0xC0000006	UNKNOWN DESTINATION ID
RCX_S_INVALID_LENGTH	0xC0000007	INVALID LENGTH
RCX_S_UNKNOWN_COMMAND	0xC0000004	UNKNOWN COMMAND
RCX_S_INVALID_EXTENSION	0xC0000008	INVALID EXTENSION

Table 56: RCX Status & Error Codes

#### 10.3.3.1 RCX Status & Error Codes Slave State

Error Code (Definition)	Value	Description
RCX_SLAVE_STATE_UNDEFINED	0x00000000	UNDEFINED
RCX_SLAVE_STATE_OK	0x00000001	OK
RCX_SLAVE_STATE_FAILED	0x00000002	FAILED (at least one slave)

Table 57: RCX Status & Error Codes Slave State

## 10.4 ODM Error Codes

### 10.4.1 General ODM Error Codes

Error Code (Definition)	Value	Description
CODM3_E_INTERNALERROR	0x8004C700	Internal ODM Error
ODM3_E_DESCRIPTION_NOTFOUND	0x8004C701	Description not found in ODM database
CODM3_E_WRITEREGISTRY	0x8004C710	Error writing to the registry
CODM3_E_BAD_REGULAR_EXPRESSION	0x8004C711	Invalid regular expression
CODM3_E_COMCATEGORIE_MANAGER_FAILED	0x8004C712	Component Category Manager could not be instantiated
CODM3_E_COMCATEGORIE_ENUMERATION_FAILED	0x8004C713	Driver could not be enumerated by the Category Manager
CODM3_E_CREATE_LOCAL_BUFFER	0x8004C714	Error creating local buffers
CODM3_E_UNKNOWNHANDLE	0x8004C715	Unknown handle
CODM3_E_QUEUE_LIMIT_REACHED	0x8004C717	Queue size limit for connection reached
CODM3_E_DATASIZE_ZERO	0x8004C718	Zero data length passed
CODM3_E_INVALID_DATA	0x8004C719	Invalid data content
CODM3_E_INVALID_MODE	0x8004C71A	Invalid mode
CODM3_E_DATABASE_READ	0x8004C71B	Error reading database
CODM3_E_CREATE_DEVICE_THREAD	0x8004C750	Error creating device thread
CODM3_E_CREATE_DEVICE_THREAD_STOP_EVENT	0x8004C751	Error creating device thread stop event
CODM3_E_CLIENT_NOT_REGISTERED	0x8004C752	Client is not registered at the ODM
CODM3_E_NO_MORE_CLIENTS	0x8004C753	Maximum number of clients reached
CODM3_E_MAX_CLIENT_CONNECTIONS_REACHED	0x8004C754	Maximum number of client connections reached
CODM3_E_ENTRY_NOT_FOUND	0x8004C755	Driver/device not found
CODM3_E_DRIVER_NOT_FOUND	0x8004C757	The requested driver is unknown to the ODM
CODM3_E_DEVICE_ALREADY_LOCKED	0x8004C758	Device is locked by another process
CODM3_E_DEVICE_UNLOCKED_FAILED	0x8004C759	Device could not be unlocked, lock was set by another process
CODM3_E_DEVICE_LOCK_NECESSARY	0x8004C75A	Operation requires a device lock to be set
CODM3_E_DEVICE_SUBSCRIPTIONLIMIT	0x8004C75B	Maximum number of servers registered for this device reached
CODM3_E_DEVICE_NOTSUBSCRIBED	0x8004C75C	Process is not registered as a server on this device
CODM3_E_DEVICE_NO_MESSAGE	0x8004C75D	No message available
CODM3_E_TRANSFERTIMEOUT	0x8004C760	Message transfer timeout
CODM3_E_MESSAGE_INSERVICE	0x8004C761	Message in service

Table 58: ODM Error Codes - General ODM Error Codes



## 10.4.2 General ODM Driver Error Codes

Error Code (Definition)	Value	Description
CODM3_E_DRV_OPEN_DEVICE	0x8004C7A0	Packet type unsupported by driver
CODM3_E_DRV_INVALID_IDENTIFIER	0x8004C7A1	Invalid device identifier
CODM3_E_DRV_DEVICE_PARAMETERS_MISMATCH	0x8004C7A3	Parameters differ from requested device
CODM3_E_DRV_BROWSE_NO_DEVICES	0x8004C7A4	No devices found
CODM3_E_DRV_CREATE_DEVICE_INST	0x8004C7A5	Device instance could not be created
CODM3_E_DRV_DEVICE_NOMORE_TX	0x8004C7A6	Device connection limit reached
CODM3_E_DRV_DEVICE_DUPLICATE_TX	0x8004C7A7	Duplicate transmitter ID
CODM3_E_DRV_DEVICE_NOT_CONFIGURED	0x8004C7A8	Device is not configured
CODM3_E_DRV_DEVICE_COMMUNICATION	0x8004C7A9	Device communication error
CODM3_E_DRV_DEVICE_NO_MESSAGE	0x8004C7AA	No message available
CODM3_E_DRV_DEVICE_NOT_READY	0x8004C7AB	Device not ready
CODM3_E_DRV_INVALIDCONFIGURATION	0x8004C7AC	Invalid driver configuration
CODM3_E_DRV_DLINVALIDMODE	0x8004C7C0	Invalid download mode
CODM3_E_DRV_DLINPROGRESS	0x8004C7C1	Download is active
CODM3_E_DRV_ULINPROGRESS	0x8004C7C2	Upload is active

Table 59: ODM Error Codes - General ODM Driver Error Codes

### 10.4.3 cifX Driver Specific ODM Error Codes

cifX Driver Specific ODM Error Codes		
Error Code (Definition)	Value	Description
DRV_E_BOARD_NOT_INITIALIZED	0x8004C001	DRIVER Board not initialized
DRV_E_INIT_STATE_ERROR	0x8004C002	DRIVER Error in internal init state
DRV_E_READ_STATE_ERROR	0x8004C003	DRIVER Error in internal read state
DRV_E_CMD_ACTIVE	0x8004C004	DRIVER Command on this channel is active
DRV_E_PARAMETER_UNKNOWN	0x8004C005	DRIVER Unknown parameter in function
DRV_E_WRONG_DRIVER_VERSION	0x8004C006	DRIVER Version is incompatible with DLL
DRV_E_PCI_SET_CONFIG_MODE	0x8004C007	DRIVER Error during PCI set configuration mode
DRV_E_PCI_READ_DPM_LENGTH	0x8004C008	DRIVER Could not read PCI dual port memory length
DRV_E_PCI_SET_RUN_MODE	0x8004C009	DRIVER Error during PCI set run mode
DRV_E_DEV_DPM_ACCESS_ERROR	0x8004C00A	DEVICE Dual port ram not accessible(board not found)
DRV_E_DEV_NOT_READY	0x8004C00B	DEVICE Not ready (ready flag failed)
DRV_E_DEV_NOT_RUNNING	0x8004C00C	DEVICE Not running (running flag failed)
DRV_E_DEV_WATCHDOG_FAILED	0x8004C00D	DEVICE Watchdog test failed
DRV_E_DEV_OS_VERSION_ERROR	0x8004C00E	DEVICE Signals wrong OS version
DRV_E_DEV_SYSERR	0x8004C00F	DEVICE Error in dual port flags
DRV_E_DEV_MAILBOX_FULL	0x8004C010	DEVICE Send mailbox is full
DRV_E_DEV_PUT_TIMEOUT	0x8004C011	DEVICE PutMessage timeout
DRV_E_DEV_GET_TIMEOUT	0x8004C012	DEVICE GetMessage timeout
DRV_E_DEV_GET_NO_MESSAGE	0x8004C013	DEVICE No message available
DRV_E_DEV_RESET_TIMEOUT	0x8004C014	DEVICE RESET command timeout
DRV_E_DEV_NO_COM_FLAG	0x8004C015	DEVICE COM-flag not set. Check if Bus is running
DRV_E_DEV_EXCHANGE_FAILED	0x8004C016	DEVICE I/O data exchange failed
DRV_E_DEV_EXCHANGE_TIMEOUT	0x8004C017	DEVICE I/O data exchange timeout
DRV_E_DEV_COM_MODE_UNKNOWN	0x8004C018	DEVICE I/O data mode unknown
DRV_E_DEV_FUNCTION_FAILED	0x8004C019	DEVICE Function call failed
DRV_E_DEV_DPMSIZE_MISMATCH	0x8004C01A	DEVICE DPM size differs from configuration
DRV_E_DEV_STATE_MODE_UNKNOWN	0x8004C01B	DEVICE State mode unknown
DRV_E_DEV_HW_PORT_IS_USED	0x8004C01C	DEVICE Output port already in use
DRV_E_USR_OPEN_ERROR	0x8004C01E	USER Driver not opened (device driver not loaded)
DRV_E_USR_INIT_DRV_ERROR	0x8004C01F	USER Can't connect to device
DRV_E_USR_NOT_INITIALIZED	0x8004C020	USER Board not initialized (DevInitBoard not called)
DRV_E_USR_COMM_ERR	0x8004C021	USER IOCTL function failed
DRV_E_USR_DEV_NUMBER_INVALID	0x8004C022	USER Parameter DeviceNumber invalid
DRV_E_USR_INFO_AREA_INVALID	0x8004C023	USER Parameter InfoArea unknown
DRV_E_USR_NUMBER_INVALID	0x8004C024	USER Parameter Number invalid
DRV_E_USR_MODE_INVALID	0x8004C025	USER Parameter Mode invalid
DRV_E_USR_MSG_BUF_NULL_PTR	0x8004C026	USER NULL pointer assignment
DRV_E_USR_MSG_BUF_TOO_SHORT	0x8004C027	USER Message buffer too small

cifX Driver Specific ODM Error Codes		
Error Code (Definition)	Value	Description
DRV_E_USR_SIZE_INVALID	0x8004C028	USER Parameter Size invalid
DRV_E_USR_SIZE_ZERO	0x8004C02A	USER Parameter Size with zero length
DRV_E_USR_SIZE_TOO_LONG	0x8004C02B	USER Parameter Size too long
DRV_E_USR_DEV_PTR_NULL	0x8004C02C	USER Device address null pointer
DRV_E_USR_BUF_PTR_NULL	0x8004C02D	USER Pointer to buffer is a null pointer
DRV_E_USR_SENDSIZE_TOO_LONG	0x8004C02E	USER Parameter SendSize too large
DRV_E_USR_RECVSIZE_TOO_LONG	0x8004C02F	USER Parameter ReceiveSize too large
DRV_E_USR_SENDBUF_PTR_NULL	0x8004C030	USER Pointer to send buffer is a null pointer
DRV_E_USR_RECVBUF_PTR_NULL	0x8004C031	USER Pointer to receive buffer is a null pointer
DRV_E_DMA_INSUFF_MEM	0x8004C032	DMA Memory allocation error
DRV_E_DMA_TIMEOUT_CH4	0x8004C033	DMA Read I/O timeout
DRV_E_DMA_TIMEOUT_CH5	0x8004C034	DMA Write I/O timeout
DRV_E_DMA_TIMEOUT_CH6	0x8004C035	DMA PCI transfer timeout
DRV_E_DMA_TIMEOUT_CH7	0x8004C036	DMA Download timeout
DRV_E_DMA_DB_DOWN_FAIL	0x8004C037	DMA Database download failed
DRV_E_DMA_FW_DOWN_FAIL	0x8004C038	DMA Firmware download failed
DRV_E_CLEAR_DB_FAIL	0x8004C039	DMA Clear database on the device failed
DRV_E_DEV_NO_VIRTUAL_MEM	0x8004C03C	DMA USER Virtual memory not available
DRV_E_DEV_UNMAP_VIRTUAL_MEM	0x8004C03D	DMA USER Unmap virtual memory failed
DRV_E_GENERAL_ERROR	0x8004C046	DRIVER General error
DRV_E_DMA_ERROR	0x8004C047	DRIVER General DMA error
DRV_E_WDG_IO_ERROR	0x8004C048	DRIVER I/O WatchDog failed
DRV_E_WDG_DEV_ERROR	0x8004C049	DRIVER Device Watchdog failed
DRV_E_USR_DRIVER_UNKNOWN	0x8004C050	USER Driver unknown
DRV_E_USR_DEVICE_NAME_INVALID	0x8004C051	USER Device name invalid
DRV_E_USR_DEVICE_NAME_UNKNOWN	0x8004C052	USER Device name unknown
DRV_E_USR_DEVICE_FUNC_NOTIMPL	0x8004C053	USER Device function not implemented
DRV_E_USR_FILE_OPEN_FAILED	0x8004C064	USER File could not be opened
DRV_E_USR_FILE_SIZE_ZERO	0x8004C065	USER File size zero
DRV_E_USR_FILE_NO_MEMORY	0x8004C066	USER Not enough memory to load file
DRV_E_USR_FILE_READ_FAILED	0x8004C067	USER File read failed
DRV_E_USR_INVALID_FILETYPE	0x8004C068	USER File type invalid
DRV_E_USR_FILENAME_INVALID	0x8004C069	USER Invalid filename
DRV_E_FW_FILE_OPEN_FAILED	0x8004C06E	USER Firmware file could not be opened
DRV_E_FW_FILE_SIZE_ZERO	0x8004C06F	USER Not enough memory to load firmware file
DRV_E_FW_FILE_NO_MEMORY	0x8004C070	USER Not enough memory to load firmware file
DRV_E_FW_FILE_READ_FAILED	0x8004C071	USER Firmware file read failed
DRV_E_FW_INVALID_FILETYPE	0x8004C072	USER Firmware file type invalid
DRV_E_FW_FILENAME_INVALID	0x8004C073	USER Firmware file name not valid
DRV_E_FW_DOWNLOAD_ERROR	0x8004C074	USER Firmware file download error
DRV_E_FW_FILENAME_NOT_FOUND	0x8004C075	USER Firmware file not found in the internal table
DRV_E_FW_BOOTLOADER_ACTIVE	0x8004C076	USER Firmware file BOOTLOADER active

cifX Driver Specific ODM Error Codes		
Error Code (Definition)	Value	Description
DRV_E_FW_NO_FILE_PATH	0x8004C077	USER Firmware file no file path
DRV_E_CF_FILE_OPEN_FAILED	0x8004C078	USER Configuration file could not be opened
DRV_E_CF_FILE_SIZE_ZERO	0x8004C079	USER Configuration file size zero
DRV_E_CF_FILE_NO_MEMORY	0x8004C07A	USER Not enough memory to load configuration file
DRV_E_CF_FILE_READ_FAILED	0x8004C07B	USER Configuration file read failed
DRV_E_CF_INVALID_FILETYPE	0x8004C07C	USER Configuration file type invalid
DRV_E_CF_FILENAME_INVALID	0x8004C07D	USER Configuration file name not valid
DRV_E_CF_DOWNLOAD_ERROR	0x8004C07E	USER Configuration file download error
DRV_E_CF_FILE_NO_SEGMENT	0x8004C07F	USER No flash segment in the configuration file
DRV_E_CF_DIFFERS_FROM_DBM	0x8004C080	USER Configuration file differs from database
DRV_E_DBM_SIZE_ZERO	0x8004C083	USER Database size zero
DRV_E_DBM_NO_MEMORY	0x8004C084	USER Not enough memory to upload database
DRV_E_DBM_READ_FAILED	0x8004C085	USER Database read failed
DRV_E_DBM_NO_FLASH_SEGMENT	0x8004C086	USER Database segment unknown
DEV_E_CF_INVALID_DESCRIPTOR_VERSION	0x8004C096	CONFIG Version of the descriptor table invalid
DEV_E_CF_INVALID_INPUT_OFFSET	0x8004C097	CONFIG Input offset is invalid
DEV_E_CF_NO_INPUT_SIZE	0x8004C098	CONFIG Input size is 0
DEV_E_CF_MISMATCH_INPUT_SIZE	0x8004C099	CONFIG Input size does not match configuration
DEV_E_CF_INVALID_OUTPUT_OFFSET	0x8004C09A	CONFIG Invalid output offset
DEV_E_CF_NO_OUTPUT_SIZE	0x8004C09B	CONFIG Output size is 0
DEV_E_CF_MISMATCH_OUTPUT_SIZE	0x8004C09C	CONFIG Output size does not match configuration
DEV_E_CF_STN_NOT_CONFIGURED	0x8004C09D	CONFIG Station not configured
DEV_E_CF_CANNOT_GET_STN_CONFIG	0x8004C09E	CONFIG Cannot get the Station configuration
DEV_E_CF_MODULE_DEF_MISSING	0x8004C09F	CONFIG Module definition is missing
DEV_E_CF_MISMATCH_EMPTY_SLOT	0x8004C0A0	CONFIG Empty slot mismatch
DEV_E_CF_MISMATCH_INPUT_OFFSET	0x8004C0A1	CONFIG Input offset mismatch
DEV_E_CF_MISMATCH_OUTPUT_OFFSET	0x8004C0A2	CONFIG Output offset mismatch
DEV_E_CF_MISMATCH_DATA_TYPE	0x8004C0A3	CONFIG Data type mismatch
DEV_E_CF_MODULE_DEF_MISSING_NO_SI	0x8004C0A4	CONFIG Module definition is missing,(no Slot/Idx)

Table 60: cifX Driver Specific ODM Error Codes

## 10.5 Error Codes cifX Device Driver and netX Driver

### 10.5.1 Generic Error Codes

Error Code (Definition)	Value	Description
CIFX_INVALID_POINTER	0x800A0001L	Invalid pointer (NULL) passed to driver
CIFX_INVALID_BOARD	0x800A0002L	No board with the given nameindex available
CIFX_INVALID_CHANNEL	0x800A0003L	No channel with the given index available
CIFX_INVALID_HANDLE	0x800A0004L	Invalid handle passed to driver
CIFX_INVALID_PARAMETER	0x800A0005L	Invalid parameter
CIFX_INVALID_COMMAND	0x800A0006L	Invalid command
CIFX_INVALID_BUFFERSIZE	0x800A0007L	Invalid buffer size
CIFX_INVALID_ACCESS_SIZE	0x800A0008L	Invalid access size
CIFX_FUNCTION_FAILED	0x800A0009L	Function failed
CIFX_FILE_OPEN_FAILED	0x800A000AL	File could not be opened
CIFX_FILE_SIZE_ZERO	0x800A000BL	File size is zero
CIFX_FILE_LOAD_INSUFF_MEM	0x800A000CL	Insufficient memory to load file
CIFX_FILE_CHECKSUM_ERROR	0x800A000DL	File checksum compare failed
CIFX_FILE_READ_ERROR	0x800A000EL	Error reading from file
CIFX_FILE_TYPE_INVALID	0x800A000FL	Invalid file type
CIFX_FILE_NAME_INVALID	0x800A0010L	Invalid file name
CIFX_FUNCTION_NOT_AVAILABLE	0x800A0011L	Driver function not available
CIFX_BUFFER_TOO_SHORT	0x800A0012L	Given buffer is too short
CIFX_MEMORY_MAPPING_FAILED	0x800A0013L	Failed to map the memory
CIFX_NO_MORE_ENTRIES	0x800A0014L	No more entries available
CIFX_CALLBACK_MODE_UNKNOWN	0x800A0015L	Unkown callback handling mode
CIFX_CALLBACK_CREATE_EVENT_FAILED	0x800A0016L	Failed to create callback events
CIFX_CALLBACK_CREATE_RECV_BUFFER	0x800A0017L	Failed to create callback receive buffer

Table 61: Generic Error Codes

## 10.5.2 Generic Driver Error Codes

Error Code (Definition)	Value	Description
CIFX_DRV_NOT_INITIALIZED	0x800B0001L	Driver not initialized
CIFX_DRV_INIT_STATE_ERROR	0x800B0002L	Driver init state error
CIFX_DRV_READ_STATE_ERROR	0x800B0003L	Driver read state error
CIFX_DRV_CMD_ACTIVE	0x800B0004L	Command is active on device
CIFX_DRV_DOWNLOAD_FAILED	0x800B0005L	General error during download
CIFX_DRV_WRONG_DRIVER_VERSION	0x800B0006L	Wrong driver version
CIFX_DRV_DRIVER_NOT_LOADED	0x800B0030L	CIFx driver is not running
CIFX_DRV_INIT_ERROR	0x800B0031L	Failed to initialize the device
CIFX_DRV_CHANNEL_NOT_INITIALIZED	0x800B0032L	Channel not initialized (xOpenChannel not called)
CIFX_DRV_IO_CONTROL_FAILED	0x800B0033L	IOControl call failed
CIFX_DRV_NOT_OPENED(	0x800B0034L	Driver was not opened
CIFX_DRV_DOWNLOAD_STORAGE_UNKN OWN	0x800B0040L	Unknown download storage type (RAMFLASH based) found
CIFX_DRV_DOWNLOAD_FW_WRONG_CHA NNEL	0x800B0041L	Channel number for a firmware download not supported
CIFX_DRV_DOWNLOAD_MODULE_NO_BAS EOS	0x800B0042L	Modules are not allowed without a Base OS firmware

Table 62: Generic Driver Error Codes

### 10.5.3 Generic Device Error Codes

Error Code (Definition)	Value	Description
CIFX_DEV_DPM_ACCESS_ERROR	0x800C0010L	Dual port memory not accessible (board not found)
CIFX_DEV_NOT_READY	0x800C0011L	Device not ready (ready flag failed)
CIFX_DEV_NOT_RUNNING	0x800C0012L	Device not running (running flag failed)
CIFX_DEV_WATCHDOG_FAILED	0x800C0013L	Watchdog test failed
CIFX_DEV_SYSERR	0x800C0015L	Error in handshake flags
CIFX_DEV_MAILBOX_FULL	0x800C0016L	Send mailbox is full
CIFX_DEV_PUT_TIMEOUT	0x800C0017L	Send packet timeout
CIFX_DEV_GET_TIMEOUT	0x800C0018L	Receive packet timeout
CIFX_DEV_GET_NO_PACKET	0x800C0019L	No packet available
CIFX_DEV_MAILBOX_TOO_SHORT	0x800C001AL	Mailbox too short
CIFX_DEV_RESET_TIMEOUT	0x800C0020L	Reset command timeout
CIFX_DEV_NO_COM_FLAG	0x800C0021L	COM-flag not set
CIFX_DEV_EXCHANGE_FAILED	0x800C0022L	IO data exchange failed
CIFX_DEV_EXCHANGE_TIMEOUT	0x800C0023L	IO data exchange timeout
CIFX_DEV_COM_MODE_UNKNOWN	0x800C0024L	Unknown IO exchange mode
CIFX_DEV_FUNCTION_FAILED	0x800C0025L	Device function failed
CIFX_DEV_DPMSIZE_MISMATCH	0x800C0026L	DPM size differs from configuration
CIFX_DEV_STATE_MODE_UNKNOWN	0x800C0027L	Unknown state mode
CIFX_DEV_HW_PORT_IS_USED	0x800C0028L	Device is still accessed
CIFX_DEV_CONFIG_LOCK_TIMEOUT	0x800C0029L	Configuration locking timeout
CIFX_DEV_CONFIG_UNLOCK_TIMEOUT	0x800C002AL	Configuration unlocking timeout
CIFX_DEV_HOST_STATE_SET_TIMEOUT	0x800C002BL	Set HOST state timeout
CIFX_DEV_HOST_STATE_CLEAR_TIMEOUT	0x800C002CL	Clear HOST state timeout
CIFX_DEV_INITIALIZATION_TIMEOUT	0x800C002DL	Timeout during channel initialization
CIFX_DEV_BUS_STATE_ON_TIMEOUT	0x800C002EL	Set Bus ON Timeout
CIFX_DEV_BUS_STATE_OFF_TIMEOUT	0x800C002FL	Set Bus OFF Timeout
CIFX_DEV_MODULE_ALREADY_RUNNING	0x800C0040L	Module already running
CIFX_DEV_MODULE_ALREADY_EXISTS	0x800C0041L	Module already exists

Table 63: Generic Device Error Codes

## 10.6 Error Codes netX Driver

### 10.6.1 CIFS API Transport Error Codes

Error Code (Definition)	Value	Description
CIFS_TRANSPORT_SEND_TIMEOUT	0x800D0001L	Time out while sending data
CIFS_TRANSPORT_RECV_TIMEOUT	0x800D0002L	Time out waiting for incoming data
CIFS_TRANSPORT_CONNECT	0x800D0003L	Unable to communicate to the device no answer
CIFS_TRANSPORT_ABORTED	0x800D0004L	Transfer has been aborted due to keep alive timeout or interface detachment
CIFS_CONNECTOR_FUNCTIONS_READ_ERROR	0x800D0010L	Error reading the connector functions from the DLL
CIFS_CONNECTOR_IDENTIFIER_TOO_LONG	0x800D0011L	Connector delivers an identifier longer than 6 characters
CIFS_CONNECTOR_IDENTIFIER_EMPTY	0x800D0012L	Connector delivers an empty identifier
CIFS_CONNECTOR_DUPLICATE_IDENTIFIER	0x800D0013L	Connector identifier already used

Table 64: CIFS API Transport Error Codes

### 10.6.2 CIFS API Transport Header State Error Codes

Error Code (Definition)	Value	Description
CIFS_TRANSPORT_ERROR_UNKNOWN	0x800E0001L	Unknown error code in transport header
CIFS_TRANSPORT_CHECKSUM_ERROR	0x800E0002L	CRC16 checksum failed
CIFS_TRANSPORT_LENGTH_INCOMPLETE	0x800E0003L	Transaction with incomplete length detected
CIFS_TRANSPORT_DATA_TYPE_UNKNOWN	0x800E0004L	Device does not support requested data type
CIFS_TRANSPORT_DEVICE_UNKNOWN	0x800E0005L	Device not available unknown
CIFS_TRANSPORT_CHANNEL_UNKNOWN	0x800E0006L	Channel not available unknown
CIFS_TRANSPORT_SEQUENCE	0x800E0007L	Sequence error detected
CIFS_TRANSPORT_BUFFER_OVERFLOW	0x800E0008L	Buffer overflow detected
CIFS_TRANSPORT_RESOURCE	0x800E0009L	Device signals out of resources
CIFS_TRANSPORT_KEEPALIVE	0x800E000AL	Device connection monitoring error (Keep alive)
CIFS_TRANSPORT_DATA_TOO_SHORT	0x800E000BL	Received transaction data too short

Table 65: CIFS API Transport Header State Error Codes



## 10.7 ODM Error Codes DBM V4

ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_MD5_INVALID	0XC004C810	Checksum invalid
CDBM_E_INTERNALERROR	0XC004C811	Internal Error
CDBM_W_WRITEREGISTRY	0X8004C812	Error writing to the registry
CDBM_E_UNEXPECTED_VALUE_IN_OLD_HEADER_FORMAT	0XC004C813	Error in a file containing the old DBM Header format.
CDBM_E_CHECKSUM_INVALID	0XC004C814	The Checksum of the old Header is invalid
CDBM_E_DB_ALREADY_LOADED_FORMAT	0XC004C815	A database is already loaded
CDBM_E_NO_VALID_TRANSACTION	0XC004C816	No valid transaction handle given
CDBM_E_STD_STRUCT_ERROR	0XC004C817	An error occurred during validation of data
CDBM_E_UNSUPPORTED_DATA_TYPE_FORMAT	0XC004C818	Unsupported DataType
CDBM_W_CLASS_DELETED_FORMAT	0X8004C819 (Warning)	Using an Object which is marked as deleted
CDBM_W_CLIENT_DISCONNECTED	0X8004C81A (Warning)	A Client has already an outstanding connection to a Table. The connection is now destroyed.
CDBM_E_STRUCTURE_DEFINITION_INVALID	0XC004C81B	A structure definition of an Element in a Table is invalid
CDBM_E_NO_DATA_AVAILABLE	0XC004C81C	No data available for this operation
CDBM_E_NO_VALID_STRUCTURE	0XC004C81D	No valid structure available for this operation
CDBM_E_NO_TOGGLE_STRING_FOUND	0XC004C81E	No Toggle string found for this number
CDBM_E_ELEMENT_OUT_OF_RANGE	0XC004C81F	An element wasn't found in the Record of a Table
CDBM_E_ELEMENT_NOT_IN_TABLE	0XC004C820	The element is not part of the Table
CDBM_E_CANNOT_CONVERT_INTO_CLIENT_TYPE	0XC004C821	The data can't be converted into the Client type
CDBM_E_TRANSACTION_ALREADY_OPEN	0XC004C822	A transaction is already open. Please close this one first before opening a new one.
CDBM_I_OLD_WITHOUT_HEADER	0X4004C823 (Informational)	Use of an old DBM file Format without Header
CDBM_E_HR_FROM	0XC004C824	An HRESULT was received from a Subroutine
CDBM_E_PARAMETER	0XC004C825	A Parameter is invalid
CDBM_E_NOTIMPL	0XC004C826	Method is currently not implemented
CDBM_E_OUTOFMEMORY	0XC004C827	Out of memory
CDBM_E_NO_OPEN_TRANSACTION	0XC004C828	No transaction open
CDBM_E_NO_CONTENTS	0XC004C829	No contents available
CDBM_REC_NO_NOT_FOUND	0XC004C82A	Record not found
CDBM_STRUCTURE_ELEMENT_NOT_FOUND	0XC004C82B	Element of the Structure not found
CDBM_E_NO_MORE_RECORDS_IN_TABTYPE	0XC004C82C	Table type 3 can contain only one record
CDBM_E_WRITE	0XC004C82D	The data in the VARIANT must be given in a SafeArray
CDBM_E_WRITE_NO_PARRAY	0XC004C82E	The VARIANT contains no valid [parray] element
CDBM_E_WRITE_CANT_ACCESS_DATA	0XC004C82F	Unable to access SafeArray Data in the VARIANT

ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_WRITE_DATA	0XC004C830	To write the data of this Element it must be given as a BSTR, or as an Array of VT_UI1/VT_I1
CDBM_E_WRITE_BSTR_E1	0XC004C831	The BSTR string must have an even length.
CDBM_E_WRITE_BSTR_E2	0XC004C832	The BSTR string must contain only hex digits (0..9 and a/A..f/F).
CDBM_E_WRITE_CANT_INTERPRET_ARRAY	0XC004C833	Unable to interpret data in the SafeArray.
CDBM_E_WRITE_VT_ERROR	0XC004C834	Data type in the SafeArray is not VT_UI1 or VT_I1.
CDBM_E_WRITE_LENGTH	0XC004C835	Data length is invalid for write operation of this type.
CDBM_WRITE_ELEMENT	0XC004C836	Element not found in the Record of the Table
CDBM_MIN_MAX_ERROR	0XC004C837	Can't write data because of min underflow or max overflow
CDBM_TABLE_EXIST	0XC004C838	Table already exist in the database
CDBM_MIN_MAX_INVALID	0XC004C839	The Min value is greater than the Max Value
CDBM_DEF_MIN_MAX_INVALID	0XC004C83A	The Default Value is not in the range between the Min value and the Max Value
CDBM_CANT_CHANGE_STRUCTURE_WHILE_RECORDS_EXIST	0XC004C83B	It's not allowed to change the structure while Records exist in the Table
CDBM_NEW_STRUCT_NEEDS_TYPE	0XC004C83C	In a newly added structure the data type must be set also
CDBM_VALUE_ERROR	0XC004C83D	Range error while validating a value
CDBM_DATATYPE_UNSUPPORTED_IN_RCS	0XC004C83E	The data type is unsupported in the RCS file format
CDBM_I_COUNT_OF_TABLES_EXCEEDS_RCS_RANGE	0X4004C83F (Informational)	The count of Tables exceeds the RCS range of Tables. This can cause problems if the file is downloaded to RCS Systems
CDBM_I_COUNT_OF_TABLES_EXCEEDS_OLDDBM_RANGE	0X4004C840 (Informational)	The count of Tables exceeds the DBM32.DLL range of Tables. This can cause problems if the file is used with older Tools using the DBM32.DLL
CDBM_UNSUPPORTED_DATATYPE_IN_RCS_MODE	0XC004C841	The Data type is not compatible with the old database format
CDBM_WRITE_UNSTRUCTURED_1	0XC004C842	The data of an unstructured record can only be written with the 'Write' Method not with 'WriteElement'.
CDBM_READ_UNSTRUCTURED_1	0XC004C843	The data of an unstructured record can only be read with the 'Read' Method not with 'ReadElement'
CDBM_WRITE_DATA_LENGTH_INVALID	0XC004C844	The given data length doesn't correspond with the expected data length.
CDBM_UNKNOWN_VIEW_MODE	0XC004C845	The View Mode is unknown.
CDBM_E_DIAG_TABLE	0XC004C846	It doesn't make much sense to add or delete records from a diagnostic table because those changes are never saved.
CDBM_E_ADR_STRING_ERROR	0XC004C847	The given Address string doesn't fit the required format of this type where all address bytes must be in the range between 0 and FF
CDBM_ERROR_FROM_VAR_CHANGE_TYPE	0XC004C848	Function VariantChangeType return an error when trying to convert the Parameter

ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_MINERROR	0XC004C849	Error while comparing the Value with the lower range
CDBM_E_MAXERROR	0XC004C84A	Error while comparing the Value with the upper range
CDBM_E_RANGE_ERROR	0XC004C84B	Value out of Range
CDBM_E_TABLE_TYPE1	0XC004C84C	Table type 1 doesn't have a unique record length over all records
CDBM_E_TABLE_TYPE3_ADDREC	0XC004C84D	Table type 3 doesn't allow to insert more than one Record
CDBM_E_TABTYPE1	0XC004C84E	It's not allowed to insert more Records than structure definitions in Table Type 1
CDBM_E_TOGGLE_NOT_FOUND	0XC004C84F	Could not find the string for this value in the list of valid toggle strings
CDBM_E_TOGGLE_VALUE_IS_EMPTY_STRING	0XC004C850	The toggle string for this value is empty.
CDBM_VARIANT2BYTEARRAY_ERROR	0XC004C851	Error during conversion of Variant to byte array
CDBM_E_SET_ELEM_PROP_DEPENDENCY	0XC004C852	The Toggle Type needs also the additional string and the additional number entries in the Method
CDBM_E_TABTYPE1_REC_DOESNT_CORRESPOND_WITH_ELEMENT	0XC004C853	When reading the records of Table type 1 elementwise the record number must correspond with the element number
CDBM_TABTYPE1_NO_DATA_FOUND_FOR_RECORD	0XC004C854	When reading the records of Table type 1 and structure definitions are present it's assumed that for each structure element a corresponding record must exist
CDBM_E_TABTYPE1_WRITE_ELEMENT_NE_RECORD	0XC004C855	When writing the records of Table type 1 elementwise and structure definitions are present it's only allowed to write the corresponding element number in each record
CDBM_E_TABTYPE1_WRITE_ELEMENT_NOT_FOUND	0XC004C856	When writing the records of Table type 1 with an array and structure definitions are present it's assumed that a corresponding element number of this record exist
CDBM_I_TABLE_NAME_EXCEEDS_RCS_RANGE	0X4004C857 (Informational)	The Table name exceeds the maximum length of RCS compatible Table names
CDBM_W_CUT_STRING	0X8004C858 (Warning)	The string exceeds the maximum length and will be limited to the maximum length
CDBM_I_STRING_TOO_SHORT	0X4004C859 (Informational)	The string is below the minimum length. The minimum length will be reduced.
CDBM_I_STRING_TOO_LONG	0X4004C85A (Informational)	The string is exceeding the maximum. The maximum length will be extended.
CDBM_E_STRING_TOO_SHORT	0XC004C85B (Error)	The string is below the minimum length.
CDBM_E_STRING_TOO_LONG	0XC004C85C (Error)	The string is exceeding the maximum length
CDBM_E_WRONG_TYPE_FOR_WRITE	0XC004C85D	Writing on the Element type with the given Data type is not implemented
CDBM_E_NO_APPEND_IN_STRUCTURED_RECORDS	0XC004C85E	Method IDbmRecord::AppendData is not allowed for structured records
CDBM_E_DATA_UNAVAILABLE	0XC004C85F	No data available

ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_CANT_CONVERT_INT	0XC004C860	Unable to convert the value into the Element type
CDBM_E_DBM_FILE_OVERFLOW	0XC004C861	You try to write a RCS like database which needs too much bytes
CDBM_E_PW_ERROR	0XC004C862	Password not correct
CDBM_E_FILELENGTH_CORRUPT	0XC004C863	The file length doesn't correspond to the length given in the Header.
CDBM_E_STRUCT_TYPE	0XC004C864	Error in the file.
CDBM_E_MD5SUM_INVALID	0XC004C865	MD5 sum invalid
CDBM_E_STRUCT_LENGTH	0XC004C866	Error in the expected and given structure length at a specific offset in the file.
CDBM_E_APPEND	0XC004C867	Append of data is only allowed if the Record contains only one data field and the field type will support this
CDBM_APPEND_NOT_SUPPORTED	0XC004C868	Append of Data not supported by this filed type
CDBM_DATA_TYPE_APPEND_ERROR	0XC004C869	Can't append Data of this type.
CDBM_E_UNSTRUCTURED_TABLE_DOESNT_SUPPORT_LENGTH	0XC004C86A	A Table without structure information doesn't support a record length
CDBM_E_DISABLED_WHILE_TRANSACTION_IS_OPEN	0XC004C86B	The Method is disabled while a transaction is open. Please close this one first and call the Method again.
CDBM_E_UNABLE_TO_CALL_READ_ON_LINKED_LIST	0XC004C86C	The Method is disabled on a LinkedList type. Please use the IRecordCollection on this type.
CDBM_E_ELEMENT_HAS_NO_SUBSTRUCTURE	0XC004C86D	An Element from a Table has no substructure
CDBM_STRUCT_ERROR_FROM_VAR_CHANGE_TYPE	0XC004C86E	Error from calling VariantChangeType
CDBM_E_FOREIGNKEY_DEF	0XC004C86F	The definition of a FOREIGNKEY must contain the name of the related Table in the description and this Table must exist at this time
CDBM_E_FOREIGNKEY_REF_TAB	0XC004C870	The description of a FOREIGNKEY must refer to a Table of type 'eDbmTableTypeLinkedList'
CDBM_E_KEY	0XC004C871	To create a Record Collection with a KEY it's necessary to have the data type KEY at the first position in all Records of the searched Table
CDBM_E_KEY_TABLE_TYPE	0XC004C872	This Method needs a Table of type 'eDbmTableTypeLinkedList'
CDBM_DATATYPE_NOT_IMPLEMENTED	0XC004C873	This data type is currently not implemented
CDBM_INSERT_POS_NOT_FOUND	0XC004C874	The position of the Record where the new one should be inserted wasn't found
CDBM_E_INSERT_REC_QI	0XC004C875	Error during insertion of a Record
CDBM_E_TAB_PROP	0XC004C876	Invalid Property in Table
CDBM_E_KEY_NOT_FOUND	0XC004C877	The KEY wasn't found in the Table
CDBM_E_KEY_INVALID	0XC004C878	The KEY is invalid for this operation

Table 66: ODM Error Codes DBM V4

# 11 Appendix

## 11.1 User Rights

User-rights are set within the FDT-container. Depending on the level the configuration is accessible by the user or read-only.

To access the **Settings**, **Configuration** and **Diagnosis** panes of the DeviceNet Master DTM you do not need special user rights. Also all users can select the decimal or hexadecimal Display mode or sort table entries.



**Note:** To edit, set or configure the parameters of the **Settings** and **Configuration** panes, you need user rights for *Maintenance*, for *Planning Engineer* or for *Administrator*.

The following tables give an overview of the user right groups and which user rights you need to configure the single parameters.

### 11.1.1 Settings

	Observer	Operator	Maintenance	Planning Engineer	Administrator
<i>Driver</i>	D	D	X	X	X
<i>Verify or adapt Driver Settings</i>	-	-	X	X	X
<i>Configuring netX Driver</i>	-	-	X	X	X
<i>Device Assignment</i>	D	D	X	X	X
<i>Scanning for Devices</i>	-	-	X	X	X
<i>Selecting the Device (with or without firmware)</i>	-	-	X	X	X
<i>Selecting the Device once more (with Firmware)</i>	-	-	X	X	X
<i>Firmware Download</i>	D	D	X	X	X

Table 67: Settings (D = Displaying, X = Editing, Configuring)

### 11.1.2 Configuration

	Observer	Operator	Maintenance	Planning Engineer	Administrator
<i>Bus Parameters</i>	D	D	X	X	X
<i>Server Parameters</i>	D	D	X	X	X
<i>Process Data</i>	D	D	X	X	X
<i>Address Table</i>	D	D	X	X	X
<i>MAC ID Table</i>	D	D	X	X	X
<i>Quick Connect Table</i>	D	D	X	X	X
<i>Master Settings</i>	D	D	X	X	X

Table 68: Configuration (D = Displaying, X = Editing, Configuring)

## 11.2 References

- [1] Device Type Manager (DTM) Style Guide, Version 1.0 ; FDT-JIG - Order No. <0001-0008-000>
- [2] BOSCH CAN Specification 2.0, 1991.
- [3] THE CIP NETWORKS LIBRARY, Volume 3, DeviceNet Adaptation of CIP, Edition 1.15, April 2013
- [4] RSNetWorx & RSNetWorx MDfor DeviceNet, ControlNet, and EtherNet/IP, Seite 4, netwrx-td001\_-en-p.pdf, www.rockwellautomation.com
- [5] Rockwell Automation, DeviceNet Book of Knowledge, Version 7/29/2009, Robert D. Law P.E
- [6] DeviceNet Master Protocol API Manual, Revision 9, Hilscher GmbH 2013
- [7] DeviceNet Slave Protocol API Manual, Revision 12, Hilscher GmbH 2013

## 11.3 List of Figures

Figure 1: Dialog Structure of the DeviceNet Master DTM	15
Figure 2: Navigation Area	16
Figure 3: Status Bar – Status Fields 1 to 6	19
Figure 4: Status Bar Display Examples	19
Figure 5: Default Driver ‚cifX Device Driver’ for PC cards cifX	32
Figure 6: Default Driver ‚cifX Device Driver’ for PC cards cifX (example)	32
Figure 7: Default Driver ‚netX Driver’ for Hilscher devices except for PC cards cifX (example)	32
Figure 8: Manual Selection of multiple drivers (Example)	33
Figure 9: netX Driver > USB/RS232 Connection	36
Figure 10: netX Driver > TCP Connection	39
Figure 11: Device Assignment - detected Devices (* The name of the device class is displayed.) – Example for a device without firmware	41
Figure 12: Device Assignment - detected Devices (* The name of the device class is displayed.) Example for Devices without Firmware	43
Figure 13: Device Assignment - Selecting the Device (* The name of the device class is displayed.) – Example for a device without firmware / one Device is selected	44
Figure 14: Device Assignment - Selecting the Device (* The name of the device class is displayed.) – Example for Devices with and without Firmware / one Device is selected	45
Figure 15: Device Assignment - Selecting the Device (* The name of the device class is displayed.) – Example for a device with firmware / one Device is selected	46
Figure 16: Firmware Download	47
Figure 17: Error Message ‘The device is not assigned to the hardware!’	48
Figure 18: Window ‘Select Firmware File’ (Example CIFS)	49
Figure 19: Request Select Firmware File - Example Invalid Firmware	51
Figure 20: Request - Do you really want to download the firmware?	52
Figure 21: Firmware Download - Progress Bar	52
Figure 22: Clock Symbol and Hook Symbol green	53
Figure 23: Firmware Download – Download	53
Figure 24: Licensing	54
Figure 25: Bus Parameters	58
Figure 26: Bus Parameters > General	59
Figure 27: Bus Parameters > Bus Parameters	59
Figure 28: Bus Parameters > Error Handling	59
Figure 29: Server Parameters	60
Figure 30: Process Data (*The name of the Slave device is displayed.)	61
Figure 31: Configuration > Address Table (In the Figure shown here, in the column Device or Name example devices are displayed.)	62
Figure 32: Configuration > MAC ID Table (In the Figure shown here, in the column Device or Name example devices are displayed.)	63

Figure 33: Configuration > Quick Connect Table	64
Figure 34: Configuration > Master Settings	68
Figure 35: Master Settings > Start of Bus Communication	69
Figure 36: Master Settings > Application Monitoring	69
Figure 37: Master Settings > Module Alignment	70
Figure 38: Master Settings > Process Data Handshake	71
Figure 39: Master Settings > Advanced	71
Figure 40: Master Settings > Device Status Offset	72
Figure 41: Example Debug Mode with pending Diagnosis, (Master and Slave)	77
Figure 42: Set MAC ID	80
Figure 43: Live List	81
Figure 44: Starting 'Network Scan' (Example)	83
Figure 45: Scan Response dialog of the Master DTM (Example)	84
Figure 46: Scan Response dialog of the Master DTM (Example)	85
Figure 47: DTM device is created (Example)	88
Figure 48: 'Upload' the Slave Device Configuration (Example)	89
Figure 49: Query of the Upload Function (Example)	90
Figure 50: Upload succeeded (Example)	90
Figure 51: Uploaded Connection Configuration (Example)	91
Figure 52: netDevice Message: Download	93
Figure 53: License Pane	96
Figure 54: License Pane - License Type	97
Figure 55: License Pane – License Type / Master protocols	97
Figure 56: License Pane – License Type / Utilities	97
Figure 57: License Pane - Request Form, please fill out / Device Information	100
Figure 58: License Pane - Request Form, please fill out / License Type	101
Figure 59: License Pane - Request Form, please fill out / Mandatory data	101
Figure 60: License Pane – Selecting the Subsidiary / Ordering / Contacts	102
Figure 61: License Pane – placing the order by E-mail	103
Figure 62: Example: Order E-Mail License request	103
Figure 63: License Pane - placing the order by Fax or by Telephone	104
Figure 64: Example: Order Data Form PrintOrderRequest	104
Figure 65: License Pane – Fax Number of the selected Subsidiary	105
Figure 66: License Pane – Telephone Number of the selected Subsidiary	105
Figure 67: License Pane - Ordering by exported File and E-Mail	106
Figure 68: License Pane - Download License	107
Figure 69: General Diagnosis	109
Figure 70: Master Diagnosis	111
Figure 71: Bus Diagnosis - Bus Monitoring	112
Figure 72: Bus Diagnosis - Master Status	113
Figure 73: Bus Diagnosis - Server Status	114
Figure 74: Bus Diagnosis - Bus Monitoring	114
Figure 75: Station Diagnosis - Station Status	115
Figure 76: Firmware Diagnosis (*The name of the Firmware is displayed.)	116
Figure 77: Extended Diagnosis > [Folder Name] > Task Info, Example Display	118
Figure 78: Extended Diagnosis > [Folder Name] > IniBatch Status Example Display	119
Figure 79: Extended Diagnosis > CAN_DL > App Commands	120
Figure 80: Extended Diagnosis > CAN_DL > CAN Driver Status	121
Figure 81: Extended Diagnosis > DEVNET_FAL > Application Diagnosis	122
Figure 82: Extended Diagnosis > DEVNET_FAL > Device Status	123
Figure 83: Extended Diagnosis > DEVNET_FAL > Diagnosis Error	124
Figure 84: Extended Diagnosis > DEVNET_FAL > Timeout Counter	124

Figure 85: Extended Diagnosis > DEVNET_FAL > Reinit Counter	125
Figure 86: Extended Diagnosis > DEVNET_FAL > DeviceNet CAN Diagnosis	125
Figure 87: Packet Monitor	127
Figure 88: Send > Packet Header and Send Data	128
Figure 89: Packet Header and Receive Data	129
Figure 90: Packet Description DEVNET_FAL_CMD_GET_ATT_REQ - Get Attribute Request	131
Figure 91: Example - Reading data via „Get Attribute“ – Send > Packet header	132
Figure 92: Example - Read data via „Get Attribute“ - Send > Send Data	133
Figure 93: Packet Description DEVNET_FAL_CMD_GET_ATT_CNF - Confirmation of Get Attribute Request	134
Figure 94: Example - Reading data via „Get Attribute“ – Receive > Packet header	135
Figure 95: Example - Reading data via „Get Attribute“ – Receive > Receive data	136
Figure 96: Packet Description DEVNET_FAL_CMD_SET_ATT_REQ - Set Attribute Request	138
Figure 97: Example - Writing data via „Set Attribute“ – Send > Packet header	139
Figure 98: Example - Writing data via „Set Attribute“ – Send > Send Data	140
Figure 99: Packet Description DEVNET_FAL_CMD_SET_ATT_REQ - Confirmation of Set Attribute Request	141
Figure 100: Example - Writing data via „Set Attribute“ – Receive > Packet header	142
Figure 101: Example – Writing data via „Set Attribute“ – Receive > Receive data	143
Figure 102: IO Monitor	144
Figure 103: Window 'Process Image Monitor'	145

## 11.4 List of Tables

Table 1: Descriptions Dialog Panes	6
Table 2: List of Revisions	7
Table 3: General Device Information	16
Table 4: Overview Dialog Panes	17
Table 5: OK, Cancel, Apply and Help	18
Table 6: Selecting, inserting, deleting Table Line	18
Table 7: Status Bar Icons [1]	19
Table 8: Signal Words	23
Table 9: Getting started - Configuration Steps	27
Table 10: Descriptions of the Dialog Panes Settings	29
Table 11: Driver Selection List Parameters	32
Table 12: Parameters netX Driver > USB/RS232 Connection	37
Table 13: Parameters netX Driver > TCP Connection	40
Table 14: Parameters of the Device Assignment	42
Table 15: Parameter Firmware Download	47
Table 16: Parameters Select Firmware File	50
Table 17: Descriptions of the Dialog Panes Configuration	55
Table 18: Bus Parameters > Bus Parameters	59
Table 19: Server Parameters	60
Table 20: Process Data	61
Table 21: Parameters Address Table Pane - Inputs / Outputs	62
Table 22: Parameters of the MAC-ID Table	63
Table 23: Parameters of the Quick Connect Table	64
Table 24: Range of Value / Value for the Watchdog time	69
Table 25: Parameters Master Settings > Module Alignment	70
Table 26: Option Master Settings > Device Status Offset	72
Table 27: Debug Mode Busline Colors and Debug Icons	78
Table 28: Description on the Scan Response dialog of the Master DTM	87
Table 29: Descriptions of the Diagnosis Panes	108
Table 30: Indication General Diagnosis	110



Table 31: Parameter General Diagnosis	110
Table 32: Parameter Master Diagnosis	111
Table 33: Bus Diagnosis - Master Status	113
Table 34: Bus Diagnosis - Server Status	114
Table 35: Bus Diagnosis - Bus Monitoring	114
Table 36: Possible Values for the Status	115
Table 37: Description Table Task Information	116
Table 38: Descriptions of the Dialog Panes Extended Diagnosis	117
Table 39: Extended Diagnosis > [Folder Name] > Task Info	118
Table 40: Extended Diagnosis > [Folder Name] > IniBatch Status	119
Table 41: Extended Diagnosis > CAN_DL > App Commands	120
Table 42: Extended Diagnosis > CAN_DL > CAN Driver Status	121
Table 43: Extended Diagnosis > DEVNET_FAL > Application Diagnosis	123
Table 44: Extended Diagnosis > DEVNET_FAL > Device Status	123
Table 45: Extended Diagnosis > DEVNET_FAL > Diagnosis Error	124
Table 46: Extended Diagnosis > DEVNET_FAL > Timeout Counter	124
Table 47: Extended Diagnosis > DEVNET_FAL > Reinit Counter	125
Table 48: Extended Diagnosis > DEVNET_FAL > DeviceNet CAN Diagnosis	125
Table 49: Descriptions of the Diagnosis Panes	126
Table 50: Descriptions Packet Header	128
Table 51: Descriptions Packet Header	129
Table 52: Notes to the Window 'Process Image Monitor'	146
Table 53: Overview Error Codes and Ranges	148
Table 54: RCX General Task Errors	149
Table 55: RCX Common Status & Errors Codes	150
Table 56: RCX Status & Error Codes	151
Table 57: RCX Status & Error Codes Slave State	151
Table 58: ODM Error Codes - General ODM Error Codes	152
Table 59: ODM Error Codes - General ODM Driver Error Codes	153
Table 60: cifX Driver Specific ODM Error Codes	156
Table 61: Generic Error Codes	157
Table 62: Generic Driver Error Codes	158
Table 63: Generic Device Error Codes	159
Table 64: CIFS API Transport Error Codes	160
Table 65: CIFS API Transport Header State Error Codes	160
Table 66: ODM Error Codes DBM V4	164
Table 67: Settings (D = Displaying, X = Editing, Configuring)	165
Table 68: Configuration (D = Displaying, X = Editing, Configuring)	165

## 11.5 Glossary

### Data Packets

Data packets, i. e. messages are self-contained blocks of defined data length. The packets are used to communicate with the firmware and they are exchanged between the application (configuration software) and the firmware in the device. Using the configuration software feature *Packet Monitor* Packets can be sent once or cyclically to the connected device controlled by the user and packets received can be displayed.

Data packets comprise from a **Packet Header** and the **Send Data** or from a **Packet Header** and the **Receive Data**. The packet header can be evaluated by the receiver of the packet and contain the sender and receiver address, the data length, an ID number, status and error messages and the command or response code. The minimum packet size amounts 40 Byte for the packet header. The sending and receiving data are added.

### DTM

Device Type Manager

The Device Type Manager (DTM) is a software module with graphical user interface for the configuration and/or for diagnosis of devices.

### FDT

Field Device Tool

FDT specifies an interface, in order to be able to use DTM (Device Type Manager) in different applications of different manufacturers.

### MAC ID

MAC = Media Access Control

The network address of a device serves to distinguish itself on a DeviceNet fieldbus system from any other device or Slave on this network. This should be a unique number for each device. A valid MAC-ID address is within a range of 0 to 63 and can be re-entered and changed in the MAC-ID box in the Device Configuration Dialog.

### Master

Master devices initiate the data exchange at the bus.

### ODMV3

The Online-Data-Manager Version 3 (ODMV3) is an application interface. The ODMV3 works as a server, which can be run as an out-proc server or system service. Its task is to provide different applications (e. g. SYCON.net), access to multiple devices and even share one device amongst several applications.

### Predefined Master/Slave Connection

The “predefined Master/Slave connection” is a connection type, for which the properties of the connection between the Master device and the Slave device is established.

**Slave**

Slave devices are configured by the Master and perform then the communication.

**UCMM**

Unconnected Message Manager

UCMM is a connection type that allows to negotiate the connection properties during the connection is established between the Master device and the Slave device.

## 11.6 Contacts

### Headquarters

#### Germany

Hilscher Gesellschaft für  
Systemautomation mbH  
Rheinstrasse 15  
65795 Hattersheim  
Phone: +49 (0) 6190 9907-0  
Fax: +49 (0) 6190 9907-50  
E-Mail: [info@hilscher.com](mailto:info@hilscher.com)

#### Support

Phone: +49 (0) 6190 9907-99  
E-Mail: [de.support@hilscher.com](mailto:de.support@hilscher.com)

### Subsidiaries

#### China

Hilscher Systemautomation (Shanghai) Co. Ltd.  
200010 Shanghai  
Phone: +86 (0) 21-6355-5161  
E-Mail: [info@hilscher.cn](mailto:info@hilscher.cn)

#### Support

Phone: +86 (0) 21-6355-5161  
E-Mail: [cn.support@hilscher.com](mailto:cn.support@hilscher.com)

#### France

Hilscher France S.a.r.l.  
69500 Bron  
Phone: +33 (0) 4 72 37 98 40  
E-Mail: [info@hilscher.fr](mailto:info@hilscher.fr)

#### Support

Phone: +33 (0) 4 72 37 98 40  
E-Mail: [fr.support@hilscher.com](mailto:fr.support@hilscher.com)

#### India

Hilscher India Pvt. Ltd.  
Pune, Delhi, Mumbai  
Phone: +91 8888 750 777  
E-Mail: [info@hilscher.in](mailto:info@hilscher.in)

#### Italy

Hilscher Italia S.r.l.  
20090 Vimodrone (MI)  
Phone: +39 02 25007068  
E-Mail: [info@hilscher.it](mailto:info@hilscher.it)

#### Support

Phone: +39 02 25007068  
E-Mail: [it.support@hilscher.com](mailto:it.support@hilscher.com)

#### Japan

Hilscher Japan KK  
Tokyo, 160-0022  
Phone: +81 (0) 3-5362-0521  
E-Mail: [info@hilscher.jp](mailto:info@hilscher.jp)

#### Support

Phone: +81 (0) 3-5362-0521  
E-Mail: [jp.support@hilscher.com](mailto:jp.support@hilscher.com)

#### Korea

Hilscher Korea Inc.  
Seongnam, Gyeonggi, 463-400  
Phone: +82 (0) 31-789-3715  
E-Mail: [info@hilscher.kr](mailto:info@hilscher.kr)

#### Switzerland

Hilscher Swiss GmbH  
4500 Solothurn  
Phone: +41 (0) 32 623 6633  
E-Mail: [info@hilscher.ch](mailto:info@hilscher.ch)

#### Support

Phone: +49 (0) 6190 9907-99  
E-Mail: [ch.support@hilscher.com](mailto:ch.support@hilscher.com)

#### USA

Hilscher North America, Inc.  
Lisle, IL 60532  
Phone: +1 630-505-5301  
E-Mail: [info@hilscher.us](mailto:info@hilscher.us)

#### Support

Phone: +1 630-505-5301  
E-Mail: [us.support@hilscher.com](mailto:us.support@hilscher.com)