



**Operating Instruction Manual**  
**DTM for Hilscher AS-Interface Master Devices**  
**Configuration of Hilscher Master Devices**

**Hilscher Gesellschaft für Systemautomation mbH**

**[www.hilscher.com](http://www.hilscher.com)**

DOC090603OI07EN | Revision 7 | English | 2017-03 | Released | Public

# Table of Contents

1	INTRODUCTION.....	6
1.1	About this Manual .....	6
1.1.1	Descriptions of the Dialog Panes .....	6
1.1.2	Online Help .....	6
1.1.3	List of Revisions .....	7
1.1.4	Conventions in this Manual .....	8
1.2	Legal Notes.....	9
1.3	Registered Trademarks.....	12
1.4	About AS-Interface Master DTM .....	12
1.4.1	Requirements .....	13
1.5	Dialog Structure of the AS-Interface Master DTM.....	14
1.5.1	General Device Information.....	15
1.5.2	Navigation Area .....	15
1.5.3	Dialog Panes .....	16
1.5.4	OK, Cancel, Apply and Help.....	17
1.5.5	Table Lines .....	17
1.5.6	Status Bar .....	18
2	SAFETY .....	19
2.1	General Note.....	19
2.2	Intended Use.....	19
2.3	Personnel Qualification .....	19
2.4	Personal Injury .....	20
2.4.1	Communication Stop .....	20
2.4.2	Mismatching System Configuration .....	20
2.5	Property Damage .....	21
2.5.1	Communication Stop .....	21
2.5.2	Invalid Firmware .....	21
2.5.3	Mismatching System Configuration .....	21
2.6	Labeling of Safety Messages .....	22
2.7	References Safety.....	22
3	GETTING STARTED.....	23
3.1	Configuration Steps.....	23
3.2	Safety Messages on Firmware or Configuration Download .....	27
4	SETTINGS .....	29
4.1	Overview Settings .....	29
4.2	Settings for Driver and Device Assignment .....	30
4.3	Driver .....	32

4.3.1	Verify or adapt Driver Settings .....	32
4.3.2	cifX Device Driver .....	34
4.3.3	netX Driver.....	34
4.3.4	Configuring netX Driver .....	35
4.3.5	netX Driver - USB/RS232 Connection.....	36
4.3.6	netX Driver - TCP/IP Connection .....	38
4.4	Device Assignment .....	41
4.4.1	Scanning for Devices.....	41
4.4.2	Selecting the Device (with or without firmware) .....	44
4.4.3	Selecting the Device once more (with Firmware).....	45
4.5	Firmware Download .....	47
4.6	Licensing.....	54
5	CONFIGURATION .....	55
5.1	Overview Configuration .....	55
5.2	Configuring Device Parameters.....	56
5.3	Process Data .....	58
5.4	Address Table .....	59
5.4.1	Description of the Parameters .....	59
5.4.2	Auto Addressing, Display Mode, CSV Export, Inputs / Outputs.....	60
5.5	Station Table .....	61
5.6	Master Settings .....	62
5.6.1	Start of Bus Communication.....	63
5.6.2	Application Monitoring .....	63
5.6.3	Process Image Storage Format .....	64
5.6.4	Module Alignment.....	64
5.6.5	Process Data Handshake.....	65
5.7	Bus Parameters .....	66
6	ONLINE FUNCTIONS .....	67
6.1	Connecting/Disconnecting Device .....	67
6.2	Debug Mode .....	69
6.2.1	Requirements .....	70
6.2.2	Starting Debug Mode.....	71
6.2.3	Debug Mode Busline Colors and Debug Icons .....	72
6.2.4	Reset of the Diagnosis Information and of the Station Status .....	73
6.2.5	Stopping Debug Mode.....	73
6.3	Set Station Address .....	74
6.4	Change Extended ID1 Code.....	75
6.5	Live List.....	76
6.5.1	Access to the Live List.....	76
6.5.2	Display Additional Information, Update Live List.....	78
6.6	Network Scan.....	79
6.6.1	Starting 'Network Scan' .....	80
6.6.2	Settings in the Scan Response Dialog of the Master DTM.....	82

6.6.3	Description on the Scan Response dialog of the Master DTM .....	83
6.6.4	Creating Devices .....	84
6.6.5	Download to the AS-Interface Master Device .....	86
6.7	Download Configuration .....	87
6.8	Start /Stop Communication .....	89
6.9	Licensing.....	90
6.9.1	Open License Dialog .....	90
6.9.2	License Dialog .....	91
6.9.3	Which Licenses are present in the Device? .....	92
6.9.4	How to order a License.....	94
6.9.5	Selecting License(s) .....	94
6.9.6	Ordering Data .....	95
6.9.7	Ordering the License .....	97
6.9.8	How to get the License and transfer it to the Device.....	102
7	DIAGNOSIS .....	103
7.1	Overview Diagnosis .....	103
7.2	General Diagnosis.....	104
7.3	Master Diagnosis .....	106
7.4	Station Diagnosis .....	107
7.5	Interface Diagnosis .....	108
7.5.1	Interface flags .....	108
7.5.2	Periphery errors.....	109
7.6	Firmware Diagnosis .....	110
8	EXTENDED DIAGNOSIS .....	111
8.1	Overview Extended Diagnosis.....	111
8.2	Task Information .....	112
8.3	IniBatch Status.....	113
8.4	ASI_Master .....	114
8.4.1	Commands .....	114
8.4.2	Interrupts .....	115
8.4.3	xC managment area .....	116
8.4.4	xC Slave config area .....	117
8.4.5	xC configuration area .....	117
8.5	ASI_APM .....	118
8.5.1	Master configuration .....	118
8.5.2	Commands .....	119
8.5.3	DPM data exchange .....	120
8.5.4	IO Status.....	121
9	TOOLS .....	122
9.1	Overview Tools .....	122
9.2	Packet Monitor .....	123
9.2.1	Sending Packet .....	124

9.2.2	Receiving Packet.....	125
9.3	IO Monitor .....	126
9.4	Process Image Monitor .....	127
10	ERROR CODES.....	129
10.1	Error Code Definition.....	129
10.2	Overview Error Codes .....	130
10.3	General Hardware Error Codes .....	131
10.3.1	RCX General Task Errors.....	131
10.3.2	RCX Common Status & Errors Codes .....	132
10.3.3	RCX Status & Error Codes .....	133
10.4	ODM Error Codes .....	134
10.4.1	General ODM Error Codes .....	134
10.4.2	General ODM Driver Error Codes .....	135
10.4.3	cifX Driver Specific ODM Error Codes .....	136
10.5	Error Codes cifX Device Driver and netX Driver .....	139
10.5.1	Generic Error Codes.....	139
10.5.2	Generic Driver Error Codes .....	140
10.5.3	Generic Device Error Codes .....	141
10.6	Error Codes netX Driver .....	142
10.6.1	CIFX API Transport Error Codes.....	142
10.6.2	CIFX API Transport Header State Error Codes .....	142
10.7	ODM Error Codes DBM V4 .....	143
11	APPENDIX .....	148
11.1	User Rights .....	148
11.1.1	Settings.....	148
11.1.2	Configuration .....	148
11.2	References.....	149
11.3	List of Figures .....	149
11.4	List of Tables.....	151
11.5	Glossary.....	153
11.6	Contacts.....	154

# 1 Introduction

## 1.1 About this Manual

This manual provides information on how to set and configure the device parameters of a netX based AS-Interface Master device using the AS-Interface Master DTM, and what can be read from the diagnosis panes.

### 1.1.1 Descriptions of the Dialog Panes

The table below gives an overview for the individual dialog panes descriptions:

Section	Subsection	Page
<i>Settings</i>	<i>Overview Settings</i>	29
	<i>Driver</i>	32
	<i>Device Assignment</i>	41
	<i>Firmware Download</i>	47
	<i>Licensing</i>	90
<i>Configuration</i>	<i>Overview Configuration</i>	55
	<i>Process Data</i>	58
	<i>Address Table</i>	59
	<i>Station Table</i>	61
	<i>Master Settings</i>	62
	<i>Bus Parameters</i>	66
<i>Diagnosis</i>	<i>Overview Diagnosis</i>	103
	<i>General Diagnosis</i>	104
	<i>Master Diagnosis</i>	106
	<i>Station Diagnosis</i>	107
	<i>Interface Diagnosis</i>	108
	<i>Firmware Diagnosis</i>	110
<i>Extended Diagnosis</i>	<i>Overview Extended Diagnosis</i>	111
<i>Tools</i>	<i>Overview Tools</i>	122
	<i>Packet Monitor</i>	123
	<i>IO Monitor</i>	126
	<i>Process Image Monitor</i>	127

Table 1: Descriptions Dialog Pages

### 1.1.2 Online Help

The AS-Interface Master DTM contains an integrated online help facility.

- To open the online help, click on **Help** or press **F1**.

### 1.1.3 List of Revisions

Index	Date	Version	Component	Chapter	Revision
6	15-10-22	1.3.x.x 1.3.x.x	ASiMasterDTMx.dll ASiMasterGULx.ocx	2, 3.2,  4.5,  5.3, 6	Safety information added throughout the document.: Chapter <i>Safety</i> , section <i>Safety Messages on Firmware or Configuration Download</i> , section <i>Firmware Download</i> and further safety messages according to firmware and configuration download. Section <i>Process Data</i> revised. Chapter <i>Online Functions</i> : Note 'Getting Access to SYCON.net Online Functions' added and safety messages according to firmware and configuration download.
7	17-02-22	1.1000.x.x 1.1000.x.x	ASiMasterDTMx.dll ASiMasterGULx.ocx	1.4.1	Section <i>Requirements</i> Internet access added, Windows 8.1 and Windows 10 added.

Table 2: List of Revisions

## 1.1.4 Conventions in this Manual

Notes, operation instructions and results of operation steps are marked as follows:

### Notes



**Important:** <important note you must follow to avoid malfunction>



**Note:** <general note>



<note, where to find further information>

### Operation Instructions

1. <instruction>

2. <instruction>

or

➤ <instruction>

### Results

↪ <result>

### Positions in Figures

The *Positions* ①, ②, ③ ... or Ⓐ, Ⓑ, Ⓒ ... or Ⓐ, Ⓑ, Ⓒ ... refer to the figure used in that section. If the numbers reference to a section outside the current section then a cross reference to that section and figure is indicated.



## 1.2 Legal Notes

### Copyright

© Hilscher Gesellschaft für Systemautomation mbH

All rights reserved.

The images, photographs and texts in the accompanying materials (in the form of a user's manual, operator's manual, Statement of Work document and all other document types, support texts, documentation, etc.) are protected by German and international copyright and by international trade and protective provisions. Without the prior written consent, you do not have permission to duplicate them either in full or in part using technical or mechanical methods (print, photocopy or any other method), to edit them using electronic systems or to transfer them. You are not permitted to make changes to copyright notices, markings, trademarks or ownership declarations. Illustrations are provided without taking the patent situation into account. Any company names and product designations provided in this document may be brands or trademarks by the corresponding owner and may be protected under trademark, brand or patent law. Any form of further use shall require the express consent from the relevant owner of the rights.

### Important notes

Utmost care was/is given in the preparation of the documentation at hand consisting of a user's manual, operating manual and any other document type and accompanying texts. However, errors cannot be ruled out. Therefore, we cannot assume any guarantee or legal responsibility for erroneous information or liability of any kind. You are hereby made aware that descriptions found in the user's manual, the accompanying texts and the documentation neither represent a guarantee nor any indication on proper use as stipulated in the agreement or a promised attribute. It cannot be ruled out that the user's manual, the accompanying texts and the documentation do not completely match the described attributes, standards or any other data for the delivered product. A warranty or guarantee with respect to the correctness or accuracy of the information is not assumed.

We reserve the right to modify our products and the specifications for such as well as the corresponding documentation in the form of a user's manual, operating manual and/or any other document types and accompanying texts at any time and without notice without being required to notify of said modification. Changes shall be taken into account in future manuals and do not represent an obligation of any kind, in particular there shall be no right to have delivered documents revised. The manual delivered with the product shall apply.

Under no circumstances shall Hilscher Gesellschaft für Systemautomation mbH be liable for direct, indirect, ancillary or subsequent damage, or for any loss of income, which may arise after use of the information contained herein.

### Liability disclaimer

The hardware and/or software was created and tested by Hilscher Gesellschaft für Systemautomation mbH with utmost care and is made available as is. No warranty can be assumed for the performance or flawlessness of the hardware and/or software under all application

conditions and scenarios and the work results achieved by the user when using the hardware and/or software. Liability for any damage that may have occurred as a result of using the hardware and/or software or the corresponding documents shall be limited to an event involving willful intent or a grossly negligent violation of a fundamental contractual obligation. However, the right to assert damages due to a violation of a fundamental contractual obligation shall be limited to contract-typical foreseeable damage.

It is hereby expressly agreed upon in particular that any use or utilization of the hardware and/or software in connection with

- Flight control systems in aviation and aerospace;
- Nuclear fusion processes in nuclear power plants;
- Medical devices used for life support and
- Vehicle control systems used in passenger transport

shall be excluded. Use of the hardware and/or software in any of the following areas is strictly prohibited:

- For military purposes or in weaponry;
- For designing, engineering, maintaining or operating nuclear systems;
- In flight safety systems, aviation and flight telecommunications systems;
- In life-support systems;
- In systems in which any malfunction in the hardware and/or software may result in physical injuries or fatalities.

You are hereby made aware that the hardware and/or software was not created for use in hazardous environments, which require fail-safe control mechanisms. Use of the hardware and/or software in this kind of environment shall be at your own risk; any liability for damage or loss due to impermissible use shall be excluded.

### Warranty

Hilscher Gesellschaft für Systemautomation mbH hereby guarantees that the software shall run without errors in accordance with the requirements listed in the specifications and that there were no defects on the date of acceptance. The warranty period shall be 12 months commencing as of the date of acceptance or purchase (with express declaration or implied, by customer's conclusive behavior, e.g. putting into operation permanently).

The warranty obligation for equipment (hardware) we produce is 36 months, calculated as of the date of delivery ex works. The aforementioned provisions shall not apply if longer warranty periods are mandatory by law pursuant to Section 438 (1.2) BGB, Section 479 (1) BGB and Section 634a (1) BGB [Bürgerliches Gesetzbuch; German Civil Code] If, despite of all due care taken, the delivered product should have a defect, which already existed at the time of the transfer of risk, it shall be at our discretion to either repair the product or to deliver a replacement product, subject to timely notification of defect.

The warranty obligation shall not apply if the notification of defect is not asserted promptly, if the purchaser or third party has tampered with the products, if the defect is the result of natural wear, was caused by unfavorable operating conditions or is due to violations against our operating regulations or against rules of good electrical engineering

practice, or if our request to return the defective object is not promptly complied with.

### **Costs of support, maintenance, customization and product care**

Please be advised that any subsequent improvement shall only be free of charge if a defect is found. Any form of technical support, maintenance and customization is not a warranty service, but instead shall be charged extra.

### **Additional guarantees**

Although the hardware and software was developed and tested in-depth with greatest care, Hilscher Gesellschaft für Systemautomation mbH shall not assume any guarantee for the suitability thereof for any purpose that was not confirmed in writing. No guarantee can be granted whereby the hardware and software satisfies your requirements, or the use of the hardware and/or software is uninterrupted or the hardware and/or software is fault-free.

It cannot be guaranteed that patents and/or ownership privileges have not been infringed upon or violated or that the products are free from third-party influence. No additional guarantees or promises shall be made as to whether the product is market current, free from deficiency in title, or can be integrated or is usable for specific purposes, unless such guarantees or promises are required under existing law and cannot be restricted.

### **Confidentiality**

The customer hereby expressly acknowledges that this document contains trade secrets, information protected by copyright and other patent and ownership privileges as well as any related rights of Hilscher Gesellschaft für Systemautomation mbH. The customer agrees to treat as confidential all of the information made available to customer by Hilscher Gesellschaft für Systemautomation mbH and rights, which were disclosed by Hilscher Gesellschaft für Systemautomation mbH and that were made accessible as well as the terms and conditions of this agreement itself.

The parties hereby agree to one another that the information that each party receives from the other party respectively is and shall remain the intellectual property of said other party, unless provided for otherwise in a contractual agreement.

The customer must not allow any third party to become knowledgeable of this expertise and shall only provide knowledge thereof to authorized users as appropriate and necessary. Companies associated with the customer shall not be deemed third parties. The customer must obligate authorized users to confidentiality. The customer should only use the confidential information in connection with the performances specified in this agreement.

The customer must not use this confidential information to his own advantage or for his own purposes or rather to the advantage or for the purpose of a third party, nor must it be used for commercial purposes and this confidential information must only be used to the extent provided for in this agreement or otherwise to the extent as expressly authorized by the disclosing party in written form. The customer has the right, subject to the obligation to confidentiality, to disclose the terms and conditions of this agreement directly to his legal and financial consultants as would be required for the customer's normal business operation.

### Export provisions

The delivered product (including technical data) is subject to the legal export and/or import laws as well as any associated regulations of various countries, especially such laws applicable in Germany and in the United States. The products / hardware / software must not be exported into such countries for which export is prohibited under US American export control laws and its supplementary provisions. You hereby agree to strictly follow the regulations and to yourself be responsible for observing them. You are hereby made aware that you may be required to obtain governmental approval to export, reexport or import the product.

## 1.3 Registered Trademarks

Windows® XP, Windows® Vista, Windows® 7, Windows® 8, Windows® 8.1 and Windows® 10 are registered trademarks of Microsoft Corporation.

CODESYS® is a registered trademark of 3S-Smart Software Solutions GmbH, Deutschland.

All other mentioned trademarks are property of their respective legal owners.

## 1.4 About AS-Interface Master DTM

You can use the AS-Interface Master DTM to configure the AS-Interface Master device within a FDT Framework.



---

**Important:** For a 2-channel device consecutively channel 1 or channel 2 must be assigned to the DTM and each must be configured individually.

---

## 1.4.1 Requirements

### System Requirements

- PC with 1 GHz processor or higher
- Windows® XP SP3,  
Windows® Vista (32 bit) SP2,  
Windows® 7 (32 bit und 64-Bit) SP1,  
Windows® 8 (32-Bit und 64-Bit),  
Windows® 8.1 (32-Bit und 64-Bit),  
Windows® 10 (32-Bit und 64-Bit)
- Administrator privilege required for installation
- Internet Explorer 5.5 or higher
- RAM: min. 512 MByte, recommended 1024 MByte
- Graphic resolution: min. 1024 x 768 pixel
- Keyboard and Mouse
- Restriction: Touch screen is not supported.



**Note:** If the project file is used on another PC,

- the other PC must also comply to these system requirements,
- the device description files of the devices used in the project must be imported to the configuration software SYCON.net on the other PC,
- respectively the DTMs of the devices used in the project must be installed on the other PC.

### Requirements AS-Interface Master DTM

To configure the AS-Interface Master device with the AS-Interface Master DTM the following requirements have to be accomplished:

- Completed hardware installation of a netX based DTM-compatible AS-Interface Master device, inclusive loaded firmware, license and loaded cifX configuration file
- Installed FDT/DTM V 1.2 compliant frame application
- Loaded DTM in the Device Catalog of the FTD Framework



**Note:** If the AS-Interface Master DTM and the AS-Interface Master device are installed on the same PC, the **cifX Device Driver** must be installed on that PC, as you can connect the DTM to the device.



For more information to the hardware installation, please refer to the corresponding **User Manual** of your device.

To get information on how to order and to download the license to the device, please refer to section *Licensing* on page 90.

## 1.5 Dialog Structure of the AS-Interface Master DTM

The graphical user interface of the DTM is composed of different areas and elements listed hereafter:

1. A header area containing the **General Device Information**,
2. The **Navigation Area** (area on the left side),
3. The **Dialog Pane** (main area on the right side),
4. **OK, Cancel, Apply, Help**,
5. The **Status Line** containing information e. g. the online-state of the DTM.




Figure 1: Dialog Structure of the AS-Interface Master DTM

## 1.5.1 General Device Information

Parameter	Meaning
IO Device	Name of the device
Vendor	Vendor name of the device
Device ID	Identification number of the device
Vendor ID	Identification number of the vendor

Table 3: General Device Information

## 1.5.2 Navigation Area

The **Navigation Area** contains folders and subfolders to open the dialog panes of the DTM.




Figure 2: Navigation Area

- Select the required folder and subfolder.
- The corresponding Dialog pane is displayed.

### Hide / display Navigation

	Hiding the navigation area (above right side).
Show navigation area	Opening the navigation area (below left side).

### 1.5.3 Dialog Panes

At the dialog pane the **Settings**, **Configuration**, **Diagnosis/Extended Diagnosis** or the **Tools** panes are opened via the corresponding folder in the navigation area.

Settings	
Driver	To establish a connection from the AS-Interface Master DTM to the AS-Interface Master device, on the pane <b>Driver</b> you can verify if the default driver is checked and respectively check another driver or multiple drivers. For further information, refer to section <i>Driver</i> on page 32.
Device Assignment	On the pane <b>Device Assignment</b> you select the device and assign the device to the driver. For further information, refer to section <i>Device Assignment</i> on page 41.
Firmware Download	The dialog on the pane <b>Firmware Download</b> is used to load a new firmware into the device. A detailed description can be found in section <i>Firmware Download</i> on page 47.
Licensing	Using the license dialog, you can order licenses for Master protocols or Utilities and download them to your device. A detailed description can be found in section <i>Licensing</i> on page 90.
Configuration	
Process Data	The <b>Process Data</b> pane serves for the AS-Interface Master DTM as an external process data interface. For further information, refer to section <i>Process Data</i> on page 58.
Address Table	The <b>Address Table</b> shows a list of all dpram addresses used in the process data image. For further information, refer to section <i>Address Table</i> on page 59.
Station Table	The <b>Station Table</b> displays the list of all configured slave devices. Further information to the station table can be found in the section <i>Station Table</i> on page 61.
Master Settings	At the <b>Master Settings</b> pane device related settings can be made. For further information, refer to section <i>Master Settings</i> on page 62.
Bus Parameter	The <b>Bus Parameters</b> are the basis of an operating data exchange. For further information refer to section <i>Bus Parameters</i> on page 66.
Diagnosis	
Diagnosis/ Extended Diagnosis	At the <b>Diagnosis</b> panes information can be read for troubleshooting. For further information, refer to section <i>Overview Diagnosis</i> on page 103 or section <i>Overview Extended Diagnosis</i> on page 111.
Tools	
Packet Monitor/ IO Monitor/ Process Image Monitor	Under <b>Tools</b> the Packet Monitor and the IO Monitor are provided for test and diagnosis purposes. For further information, refer to section <i>Packet Monitor</i> on page 123 or section <i>IO Monitor</i> on page 126 or section <i>Process Image Monitor</i> on page 127.

Table 4: Overview Dialog Panes



**Note:** Accessing the **Diagnosis** panes of the AS-Interface Master DTM requires an online connection from the AS-Interface Master DTM to the AS-Interface Master device.



For further information, refer to section *Connecting/Disconnecting Device* on page 67.



## 1.5.4 OK, Cancel, Apply and Help

**OK, Cancel, Apply and Help** you can use as described hereafter.

	Meaning
<b>OK</b>	To confirm your latest settings, click <b>OK</b> . All changed values will be applied on the frame application database. <i>The dialog then closes.</i>
<b>Cancel</b>	To cancel your latest changes, click <b>Cancel</b> . Answer to the safety query <b>Configuration data has been changed. Do you want to save the data?</b> by <b>Yes</b> , <b>No</b> or <b>Cancel</b> . <b>Yes:</b> The changes are saved or the changed values are applied on the frame application database. <i>The dialog then closes.</i> <b>No:</b> The changes are <u>not</u> saved or the changed values are not applied on the frame application database. <i>The dialog then closes.</i> <b>Cancel:</b> <i>Back to the DTM.</i>
<b>Apply</b>	To confirm your latest settings, click <b>Apply</b> . All changed values will be applied on the frame application database. <i>The dialog remains opened.</i>
<b>Help</b>	To open the DTM online help, click <b>Help</b> .

Table 5: OK, Cancel, Apply and Help

## 1.5.5 Table Lines

In the DTM dialog pane table lines can be selected, inserted or deleted.







	Meaning
	To select the first line of a table use <b>First Line</b> .
	To select the previous line of a table use <b>Previous Line</b> .
	To select the next line of a table use <b>Next Line</b> .
	To select the last line of a table use <b>Last Line</b> .
	<b>Create a new Line</b> inserts new lines into the table.
	<b>Delete selected Line</b> deletes the selected line from the table.

Table 6: Selecting, inserting, deleting Table Line

## 1.5.6 Status Bar

The **Status Bar** displays information about the current state of the DTM. The current activity, e.g. download, is signaled graphically via icons in the status bar.





Figure 3: Status Bar – Status Fields 1 to 6


Status Field	Icon / Meaning	
1	<b>DTM Connection States</b>	
		<b>Connected:</b> Icon closed = Device is online
		<b>Disconnected:</b> Icon opened = Device is offline
2	<b>Data Source States</b>	
		<b>Data set:</b> The displayed data are read out from the instance data set (database).
		<b>Device:</b> The displayed data are read out from the device.
3	<b>States of the instance Date Set</b>	
		<b>Valid Modified:</b> Parameter is changed (not equal to data source).
4	<b>Changes directly made on the Device</b>	
		Load/configure diagnosis parameters: Diagnosis is activated.
6	<b>Device Diagnosis Status</b>	
		<b>Save operation succeeded:</b> The save operation has been successful. Further messages due to successful handling of device data.
		<b>Firmware Download:</b> Firmware Download is running
		<b>Save operation failed:</b> The save operation has failed. Further fail operation messages due to incorrect communication due to malfunction in the field device or its peripherals.

Table 7: Status Bar Icons [1]


Offline State




Save operation succeeded



Firmware Download



Firmware Download successful



Online State and Diagnosis




Figure 4: Status Bar Display Examples

## **2 Safety**

### **2.1 General Note**

The documentation in the form of a user manual, an operating instruction manual or other manual types, as well as the accompanying texts have been created for the use of the products by educated personnel. When using the products, all Safety Messages, Integrated Safety Messages, Property Damage Messages and all valid legal regulations must be obeyed. Technical knowledge is presumed. The user has to assure that all legal regulations are obeyed.

### **2.2 Intended Use**

The AS-Interface Master DTM serves for configuration and diagnosis of AS-Interface Master devices.

### **2.3 Personnel Qualification**

Personnel responsible for the application of the network system shall be aware of the system behavior and shall be trained in using the system.

## 2.4 Personal Injury

To ensure your own personal safety and to avoid personal injury, you necessarily must read, understand, and comply with the safety instructions and safety messages in this manual before you configure your system.

### 2.4.1 Communication Stop

If you perform a firmware download or a configuration download via the AS-Interface Master DTM be aware of the following:

- Together with the firmware download, an automated device reset is performed that will interrupt all network communications and established connections will drop.
- If you attempt to download the configuration during bus operation, the communication between Master and Slaves is stopped.
- Unexpected equipment operation may cause personal injury.
- Stop the application program before starting upgrading the firmware or downloading the configuration.
- Make sure that your equipment operates under conditions that prevent personal injury. All network devices should be placed in a fail-safe mode before upgrading the firmware or downloading a configuration.

You find the description about the firmware download in section *Firmware Download* on page 47 and about the configuration download in section *Download Configuration* on page 87.

### 2.4.2 Mismatching System Configuration

Mismatching system configuration loaded into the device could result in faulty data mapping in the application program and thus unexpected equipment operation may cause personal injury.

## 2.5 Property Damage

To avoid property damage respectively device destruction and damage to your system or to your equipment, you necessarily must read, understand, and comply with the safety instructions and safety messages in this manual before you configure your system.

### 2.5.1 Communication Stop

If you perform a firmware download or a configuration download via the AS-Interface Master DTM be aware of the following:

- Together with the firmware download, an automated device reset is performed that will interrupt all network communications and established connections will drop.
- If you attempt to download the configuration during bus operation, the communication between Master and Slaves is stopped.

#### **Damage of Equipment**

- Unexpected equipment operation may cause property damage.
- Stop the application program before starting upgrading the firmware or downloading the configuration.
- Make sure that your equipment operates under conditions that prevent property damage. All network devices should be placed in a fail-safe mode before upgrading the firmware or downloading a configuration.

#### **Loss of Device Parameters**

- Both the firmware download and the configuration download erase the configuration data base. The firmware download overwrites the existing firmware in the network device.
- Device parameters that have not been saved non-volatile are getting lost during the reset.
- To complete the firmware update and to make the device operable again, re-download the configuration when the firmware update has been finished.

### 2.5.2 Invalid Firmware

Loading invalid firmware files could render your module unusable.

### 2.5.3 Mismatching System Configuration

Mismatching system configuration loaded into the device could result in faulty data mapping in the application program and thus unexpected equipment operation may cause damage of equipment.

## 2.6 Labeling of Safety Messages

- The **Section Safety Messages** at the beginning of a chapter are pinpointed particularly and highlighted by a signal word according to the degree of endangerment. The kind of danger is specified exactly by the safety message text
- The **Integrated Safety Messages** within an instruction description are highlighted with a signal word according to the degree of endangerment. The kind of danger is specified exactly by the safety message text.




Signal Word	Meaning (international)	Meaning (USA)
 <b>DANGER</b>	Indicates a direct hazard with high risk, which will have as consequence death or grievous bodily harm if it isn't avoided.	Indicates a Hazardous Situation Which if not Avoided, will Result in Death or Serious Injury.
 <b>WARNING</b>	Indicates a possible hazard with medium risk, which will have as consequence death or (grievous) bodily harm if it isn't avoided.	Indicates a Hazardous Situation Which if not Avoided, could Result in Death or Serious Injury.
 <b>CAUTION</b>	Indicates a minor hazard with medium risk, which could have as consequence simple battery if it isn't avoided.	Indicates a Hazardous Situation Which if not Avoided, may Result in Minor or Moderate Injury.

Table 8: Signal Words in Safety Messages on Personal Injury


Signal Word	Meaning (international and USA)
 <b>NOTICE</b>	Indicates a Property Damage Message.

Table 9: Signal Words in Safety Messages on Property Damage

In this document all Safety Instructions and Safety Messages are designed according both to the international used safety conventions as well as to the ANSI Z535.6 standard, refer to reference safety [S1].

In this document the signal words 'WARNING', 'CAUTION' and 'NOTICE' are used according to ANSI Z535.6 standard. The meaning given in ISO/IEC 26514 [S4] section '11.11 Contents of warnings and cautions' is not relevant in this manual.

## 2.7 References Safety

- [S1] ANSI Z535.6-2006 American National Standard for Product Safety Information in Product Manuals, Instructions, and Other Collateral Materials
- [S4] 26514-2010 - IEEE Standard for Adoption of ISO/IEC 26514:2008 Systems and Software Engineering--Requirements for Designers and Developers of User Documentation

## 3 Getting started

### 3.1 Configuration Steps




The following overview provides to you the step sequence on how to configure a netX based AS-Interface Master device with AS-Interface Master DTM as it is typical for many cases. At this time it is presupposed that the hardware installation was done.

The overview lists all the steps in a compressed form. For detailed descriptions of each step refer to the sections noted in the column *For detailed information see section*.



**Important:** For a 2-channel device consecutively channel 1 or channel 2 must be assigned to the DTM and each must be configured individually.

#	Step	Short Description	For detailed information see section	Page
1	Add AS-Interface Slave in the Device Catalog	Add the Slave in the Device Catalog by importing the device description file to the Device Catalog. Depending of the FDT Container. For netDevice: - <b>Network &gt; Import Device Descriptions</b> .	(See <i>Operating Instruction Manual netDevice and netProject</i> )	-
2	Load device catalog	Depending of the FDT Container: For netDevice: - select <b>Network &gt; Device Catalog</b> , - select <b>Reload Catalog</b> .	(See <i>Operating Instruction Manual netDevice and netProject</i> )	-
3	Create new project / Open existing project	Depending of the frame application. For the configuration software: - select <b>File &gt; New</b> or <b>File &gt; Open</b> .	(See <i>Operating Instruction Manual of the Frame Application</i> )	-
4	Insert Master or Slave into configuration	Depending of the FDT Container: For netDevice: - in the Device Catalog click to the Master, - and insert the device via drag and drop <b>to the line</b> in the network view, - in the Device Catalog click to the Slave*, - and insert the device via drag and drop <b>to the Master bus line</b> in the network view. (*This step won't be necessary if the network structure is scanned automatically. See <i>step 17</i> .)	(See <i>Operating Instruction Manual netDevice and netProject</i> )	-
5	Open the Master DTM configuration dialog	Open the Master DTM configuration dialog. - Double click to the device icon of the Master. - The Master DTM configuration dialog is displayed.	-	-

#	Step	Short Description	For detailed information see section	Page
6	Verify or adapt Driver Settings	<p>In the Master DTM configuration dialog: - select <b>Settings &gt; Driver</b>.</p> <div>  <p><b>Note!</b> For PC cards cifX the <b>cifX Device Driver</b> is preset as a default driver. For all the other Hilscher devices the <b>netX Driver</b> is preset as a default driver.</p> <ul style="list-style-type: none"> <li>• Use the <b>cifX Device Driver</b> if the AS-Interface Master DTM is installed on the same PC as the AS-Interface Master device.</li> <li>• Use the <b>netX Driver</b> to establish a USB, Serial (RS232) or TCP/IP connection from the AS-Interface Master DTM to the AS-Interface Master device.</li> <li>• <b>The 3SGateway Driver for netX (V3.x)</b> is used only in relationship with CODESYS.</li> </ul> <p>To search for devices you can check one or multiple drivers simultaneously.</p> </div> <p>- Verify that the default driver is checked. - If necessary, check another driver or multiple drivers.</p>	<p><i>Settings for Driver and Device Assignment and Driver</i></p>	<p>30</p> <p>32</p>
7	Configure Driver	<p>If you use the <b>netX Driver</b>, you respectively must configure it.</p> <p>For <b>netX Driver and communication via TCP/IP</b> set the IP address of the device: - Select <b>Settings &gt; Driver &gt; netX Driver &gt; TCP Connection</b>. - Via  add an IP range. - Under <b>IP Address</b> enter the IP Address of the device or an IP range. - Click <b>Save</b>.</p> <p>Adjust the driver parameters <b>netX Driver USB/RS232</b> only if they differ from the default settings.</p> <div>  <p><b>Note!</b></p> <ul style="list-style-type: none"> <li>• The <b>cifX Device Driver</b> requires no configuration.</li> <li>• The configuration of the <b>3SGateway Driver for netX (V3.x)</b> is carried out via the CODESYS surface.</li> </ul> </div>	<p><i>Configuring netX Driver</i></p>	<p>35</p>
8	Assign Master device (with or without firmware)	<p>Assign the device to this driver.</p> <p>In the Master DTM configuration dialog: - select <b>Settings &gt; Device Assignment</b>, - select a Master device (with or without firmware), - therefore check the appropriate checkbox, - select <b>Apply</b>.</p>	<p><i>Selecting the Device (with or without firmware)</i></p>	<p>44</p>



#	Step	Short Description	For detailed information see section	Page
9	Select and download firmware	<p>If not yet a firmware was loaded to the device:</p> <ul style="list-style-type: none"> <li>- Adhere to the necessary safety precautions to prevent personnel injury and property damage that may occur in consequence of a communication stop.</li> </ul> <p>In the Master DTM configuration dialog:</p> <ul style="list-style-type: none"> <li>- select <b>Settings &gt; Firmware Download</b>,</li> <li>- select <b>Browse..</b>,</li> <li>- select a firmware file,</li> <li>- select <b>Open</b>,</li> <li>- select <b>Download</b> and <b>Yes</b>.</li> </ul>	<p><i>Safety Messages on Firmware or Configuration Download</i></p> <p><i>Firmware Download</i></p>	<p>27</p> <p>47</p>
10	Assign Master device once more (with firmware and system channel) <i>For repeated download this step is omitted.</i>	<p>In the Master DTM configuration dialog:</p> <ul style="list-style-type: none"> <li>- select <b>Settings &gt; Device Assignment</b>,</li> <li>- select <b>Scan</b>,</li> <li>- select the Master device (with loaded and defined system channel),</li> <li>- therefore check the appropriate checkbox,</li> <li>- select <b>Apply</b>,</li> <li>- close the Master DTM configuration dialog via <b>OK</b>.</li> </ul>	<i>Selecting the Device once more (with Firmware)</i>	45
11	Configure Slave device* (*This step won't be necessary if the network structure is scanned automatically. See step 17.)	<p>Configure the Slave device.</p> <ul style="list-style-type: none"> <li>- Double click to the device icon of the Slave.</li> <li>- The Slave DTM configuration dialog is displayed.</li> </ul> <p>In the Slave DTM configuration dialog:</p> <ul style="list-style-type: none"> <li>- select <b>Configuration &gt; General</b>,</li> <li>- set the symbolic name of the generic AS-Interface device station,</li> <li>- select <b>Configuration &gt; Configuration</b>,</li> <li>- set the Slave data and the parameter data,</li> <li>- select <b>Configuration &gt; Signal Configuration</b>,</li> <li>- set for the single signals the names of the tags or the data types,</li> <li>- close the Slave DTM configuration dialog via <b>OK</b>.</li> </ul>	<i>(See Operating Instruction Manual Generic Slave DTM for AS-Interface Slave Devices)</i>	-
12	Configure Master device	<p>Configure the Master device.</p> <ul style="list-style-type: none"> <li>- Double click to the device icon of the Master.</li> <li>- The Master DTM configuration dialog is displayed.</li> </ul> <p>In the Master DTM configuration dialog:</p> <ul style="list-style-type: none"> <li>- select <b>Configuration &gt; Process data</b>,</li> <li>- set symbolic names for the configured modules or signals.</li> <li>- select <b>Configuration &gt; Address table</b>,</li> <li>- set the device address, if necessary,</li> <li>- select <b>Configuration &gt; Station Table</b>,</li> <li>- set the station address of the devices,</li> <li>- select <b>Configuration &gt; Master Settings</b>,</li> <li>- set the Master <b>Settings</b>.</li> <li>- select <b>Configuration &gt; Bus Parameters</b>,</li> <li>- set the bus parameters,</li> <li>- close the Master DTM configuration dialog via <b>OK</b>.</li> </ul>	<p><i>Configuring Device Parameters</i></p> <p><i>Process Data</i></p> <p><i>Address Table</i></p> <p><i>Station Table</i></p> <p><i>Master Settings</i></p> <p><i>Bus Parameters</i></p>	<p>56</p> <p>58</p> <p>59</p> <p>61</p> <p>62</p> <p>66</p>
13	Save project	<p>Depending of the frame application.</p> <p>For the configuration software:</p> <ul style="list-style-type: none"> <li>- select <b>File &gt; Save</b>.</li> </ul>	<i>(See Operating Instruction Manual of the Frame Application)</i>	-
14	Connect Master device	<p>Depending of the FDT Container.</p> <p>For netDevice:</p> <ul style="list-style-type: none"> <li>- right click to the device icon of the Master,</li> <li>- select <b>Connect</b>.</li> </ul>	<i>Connecting/Disconnecting Device</i>	67
15	Licensing	How to order licenses later and how to transfer them to the device.	<i>Licensing</i>	90

#	Step	Short Description	For detailed information see section	Page
16	Download Configuration	<p>- Adhere to the necessary safety precautions to prevent personnel injury and property damage that may occur in consequence of a communication stop or in consequence of a mismatching system configuration.</p> <p>Depending of the FDT Container. For netDevice:</p> <ul style="list-style-type: none"> <li>- right click to the device icon of the Master,</li> <li>- select <b>Download</b>.</li> </ul>	<p><i>Safety Messages on Firmware or Configuration Download</i></p> <p><i>Download Configuration</i></p>	<p>27</p> <p>87</p>
17	Network Scan / Live List	<p>As an alternative to manually configure the Slave device, you can automatically scan the network structure by using the context menu <b>Network Scan</b>.</p> <p>Therefore proceed the following steps:</p> <ol style="list-style-type: none"> <li>1. Start the <b>Network Scan</b> function.</li> <li>2. Make the settings in the <b>Scan Response</b> dialog of the Master DTM.</li> <li>3. Click <b>Create devices</b>.</li> <li>4. Download of the Device configuration to the Master device (<b>Download</b>).</li> </ol> <p>Via the context menu <b>Additional Functions &gt; Live List</b> you can display the devices present at the bus.</p>	<p><i>Network Scan</i></p> <p><i>Live List</i></p>	<p>79</p> <p>76</p>
18	Diagnosis	<p>Depending of the FDT Container. For netDevice:</p> <ul style="list-style-type: none"> <li>- right click to the device icon of the Master,</li> <li>- select <b>Diagnosis</b>.</li> <li>- The Master DTM diagnosis dialog is displayed.</li> </ul> <p>(1) Check whether the communication is OK: <b>Diagnosis &gt; General Diagnosis &gt; Device status "Communication"</b> must be green!</p> <p>(2) <b>"Communication"</b> is green: Open the IO Monitor and test the input or output data.</p> <p>(3) <b>"Communication"</b> is not green: Use Diagnosis and Extended diagnosis for troubleshooting.</p> <ul style="list-style-type: none"> <li>- close the Master DTM diagnosis dialog via <b>OK</b>.</li> </ul>	<i>Overview Diagnosis</i>	103
19	IO Monitor	<p>Depending of the FDT Container: For netDevice:</p> <ul style="list-style-type: none"> <li>- right click to the device icon of the Master,</li> <li>- select <b>Diagnosis</b>,</li> <li>- select <b>Tools &gt; IO Monitor</b>.</li> <li>- Check the input or output data,</li> <li>- close the IO Monitor dialog via <b>OK</b>.</li> </ul>	<i>IO Monitor</i>	126
20	Disconnect	<p>Depending of the FDT Container. For netDevice:</p> <ul style="list-style-type: none"> <li>- right click to the device icon of the Master,</li> <li>- select <b>Disconnect</b>.</li> </ul>	<i>Connecting/Disconnecting Device</i>	67

Table 10: Getting started - Configuration Steps

## 3.2 Safety Messages on Firmware or Configuration Download

If you perform a firmware download or a configuration download via the AS-Interface Master DTM adhere to the necessary safety precautions to prevent personnel injury and property damage that may occur in consequence of a communication stop or in consequence of a mismatching system configuration. Also invalid or non-authorized firmware can damage your device.

### **Personnel Injury**

---



#### **Communication Stop**

- Together with the firmware download, an automated device reset is performed that will interrupt all network communications and established connections will drop.
- If you attempt to download the configuration during bus operation, the communication between Master and Slaves is stopped.
- Unexpected equipment operation may cause personal injury.
- Stop the application program before starting upgrading the firmware or downloading the configuration.
- Make sure that your equipment operates under conditions that prevent personal injury. All network devices should be placed in a fail-safe mode before upgrading the firmware or downloading a configuration.

#### **Mismatching System Configuration**

- Mismatching system configuration loaded into the device could result in faulty data mapping in the application program and thus unexpected equipment operation may cause personal injury.
- 

*For more refer to next page.*

---

**Property Damage**

---

**NOTICE****Communication Stop**

- Together with the firmware download, an automated device reset is performed that will interrupt all network communications and established connections will drop.
- If you attempt to download the configuration during bus operation, the communication between Master and Slaves is stopped.

**Damage of Equipment**

- Unexpected equipment operation may cause property damage.
- Stop the application program before starting upgrading the firmware or downloading the configuration.
- Make sure that your equipment operates under conditions that prevent property damage. All network devices should be placed in a fail-safe mode before upgrading the firmware or downloading a configuration.

**Loss of Device Parameters**

- Both the firmware download and the configuration download erase the configuration data base and overwrites the existing firmware in the device.
- Device parameters that have not been saved non-volatile such as a temporary IP address are getting lost during the reset.
- Before you initiate firmware or a configuration download make sure that your project configuration data are saved non-volatile in order to prevent loss of configuration data.
- To complete the update and to make the device operable again, please re-download the configuration when this operation has finished.

**Invalid or non-authorized Firmware**

- Loading invalid or non authorized firmware files could render your module unusable. Only proceed with a authorized firmware update.

**Mismatching System Configuration**

- Mismatching system configuration loaded into the device could result in faulty data mapping in the application program and thus unexpected equipment operation may cause property damage.
-

## 4 Settings

### 4.1 Overview Settings

#### Settings Dialog Panes

The table below gives an overview for the individual **Settings** dialog panes descriptions:


AS-Interface Master DTM	Folder Name / Section	Subsection	Manual Page
 <p>Navigation Area – Settings (Example) Additional drivers can be displayed.</p>	Driver		32
		Verify or adapt Driver Settings	32
		cifX Device Driver	34
		netX Driver	34
		Configuring netX Driver	35
	Device Assignment		41
		Scanning for Devices	41
		Scanning for all Devices or for suitable only	43
		Selecting the Device (with or without firmware)	44
		Selecting the Device once more (with Firmware)	45
	Firmware Download		47
	Licensing		90

Table 11: Descriptions of the Dialog Panes Settings



**Note:** To edit the **Settings** dialog panes you need *User Rights* for “Maintenance”.



Notice the descriptions in the section *Settings for Driver and Device Assignment* on page 30.

To access to the online help with the descriptions of the drivers:

- Select **Settings > Driver > [Name of the assigned driver]**.
- Press the **F1** key.

## 4.2 Settings for Driver and Device Assignment



**Important:** For a 2-channel device consecutively channel 1 or channel 2 must be assigned to the DTM.

The following steps are needed to establish a connection from the AS-Interface Master DTM to the AS-Interface Master device:

### Verifying or adapting Driver Settings

Verify the Driver Settings and adapt them if necessary.

1. Open the DTM configuration dialog.
  - In the FDT container **netDevice** double click to the AS-Interface Master device icon.
2. Verify that the default driver is checked and respectively check another or multiple drivers.
  - Select **Settings > Driver**.



**Note!** For PC cards cifX the **cifX Device Driver** is preset as a default driver. For all the other Hilscher devices the **netX Driver** is preset as a default driver.

- Use the **cifX Device Driver** if the AS-Interface Master DTM is installed on the same PC as the AS-Interface Master device.
- Use the **netX Driver** to establish an USB, Serial (RS232) or TCP/IP connection from the AS-Interface Master DTM to the AS-Interface Master device.
- The **3SGateway Driver for netX (V3.x)** is used only in relationship with CODESYS.

To search for devices on the network you can check one or multiple drivers simultaneously.

- Verify that the default driver for your device is checked.
- If necessary, check another driver or multiple drivers.

### Configuring Driver



**Note!**

- The **cifX Device Driver** requires no configuration.
- The configuration of the **3SGateway Driver for netX (V3.x)** is carried out via the CODESYS surface.

If you use the **netX Driver**, you respectively must configure it.

3. Configure the **netX Driver** if necessary.

For the driver **netXDriver** an individual driver dialog window can be opened where you can configure the driver.

- Select **Settings > Driver > netX Driver**.
- For netX Driver and communication via TCP/IP set the IP address of the device.

Adjust the driver parameters **netX Driver USB/RS232** only if they differ from the default settings.

### **Assigning the Master device to the DTM**

4. Scan for and select the devices (with or without firmware).
  - Select **Settings > Device Assignment**.
  - Under **Device selection** select *suitable only* or *all* and then **Scan**.
  - In the table check the required devices.
  - Select **Apply**.

### **Selecting and downloading the Firmware**

5. If not yet a firmware was loaded to the device, select and download the firmware.
  - Select **Settings > Firmware Download**.
  - Select and download the firmware via **Download**.
  - Select **Apply**.
6. Scan for and select the devices (with firmware and defined system channel) once more.

*For repeated download this step is omitted.*

  - Select **Settings > Device Assignment**.
  - Select **Scan**.
  - In the table check the required device.
7. Close the DTM configuration dialog via **OK**.

### **Connecting the Device**

8. In **netDevice** put a right-click on the AS-Interface Master device icon.
9. Select the **Connect** command from the context menu.
- 🔗 In the network view the device description at the device icon of the Master is displayed with a green colored background. The AS-Interface Master device now is connected to the AS-Interface Master DTM via an online connection.

### **Further Information**



For descriptions about these steps refer to the sections following here-after.

## 4.3 Driver

The **Driver** dialog pane displays the drivers to be used for a AS-Interface Master DTM to establish a device communication connection.



**Note!** A **default driver** is set in the configuration software.

Driver			
	Driver	Version	ID
<input checked="" type="checkbox"/>	CIFX Device Driver	1.101.1.9801	{368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}
<input type="checkbox"/>	3SGateway Driver for netX (V3.x)	0.9.1.2	{787CD3A9-4CF6-4259-8E4D-109B6A6BEA91}
<input type="checkbox"/>	netX Driver	1.103.2.5183	{B54C8CC7-F333-4135-8405-6E12FC88EE62}

Figure 5: Default Driver ‚CIFX Device Driver’ for PC cards cifX

Parameter	Meaning
Driver	Name of the driver (for more details see descriptions hereafter)
Version	ODMV3 Version of the respective driver
ID	ID of the driver (driver identification)

Table 12: Driver Selection List Parameters

To establish a connection from the AS-Interface Master DTM to the AS-Interface Master device, verify if the default driver is checked and respectively check another driver or multiple drivers.

### 4.3.1 Verify or adapt Driver Settings

Proceed as follows:

1. Select **Settings > Driver** in the navigation area.
- The **Driver** dialog pane is displayed with the available drivers and the setting for the default driver.

Driver			
	Driver	Version	ID
<input checked="" type="checkbox"/>	CIFX Device Driver	1.101.1.9801	{368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}
<input type="checkbox"/>	3SGateway Driver for netX (V3.x)	0.9.1.2	{787CD3A9-4CF6-4259-8E4D-109B6A6BEA91}
<input type="checkbox"/>	netX Driver	1.103.2.5183	{B54C8CC7-F333-4135-8405-6E12FC88EE62}

Figure 6: Default Driver ‚CIFX Device Driver’ for PC cards cifX (example)

Driver			
	Driver	Version	ID
<input type="checkbox"/>	CIFX Device Driver	1.101.1.9801	{368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}
<input type="checkbox"/>	3SGateway Driver for netX (V3.x)	0.9.1.2	{787CD3A9-4CF6-4259-8E4D-109B6A6BEA91}
<input checked="" type="checkbox"/>	netX Driver	1.103.2.5183	{B54C8CC7-F333-4135-8405-6E12FC88EE62}

Figure 7: Default Driver ‚netX Driver’ for Hilscher devices except for PC cards cifX (example)

2. Verify that the default driver is checked.
- Verify that the default driver for your device is checked.



**Default Driver** (Pre-settings in the Configuration Software): For PC cards cifX the **cifX Device Driver** is preset as a default driver. For all the other Hilscher devices the **netX Driver** is preset as a default driver.

3. Respectively check another driver.



**Note!** The driver used for the connection from the AS-Interface Master DTM to the AS-Interface Master device must be supported by the device and must be available for the device.

- Use the **cifX Device Driver** if the AS-Interface Master DTM is installed on the same PC as the AS-Interface Master device.
- Use the **netX Driver** to establish a USB, Serial (RS232) or TCP/IP connection from the AS-Interface Master DTM to the AS-Interface Master device.
- The **3SGateway Driver for netX (V3.x)** is used only in relationship with CODESYS. The version V3.x refers to the driver version defined by 3S-Smart Software Solutions GmbH.

➤ Check the checkbox for the driver in the selection list.

4. Respectively check multiple drivers.

To search for devices on the network you can check multiple drivers simultaneously.

Driver			
	Driver	Version	ID
<input checked="" type="checkbox"/>	CIFX Device Driver	1.101.1.9801	{368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}
<input type="checkbox"/>	3SGateway Driver for netX (V3.x)	0.9.1.2	{787CD3A9-4CF6-4259-8E4D-109B6A6BEA91}
<input checked="" type="checkbox"/>	netX Driver	1.103.2.5183	{B54C8CC7-F333-4135-8405-6E12FC88EE62}

Figure 8: Manual Selection of multiple drivers (Example)

### 4.3.2 cifX Device Driver

In the AS-Interface Master DTM for the **cifX Device Driver** no driver dialog pane is available, since for the **cifX Device Driver** no driver settings are required.

The **cifX Device Driver** will be used if the AS-Interface Master DTM is installed in the same PC as the AS-Interface Master device.



**Note:** To establish a connection from a DTM to a Master device via the **cifX Device Driver**, the **cifX Device Driver** must be installed and the driver must have access to the Master device.

### 4.3.3 netX Driver

The **netX Driver** is used to connect the DTM to the device via different connection types. The DTM communicates with the device via an USB connection, a serial (RS232) connection or a TCP/IP connection. The **netX Driver** establishes

- via the USB interface of the device and the USB port of the PC an USB connection to the device,
- via the RS232 interface of the device and the COM port of the PC a serial connection (RS232) to the device
- and via Ethernet a TCP/IP connection to the device.

To connect the DTM to the physical layer of the device the **netX Driver** software works in combination with the software components:

- “USB/COM connector” for the USB connection and for the serial connection (RS232) and
- “TCP/IP connector” for the Ethernet connection.

## 4.3.4 Configuring netX Driver

The following steps are required to configure the netX Driver:

### USB/RS232 Connection

To set the driver parameters for an USB/RS232 connection note:




**Note:** Adjust the driver parameters netX Driver USB/RS232 only if they differ from the default settings. After saving the changed driver parameters, these parameters are used for the device assignment when scanning devices.

For setting the driver parameters for an USB connection or a serial connection:

1. Select **Settings > Driver > netX Driver > USB/RS232 Connection**.
  - Set the driver netX Driver USB/RS232 parameters.

### TCP/IP Connection

For setting the driver parameters for a TCP/IP connection:

1. Select **Settings > Driver > netX Driver > TCP Connection**.
2. Set IP Address of the device:
  - Add an IP Range via **Select IP Range** .
3. Under **IP Range Configuration > IP Address** enter the IP Address of the device (**Use IP Range** is unchecked).

Or

4. Set IP Range:
    - Check **Use IP Range**.
    - Under **IP Range Configuration > IP Address** enter the start address (left side) and the ending address of the IP scanning range (right side).
  5. Click **Save**, to save the IP address or the IP range.
- After saving the changed driver parameters, these parameters are used for the device assignment when scanning devices.

### 4.3.5 netX Driver - USB/RS232 Connection

The communication from the DTM to the device via an **USB/RS232 Connection** is used when the DTM is installed on a PC and between the PC and the device

- an USB connection
- or a serial connection (RS232) exists.

The DTM accesses the device via the USB interface or via the RS232 interface. This requires either to connect an USB port of the PC to the USB interface of the device using an USB cable or to connect a physical COM port of the PC to the RS232 interface of the device via a serial cable.

The **netX Driver / USB/RS232 Connection** supports all physical and virtual COM ports available on the PC.

Via the RS232 interface or USB interface, the device is configured or diagnosis is performed.

#### 4.3.5.1 Driver Parameters for netX Driver - USB/RS232 Connection

The settings of the driver parameters for the USB/RS232 connection are made via the **netX Driver / USB/RS232 Connection** configuration dialog.

- Open the **USB/RS232 Connection** dialog via navigation area **Settings > Driver > netX Driver**.

- The **USB/RS232 Connection** dialog is displayed:

The screenshot shows the 'netX Driver' configuration window with the 'USB/RS232 Connection' tab selected. The 'TCP Connection' tab is also visible. The 'Enable USB/RS232 Connector (Restart of ODM required)' checkbox is checked. The 'Select Port:' dropdown is set to 'COM1'. The 'Port Configuration' section contains a 'Disable Port' checkbox (unchecked) and several settings: 'Baud Rate' (115.2 kBit/s), 'Byte Size' (8 Byte), 'Stop Bits' (1 Stopbit), 'Parity' (No Parity), 'Send Timeout' (1000 ms), 'Reset Timeout' (10000 ms), and 'Keep Alive Timeout' (2000 ms). At the bottom, there are three buttons: 'Restore', 'Save', and 'Save All'.

Figure 9: netX Driver > USB/RS232 Connection


Parameter	Meaning	Range of Value / Default Value
<b>Enable USB/RS232 Connector (Restart of ODM required)</b>	<p>checked: The netX Driver can communicate via the USB/RS232 interface.</p> <p>unchecked: The netX Driver can <u>not</u> communicate via the USB/RS232 interface.</p> <p>If the check mark for <b>Enable USB/RS232 Connector</b> is set or removed, then the ODM server must be restarted<sup>1</sup>, to make the new setting valid.</p> <p><sup>1</sup> Restart the ODM server via the <b>ODMV3 Tray Application</b>:</p> <p>- In the foot line click on  using the right mouse key.</p> <p>- In the context menu select <b>Service &gt; Start</b>.</p>	checked, unchecked; Default: unchecked
<b>Select Port</b>	Depending on the COM ports (interfaces) available on the PC, they will be listed under <b>Select Port</b> .	COM 1 to COM N
<b>Port Configuration</b>		
<b>Disable Port</b>	<p>checked: No connection.</p> <p>unchecked: The netX Driver tries to establish a connection using the configured USB/RS232 interface.</p>	checked, unchecked (Default)
<b>Baud rate</b>	<p>Transfer rate: number of bits per second.</p> <p>The device must support the baud rate.</p>	9.6, 19.2, 38.4, 57.6 or 115.2 [kBit/s]; Default (RS232): 115.2 [kBit/s]
<b>Stop bits</b>	Number of stop bits sent after the transfer of the send data for synchronization purposes to the receiver.	Stop bit: 1, 1.5, 2; Default (RS232): 1
<b>Send Timeout</b>	Maximum time before the transfer of the transmission data is canceled, when the send process fails, for example, because of the transfer buffer is full.	100 ... 60.000 [ms]; Default (RS232 and USB): 1000 ms
<b>Reset Timeout</b>	Maximum time for a device reset, including the re-initialization of the physical interface used for the communication.	100 ... 60.000 [ms]; Default (RS232 and USB): 5000 ms
<b>Byte size</b>	Number of bits per byte by byte specification	7 Bit, 8 Bit; Default (RS232): 8 Bit
<b>Parity</b>	<p>In the error detection in data transmission using parity bits, "parity" describes the number of bits occupied with 1 in the transmitted information word.</p> <p>No Parity: no parity bit</p> <p>Odd Parity: The parity is "odd" if the number of bits occupied with 1 in the transmitted information word will be odd.</p> <p>Even parity: The parity is "even" if the number of bits occupied with 1 in the transmitted information word will be even.</p> <p>Mark Parity: if the parity bit is always 1, this will be named mark-parity (the bit does not contain any information).</p> <p>Space Parity: if the parity bit always 0, this will be named space-parity (the bit represents an empty space).</p>	No Parity, Odd Parity, Even Parity, Mark Parity, Space Parity; Default (RS232): No Parity
<b>Keep Alive Timeout</b>	The "Keep Alive" mechanism is used to monitor whether the connection to the device is active. Connection errors are detected using a periodic heartbeat mechanism. The heartbeat mechanism will be initiated after the set time has elapsed if the communication has failed.	100 ... 60.000 [ms]; Default (RS232 and USB): 2000 ms
<b>Restore</b>	Resets all settings in the configuration dialog to the default values.	
<b>Save</b>	Saving all settings made in the configuration dialog <b>netX Driver &gt; Save USB/RS232 Connection</b> , i. e. only for the selected connection type.	
<b>Save All</b>	Saving all settings made in the configuration dialog <b>netX Driver</b> , i. e. for all connection types.	

Table 13: Parameters netX Driver &gt; USB/RS232 Connection

### 4.3.6 netX Driver - TCP/IP Connection

The communication from the DTM to the device via a **TCP/IP Connection** is used in the following two typical applications:

Application 1: The device has its own Ethernet interface. The DTM is installed on a PC and the TCP/IP connection is established from this PC to the stand-alone device. The IP address of the device is used.

Application 2: The device is installed in a remote PC. The DTM is installed on an additional PC and the TCP/IP connection is established from this PC to the remote PC. The IP address of the remote PC is used. For the TCP/IP connection is made, on the remote PC the cifX TCP/IP server must be started. The cifX TCP/IP server allows the remote access to the device via a TCP/IP connection.



---

**Note:** An exe file for the cifXTCP/IP server is provided on the product CD in the *Tools* directory.

---

Via the TCP/IP interface of the device or of the remote PC, the device is configured or diagnosis is performed.

#### 4.3.6.1 Driver Parameters for netX Driver - TCP/IP Connection

The settings of the driver parameters for the TCP/IP connection are made via the **netX Driver / TCP Connection** configuration dialog.

- Open the **TCP Connection** dialog via navigation area **Settings > Driver > netX Driver**.
- The dialog **netX Driver** is displayed:
- Select **TCP Connection**.







Figure 10: netX Driver > TCP Connection

Parameter	Meaning	Range of Value / Default Value
<b>Enable TCP Connector (Restart of ODM required)</b>	<p>checked: The netX Driver can communicate via the TCP/IP interface.</p> <p>unchecked: The netX Driver can <u>not</u> communicate via the TCP/IP interface.</p> <p>If the check mark for <b>Enable TCP Connector</b> is set or removed, then the ODM server must be restarted<sup>1</sup>, to make the new setting valid.</p> <p><sup>1</sup> Restart the ODM server via the <b>ODMV3 Tray Application</b>:</p> <ul style="list-style-type: none"> <li>- In the foot line click on  using the right mouse key.</li> <li>- In the context menu select <b>Service &gt; Start</b>.</li> </ul>	checked, unchecked; Default: unchecked
<b>Select IP Range</b>	<p>Via <b>Select IP Range</b> already created IP ranges can be selected.</p> <p>Via  an additional IP range can be added.</p> <p>Via  an IP range can be deleted.</p>	

Parameter	Meaning	Range of Value / Default Value
<b>Scan Timeout [ms]</b>	With <b>Scan Timeout</b> can be set, how long to wait for a response while a connection is established.	10 ... 10000 [ms]; Default: 100 ms
<b>IP Range Configuration</b>		
<b>Disable IP Range</b>	checked: No connection. unchecked: The netX Driver tries to establish a connection using the configured TCP/IP interface.	checked, unchecked (Default)
<b>IP Address (left)</b>	Enter the IP address of the device, (if <b>Use IP Range</b> is not checked). Enter the start address of the IP scanning range, (if <b>Use IP Range</b> is checked).	valid IP address; Default: 192.168.1.1
<b>Use IP Range</b>	checked: An IP address range is used. unchecked: Only one IP address is used.	checked, unchecked; Default: unchecked
<b>IP Address (right)</b>	Enter the ending address of the IP scanning range, (only if <b>Use IP Range</b> is checked).	valid IP address; Default: 0.0.0.0
<b>Address Count</b>	Displays the scanning range address count, depending on the selected IP-start or IP-end address. (For this read the note given below.)	recommended: 10
<b>TCP Port</b>	Identifies the endpoint of a logical connection or addresses a specific endpoint on the device or PC.	0 - 65535; Default Hilscher device: 50111
<b>Send Timeout [ms]</b>	Maximum time before the transfer of the transmission data is canceled, when the send process fails, for example, because of the transfer buffer is full.	100 ... 60.000 [ms]; Default (TCP/IP): 1000 ms
<b>Reset Timeout [ms]</b>	Maximum time for a device reset, including the re-initialization of the physical interface used for the communication.	100 ... 60.000 [ms]; Default (TCP/IP): 2000 ms
<b>Keep Alive Timeout [ms]</b>	The "Keep Alive" mechanism is used to monitor whether the connection to the device is active. Connection errors are detected using a periodic heartbeat mechanism. The heartbeat mechanism will be initiated after the set time has elapsed if the communication has failed.	100 ... 60.000 [ms]; Default (TCP/IP): 2000 ms
<b>Restore</b>	Resets all settings in the configuration dialog to the default values.	
<b>Save</b>	Saving all settings made in the configuration dialog <b>netX Driver &gt; Save TCP/IP Connection</b> , i. e. only for the selected connection type.	
<b>Save All</b>	Saving all settings made in the configuration dialog <b>netX Driver</b> , i. e. for all connection types.	

Table 14: Parameters netX Driver &gt; TCP Connection



**Note:** Do not use large IP ranges in combination with a low scan timeout. Microsoft introduced in Windows® XP SP2 a limit of concurrent half-open outbound TCP/IP connections (connection attempts) to slow the spread of virus and malware from system to system. This limit makes it impossible to have more than 10 concurrent half-open outbound connections. Every further connection attempt is put in a queue and forced to wait. Due to this limitation a large IP range used in combination with a low scan timeout could prevent the connection establishment to a device.



## 4.4 Device Assignment



**Note:** In the **Device Assignment** dialog pane you first must assign the AS-Interface Master device to the AS-Interface Master DTM by checking the check box. This is essential to establish an online connection from the AS-Interface Master DTM to the AS-Interface Master device later, as described in section *Connecting/Disconnecting Device* on page 67.

Therefore in the **Device Assignment** dialog pane you scan for the AS-Interface Master device and select it.

If the device did not get a firmware or shall get a new firmware:

1. first you scan for the device (with or without firmware) and select the device,
2. then you download a firmware to the device and
3. subsequently you scan for the device (with firmware) once more and select the device again.



**Important:** For a 2-channel device consecutively channel 1 or channel 2 must be assigned to the DTM.

### 4.4.1 Scanning for Devices

1. Select **Settings > Device Assignment** in the navigation area.
- The dialog pane **Device Assignment** is displayed.

	Device	Hardware Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input type="checkbox"/>	Device Cl*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	Undefined Undefined	...\cifX3_SYS

Figure 11: Device Assignment - detected Devices (\* The name of the device class is displayed.) – Example for a device without firmware

2. Under **Device Selection** select *suitable only*.
3. Select **Scan**, to start the scanning process.
- In the table all devices are displayed, which can be connected to the AS-Interface Master DTM via the preselected driver.



**Note:** For devices, which have been found via the **cifX Device Driver** in the column **Access path** the indication **...\cifX[0toN]\_SYS** is displayed. This is correct, as long as a device did not get a firmware. After the firmware download has been completed, in the column **Access path** the indication **...\cifX[0toN]\_Ch[0to3]** is displayed.

Parameter	Meaning	Range of Value / Default Value
Device selection	Selecting <b>suitable only</b> or <b>all</b> devices.	suitable only, all
Device	Device class of the AS-Interface Master Devices.	
Hardware Port 0/1/2/3	Shows, which hardware is assigned to which communication interface.	
Slot number	Shows the <b>Slot Number (Card ID)</b> preset at the PC card cifX via the <b>Rotary Switch Slot Number (Card ID)</b> .  The indication <b>n/a</b> means, that no <b>Slot-Nummer (Card ID)</b> exists. This will occur if the PC card cifX is not equipped with a <b>Rotary Switch Slot Number (Card ID)</b> or for PC cards cifX equipped with a <b>Rotary Switch Slot Number (Card ID)</b> if the rotary switch is set to the value 0 (zero).	1 to 9, n/a
Serial number	Serial number of the device	
Driver	Name of the driver	
Channel Protocol	Shows, which firmware is loaded to which device channel.  The data for the used channel consists of the protocol class and the communication class.  a.) For devices without firmware: Undefined Undefined, b.) For devices with firmware: Protocol name corresponding to the used Firmware	
Access path (last column on the right)	Depending on the used driver in the column <b>Access path</b> different data to the device are displayed.  For the <b>cifX Device Driver</b> the following data are displayed: a.) For devices without firmware: ...cifX[0toN]_SYS, b.) For devices with firmware: ...cifX[0toN]_Ch[0to3].  cifX[0toN] = Board number 0 to N Ch[0to3] = Channel number 0 to 3	Depending on the device and on the driver: board or channel number, IP address or COM interface
Access path (at the lower side of the dialog pane)	If in the table a device is checked, under <b>Access path</b> (at the lower side of the dialog pane) the driver identification or depending on the used driver additional data to the device will be displayed.  For the <b>cifX Device Driver</b> the following data are displayed: a.) For devices without firmware: ...cifX[0toN]_SYS, b.) For devices with firmware: ...cifX[0toN]_Ch[0to3].  cifX[0toN] = Board number 0 to N Ch[0to3] = Channel number 0 to 3	driver identification (ID)  depending on the device and on the driver: board or channel number, IP address or COM interface

Table 15: Parameters of the Device Assignment

#### 4.4.1.1 Scanning for all Devices or for suitable only

##### all

1. Under **Device Selection** select *all*.
2. Select **Scan**.




Figure 12: Device Assignment - detected Devices (\* The name of the device class is displayed.) Example for Devices without Firmware

- ⇒ In the table all devices are displayed, which are attainable in the network and which can be connected to a single DTM each via the preselected drivers.



**Note:** During a subsequent firmware download in the selection window **Select Firmware File** all files from the selected folder are displayed, under **Files of Type** „All Files (\*.\*)“ is displayed and the check box **Validate the selected firmware file.** is unchecked.

##### suitable only

1. Under **Device Selection** select *suitable only*.
2. Select **Scan**.

- ⇒ In the table all devices are displayed, which can be connected to the AS-Interface Master DTM via the preselected drivers.



**Note:** During a subsequent firmware download in the selection window **Select Firmware File** only firmware files from the selected folder are displayed, under **Files of Type** „Firmware Files (\*.nxm)“ or „Firmware Files (\*.nxf)“ is displayed and the check box **Validate the selected firmware file.** is checked.

## 4.4.2 Selecting the Device (with or without firmware)



**Note:** A connection with the AS-Interface Master DTM can only be established with one AS-Interface Master device.

To select the physical AS-Interface Master device (with or without firmware):

1. Check the appropriate device.

Device Assignment

Scan progress: 5/5 Devices (Current device: -)

Device selection:  Scan

Device selection:  suitable only

	Device	Hardware Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input checked="" type="checkbox"/>	Device Cl*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	PROFIBUS Master	... \cifX3_SYS

Access path:  {368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA} \cifX3\_SYS

Figure 13: Device Assignment - Selecting the Device (\* The name of the device class is displayed.) – Example for a device without firmware / one Device is selected

- Under **Access path** (below in the dialog pane) the access path to the device, e. g. the driver identification, or depending on the used driver additional access data of the device are displayed.

2. Select **Apply**, to apply the selection.



**Note:** Before an online connection from the AS-Interface Master DTM to the AS-Interface Master device can be established, a firmware must be loaded to the device and the device must be selected once more.



For further information refer to section *Firmware Download* on page 47 or to section *Selecting the Device once more (with Firmware)* on page 45.

### 4.4.3 Selecting the Device once more (with Firmware)



**Note:** For repeated download this step is omitted.

To select the AS-Interface Master device (with firmware and defined system channel) once more, proceed as described hereafter:

#### all

1. Under **Device Selection** select *all*.
2. Select **Scan**.
  - In the table all devices are displayed, which are attainable in the network and which can be connected to a DTM via the preselected drivers.
3. Check the appropriate device.

**Device Assignment**

Scan progress: 5/5 Devices (Current device: -)

Device selection: all Scan

	Device	Hardware-Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input checked="" type="checkbox"/>	Device Cl.*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	PROFIBUS-DP Master	...\cifX3_Ch0
<input type="checkbox"/>	Device Cl.*	-/-/DeviceNet/-	n/a	20027	CIFX Device Driver	DeviceNet Master	...\cifX1_Ch0
<input type="checkbox"/>	Device Cl.*	-/-/-/-	n/a	20058	netX Driver	Undefined Undefined	...\192.168....
<input type="checkbox"/>	Device Cl.*	Ethernet/Ethernet/-/-	n/a	20288	CIFX Device Driver	PROFINET IO Device	...\cifX2_Ch0
<input type="checkbox"/>	Device Cl.*	-/-/CANopen/-	n/a	20022	CIFX Device Driver	Undefined Undefined	...\cifX0_SYS

Access path: {368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}\cifX3\_Ch0

Figure 14: Device Assignment - Selecting the Device (\* The name of the device class is displayed.) – Example for Devices with and without Firmware / one Device is selected



**Note:** After the firmware download has been completed, for the devices which have been detected via the **cifX Device Driver** the following data are displayed:

- In the column **Channel Protocol**: the data for the firmware for the used channel
- In the column **Access path** or under **Access path** (below in the dialog pane): the data: ...\\cifX[0toN]\_Ch[0to3].  
 cifX[0toN] = board number 0 to N  
 Ch[0to3] = channel number 0 to 3

4. Select **Apply**, to apply the selection.
5. Or select **OK**, to apply the selection and to close the DTM interface dialog.
6. Connect the DTM to the device using the context menu (right mouse click).

Or:

### suitable only

1. Under **Device Selection** select *suitable only*.
2. Select **Scan**.
- In the table all devices are displayed, which can be connected to the AS-Interface Master DTM via the preselected drivers.
3. Check the appropriate device.

Device Assignment

Scan progress: 5/5 Devices (Current device: -)

Device selection: suitable only Scan

	Device	Hardware Port 0/1/2/3	Slot number	Serial number	Driver	Channel Protocol	Access path
<input checked="" type="checkbox"/>	Device Cl*	-/-/PROFIBUS/-	1	20148	CIFX Device Driver	PROFIBUS-DP Master	...\cifX3_Ch0

Access path: {368BEC5B-0E92-4C0E-B4A9-64F62AE7AAFA}\cifX3\_Ch0

Figure 15: Device Assignment - Selecting the Device (\* The name of the device class is displayed.) – Example for a device with firmware / one Device is selected



**Note:** After the firmware download has been completed, for the devices which have been detected via the **cifX Device Driver** the following data are displayed:

- In the column **Channel Protocol**: the data for the firmware for the used channel
- In the column **Access path** or under **Access path** (below in the dialog pane): the data: ...\\cifX[0toN]\_Ch[0to3].  
cifX[0toN] = board number 0 to N  
Ch[0to3] = channel number 0 to 3

4. Select **Apply**, to apply the selection.
5. Or select **OK**, to apply the selection and to close the DTM interface dialog.
6. Connect the DTM to the device using the context menu (right mouse click).



For further information how to establish an online connection from the AS-Interface Master DTM to the AS-Interface Master device, refer to section *Connecting/Disconnecting Device* on page 67.

## 4.5 Firmware Download

Using the **Firmware Download** dialog a firmware can be transferred to the device.



**Note:** Prior to the firmware download, you must select the driver and the Master device (with or without firmware) and the device must be assigned to the hardware.



For further information refer to section **Overview Settings** on page 29.

To load the firmware to the device:

1. In the navigation area select **Settings > Firmware Download**.

➤ The dialog **Firmware-Download** pane is displayed.

Figure 16: Firmware Download

Element	Meaning
Name	The path and name of the firmware file selected are displayed.
Version	The version and build version of the firmware file selected are displayed.
Browse...	Via 'Browse...' you can select the firmware file for the download.
Download	Via 'Download' you can download the firmware to the device.

Table 16: Parameter Firmware Download

2. Select the firmware file.

➤ Select **Browse**.

### **Device is not assigned to the Hardware**

If the device is not assigned to the Hardware, the error message 'The device is not assigned to the hardware!' is displayed:




Figure 17: Error Message 'The device is not assigned to the hardware!'

- Click **OK** and select and assign the Master device as described in section *Device Assignment*.

### **Device is assigned to the Hardware**

- The selection window **Select Firmware File** is displayed.
- Enlarge the selection window to view the columns **Hardware** and **Version**.






Figure 18: Window 'Select Firmware File' (Example CIFX)

Parameter	Meaning	Range of Value / Default Value
Column <b>Name</b>	File name of the firmware file To sort the entries of the window <b>Select Firmware File</b> by name click to the column head <b>Name</b> .	nxf, nxm
Column <b>Firmware</b>	Name of the firmware (consisting of the protocol name and protocol class)	
Column <b>Hardware</b>	Device class of the associated hardware	e. g. CIFX, COMX, COMX 51, NETJACK 10, NETJACK 50, NETJACK 51,

		NETJACK 100, NETTAP 50 (Gateway), NETTAP 100 (Gateway), NETBRICK 100 (Gateway)
<b>Column Version</b>	Firmware version	x.x (build x)
<b>Tooltip</b>	To view the tooltip information move with the mouse pointer over the selected firmware line.  <div> Type: Hilscher firmware file for netX-based targets (NXF)  Size: 563 KB  Date of change: 2013/03/26 11:10 </div>	
<b>Files of Type</b>	„All Files (*.*)“ if before in the <b>Device Assignment</b> pane under <b>Device selection</b> <i>all</i> was selected. „Firmware Files (*.nxm)“ or <i>Firmware Files (*.nxf)</i> if before in the <b>Device Assignment</b> pane under <b>Device selection</b> <i>suitable only</i> was selected.	All Files (*.*), Firmware Files (*.nxm), Firmware Files (*.nxf)
<b>Recent folders</b>	Path of the recently opened folder	
<b>Firmware</b>	As soon as the firmware file has been selected, under <b>Firmware</b> the name, the version and the build version as well as the device class for the selected firmware is displayed.	Name, Version, Build Version, Device Class for the selected firmware
<b>Help</b>	Button, to open the online help of the DTM.	

Table 17: Parameters Select Firmware File




Further descriptions to the selection window **Select Firmware File** are included in the context sensitive help (**F1** key) of the Microsoft Corporation.




**Note:** After in the **Device Assignment** pane under **Device selection** *all* or *suitable only* has been set, during a subsequent firmware download in the selection window **Select Firmware File** the following data are displayed or set:

(for list box entry →)	<b>all</b>	<b>suitable only</b>
In the selection window <b>Select Firmware File</b> :	all files from the selected folder	only firmware files from the selected folder
Under <b>Files of Type</b> *:	„All Files (*.*)“	„Firmware Files (*.nxm)“, „Firmware Files (*.nxf)“
Validation:	A restricted validation will be performed if the selected firmware is applied for the download.	A validation is made whether the firmware file is suitable for the AS-Interface Master DTM.

\*These settings in the selection window **Select Firmware File** can also be changed manually.

- In the selection window mark the firmware file to be loaded using the mouse.
-  In the selection window under **Firmware** the name and the version of the firmware are displayed.
- In the selection window select the **Open** button.

### Validation

-  A validation is made, whether the selected firmware file is suitable for the AS-Interface Master device.

## Invalid Firmware

### NOTICE

#### Device Destruction caused by invalid Firmware

Loading invalid firmware files could render your device unusable.

- If a firmware file is selected, which is not valid for the assigned device, the request **Select Firmware File** will be displayed.

‘Invalid firmware for assigned device!’

[detailed explication]

Shall firmware file nevertheless be applied for the download?’



Figure 19: Request Select Firmware File - Example Invalid Firmware

- Answer to the request with **No** and select a valid firmware.
- The selection window is closed.

### **Valid Firmware**

➤ The selection window is directly closed (without dialog).

5. Start firmware upgrade.

#### **⚠ WARNING**

#### **Personnel Injury in Consequence of a Communication Stop**

- Stop your application program before starting upgrading the firmware.
- Make sure that your equipment operates under conditions that prevent personal injury. All network devices should be placed in a fail-safe mode before upgrading the firmware.
- Unexpected equipment operation may cause personal injury.

#### **NOTICE**

#### **Damage of Equipment and Loss of Device Parameters in Consequence of a Communication Stop**

- Stop your application program before starting upgrading the firmware.
- Make sure that your equipment operates under conditions that prevent property damage. All network devices should be placed in a fail-safe mode before upgrading the firmware.
- Unexpected equipment operation may cause property damage.
- Before you initiate firmware download make sure that your project configuration data are saved non-volatile in order to prevent loss of configuration data.

#### **Invalid or non-authorized Firmware**

- Loading invalid or non authorized firmware files could render your module unusable. Only proceed with a authorized firmware update.
- In the dialog pane **Firmware Download** click to the **Download** button, to download the firmware.
- The request **Do you really want to download the firmware?** is displayed.




Figure 20: Request - Do you really want to download the firmware?

6. Click **Yes**.

- If you are sure, that you have selected the appropriate firmware file answer to the request with **Yes** otherwise with **No**.

- During the download a progress bar is displayed ('Download active, device performs initialization...'), in the status line a clock / green hook symbol is displayed and in the dialog pane **Firmware Download** **Download** is grayed out.




Figure 21: Firmware Download - Progress Bar




Figure 22: Clock Symbol and Hook Symbol green

- In the **Firmware-Download** dialog pane the path and name as well as the version of the selected firmware file are displayed.




Figure 23: Firmware Download – Download

## 4.6 Licensing

To open the Licensing pane:

1. In the navigation area select **Settings > Licensing**.
- The dialog **Licensing** pane is displayed.

**Licensing**

License Type

	Existing	Order
<b>Master protocols</b>		
One General Master License	NO	<input type="checkbox"/>
Two General Master Licenses	NO	<input type="checkbox"/>
PROFIBUS Master	YES	<input type="checkbox"/>
CANopen Master	YES	<input type="checkbox"/>
DeviceNet Master	YES	<input type="checkbox"/>
AS-Interface Master	YES	<input type="checkbox"/>
PROFINET IO RT Controller	YES	<input type="checkbox"/>

Request Form, please fill out

Name	Value
License type	User Single Device License
Manufacturer*	00000001
Article number*	01250510
Serial number*	00020086
Chiptype*	00000002
Step*	00000000
Romcode revision*	00000002

Fields marked with '\*' are mandatory.

Hilscher Germany

E-mail... license@hilscher.com

Print Fax Form... +49 6190 9907-50

Telephone... +49 6190 9907-0

Export License Request...

Download License

Figure 24: Licensing



For a detailed description refer to section *Licensing* on page90.

## 5 Configuration

### 5.1 Overview Configuration

#### Configuration Dialog Panes

The table below gives an overview for the **Configuration** dialog panes descriptions:


AS-Interface Master DTM	Folder Name / Section	Subsection	Page
 Navigation Area – Configuration	Process Data		58
	Address Table		59
	Station Table		61
	Master Settings		62
		Start of Bus Communication	63
		Application Monitoring	63
		Process Image Storage Format	64
		Module Alignment	64
		Process Data Handshake	65
	Bus Parameters		66

Table 18: Descriptions of the Dialog Panes Configuration



Notice the descriptions in the section *Configuration Steps* on page 23.

## 5.2 Configuring Device Parameters



**Important:** For a 2-channel device consecutively channel 1 or channel 2 each must be configured individually.

The following steps are required to configure the parameters of the AS-Interface Master device using the AS-Interface Master DTM:

### Process Data

1. Set the process data:
  - Select **Configuration > Process Data** in the navigation area.
  - Set symbolic names for the configured modules or signals.

### Address Table

2. Set the device address:
  - Select **Configuration > Address Table** in the navigation area.

### Station Table

3. Set the station address of the devices:
  - Select **Configuration > Station Table** in the navigation area.

### Master Settings

4. Set the **Master Settings**:
  - Select **Configuration > Master Settings** in the navigation area.
  - Under **Start of Bus Communication**: Select **Automatically by device** or **Controlled by application** option.
  - Under **Application Monitoring**: Set **Watchdog time**.
  - Under **Module Alignment**: Set **Byte boundaries** or **2 Byte boundaries** option.
  - Under **Process Data Handshakes**: Select the **Process Data Handshake** type to be used.
5. Set the bus parameters:
  - Select **Configuration > Bus Parameters** in the navigation area.

### Close Master DTM Configuration Dialog

6. Close the Master DTM configuration dialog via **OK** in order to store your selections.



### **Configuration Download to the AS-Interface Master Device**

Adhere to the necessary safety precautions to prevent personnel injury and property damage that may occur in consequence of a communication stop or in consequence of a mismatching system configuration.



**Note:** In order to transfer the configuration to the AS-Interface Master device, download the data of the configuration parameters in the AS-Interface Master device. See section *Download Configuration* on page 87.

### **Further Information**



For more information refer to section *Process Data* on page 58, to section *Address Table* on page 59, to section *Station Table* on page 61, to section *Master Settings* on page 62 and to section *Bus Parameters* on page 66 of this document.

## 5.3 Process Data

For the AS-Interface Master DTM the **Process Data** pane serves as an external process data interface, e. g. for data transfer to a PLC unit. The process data pane lists the Slave devices connected to the Master, as well as the configured modules or input or output signals of the devices. This makes the fieldbus structure visible.

For the configured modules or signals names can be set (Column *Tag*).

In addition signal data available to the OPC server can be checked (Column *SCADA*).






















Process Data			
	Type	Tag	SCADA
	ASiSlave <Adr 10>	S-7.0, Remote I/O Port	<input checked="" type="checkbox"/>
	Digital Input <Digital>	Digital Input	<input checked="" type="checkbox"/>
	1-bit Input_001	1-bit Input_001	<input checked="" type="checkbox"/>
	1-bit Input_002	1-bit Input_002	<input checked="" type="checkbox"/>
	1-bit Input_003	1-bit Input_003	<input checked="" type="checkbox"/>
	1-bit Input_004	1-bit Input_004	<input checked="" type="checkbox"/>
	Digital Output <Digital>	Digital Output	<input checked="" type="checkbox"/>
	1-bit Output_001	1-bit Output_001	<input checked="" type="checkbox"/>
	1-bit Output_002	1-bit Output_002	<input checked="" type="checkbox"/>
	1-bit Output_003	1-bit Output_003	<input checked="" type="checkbox"/>
	1-bit Output_004	1-bit Output_004	<input checked="" type="checkbox"/>
	ASiSlave <Adr 11>	S-7.3, Interface for 16-bit Signals	<input checked="" type="checkbox"/>
	ASiSlave <Adr 15A>	S-8.A, Extended Addressing Mode	<input checked="" type="checkbox"/>
	ASiSlave <Adr 19>	S-3.0, Remote I/O Port	<input checked="" type="checkbox"/>
	ASiSlave <Adr 1A>	S-7.A, Extended Addressing Mode	<input checked="" type="checkbox"/>
	ASiSlave <Adr 2>	S-8.0, Remote I/O Port	<input checked="" type="checkbox"/>
	ASiSlave <Adr 28>	S-7.0, Remote I/O Port	<input checked="" type="checkbox"/>
	ASiSlave <Adr 3>	S-8.0, Remote I/O Port	<input checked="" type="checkbox"/>
	ASiSlave <Adr 4>	S-7.3, Interface for 16-bit Signals	<input checked="" type="checkbox"/>
	ASiSlave <Adr 5>	S-7.3, Interface for 16-bit Signals	<input checked="" type="checkbox"/>
	ASiSlave <Adr 8>	S-7.1, Interface for 6-18-bit Signals	<input checked="" type="checkbox"/>

Figure 25: Process Data (Example)








Column	Symbol	Meaning
Type	 device	Device labeling* provided by the hardware followed by the device's name of station in pointy brackets
	 module, submodule	Description of the modules or input or output signals configured to the device (not editable)
	 I/O signal	
Tag	 device	Symbolic name* of the device
	 module, submodule	Symbolic name for the modules or for the input or output signals configured to the device (editable)
	 I/O signal	
	 warning	Duplicate Tag at the same level can cause errors by use of OPC!
SCADA	Option which module or signal data shall be provided for the OPC server. „SCADA“ (= Supervisory Control and Data Acquisition), here used with the meaning „to provide for visualizing purposes“.	
*Depending on the protocol, either the device name or the symbolic name can be edited via the device symbol context menu.		

Table 19: Process Data

## 5.4 Address Table

The **Address Table** dialog pane shows a list of all addresses used in the process data image. The displayed addresses refer to the used AS-Interface.

To configure the address data:

- Select **Configuration > Address Table** in the navigation area.

The screenshot shows the 'Address Table' dialog pane. At the top, there is a checkbox for 'Auto addressing' which is checked. To its right is a 'Display mode:' dropdown menu set to 'Decimal'. Further right is a 'CSV Export' button. Below these controls are two sections: 'Inputs:' and 'Outputs:'. Each section contains a table with columns: Station Ad..., Device, Name, Module, Type, Length, and Address.

**Inputs:**

Station Ad...	Device	Name	Module	Type	Length	Address
1A	S-7.A, Extended Addressing I	ASiSlave	Digital Input IB		1	0
4	S-7.3, Interface for 16-bit Sign	ASiSlave	Analog Input IB		8	1
5	S-7.3, Interface for 16-bit Sign	ASiSlave	Analog Input IB		8	9
8	S-7.1, Interface for 6-18-bit Sig	ASiSlave	Digital Input IB		1	17
10	S-7.0, Remote I/O Port	ASiSlave	Digital Input IB		1	18
11	S-7.3, Interface for 16-bit Sign	ASiSlave	Analog Input IB		8	19
15A	S-B.A, Extended Addressing I	ASiSlave	Digital Input IB		1	27
19	S-3.0, Remote I/O Port	ASiSlave	Digital Input IB		1	28
28	S-7.0, Remote I/O Port	ASiSlave	Digital Input IB		1	29

**Outputs:**

Station Ad...	Device	Name	Module	Type	Length	Address
1A	S-7.A, Extended Addressing I	ASiSlave	Digital Output QB		1	0
2	S-8.0, Remote I/O Port	ASiSlave	Digital Output QB		1	1
3	S-8.0, Remote I/O Port	ASiSlave	Digital Output QB		1	2
8	S-7.1, Interface for 6-18-bit Sig	ASiSlave	Digital Output QB		1	3
10	S-7.0, Remote I/O Port	ASiSlave	Digital Output QB		1	4
15A	S-B.A, Extended Addressing I	ASiSlave	Digital Output QB		1	5
19	S-3.0, Remote I/O Port	ASiSlave	Digital Output QB		1	6
28	S-7.0, Remote I/O Port	ASiSlave	Digital Output QB		1	7

Figure 26: Configuration > Address Table (Example)

### 5.4.1 Description of the Parameters

Parameter	Meaning
Station Address	Station address of the assigned Slave device
Device	Actual device name of the assigned Slave device from the GSE file.
Name	Free definable symbolic name of the assigned Slave device.
Module	Name of the module according GSD
Type	Input data type or output data type
Length	Number of the Signals included (IB, QB, IW or QW)
Address	Output data offset address or input data offset address

Table 20: Parameters Address Table Pane - Inputs / Outputs

## 5.4.2 Auto Addressing, Display Mode, CSV Export, Inputs / Outputs

### Auto Addressing




Figure 27: Configuration > Address Table - Auto Addressing

The **Auto Addressing** is used by default. For manual addressing the check-box must be unchecked.

### Display Mode

- Use the **Display Mode** drop-down list to select data display mode decimal or hexadecimal.




Figure 28: Configuration > Address Table - Display Mode

### CSV Export

**CSV Export** allows to export input- and output addresses as CSV file (CSV = comma separated value). Therefore:

- Click **CSV Export**.
- A file saving dialog opens.
- Save the data as \*.CSV file.

You can open the generated data by means of a spreadsheet application.

### Inputs / Outputs

If manual addressing is allowed, you can assign the input or output addresses of the modules manually:

- Click on an address of a module.
- Edit the field and type in a new address.
- Confirm your modifications by clicking on **OK**.
- The manually changed address is now set.

### Sort Addresses

- To sort the address data, click on the respective column header.

## 5.5 Station Table

The **Station Table** shows the list of all slave devices configured in the master configuration.

Station Table					
	Activate	Station Ad...	Device	Name	Vendor
▶	<input checked="" type="checkbox"/>		1A S-7.A, Extended Addressing Mode	ASiSlave	-
	<input checked="" type="checkbox"/>		2 S-8.0, Remote I/O Port	ASiSlave	-
	<input checked="" type="checkbox"/>		3 S-8.0, Remote I/O Port	ASiSlave	-
	<input checked="" type="checkbox"/>		4 S-7.3, Interface for 16-bit Signals	ASiSlave	-
	<input checked="" type="checkbox"/>		5 S-7.3, Interface for 16-bit Signals	ASiSlave	-
	<input checked="" type="checkbox"/>		8 S-7.1, Interface for 6-18-bit Signals	ASiSlave	-
	<input checked="" type="checkbox"/>		10 S-7.0, Remote I/O Port	ASiSlave	-
	<input checked="" type="checkbox"/>		11 S-7.3, Interface for 16-bit Signals	ASiSlave	-
	<input checked="" type="checkbox"/>		15A S-B.A, Extended Addressing Mode	ASiSlave	-
	<input checked="" type="checkbox"/>		19 S-3.0, Remote I/O Port	ASiSlave	-
	<input checked="" type="checkbox"/>		28 S-7.0, Remote I/O Port	ASiSlave	-

Figure 29: Station Table (Example)

Column	Meaning
Activate	Checkbox, to activate / deactivate a station
Station Address	<p>Station address of the Salve assigned</p> <p>For standard Slave devices valid addresses from 1 to 31 are available. For A/B Slaves with the ID code "A", which support the extended address range, the valid addresses 1A to 31A and 1B to 31B are available. The address 0 is used for configuration of newly detected slaves.</p> <p>Range for valid station address:</p> <p><u>Standard Slave addresses:</u> 1 – 31</p> <p><u>Extended Addressing Region:</u> A/B Slaves share an address. The addresses range from 1A to 31A and 1B to 31B. In the application, this corresponds to a range from 1 to 31 and 32 to 62. A/B Slaves are identifiable on their ID code "A".</p>
Device	Name of the salve assigned
Name	Name of the salve assigned
Vendor	Name of the vendor of the device

Table 21: Station Table

## 5.6 Master Settings

At the **Master Settings** pane device related settings can be made. These settings only become active after the configuration was downloaded to the device.



Information about the download you find in section *Download Configuration* on page 87).

- Open **Settings > Master Settings**.

Master Settings	
<b>Start of bus communication</b> <input checked="" type="radio"/> Automatically by device <input type="radio"/> Controlled by application	<b>Module Alignment</b> <input checked="" type="radio"/> Byte boundaries <input type="radio"/> 2 Byte boundaries
<b>Application monitoring</b> Watchdog time: <input type="text" value="1000"/> ms	<b>Process data handshake</b> <input type="radio"/> Bus synchronous, device controlled <input type="radio"/> Buffered, device controlled <input type="radio"/> No consistence, uncontrolled <input checked="" type="radio"/> Buffered, host controlled <input type="radio"/> Bus synchronous, host controlled <input type="radio"/> Buffered, extended host controlled
<b>Process image storage format</b> <input checked="" type="radio"/> Big Endian (MSB first) <input type="radio"/> Little Endian (LSB first)	

Figure 30: Configuration > Master Settings



**Note:** The setting options at the dialog pane **Master Settings** for client specific variants of the configuration software can differ from the setting options displayed here.

## 5.6.1 Start of Bus Communication




Figure 31: Master Settings > Start of Bus Communication

If **Automatically by device** is selected, the AS-Interface Master device will start with the data exchange on the bus after the initialization has been ended.

When **Controlled by application** is selected, the application program must activate the data exchange on the bus.



**Note:** The setting options under **Start of Bus Communication** for client specific variants of the configuration software can differ from the setting options displayed here.

## 5.6.2 Application Monitoring




Figure 32: Master Settings > Application Monitoring

The **Watchdog time** determines the time within which the device watchdog must be re-triggered from the application program while the application program monitoring is activated. When the watchdog time value is equal to 0 the watchdog is deactivated and the application program monitoring is deactivated too.

The permissible range of values of the watchdog time is 20 to 65535. By default the watchdog time value equals to 1000 ms.

Watchdog time	Range of Value / Default Value
Permissible range of values	20 ... 65535 ms
Default	1000 ms
The software watchdog is deactivated.	0 ms

Table 22: Range of Value / Value for the Watchdog time



**Note:** The setting options under **Application Monitoring** for client specific variants of the configuration software can differ from the setting options displayed here.

### 5.6.3 Process Image Storage Format




Figure 33: Master Settings > Process Image Storage Format

The **Process Image Storage Format** determines how the data words are stored in the process image.

For the data type Word it is possible to choose **Big Endian** or **Little Endian**.

Storage format (word module)	
Big Endian	<b>MSB/LSB</b> = higher/lower = Motorola format = Big Endian
Little Endian	<b>LSB/MSB</b> = lower/higher = Intel format = Little Endian

Table 23: Master Settings Pane Parameters - Process Image Storage Format



**Note:** The setting options under **Process Image Storage Format** for client specific variants of the configuration software can differ from the setting options displayed here.

### 5.6.4 Module Alignment




Figure 34: Master Settings > Module Alignment

The **Module Alignment** defines the addressing mode of the process data image. The addresses (offsets) of the process data are always interpreted as byte addresses. The **Module Alignment** then defines the addressing mode, **Byte boundaries** or **2 Byte boundaries**.

Parameter	Meaning
Byte boundaries	The module address can start at any byte offset.
2 Byte boundaries	The module address can only start at even byte offsets.

Table 24: Parameters Master Settings > Module Alignment



**Note:** The setting options under **Module Alignment** for client specific variants of the configuration software can differ from the setting options displayed here.



## 5.6.5 Process Data Handshake




Figure 35: Master Settings > Process Data Handshake

The various types of **Process Data Handshakes** are used for setting the handshake of the process data for the AS-Interface Master device.

The selection of the used process data handshake is important for the correct data exchange between the application program and the device.

The used handshake of the process data needs to be supported by the used application program.

Only the **Buffered, host controlled** handshake mode is supported.



**Note:** The setting options under **Process Data Handshake** for client specific variants of the configuration software can differ from the setting options displayed here.

## 5.7 Bus Parameters

➤ Open **Settings > Bus Parameters**.

**Bus Parameter**

**Behaviour in case of defective slave device**

- ☒ Don't take care about the status of any connected slave devices
- ☐ Stop communication if a device is missing
- ☐ Stop communication if a device is reporting a periphery failure
- ☐ Stop communication if a device is missing or reporting a periphery failure

**Behaviour during start up sequence**

- ☒ Protected mode
- ☒ Auto address assignment

**Overwrite configuration database**

- ☐ Overwrite

Figure 36: Bus Parameters

Parameter	Meaning
<b>Behavior in case of defective Slave device</b>	
	Determines the procedure of the Master, if a Slave is detected as missed during run time and during the first network start up phase
Don't take care about the status of any connected Slave devices.	The Master tries to keep the network communication notwithstanding of the states of the connected Slaves.
Stop communication if a device is missing.	The Master stops the network communication for the assigned channel, if it detects a missing Slave during the first network scan or during the data exchange.
Stop communication if a device is reporting a periphery failure.	The Master stops the network communication for the assigned channel, if at least one Slave is reporting a periphery failure.
Stop communication if a device is missing or reporting a periphery failure.	The Master stops the network communication for the assigned channel, if it detects a missing Slave or a Slave reports a periphery failure.
<b>Behavior during start up sequence</b>	
	Determines the procedure of the Master during the start up in relation to the Slaves connected to the channel that is assigned to the Master.
Protected mode	If checked, the Master chip of the assigned channel goes in the "protected data exchange mode". If unchecked, it goes in the "configuration mode".
Auto address assignment	If checked and if the Master detects a Slave, which can replace a missing Slave (i. e. with identical I/O, ID, ID1 and ID2 code), the Master assigns the address of the missing Slave to the detected one, provided that the new Slave has the address 0 (zero).
<b>Overwrite configuration database</b>	
Overwrite	If checked, the AS-Interface Master overwrites the database if the Master receives configuration commands from the packet interface. (The services of the single configuration packets are described in the API manual.)

Table 25: Bus Parameters

## 6 Online Functions

### Getting Access to SYCON.net Online Functions



**Note!** If under 'Configuration' > 'Master Settings' > 'Start of bus communication' > 'Controlled by application' is selected, after 'Power on Reset' the Master device is in 'Offline' state! In this state you can not use the SYCON.net online functions 'Debug Mode', 'LifeList' and 'Network Scan'. To get access to the online functions in case the Master device is used together with an application program, you must make sure that the application program will start the communication. Alternatively you can start the communication manually from the context menu 'Start communication' of the the Master device.

### 6.1 Connecting/Disconnecting Device



**Note:** Several AS-Interface Master DTM functions e. g. **Diagnosis** or the configuration download in the FDT Framework require an online connection from the AS-Interface Master DTM to the AS-Interface Master device.

#### Connecting Device

The following steps are needed to establish a connection from the AS-Interface Master DTM to a AS-Interface Master device:

Under **Settings** in the **Driver** pane:

1. Verify that the default driver is checked and respectively check another or multiple drivers.
2. Configure the driver if necessary.

Under **Settings** in the **Device Assignment** pane:

3. Scan for the devices (with or without firmware).
4. Select the device (with or without firmware) and apply the selection.



Before you download the firmware adhere to the necessary safety precautions to prevent personnel injury and property damage that may occur in consequence of a communication stop. For more refer to section *Safety Messages on Firmware or Configuration Download* on page 27.

Under **Settings** in the **Firmware Download** pane if not yet a firmware was loaded to the device:

5. Select and download the firmware.

Under **Settings** in the **Device Assignment** pane if not yet a firmware was loaded to the device:

6. Scan for the device (with firmware) once more.
7. Select the device (with firmware) once more.



An overview of the descriptions for these steps you find in the section *Overview Settings* on page 29.

8. In the DTM interface dialog select the **OK** button, to apply the selection and to close the DTM interface dialog.
  9. Put a right-click on the AS-Interface Master device icon.
  10. Select the **Connect** command from the context menu.
- The AS-Interface Master device now is connected to the AS-Interface Master DTM via an online connection. In the network view the device description at the device icon of the Master is displayed with a green colored background.

### **Disconnecting Device**

To disconnect an online connection from the AS-Interface Master device to a AS-Interface Master DTM take the following steps:

1. In the DTM interface dialog select the **OK** button, to close the DTM interface dialog.
  2. Right-click on the AS-Interface Master device icon.
  3. Select the **Disconnect** command from the context menu.
- In the network view the device description at the device icon of the Master is not any more displayed with a green colored background. Now the AS-Interface Master device is disconnected from the DTM.



---

**Important:** For a 2-channel devices channel 1 or channel 2 must be individually connected to the DTM.

---




## 6.2 Debug Mode







**Note:** Depending by the software variant of the frame application the **debug mode** is available or not.

The **debug mode** allows identifying the status of the cyclical communication between a Master device and its Slave devices on a network based on the colors of the bus lines as well as the debug icons.

For the Master device or the Master bus line this is valid:

- Master device in operation, cyclical communication runs. (Bus line **light green**/debug icon „RUN“  next to the Master device icon)
- Master device not operable.  
(Bus line **blue**/debug icon „ATTENTION“  next to the Master device icon)
- Master in STOP state.  
(Bus line **red**/debug icon „STOP“  next to the Master device icon)

For the Slave device or the bus line from the Master bus line to the Slave device this is valid:

- Slave device in operation, cyclical communication to the Master device runs. (Bus line **light green**/debug icon „RUN“  next to the Slave device icon)
- Diagnosis message available at the Master device.  
(Bus line **yellow** (yellow)/debug icon „RUN“  next to the Slave device icon)
- Slave device not found during cyclical communication boot up.  
(Bus line **blue**/ debug icon „ATTENTION“  next to the Slave device icon)
- Error in the Slave-to-Master communication.  
(Bus line **red**/debug icon „STOP“  next to the Slave device icon)
- Slave device is not configured.  
(Bus line **gray**)

## 6.2.1 Requirements



---

**Note:** You first must:

- assign the Master device to the Master DTM,
- configure the Master or the Slave device parameters,
- and download the configuration to the Master.

Only then the debug mode can be used appropriately.

---



For details to the device assignment, refer to section *Settings for Driver and Device Assignment* on page 30.

For information on how to configure the Master device or how to download the configuration, refer to this Operating Instruction Manual and to the Operating Instruction Manual for the netDevice.

For information on how to configure the Slave device, refer to the Operating Instruction Manual of the Slave DTM.

---

## 6.2.2 Starting Debug Mode




**Note:** The menu entries for the **debug mode** will be only available if the debug mode is supported by the frame application and the Master DTM.

For a single network:

- Therefore open the context menu of the Master via right mouse click to the device icon.
- Select the **Start Debug Mode** command from the context menu.

For the entire project:

- Click to the menu **Network > Start Project Debug Mode** or in the netDevice toolbar **Debug** to the icon .
- In the debug mode, the bus lines in the network view are displayed depending on the status of the cyclical communications in various colors. Additionally next to the device icon different debug icons are displayed.




Figure 37: Example Debug Mode with pending Diagnosis, Network View of a Project with one Network (Master and Slave)

- **Root Busline:** This busline is displayed always in **gray**.
- **Branch Line of the Master device** (Busline from the Root to the Master Busline): During the debug mode this busline is displayed **light green**, **blue** or **red** colored. If the debug mode is not used, this bus line will be displayed **gray** colored.
- **Master Busline or Branch Line of the Slave device:** During the debug mode these buslines are displayed **light green**, **yellow** (yellow), **blue** or **red** colored. If the debug mode is not used, this bus line will be displayed in the respective *fieldbus* or *protocol specific* color (PROFIBUS: **violet**).

## 6.2.3 Debug Mode Busline Colors and Debug Icons

The following table contains information about the displayed colors of the bus lines and on the icons in the debug mode.








Debug Mode Busline Colors	Debug Icon	Meaning
Master Busline	Next to the Master device icon	
light green		The Master device has cyclic communication
blue		The Master device is not operable. This may have different causes. For example: - There is no valid license in the Master device. - There is no valid firmware in the Master device.
red		The Master device is in STOP state. The cyclic communication has been stopped.
Branch Line of the Slave device	Next to the Slave device icon	Meaning
light green		The Master device has cyclic communication to this Slave device.
yellow (yellow)		The Master device has cyclic communication to this Slave device, but in the diagnostic buffer of the Master device a diagnostic information about this Slave is pending.
blue		The device was not found. This may have different causes. For example: - The configuration download to the Master device is still missing. - The Slave device is not available in the network. - There is no valid firmware in the Master device. - Parameter or configuration error at the Master device. - The cyclic communication to this Slave device has been stopped (without diagnosis information at the Master).
red		Due to a communication error, the cyclic communication from the Master device to this Slave device is not possible. This may have different causes. For example: - The cyclical communication to this Slave device has been stopped. - Parameter or configuration error at the Slave device. - The validation of the manufacturer or device ID shows different values. - The diagnostic buffer of the Master device still a diagnostic information about this Slave is pending and the cyclic communication to this Slave device has been stopped.
gray	-	The Slave device is not configured. I. e., in the configuration of the Master device there are no configuration parameters to this Slave available.

Table 26: Debug Mode Busline Colors and Debug Icons



## 6.2.4 Reset of the Diagnosis Information and of the Station Status

To analyze the diagnosis information:

- Select the diagnosis windows in the Master DTM dialog.
- Therefore select **Diagnosis** > [*diagnostic window*] in the navigation area.

To read the diagnosis buffer of the Master device and thus to reset the device:

- Select **Diagnosis** > **Station diagnostic** in the navigation area.
- In the window **Station diagnostic** click with the right mouse button to the station status LED for the device (yellow).
- From the context menu select **Reset** or **Reset All**.

In the window **Station diagnostic** the station status LED for the device is displayed in green and the network will display the bus line from the Master device icon to the Slave device icon in **light green**.

## 6.2.5 Stopping Debug Mode

For a single network:

- Therefore open the context menu of the Master via right mouse click to the device icon.
- Select the **Stop Debug Mode** command from the context menu.

For the entire project:

- Click to the menu **Network** > **Stop Project Debug Mode** or in the netDevice toolbar **Debug** to the icon .

## 6.3 Set Station Address

With the dialog **Set Station Address** the AS-Interface station address of the device can be changed.

To set the station address, proceed as described hereafter:

1. Select and connect the device.
2. Disconnect the device (only if the device is online).



**Note:** The dialog **Set Station Address** is enabled only during offline mode. The online-connection between the AS-Interface Master DTM and the AS-Interface Master device must be disconnected.



For further information how to establish or how to disconnect an online connection from the AS-Interface Master DTM to the AS-Interface Master device, refer to section *Connecting/Disconnecting Device* on page 67.

3. Select **Additional Functions > Set Station Address** from the context menu (right mouse click).

Figure 38: Set Station Address

4. Enter the new station address and select **Set Address**.
- The new station address of the device is set and in addition it is displayed in the **Current station address** list.

## 6.4 Change Extended ID1 Code

With the dialog **Change Extended ID1 Code** the Extended ID1 code of the AS-Interface Slave device can be changed.

To set **Extended ID1 code**, proceed as described hereafter:

1. Connect the AS-Interface Slave device to the AS-Interface Master device using an AS-Interface cable.
2. In **netDevice**: Disconnect the AS-Interface Master device (only if the device is online).



**Note:** The dialog **Change Extended ID1 Code** is enabled only during offline mode. The online-connection between the AS-Interface Master DTM and the AS-Interface Master device must be disconnected.



For further information how to disconnect an online connection from the AS-Interface Master DTM to the AS-Interface Master device, refer to section *Connecting/Disconnecting Device* on page 67.

3. Select **Additional Functions > Change Extended ID1 Code** from the context menu (right mouse click).

Figure 39: Change Extended ID1 Code

4. Enter the new code under **Extended ID1 code** and select **Execute**.

➤ The new Extended ID1 code of the device is set.

## 6.5 Live List

The **Live List** gives an overview of the devices, which are physically present in the actual AS-Interface network constellation.




Figure 40: Live List

### 6.5.1 Access to the Live List

Proceed as follows:

1. Connecting Device:



**Note:** Accessing the **Live List** display requires an online connection from the AS-Interface Master DTM to the AS-Interface Master device.

- Under **Settings > Driver** select and configure a driver.
- Under **Device Assignment** scan, select the device and apply the device.
- Under **Firmware Download** select and download the firmware.
- Close the DTM dialog via **OK**.
- Right-click on the AS-Interface Master device icon.
- Select **Connect** from the context menu.
- The AS-Interface Master device now is connected to the AS-Interface Master DTM via an online connection.



For further information refer to section *Connecting/Disconnecting Device* on page 67.

## 2. Access to the **Live List**:

- Right-click on the AS-Interface Master device icon.
- Select **Additional Functions > Live List** from the context menu.




Figure 41: Live List > Slaves

Under **Live List > Slaves** all disposal station addresses\* and their states are shown as LED, whereby the number indicates the AS-Interface station address of the device (\*1- 31, for extended addressing mode 1A to 31A and 1B to 31B, address 0 for configuring of newly detected Slaves).

Present Slave devices are represented as a **blue** LED, present Sub-Slave devices are represented as a **light blue** LED, all other non present devices as a **grey** LED. The meaning of the other colors is given in the list below the table.

Color of the LED	Meaning
<b>blue</b>	The Slave device is present.
<b>light blue</b>	The sub Slave device is present.
<b>grey</b>	No Slave device present.

Table 27: Legend Live List > Slaves

## 6.5.2 Display Additional Information, Update Live List

### Display Additional Information

- Set the mouse pointer to the Slave device, for which additional information shall be displayed.

Additional Information			
Slave Address:	1A	Extentional ID1 Code:	7
I/O Configuration:	7	Extentional ID2 Code:	A
ID Code:	A		

Figure 42: Live List > Additional Information

- Under **Additional Information** the following data are displayed:

Parameter	Meaning
Data of the generic AS-Interface Slave device station	
Slave Address	The device address
I/O Configuration	As specified in the EDS file.
ID Code	As specified in the EDS file.
Extended ID1 Code	To set by the user in the generic Slave DTM.
Extended ID2 Code	To set by the user in the generic Slave DTM.

Table 28: Live List > Additional Information

### Update Live List

The display is not updated automatically as this function loads the AS-Interface network. However, the Live List can be renewed with the **Update** button.

## 6.6 Network Scan

With the function **Network Scan...** of the AS-Interface Master DTM you can find out automatically which AS-Interface Slaves are attached to the AS-Interface Master device and how these devices are configured. During the network scan the Master device requests the ident codes of the Slave devices found at the bus. For each connected Slave device its ident code is read out.

In the **Scan Response** dialog of the Master DTM the assigned device description files or DTM devices are displayed. Exactly one ident code is assigned to each device description file and to each DTM device. Different versions (also language versions) of the same device description file are defined by the same ident code. For every identified device you can select the assigned DTM device according to the firmware loaded in that Slave device. Via **Create Devices** for each Slave device the selected DTM device is created.

### Requirements

The AS-Interface Master device must be configured.



**Important:** The configuration of the Master device must be downloaded in the Master device. For more see section *Configuration Steps* on page 23 .

### Overview of the Steps

1. Starting the **Network Scan** function of the Master DTM.
2. Make the settings in the **Scan Response** dialog of the Master DTM.
3. Click **Create Devices**.
4. Via the **Download** function of the Master DTM, download the current configurations of the Slave devices to the Master device.

## 6.6.1 Starting 'Network Scan'

### 1. Starting the **Network Scan** function of the Master DTM.

- In netDevice: right-click on the device symbol of the AS-Interface Master DTM.
- Select **Network Scan...** from the context menu.




Figure 43: Starting 'Network Scan' (Example)

- Wait for a short time.
- If the query is displayed if the IO communication shall be stopped, click **Yes**.



**Note:** It can last some seconds, until the **Network Scan...** dialog is displayed.

Via **Network Scan...** an online connection from the AS-Interface Master DTM to the AS-Interface Master device is established. The configuration software scans, which AS-Interface Slaves are attached to the AS-Interface network or to the AS-Interface Master device.



➤ The **Scan Response** dialog of the Master DTM is displayed.




Figure 44: Scan Response dialog of the Master DTM (Example)

## 6.6.2 Settings in the Scan Response Dialog of the Master DTM

### 2. Make the settings in the **Scan Response** dialog of the Master DTM

- In the **DTM to Use** column the DTM devices assigned to the found ident codes appear.




Figure 45: Scan Response dialog of the Master DTM (Example)

- In the **DTM to Use** column select for every identified device the DTM device corresponding to the firmware loaded in this Slave device (only if the corresponding DTM devices are in use).
- If in the **DTM to Use** column no DTM device or a DTM device not desired is displayed, add the required DTM devices to the device catalog.
- or adapt the creation mode under **Creation Mode**.
- In the **Action** column select, whether the found DTM device shall be:
  - *added* or *skipped*  
(if a device is not yet present in the project),
  - *or replaced* or *skipped*  
(if a device is already present in the project)

### 6.6.3 Description on the Scan Response dialog of the Master DTM

In the following table you find a description about the **Scan Response** dialog of the Master DTM.

Column	Description
<b>Title Bar</b>	With the text: <i>Symbolic Name of the Master Device [Device Description] &lt;Device Address&gt; (#Network ID) channel: /ASi.</i>
<b>Instruction</b>	In the Network Scan window the instruction text is displayed: <b>The following hardware-devices have been found during network scan. Please check automatic selection of corresponding devices found in device catalog in column 'DTM Devices' before creating devices.</b>
<b>Station Address</b>	AS-Interface station address, which displays the logical sequence of the devices within a AS-Interface network.
<b>Colors</b>	Meaning of colors in the <b>Scan Response</b> dialog of the Master DTM: <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;"> <div style="background-color: red; width: 20px; height: 15px; display: inline-block;"></div> <b>Red</b>  <div style="background-color: yellow; width: 20px; height: 15px; display: inline-block;"></div> <b>Yellow</b> </div> <div> <p>If a field marked in red appears in column <b>Station address</b>, the respective DTM device is already present on the network.</p> <p>If a field appears marked in yellow, a selection can be made by a combo box.</p> </div> </div>
<b>Device Type ID</b>	Value of the AS-Interface Slave device parameter „I/O Configuration“ according to the first position of the Slave profile.
<b>Sub Device Type</b>	Value of the AS-Interface Slave device parameter „I/O Code“ according to the second position of the Slave profile.
<b>DTM to Use</b>	<p>Display of the DTM devices, which are assigned to the ident codes found during scanning:</p> <p>If <u>Use Hilscher generic DTMs if available</u> is displayed <i>without color marking</i>, there is no selection possibility.</p> <p>If <u>Use Hilscher generic DTMs if available</u> is displayed <i>marked in yellow</i>, the following selection can be made:</p> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">Use Hilscher generic DTMs if available</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">Use Hilscher generic DTMs if available</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 2px;">Use vendors DTMs if available</div> <div style="margin-left: 10px;">(In the figure shown example DTMs are displayed.)</div> </div> <p>A selection will only be displayed if under <b>Creation Mode &gt; Choose for each device</b> was selected and if another DTM has been found for the respective device.</p>
<b>Device Class</b>	DTM Specific Group (Information from DTM)
<b>DTM Device</b>	<p>Found DTM device (the device name as taken from the DTM)</p> <p>Only the device description files or DTM devices can be displayed within the column <b>DTM Devices</b>:</p> <ul style="list-style-type: none"> <li>• Which are available in the device catalog for the scanned ident code,</li> <li>• Respectively, which belong to the selection made under <b>Creation Mode</b></li> <li>• and which belong to the selection made under <b>Creation Mode &gt; Choose for each device</b> under <b>DTM to create</b>.</li> </ul> <div style="display: flex;"> <div style="flex: 1;"> <p>For each device type ID in the column <b>DTM Device</b> the following is displayed:</p> <ul style="list-style-type: none"> <li>• <u>no</u> device,</li> <li>• <u>one</u> single device</li> <li>• or <u>multiple</u> devices (within a combobox).</li> </ul> </div> <div style="flex: 1;"> <p>This means, within the device catalog of netDevice for the found ident code and the selected <b>Creation Mode</b> these alternatives are available:</p> <ul style="list-style-type: none"> <li>• no DTM</li> <li>• A device description file or a DTM device of the manufacturer</li> <li>• One or more device description files or DTM devices of a manufacturer</li> </ul> </div> </div>
<b>Quality</b>	Associated quality information Display: [1] DTM found, [3] Generic found



Column	Description
<b>Action</b>	<p>The action to be performed with the corresponding device during the process of device creation.</p> <ul style="list-style-type: none"> <li>If no device is present within the current project, the selection <b>Add/Skip</b> will appear.</li> <li>If there is already a device present within the current project, the selection <b>Replace/Skip</b> will appear.</li> </ul> <p><b>Add</b> adds a new instance for the selected DTM during the process of creation of a device.</p> <p><b>Skip</b> skips the process of creation of a device for the respective device address.</p> <p><b>Replace</b> erases the instance of the DTM currently located at this address during the process of creation of a device, and replaces it with the instance of the chosen DTM.</p>
<b>Table below</b>	<p>The lower table in the <b>Scan Response</b> dialog of the Master DTM shows a comparison of possible differences in device information taken from:</p> <ul style="list-style-type: none"> <li>The hardware device (displayed in central column of 3)</li> <li>and the DTM (displayed in right column of 3)</li> </ul> <p>The left column contains which information is compared between the information sources 'Hardware Device' and 'DTM'.</p> <hr/> <p> <b>Note:</b> If a field contains the text 'n/a', the corresponding information is not applicable in the current context (fieldbus).</p>
<b>Creation Mode</b>	<p>Under <b>Creation Mode</b> one of the following options can be selected:</p> <ul style="list-style-type: none"> <li>User Hilscher generic DTM if available</li> <li>Use vendors DTMs if available</li> <li>Choose for each device</li> </ul> <div data-bbox="379 996 858 1122">  </div> <p><i>Scan Response dialog of the Master DTM &gt; 'Creation Mode'</i></p>
<b>Create Devices</b>	<p>About <b>Create Devices</b> ...</p> <ul style="list-style-type: none"> <li>for each Slave device the previously selected DTM device is created.</li> <li>the Slave device configuration is uploaded to the created Slave-DTM and thereby the module configuration is generated.</li> </ul> <p>In case a conflict occurs between a device description file and a device, the <b>Upload</b> dialog appears, where conflicts are displayed in red.</p>
<b>Cancel</b>	Click <b>Cancel</b> to leave the dialog without creating a Device.

Table 29: Description on the Scan Response dialog of the Master DTM

## 6.6.4 Creating Devices

### 3. Click **Create Devices**

- In the **Scan Response** dialog of the Master DTM click **Create Devices**.
- For each Slave device the previously selected DTM device is created.
- The dialog **netDevice** appears showing the progress bar **Creating DTM Device**. The dialog shows the the progress of the device creating process.



**Note:** Depending on the manufacturer of the respective device, also a dialog with some slight deviations from this one may be displayed.




Figure 46: Creating the DTM devices (Example)

➤ The generated Slave devices are added to the Master bus in the network.




Figure 47: Created Slave Devices in the Network (Example)

## 6.6.5 Download to the AS-Interface Master Device



Adhere to the necessary safety precautions to prevent personnel injury and property damage that may occur in consequence of a communication stop or in consequence of a mismatching system configuration. For more refer to section *Safety Messages on Firmware or Configuration Download* on page 27.

4. Via the **Download** function of the Master DTM, download the current configurations of the Slave devices to the Master device.

- In **netDevice**: right-click on the device symbol of the AS-Interface Master DTM.
- Select **Download** from the context menu.




Figure 48: 'Download' current Configuration to AS-Interface Master (Example)

➤ The Dialog **netDevice - Download** appears:

**If you attempt to download during bus operation, communication between master and slaves is stopped.**

**Do you really want to download?**

➤ Click **Yes**.

➤ The dialog **netDevice** appears showing the progress bar **Download active, device performs initialisation...**

➤ The **netDevice** window shows the message (example): **Download succeeded to device CIFX\_RE\_ASM[CIFX RE/ASM]<=>(# 1).**



## 6.7 Download Configuration

The device configuration is created *offline* in the DTM (application program). A download to the device is required, to transfer the configuration with the parameter data to the device.



**Note:** To download configuration parameter data to the AS-Interface Master device an online connection from the AS-Interface Master DTM to the AS-Interface Master device is required.



Further information can be found in the *Connecting/Disconnecting Device* section on page 67.

### **Safety Precautions**

Adhere to the necessary safety precautions to prevent personnel injury and property damage that may occur in consequence of a communication stop or in consequence of a mismatching system configuration.

#### **⚠ WARNING**

##### **Personnel Injury in Consequence of a Communication Stop**

- Stop the application program before starting a configuration download.
- Make sure that your equipment operates under conditions that prevent personal injury. All network devices should be placed in a fail-safe mode before downloading a configuration.
- Unexpected equipment operation may cause personal injury.

##### **Personnel Injury as a result of mismatching System Configuration**

- Mismatching system configuration loaded into the device could result in faulty data mapping in the application program and thus unexpected equipment operation may cause personal injury.

#### **NOTICE**

##### **Damage of Equipment and Loss of Device Parameters in Consequence of a Communication Stop**

- Stop the application program before starting a configuration download.
- Make sure that your equipment operates under conditions that prevent property damage. All network devices should be placed in a fail-safe mode before downloading a configuration.
- Unexpected equipment operation may cause property damage.
- Before you initiate a configuration download make sure that your current project configuration data are saved non-volatile in order to prevent loss of configuration data.

##### **Damage of Equipment as a result of mismatching System Configuration**

- Mismatching system configuration loaded into the device could result in faulty data mapping in the application program and thus unexpected equipment operation may cause damage of equipment.

### **Download Steps**

To transfer the configuration with the corresponding parameter data to the AS-Interface Master device you download the data using the frame application of the configuration software.

For netDevice the download is made via **Device > Download** or use the context menu with **Download**.

1. Select **Download** in the context menu of the device.

⇒ If the download is started as long as the Slave devices are connected to the Master device, the following message is displayed: 'If you attempt to download during bus operation, communication between Master and Slaves is stopped. Do you really want to download?'




Figure 49: netDevice Message: Download



**Important:** If the communication between the Master and the Slave devices is stopped, the data exchange between the Master device and the Slave devices is stopped.

2. Click to **Yes** if you intend to download the configuration.

⇒ Then the current configuration in the application program is downloaded to the device.

3. Otherwise click to **No**.



## 6.8 Start /Stop Communication

You can manually start or stop the communication between a AS-Interface Master device and AS-Interface Slave devices.

- **Start Communication** can be enabled if the communication was stopped before or if the configuration requires this (Controlled release of communication).
- **Stop Communication** can be enabled if the communication was started.

To start or to stop the communication, proceed as follows:

- Adhere to the necessary safety precautions to prevent personnel injury and property damage that may occur in consequence of a communication stop.

### **WARNING**

#### **Personnel Injury in Consequence of a Communication Stop**

- Make sure that your equipment operates under conditions that prevent personal injury. All network devices should be placed in a fail-safe mode before downloading a configuration.
- Unexpected equipment operation may cause personal injury.

### **NOTICE**

#### **Damage of Equipment and Loss of Device Parameters in Consequence of a Communication Stop**

- Make sure that your equipment operates under conditions that prevent property damage. All network devices should be placed in a fail-safe mode before downloading a configuration.
- Unexpected equipment operation may cause property damage.

### **Start Communication**

1. Connecting device:



**Note:** To start the communication of the device at the bus manually, an online connection from the AS-Interface Master DTM to the AS-Interface Master device is required.



Further information can be found in the *Connecting/Disconnecting Device* section on page 67.

2. Select **Additional Functions > Service > Start Communication** from the context menu (right mouse click).

➤ The device communicates at the bus.

### **Stop Communication**

1. Select **Additional Functions > Service > Stop Communication** from the context menu (right mouse click).

➤ The communication of the device at the bus is stopped.

## 6.9 Licensing

Using the license dialog, you can order licenses for **Master protocols** or **Utilities** and download them to your device.

### 6.9.1 Open License Dialog

You first open the **License** window.



**Note:** You first need to assign the Master device to the DTM. Only then the device data and the licenses already present in the device are displayed in the **License** dialog.

How to proceed:

#### A.) Assigning the Master device to the DTM

1. Open the DTM configuration dialog.
  - In the FDT container **netDevice** double click to the device icon.
2. Select one or several drivers.
  - Select **Settings > Driver**.
  - Check the drivers.
3. Configure the driver if necessary.
  - Select **Settings > Driver > [Name of the assigned driver]**.
  - Configure the driver settings.
4. Scan for and select the devices.
  - Select **Settings > Device Assignment**.
  - Under **Device selection** select *suitable only* or *all* and then **Scan**.
  - In the table check the required devices.
  - Select **Apply**.
5. Close the DTM configuration dialog via **OK**.



For details to the device assignment, refer to section **Overview Settings** on page 29.

#### B.) Open the License pane

- In the FDT container **netDevice** right click to the device icon.
- From the context menu select **Additional Functions > License**.
- The **License pane** opens.

## 6.9.2 License Dialog

In the **License**<sup>1</sup> pane you can:

- check, which licenses for Master protocols or Utilities are present in the device (Position ① in the figure below),
- order licenses (Positions ② to ⑪),
- transfer licenses to the device ⑫.

netDevice - License

License Type ①

	Existing	Order ②
<b>Master protocols</b>		
One General Master License	NO	<input type="checkbox"/>
Two General Master Licenses	NO	<input type="checkbox"/>
PROFIBUS Master	YES	<input type="checkbox"/>
CANopen Master	YES	<input type="checkbox"/>
DeviceNet Master	YES	<input type="checkbox"/>
AS-Interface Master	YES	<input type="checkbox"/>
PROFINET IO RT Controller	YES	<input type="checkbox"/>

Request Form, please fill out

Name	Value ③
License type	User Single Device License
Manufacturer*	0x0001
Article number*	1251100
Serial number*	20007
Chiptype*	0x00000001
Step*	0x00000000
Romcode revision*	0x00000000

Fields marked with "\*" are mandatory.

④

E-mail... ⑤

Print Fax Form... ⑥

Telephone... ⑦

Export License Request... ⑧

⑨

⑩

⑪

⑫ Download License

Close Help

Figure 50: License Pane



**Note:** To display further entries under **License Type**, move the scroll box ① downwards or upwards. To display further entries under **Request Form, please fill out**, move the scroll box ② downwards or upwards.

<sup>1</sup> The title bar contains the notation of the **device description**:  
Symbolic Name [Device Description] <Station Address> (#Network ID).

### 6.9.3 Which Licenses are present in the Device?

Check, which licenses are present in the device.

How to proceed:

- Open the **License** pane as described under section *Open License Dialog* on page 90.




Figure 51: License Pane - License Type

- Under **License Type** click **+** at **Master protocols**.
- The **Master protocols** overview opens:




Figure 52: License Pane – License Type / Master protocols

- Or click **+** at **Utilities**.
- The **Utilities** overview opens:




Figure 53: License Pane – License Type / Utilities

- The column **Existing** indicates which licenses are present in the device.  
**Yes** = License is present in the device.  
**No** = License is not present in the device.



**Note:** In newer versions of the present configuration software under **License Type** may be displayed additional licenses or other protocols that can be ordered later.

### 6.9.3.1 License for Master Protocols

*One General Master License:*

On the device maximally 1 communication protocol with master function can be implemented.

*Two General Master Licenses:*

On the device maximally 2 communication protocols with master function can be implemented.

The license includes the following Master protocols:

- AS-Interface Master
- CANopen Master
- DeviceNet Master
- EtherCat Master
- EtherNet/IP Scanner
- PROFIBUS Master
- PROFINET IO RT Controller
- Sercos Master

### 6.9.3.2 License for Utilities

- SYCON.net
- OPC Server
- QVis Minimum Size
- QVis Standard Size
- QVis Maximum Size
- CoDeSys Minimum Size
- CoDeSys Standard Size
- CoDeSys Maximum Size

For the utilities QVis and CoDeSys, only one license each may be chosen alternatively as:

- *Minimum Size,*
- *Standard Size or*
- *Maximum Size.*



## 6.9.4 How to order a License

To order a license, proceed as follows:

	<i>Refer to Section:</i>	<i>Page</i>
1. Open the license dialog.	<i>Open License Dialog</i>	90
2. Select the required licenses.	<i>Selecting License</i>	94
3. Enter the ordering data.	<i>Ordering Data</i>	95
4. Place your order.	<i>Ordering the License</i>	97

## 6.9.5 Selecting License(s)

You can select licenses for Master protocols and / or utilities.

1. Selecting license(s) for Master protocol(s):
  - Under **License Type** click  at **Master protocols** in the **License** pane.
  - Under **Order** check as many licenses must run simultaneously on your device:  
*One General Master License or  
Two General Master Licenses.*
2. And/or select license(s) for utility(utilities):
  - In the **License** pane under **License Type** click  at **Utilities**.
  - Under **Order** check the required utility(utilities)  
*(single or several)<sup>2</sup>*:
    - SYCON.net
    - OPC Server
    - QVis Minimum Size\*
    - QVis Standard Size\*
    - QVis Maximum Size\*
    - CoDeSys Minimum Size\*\*
    - CoDeSys Standard Size\*\*
    - CoDeSys Maximum Size\*\*

<sup>2</sup> For \*) and \*\*) minimum size, standard size or maximum size can be selected only as an alternative.

## 6.9.6 Ordering Data

### 1. Device Information

- The *Device Information* required for the order are read from the device and automatically filled in the order.

### 2. Ordering Data

Enter the *Ordering Data* into the **License** pane.

- Enter the **Data to manage the Order** (therefore refer to section *Data to manage the Order (License Information)* on page 96).

### 6.9.6.1 Device Information (Ordering data read from the Device)

The following ordering data are read from the device and displayed in the **License** pane:

- Manufacturer
- Device number
- Serial number
- Chiptype
- Step (chip revision)
- Romcode revision
- Checksum (checksum of the device data)

- The gray fields under **Request Form, please fill out** contain the ordering data read from the device:

Request Form, please fill out

Name	Value
Manufacturer*	0x0001
Article number*	1251100
Serial number*	20007
Chiptype*	0x00000001
Step*	0x00000000
Romcode revision*	0x00000000
Checksum*	G

Fields marked with '\*' are mandatory.

Figure 54: License Pane - Request Form, please fill out / Device Information

- These ordering data read out from the device are displayed automatically from the device.

### 6.9.6.2 Data to manage the Order (License Information)

For your order you must enter the following data to the **License** pane:

1. License Type (User Single Device License).

Name	Value
License type	User Single Device License

Figure 55: License Pane - Request Form, please fill out / License Type

- Select the license type under **Request Form, please fill out > Value**, (for future application, currently only *User Single Device License* can be selected).
- 2. Mandatory data to the order request (editable fields):
  - First Name
  - Surname
  - E Mail (address, to which the license download link shall be send.)
  - Telephone
  - Company
  - Address
  - Country
  - City, State, Zip

Name	Value
First name*	John
Surname*	Doe
E-Mail*	License@doe.com
Telephone*	0011223344-55
Fax	0011223344-100
Customer number	123456789
Company*	Doe Example LTD

Fields marked with '\*' are mandatory.

Figure 56: License Pane - Request Form, please fill out / Mandatory data

- Enter all mandatory fields under **Request Form, please fill out > Value** (marked with\*).
- 3. Additional order data, not mandatory (editable fields):
  - Fax
  - Customer Number
  - Order Number
  - Value added tax identification number
- Under **Request Form, please fill out > Value** enter all fields for the additional data, which are not mandatory.



## 6.9.7 Ordering the License

Place your order in the **License** pane. Therefore:



Figure 57: License Pane – Selecting the Subsidiary / Ordering / Contacts

1. Select the **Subsidiary** (4), to which the order shall be send.
2. Place the order:

- |   | <i>Refer to Section:</i>                                  | <i>Page</i> |
|---|---|-------------|
| • by <b>E-Mail</b> (5),                               | <i>Ordering the License <u>by E Mail</u></i>              | 98          |
| • or by <b>Fax</b> (6)<br>or by <b>Telephone</b> (7), | <i>Ordering the License <u>by Fax or by Telephone</u></i> | 99          |
| • or in a <b>File</b> (8).                            | <i><u>Exporting License Request to a File</u></i>         | 101         |
- The **Contact Data** of the selected subsidiary are displayed under Position (9), (10) and (11).

### 6.9.7.1 Ordering the License by E Mail

You can place your order by e-mail.



Figure 58: License Pane – placing the order by E-mail

- Click **E-mail...** 5.
- The order E-mail **License request** opens:




Figure 59: Example: Order E-Mail License request

- The order e-mail **License request** contains:
  - the **E-mail...** of the selected subsidiary a,
  - the automatically generated **XML file** b *EmailOrderRequest\_[Devicenumbrer]\_[Serialnumber].xml* with a summary info of the **order information**,
  - the **Order Address** c,
  - the **License Information** d,
  - the **License Type** e,
  - the **Device Data** f,
  - the **ordered Licenses** g.
- Send the order e-mail **License request**.
- The order process is complete.

### 6.9.7.2 Ordering the License by Fax or by Telephone

You can place your order by Fax or by Telephone.



Figure 60: License Pane - placing the order by Fax or by Telephone

- Click **Print Fax Form** ⑥ or **Telephone...** ⑦.
- The summary of the ordering data *PrintOrderRequest\_[Devicenum-ber]\_[Serialnumber].html* is opened in a browser window.



**Note:** If your browser does not display the order data or the window **Move Element** or **Copy Element** are displayed, check the safety settings of your system.

### netX License Order Form

Doe Example LTD  
2000th Rd  
NY 11417  
U. S.  
fax: +11223344-100

#### Licensee Information ④

<i>First Name:</i>	John
<i>Surname:</i>	Doe
<i>e-Mail:</i>	License@doe.com
<i>Telephone:</i>	0011223344-55
<i>Fax:</i>	0011223344-100
<i>Customer No:</i>	123456789
<i>Company:</i>	Doe Example LTD
<i>Address:</i>	2000th Rd
<i>Country:</i>	U. S.
<i>City Zip:</i>	NY 11417
<i>Order Number:</i>	987654321
<i>Tax Ident. Number:</i>	test

#### License Type ⑤

User Single Device License

#### Device Information ⑥

<i>Manufacturer:</i>	0x0001
<i>Device Number:</i>	1251100
<i>Serial Number:</i>	20007
<i>Chip Type:</i>	0x00000001
<i>Step:</i>	0x00000000
<i>Romcode Revision:</i>	0x00000000
<i>License Flags 1:</i>	0x7f
<i>License Flags 2:</i>	0x0

#### Ordered Licenses ⑧

*Master Protocols*

- One General Master License
- Sercos III Master

*Utilities*

- SYCON.net

Date: \_\_\_\_\_

Signature: \_\_\_\_\_

Figure 61: Example: Order Data Form *PrintOrderRequest*

- The order data form contains:
- the **Order Address** <sup>c</sup>,
- the **License Information** <sup>d</sup>,
- the **License Type** <sup>e</sup>,
- the **Device Data** <sup>f</sup>,
- the **ordered Licenses** <sup>g</sup>.
- Print the order data form, sign it and send it by Fax.




Figure 62: License Pane – Fax Number of the selected Subsidiary

- Use the Fax number <sup>10</sup>, which is displayed after the subsidiary was selected in the **License** pane.

Or:

- Keep ready the order data form and communicate the order data via telephone.



Figure 63: License Pane – Telephone Number of the selected Subsidiary

- Use the telephone number <sup>11</sup>, which is displayed after the subsidiary was selected in the **License** pane.
- The order process is complete.

### 6.9.7.3 Exporting License Request to a File

If you are working on a process computer without an e-mail client, you can export your order information to a file, save the file to a removable disk and place your order manually via e-mail from a different PC.



Figure 64: License Pane - Ordering by exported File and E-Mail

- Click **Export License Request...** 8.
- The window **Browse For Folder** is displayed.
- Choose for or create a new folder on a removable disk.
- Save the automatically generated **XML file** *EmailOrderRequest\_- [Devicenumbr]\_[Serialnumber].xml* with a summary info of the **order information** to this folder.
- Send this file from a PC with an e-mail client manually via e-mail.
- Therefore use an e-mail address , which is displayed after the subsidiary was selected in the **License** pane (see Position 9 Figure *License Pane* on page 91).
- The order process is complete.

## 6.9.8 How to get the License and transfer it to the Device



**Note:** License files can only be delivered via e-mail. The e-mail contains a link to download the license file.

According to the license you ordered, you will receive an e-mail containing a **Link to download the License File**. This leads to a server PC on which the license file is provided. Using the received link you will have to save the license file on your PC and then transfer the license to your device. If your e-mail client is on another PC as your device, you must save your license file e. g. to an USB stick.

### Steps how to proceed


1. Save the license file to a PC or a disk.
  - Click to the **Link to download the License File** in the e-mail.
  - Save the license file \*.nxl to a PC or a removable disk.
2. Download the license file to the device.
  - Respectively connect the removable disk with the license file to the PC, which is connected to your device.
  - Click **Download License**  in the **License** pane in the configuration software.



Figure 65: License Pane - Download License

- The File selection window **Open** is displayed.
  - Therein select the license file *netX License Files (\*.nxl)*.
  - Click **Open**.
  - The license file is transferred to the device.
  - After this the license is present in the device and is activated with the next device reset.
3. Activate Device Reset



**Hint:** To activate the license in the first device, a device reset is required.

- To check whether the license has been activated, follow the steps in section *Which Licenses are present in the Device?* on page 92.

## 7 Diagnosis

### 7.1 Overview Diagnosis

The dialog **Diagnosis** serves to diagnose the device behavior and communication errors. For diagnosis the device must reside in online state.

#### Diagnosis Panes

The table below gives an overview for the individual **Diagnosis** dialog panes descriptions:

AS-Interface Master DTM	Folder Name / Section	Manual Page
Navigation area	<i>General Diagnosis</i>	104
Diagnosis	<i>Master Diagnosis</i>	106
General Diagnosis	<i>Station Diagnosis</i>	107
Master Diagnosis	<i>Interface Diagnosis</i>	108
Station Diagnosis	<i>Firmware Diagnosis</i>	110
Interface Diagnosis		
Firmware Diagnosis		
Extended Diagnosis		
Navigation Area - Diagnosis		

Table 30: Descriptions of the Diagnosis Panes

#### Online Connection to the Device



**Note:** Accessing the **Diagnosis** panes of the AS-Interface Master DTM requires an online connection from the AS-Interface Master DTM to the AS-Interface Master device. For further information refer to section *Connecting/Disconnecting Device* on page 67.



**Important:** For a 2-channel device channel 1 or channel 2 each must be connected to the DTM separately.

#### How to proceed

1. In the Master DTM diagnosis dialog check whether the communication is OK:

**Diagnosis > General Diagnosis > Device status "Communication"** must be green!

2. **"Communication"** is green: Open the **IO Monitor** and test the input or output data..
3. **"Communication"** is not green: Use **Diagnosis** and **Extended diagnosis** for troubleshooting.

#### Extended Diagnosis

The **Extended Diagnosis** helps to find communication and configuration errors, when default diagnosis fails. For further information refer to section *Overview Extended Diagnosis* on page 111.

## 7.2 General Diagnosis

Information regarding the Device State and other general diagnosis parameters are displayed in the **General Diagnosis** dialog.

**General Diagnosis**

**Device state**

- ☐ Communication
- ☒ Run
- ☐ Ready
- ☐ Error

**Network state**

- ☒ Operate
- ☐ Idle
- ☐ Stop
- ☐ Offline

**Configuration state**













- ☐ Configuration locked
- ☐ New configuration pending
- ☐ Reset required
- ☒ Bus ON

Communication error:

Watchdog time:

Error count:

Figure 66: General Diagnosis

LED	Meaning	Color	State
Device State			
Communication	Shows whether the AS-Interface device executes the network communication.	 (green)	In COMMUNICATION state
		 (gray)	Not in COMMUNICATION state
Run	Shows whether the AS-Interface device has been configured correctly.	 (green)	Configuration OK
		 (gray)	Configuration not OK
Ready	Shows whether the AS-Interface device has been started correctly. The AS-Interface device waits for a configuration.	 (yellow)	Device READY
		 (gray)	Device not READY
Error	Shows whether the AS-Interface device records a device status error. For further information about the error characteristics and the number of counted errors refer to the extended diagnosis.	 (red)	ERROR
		 (gray)	No ERROR
Network State			
Operate	Shows whether the AS-Interface device is in data exchange. In a cyclic data exchange the input data or the output data of the AS-Interface Master are transmitted to the AS-Interface Slave.	 (green)	In OPERATION state
		 (gray)	Not in OPERATION state
Idle	Shows whether the AS-Interface device is in idle state.	 (yellow)	In IDLE state
		 (gray)	Not in IDLE state















LED	Meaning	Color	State
Stop	Shows whether the AS-Interface device is in Stop state: There is no cyclic data exchange at the AS-Interface network. The AS-Interface device was stopped by the application program or it changed to the Stop state because of a bus error.	 (red)	In STOP state
		 (gray)	Not in STOP state
Offline	The AS-Interface Master is offline as long as it does not have a valid configuration.	 (yellow)	In OFFLINE state
		 (gray)	Not in OFFLINE state
Configuration State			
Configuration locked	Shows whether the AS-Interface device configuration is locked, to avoid the configuration data are typed over.	 (yellow)	Configuration LOCKED
		 (gray)	Configuration not LOCKED
New Configuration pending	Shows whether a new AS-Interface device configuration is available.	 (yellow)	New Configuration pending
		 (gray)	No new Configuration pending
Reset required	Shows whether a firmware reset is required as a new AS-Interface device configuration has been loaded into the device.	 (yellow)	RESET required
		 (gray)	No RESET required
Bus ON	Shows whether the bus communication was started or stopped. I. e., whether the device is active on the bus or no bus communication to the device is possible and no response telegrams are sent.	 (green)	Bus ON
		 (gray)	Bus OFF

Table 31: Indication General Diagnosis

Parameter	Meaning
Communication Error	Shows the name of the communication error. If the cause of error is resolved, the value will be set to zero again.
Watchdog time	Shows the watchdog time in ms.
Error Count	This field holds the total number of errors detected since power-up, respectively after reset. The protocol stack counts all sorts of errors in this field no matter whether they were network related or caused internally.

Table 32: Parameter General Diagnosis

## 7.3 Master Diagnosis

Information regarding the Slave State, slave errors and slaves configured, active or in diagnostic are displayed in the **Master Diagnosis** dialog.

Master Diagnosis	
Slave state	failed
Slave error log indicator	available
Configured slaves	2
Active slaves	0
Slaves with diagnostic	2

Figure 67: Master Diagnosis

Parameter	Meaning	Range of Value / Default Value
Slave state	Shows whether slave state is ok or not. The Slave state field for Master diagnosis shows whether the Master is in cyclic data exchange to all configured slaves. In case there is at least one slave missing or if the slave has a diagnostic request pending, the status will be set to FAILED. For protocols that support non-cyclic communication only, the slave state is set to OK as soon as a valid configuration is found.	UNDEFINED, OK, FAILED
Slave error log indicator	Shows whether the Slave Error Log Indicator is available. The error log indicator field holds the number of entries in the internal error log. If all entries are read from the log, the field will be set to zero.	EMPTY, AVAILABLE
Configured slaves	Shows number of configured slaves. Number of configured slaves in the network according to the slave list derived from the configuration database created by the configuration software. The list includes the slaves to which the Master has to open a connection.	
Active slaves	Shows number of active slaves. Number of slaves in data exchange mode. The list includes the slaves to which the Master has successfully opened a connection.	
Slaves with diagnostic	Shows number of slaves with diagnostic. Number of Slaves with diagnosis or error slaves.	

Table 33: Parameter Master Diagnosis

## 7.4 Station Diagnosis

### Station Status




Figure 68: Station Diagnosis - Station Status

Under **Station Status** all disposal station addresses\* and their states are shown as LED (\*1- 31, for extended addressing mode 1A to 31A and 1B to 31B, address 0 for configuring of newly detected Slaves). If a connection to the device exists, the DTM updates this display cyclically.

Below the LED a legend is represented, which describes possible states of the station addresses.

Color of the Station Status LED	Meaning
grey	This Station Address is not configured
green	This Station Address is running
yellow	Diagnosis is available for this Station Address
blue	This Station Address was parameterized, but not found
red	This Station Address is faulty

Table 34: Station Diagnosis - Station Status

#### **Reset Station Status for Status Diagnosis (yellow):**

To check, if the station status Diagnosis (yellow) persists, the **Station status** can be reset for every device separately. Therefore:

1. Select in the list field **Stations Status** the station address of the device.
2. Select **Reset**.

## 7.5 Interface Diagnosis

### 7.5.1 Interface flags

The interface flags signal the state of the AS-Interface Master device for the related channel to the user application and allows the application to control the AS-Interface Master device.



















Figure 69: Interface Diagnosis > Interface flags

Indication	Meaning
<b>Configuration OK</b>	
 <u>Configuration OK</u>	The ASI configuration is correct, the set point and the actual configuration are consistent.
 <u>Configuration is faulty</u>	The ASI configuration is faulty.
<b>Slave with address 0 detected</b>	
 <u>No Slave with address 0 detected</u>	No Slave addressed with 0 has been detected.
 <u>Slave with address 0 detected</u>	A Slave addressed with 0 has been detected.
<b>Automatic address assignment</b>	
 <u>No Automatic address assignment</u>	Automatic address assignment of the station address is not possible.
 <u>Automatic address assignment</u>	Automatic address assignment of the station address is possible.
<b>Automatic address available</b>	
 <u>Automatic address not available</u>	No automatic station address available.
 <u>Automatic address available</u>	The station address is automatically assigned, as soon as a Slave addressed with 0 and with a valid configuration has been detected. For example, a failed Slave is replaced by a device addressed with 0, and thereby the addressing is completed.
<b>Configuration mode active</b>	
 <u>Protected Mode, no Configuration</u>	The Master device is in protected mode.
 <u>Configuration mode active</u>	The Master device is in configuration mode. Any detected Slaves are involved in the data exchange.
<b>Normal operation active</b>	
 <u>Normal operation active</u>	The Master device is in cyclic normal operation mode.
 <u>Initialization or Starting Operation</u>	The Master device passes the initialization or the starting operation phase.
<b>Asia power fail</b>	
 <u>Asia Power Supply is OK</u>	The power supply of the ASI Master device is OK.
 <u>Asia Power Fail</u>	During data transmission the power supply of the ASI Master device is low or completely down.
<b>Offline ready</b>	
 <u>No Offline mode</u>	No offline mode.




Indication	Meaning
 <u>Offline ready</u>	The Master device is in offline mode and there is no data exchange.
<b>Periphery OK</b>	
 <u>Periphery OK</u>	Group reporting, none of the Slaves reports a peripheral fault.
 <u>Periphery faulty</u>	At least one Slave signals a peripheral fault.

Table 35: Interface Diagnosis &gt; Interface flags

## 7.5.2 Periphery errors

The diagnosis **Periphery Errors** displays the current periphery errors of any Slave devices configured at the AS-Interface Master.




Figure 70: Interface Diagnosis &gt; Periphery Errors

Under **Interface Diagnosis > Periphery Errors** all disposal station addresses\* for Slave devices and their diagnosis states for periphery errors are shown as LED.

The number indicates the AS-Interface station address of the Slave device (\*1- 31, for extended addressing mode 1A to 31A and 1B to 31B, address 0 for configuring of newly detected Slaves).

Configured Slave devices with periphery errors are represented as a **red** LED. Slave devices not configured or without periphery errors are represented as a **grey** LED. This display is cyclically updated.

Color of the LED	Meaning
<b>red</b>	Configured Slave devices with periphery errors
<b>grey</b>	Slave devices not configured or without periphery errors

Table 36: Legend Interface Diagnosis &gt; Periphery Errors

## 7.6 Firmware Diagnosis

In the dialog **Firmware Diagnosis** the current task information of the firmware is displayed.

Under **Firmware** or **Version** the name of the firmware and version (including the date) are indicated.

Firmware Diagnosis					
Firmware:	AS-Interface Master				
Version:	2.3.0 (Build 2)				
Date:	7.26.2012				
Task information:					
Task	Name of task	Version	Prio...	Description	State
0	RX_IDLE	1.0	63	RX IDLE Task.	Task Status ok. (0x00000000)
1	RX_TIMER	1.0	1	rcX Timer.	Task Status ok. (0x00000000)
2	RX_SYSTEM	1.16	32	Middleware Syste...	Task Status ok. (0x00000000)
3	DPM_COM0...	1.0	50	TLR-Router DPM.	Task Status ok. (0x00000000)
4	DPM_COM0...	1.0	51	TLR-Router DPM.	Task Status ok. (0x00000000)
5	TLR_TIMER	0.0	31	The task identifier ...	Task Status ok. (0x00000000)
6	ASI_MASTER	2.1	27	AS-Interface Mast...	Task Status ok. (0x00000000)
7	ASI_APM	2.1	29	AS-Interface Mast...	Task Status ok. (0x00000000)
8	MARSHALLER	2.0	56	Marshaller: Main T...	Task Status ok. (0x00000000)
9	PACKET_RO...	2.0	57	Marshaller: Packet...	Task Status ok. (0x00000000)

Figure 71: Firmware Diagnosis (Example)

### Task Information:

The table **Task Information** is listing the task information of the single firmware tasks.

Column	Meaning
Task	Task number
Name of task	Name of the task
Version	Version of the task
Prio	Priority of the task
Description	Description of the task
Status	Status of the task

Table 37: Description Table Task Information

## 8 Extended Diagnosis

### 8.1 Overview Extended Diagnosis

The **Extended Diagnosis** of the AS-Interface Master DTM helps to find communication and configuration errors. Therefore it contains a list of diagnosis structures as online counter, states and parameters.

#### Dialog Panes “Extended Diagnosis”

The table below gives an overview for the **Extended Diagnosis** dialog panes descriptions:


AS-Interface Master DTM	Folder Name / Section	Subsection	Manual Page
	RX-SYSTEM	Task Information	112
		IniBatch Status	113
	DPM_COM0_SMBX□	Task Information	112
	DPM_COM0_RMBX	Task Information	112
	ASI_Master	Task Information	112
		Commands	114
		Interrupts	115
		xC managment area	116
		xC Slave config area	117
		xC configuration area	117
	ASI_APM	Task Information	112
		Master configuration	118
		Commands	119
		DPM data exchange	120
		IO Status	121
	MARSHALLER	Task Information	112
	PACKET_ROUTER	Task Information	112

Table 38: Descriptions of the Dialog Panes Extended Diagnosis

#### Online Connection to the Device



**Note:** Accessing the **Extended Diagnosis** dialog panes of the AS-Interface Master DTM requires an online connection from the AS-Interface Master DTM to the AS-Interface Master device. For further information refer to section *Connecting/Disconnecting Device* on page 67.

## 8.2 Task Information

Task Information	
Task states	
Name	Value
Identifier	
Major version	<i>[The displayed values depend from the corresponding task]</i>
Minor version	
Maximum Packet size	
Default Que	
Unique identifier	
Init result	

Figure 72: Extended Diagnosis > [Folder Name] > Task Information Example Display

Name	Description
Identifier	Identification number of the task
Major version	Task version, contains incompatible changes
Minor version	Task version, contains compatible changes
Maximum packet size	Maximum packet size, which the task sends
Default Queue	Queue handle, which is accessible via DPM by mailbox.
UUID	Unique user ID, 16 Byte indicator used for task identification and its affiliation e. g. to a stack (therein different identification data are coded in).
Init result	Error Code, 0= no Error  The description of the error codes can be found in this manual or in the corresponding software reference manuals.

Table 39: Extended Diagnosis > [Folder Name] > Task Information



## 8.3 IniBatch Status

IniBatch-Status	
Task states	
Name	Value
Communication Channel	0
Current State	Error
IniBatch Result	No DBM file
OpenDbm Result	24975
SendPacket Result	0
Confirmation Result	0
Last Packet Number	0
Last Packet Command	0
Last Packet Length	0
Last Packet Destination	0

Figure 73: Extended Diagnosis > [Folder Name] > IniBatch Status Example Display

Name	Description
Communication Channel	Number of the communication channel used by the device.
Current State	Idle; IniBatch packets in progress; Retrying to send last packet; Error
IniBatch Result	Ok; No DBM file; No Packet table; No data set available; Data set is shorter than packet length; Packet Buffer is shorter than Packet length; Invalid packet destination; Logical queue not defined Send packet failed; Too many retries; Error in confirmation packet status
OpenDbm Result	Error when opening the IniBatch data base Under "OpenDbm Result" the error code is typed in, when "IniBatch Result" == "No DBM file" (1) is.
SendPacket Result	Error when sending a packet Under "SendPacket Result" the error code is typed in, when "IniBatch Result" == "send packet failed" (8) is.
Confirmation Result	Confirmation error when sending packets Under "Confirmation Result" the packet specific error code from the ulSta is typed in, when "IniBatch Result" == "Error in confirmation packet status" (10) is.
Last Packet Number	Value depends by the communication system.
Last Packet Command	Value depends by the communication system.
Last Packet Length	Value depends by the communication system.
Last Packet Destination	Value depends by the communication system.

Table 40: Extended Diagnosis > [Folder Name] > IniBatch Status

The task status "Confirmation Result" is bus specific. The other task statuses are rcx-related error codes.

## 8.4 ASI\_Master

### 8.4.1 Commands

Commands	
Task states	
Name	Value
Application register req.	1
Application register cnf.	1
Initialize req.	0
Initialize cnf.	1
Get buffer req.	1
Get buffer cnf.	1
Set slaveparam req.	2
Set slaveparam cnf.	2
Set busparam req.	1
Set busparam cnf.	1
Get slaveparam req.	0
Get slaveparam cnf.	0

Figure 74: Extended Diagnosis > ASI\_MASTER > Commands

Name	Description
[Service]	Diagnosis counter of the encapsulation layer. Indicates the services processed. (The services of the single packets are described in the API manual.)
Get packet failed	Number of errors during requesting a packet
Send packet failed	Number of errors during sending a packet

Table 41: Extended Diagnosis > ASI\_MASTER > Commands

## 8.4.2 Interrupts

Interrupt	
Task states	
Name	Value
Common	18383236
Enter offline phase	0
Offline ready	1
Leave offline	1
CDI updated	1874924
Enter normal operation	1
Cycle ended	18237868
Management response	0
Startup loop	1
Data exchange done	0
Transparent response	0

Figure 75: Extended Diagnosis > ASI\_MASTER > Interrupts

Name	Description
[Service]	Diagnosis counter of the encapsulation layer. Indicates the services processed. (The services of the single packets are described in the API manual.)

Table 42: Extended Diagnosis > ASI\_MASTER > Interrupts

### 8.4.3 xC managment area

xC management area	
Task states	
Name	Value
ASIM_LDS_A	0x00100000
ASIM_LAS_A	0x00000000
ASIM_LPF_A	0x00000000
ASIM_LPS_A	0x00000006
ASIM_LDS_B	0x00000000
ASIM_LAS_B	0x00000000
ASIM_LPF_B	0x00000000
ASIM_LPS_B	0x00000000
ASIM_ARM_STATUS_FLAGS	0x0000040C
ASIM_XPEC_STATUS_FLAGS	0x00000006
ASIM_MANAGEMENT_CMD	0x00000000

Figure 76: Extended Diagnosis > ASI\_MASTER > xC managment area

ID	Value	Description
ASIM_LDS_A	0x00000000	List of detected standard (A) slaves
ASIM_LAS_A	0x00000000	List of activated standard (A) slaves
ASIM_LPF_A	0x00000000	List of standard slaves (A) with periphery fault
ASIM_LPS_A	0x00000000	List of projected standard (A) slaves
ASIM_LDS_B	0x00000000	List of detected extended B slaves
ASIM_LAS_B	0x00000000	List of activated extended B slaves
ASIM_LPF_B	0x00000000	List of extended B slaves with periphery fault
ASIM_LPS_B	0x00000000	List of projected extended B slaves
ASIM_ARM_STATUS_FLAGS	0x00000000	nternal status flags (debug only)
ASIM_XPEC_STATUS_FLAGS	0x00000000	Internal status flags (debug only)
ASIM_MANAGEMENT_CMD	0x00000000	Debug only

Table 43: Extended Diagnosis > ASI\_MASTER > xC managment area

## 8.4.4 xC Slave config area

xC slave config area	
Task states	
Name	Value
ASIM_PERMANENT_SLAVE_CONFIG_0	0x00FFFFFF
ASIM_SLAVE_CONFIG_0	0x0000FFFF
ASIM_PERMANENT_SLAVE_CONFIG_1	0x00FFFF11
ASIM_SLAVE_CONFIG_1	0x0000FFFF
ASIM_PERMANENT_SLAVE_CONFIG_2	0x00FFFF02
ASIM_SLAVE_CONFIG_2	0x0000FFFF
ASIM_PERMANENT_SLAVE_CONFIG_3	0x00FFFFFF
ASIM_SLAVE_CONFIG_3	0x0000FFFF
ASIM_PERMANENT_SLAVE_CONFIG_4	0x00FFFFFF

Figure 77: Extended Diagnosis > ASI\_MASTER > xC Slave config area

ID	Value	Description
ASIM_PERMANENT_SLAVE_CONFIG_0	0x00000000	Stored Slave configuration for debug usage
ASIM_SLAVE_CONFIG_0	0x00000000	Actual Slave configuration for debug usage
to	0x00000000	...
ASIM_PERMANENT_SLAVE_CONFIG_62	0x00000000	...
ASIM_SLAVE_CONFIG_62	0x00000000	...

Table 44: Extended Diagnosis > ASI\_MASTER > xC Slave config area

## 8.4.5 xC configuration area

xC configuration area	
Task states	
Name	Value
ASIM_XPEC2ARM_INTERRUPTS_EN	0x000001F7
ASIM_MIN_CYCLE_LENGTH	0x00000000
ASIM_WATCHDOG_TIMEOUT	0x00000000

Figure 78: Extended Diagnosis > ASI\_MASTER > xC configuration area

ID	Value	Description
ASIM_XPEC2ARM_INTERRUPTS_EN	0x00000000	Debug information of activated interrupts
ASIM_MIN_CYCLE_LENGTH	0x00000000	Minimum cycle time for one ASI cycle
ASIM_WATCHDOG_TIMEOUT	0x00000000	xC watchdog timeout

Table 45: Extended Diagnosis > ASI\_MASTER > xC configuration area

## 8.5 ASI\_APM

### 8.5.1 Master configuration

Master configuration	
Task states	
Name	Value
Flags	1
Valid database found	yes
Invalid database found	no
Configured by user	no
Store configuration	no
Initialization state	Complete
Initialization result	0x00000000

Figure 79: Extended Diagnosis > ASI\_APM > Master Configuration

Name	Description
Flags	1= Valid database found 2= Invalid database found 4= Configured by user 8= Store config Several flags can be active in parallel. Example: 12 = 4 (Configured by user) + 8 (Store config)
Valid database found	yes = A valid database has been found. no = No valid database has been found.
Valid database found	yes = No valid database has been found. no = A valid database has been found.
Configured by the user	Database has been configured by the user.
Store configuration	yes = The configuration has been stored. no = The configuration has not been stored.
Initialization state	Idle; Send initialize request; Wait for initialize confirmation; Send register request; Wait for register confirmation; Send get buffer request; Wait for get buffer confirmation; Send bus parameter request; Wait for bus parameter confirmation; Complete; Failed
Initialization result	Initialization error code, 0 = no error

Table 46: Extended Diagnosis > ASI\_APM > Master Configuration

## 8.5.2 Commands

Commands	
Task states	
Name	Value
Register req.	1
Register cnf.	1
Init req.	1
Init cnf. cnf.	1
Get buffer req.	1
Get buffer cnf.	1
Slaveparam req.	0
Slaveparam cnf.	0
Busparam req.	1
Busparam cnf.	1
Offline mode req.	2
Offline mode cnf.	2
Get excution control flags req.	0
Get excution control flags cnf.	0
Read actual config req.	0
Read actual config cnf.	0
Read parameter image req.	0
Read parameter image cnf.	0
Store actual config req.	0
Store actual config cnf.	0
Store actual parameter req.	0
Store actual parameter cnf.	0
Set LPS req.	0
Set LPS cnf.	0
Get LAS req.	0
Get LAS cnf.	0
Get state req.	0
Get state cnf.	0
Transparent command req.	0
Transparent command cnf.	0
State change ind.	10
State change res.	10
Config pck. routed	0
Command pck. routed	8
Unknown req./cnf.	0
Cyclic ind.	680005
Get packet failed	0
Send packet failed	0

Figure 80: Extended Diagnosis > ASI\_APM > Commands

Name	Description
[Service]	Diagnosis counter of the encapsulation layer. Indicates the services processed. (The services of the single packets are described in the API manual.)
Get packet failed	Number of errors during requesting a packet
Send packet failed	Number of errors during sending a packet

Table 47: Extended Diagnosis > ASI\_APM > Commands

### 8.5.3 DPM data exchange

DPM data exchange	
Task states	
Name	Value
Input block size	5760
Input block mode	4
Output block size	5760
Output block mode	4
Input data count	0
Output data count	0
Input data update count	0
Output data update count	0
Transfer mode	DPM
IRQ input DMA finished count	0
IRQ output DMA finished count	0

Figure 81: Extended Diagnosis > ASI\_APM > DPM data exchange

Name	Description
Input block size	Size of the Input Data Image (cyclic data from the network) The default size of the input data image is 5760 byte.
Input block mode	Handshake mode of the input data block supported by the protocol stack, to synchronize process data exchange with the host application. 0x00 For compatibility reasons, This value is identical to 0x04 - Buffered Host Controlled IO Data Transfer 0x02 Buffered Device Controlled IO Data Transfer 0x03 Uncontrolled Mode 0x04 Buffered Host Controlled IO Data Transfer
Output block size	Size of the Output Data Image (cyclic data to the network) The default size of the output data image is 5760 byte.
Output block mode	Handshake mode of the output data blocks, see Input block mode
Input data count	Current Number of input data in bytes
Output data count	Current Number of output data in bytes
Input data update count	The total data count of input data in bytes (Counter for updating the input data)
Output data update count	The total data count of input data in bytes (Counter for updating the output data)
Transfer mode	DPM (Dual-Port Memory), DMA (Direct Memory Access)
IRQ input DMA finished count	The data count of IRQ input data in bytes when DMA is finished.
IRQ output DMA finished count	The data count of IRQ output data in bytes when DMA is finished.

Table 48: Extended Diagnosis > ASI\_APM > DPM data exchange



## 8.5.4 IO Status

IO Status	
Task-Status	
Name	Wert
IO Status Block	Aktiviert
Offset projektierte Slaves	0
Offset aktive Slaves	8
Offset Slaves mit Diagnose	16

Figure 82: Extended Diagnosis > ASI\_APM > IO Status

Name	Description
IO Status field	Indicates whether the Slave is enabled or disabled. Values: Enabled, Disabled
Offset projected slaves	Offset of the projected Slaves in Byte
Offset activated slaves	Offset of the activated Slaves in Byte
Offset slaves with diagnostic information	Offset of the Slaves with diagnostic information in Byte

Table 49: Extended Diagnosis > ASI\_APM > IO Status

## 9 Tools

### 9.1 Overview Tools

Under **Tools** the Packet Monitor and the IO Monitor are provided for test and diagnosis purposes.

#### Tools Panes

The table below gives an overview for the individual **Tools** dialog panes descriptions:


AS-Interface Master DTM	Folder Name / Section	Manual Page
 <p>Navigation Area - Tools</p>	Packet Monitor	123
	IO Monitor	126
	Process Image Monitor	127

Table 50: Descriptions of the Diagnosis Panes

#### Online Connection to the Device



**Note:** Accessing the **Tools** dialog panes of the AS-Interface Master DTM requires an online connection from the AS-Interface Master DTM to the AS-Interface Master device. For further information refer to section *Connecting/Disconnecting Device* on page 67.

## 9.2 Packet Monitor

The **Packet Monitor** serves for test and diagnosis purposes.

Data packets, i. e. messages are self-contained blocks of defined data length. The packets are used to communicate with the firmware and they are exchanged between the application (configuration software) and the firmware in the device. Packets can be sent once or cyclically to the connected device controlled by the user and packets received can be displayed.

Data packets comprise from a **Packet Header** and the **Send Data** or from a **Packet Header** and the **Receive Data**. The packet header can be evaluated by the receiver of the packet and contain the sender and receiver address, the data length, an ID number, status and error messages and the command or response code. The minimum packet size amounts 40 Byte for the packet header. The sending and receiving data are added.



For further information to the packet description refer to the *Protocol API Manual*.

- Open the **Packet Monitor** via **Tools > Packet Monitor**.

Figure 83: Packet Monitor

**Display Mode** switches the representation of the send and reception data between decimal and hexadecimal.

- Select **Reset Counter** to reset the packet counter.

## 9.2.1 Sending Packet

The screenshot shows the 'Send' dialog box with two main sections: 'Packet header' and 'Send data'.

**Packet header:**

- Dest: 00000001 (dropdown)
- Src: 00000000
- State: 00000000
- Dest ID: 00000000
- Cmd: 00002F00
- Src ID: 00000000
- Ext: 00000000
- Len: 00000012
- Rout: 00000000
- ID: 00000001
- Auto Increment ID: ☒

**Send data:**

Counter: 0

	0	1	2	3	4	5	6	7	8	9
0										
10										
20										
30										
40										
50										
60										

Buttons: Put cyclic, Put packet

Figure 84: Send > Packet Header and Send Data

### Packet Header

Under **Send > Packet Header** the elements of the packet header of the sending packet are displayed, which is transmitted from the application (configuration software) to the device. The packet header of the sending packets contain the elements described in the following table.

Element		Description
<b>Dest</b>	Destination Queue Handle	Contains the identifier of the receiver for the packet (destination task queue of the firmware).
<b>Src</b>	Source Queue Handle	Contains the identifier of the sender of the packet (sending task).
<b>Dest ID</b>	Destination Queue Reference	Contains an identifier for the receiver of unsolicited sent packets from the firmware to the application (configuration software).
<b>Src ID</b>	Source Queue Reference	Contains an identifier of the sender.
<b>Len</b>	Packet Data Length (in Bytes)	Length of the send respectively receive data.
<b>ID</b>	Packet Identification As Unique Number	Identifies identical data packets among each other.
<b>State</b>	Status / Error Code	Transmits status or error codes to the packet sender.
<b>Cmd</b>	Command / Response Code	Command or respond code.
<b>Ext</b>	Extension	Field for extensions (reserved).
<b>Rout</b>	Routing Information	Internal value of the firmware.

Table 51: Descriptions Packet Header

- Under **Dest** select the receiver (*destination task queue*).
- Under **Cmd** select the command identification (*Request*).

**Auto Increment ID** is an increment for the identifier of the data packets and increments the ID by 1 for each newly sent packet.

### Send Data

- Under **Send > Send data** enter the send data of the packet, which shall be transmitted from the application (configuration software) to the mailbox of the device. The meaning of the transmitted data depends on the command or response code.

### Sending Packets once or cyclic

- To send packet once, select **Put packet**.
- To send packet cyclic, select **Put cyclic**.

## 9.2.2 Receiving Packet

The screenshot shows a software interface for receiving packets. On the left, under the 'Receive' tab, is the 'Packet header' section with the following fields:

- Dest: 00000001
- Src: 00000000
- Dest ID: 00000000
- Src ID: 00000000
- Len: 00000012
- ID: 0000003E
- State: 00000000
- Cmd: 00002F01
- Ext: 00000000
- Rout: 00000000

On the right, under the 'Receive data' section, there is a 'Counter: 0' and a table of data bytes. The table has columns for indices 0 through 9 and a 'Counter' column. The data is as follows:

	0	1	2	3	4	5	6	7	8	9	Counter
0	00	00	00	00	00	00	00	00	00	04	
10	00	00	01	00	01	00	00	00			
20											
30											
40											
50											
60											

Figure 85: Packet Header and Receive Data

### Packet Header

Under **Receive > Packet Header** the elements of the packet header of the receiving packet are displayed, which are transmitted back from the device to the application (configuration software). The packet header of the receiving packets contain the elements described in the following table.

Element		Description
<b>Dest</b>	Destination Queue Handle	Contains the identifier of the receiver for the packet (destination task queue of the firmware).
<b>Src</b>	Source Queue Handle	Contains the identifier of the sender of the packet (sending task).
<b>Dest ID</b>	Destination Queue Reference	Contains an identifier for the receiver of unsolicited sent packets from the firmware to the application (configuration software).
<b>Src ID</b>	Source Queue Reference	Contains an identifier of the sender.
<b>Len</b>	Packet Data Length (in Bytes)	Length of the send respectively receive data.
<b>ID</b>	Packet Identification As Unique Number	Identifies identical data packets among each other.
<b>State</b>	Status / Error Code	Transmits status or error codes to the packet sender.
<b>Cmd</b>	Command / Response Code	Command or respond code.
<b>Ext</b>	Extension	Field for extensions (reserved).
<b>Rout</b>	Routing Information	Internal value of the firmware.

Table 52: Descriptions Packet Header

### Receive Data

Under **Receive > Receive Data** the receiving data of the packet, which is transmitted back from the device to the application (configuration software) are displayed.

## 9.3 IO Monitor

The **IO Monitor** serves for test and diagnosis purposes. It provides to view data of the process data image and to change output data easily. The display is always in a Byte manner.



**Note:** Only change and write output data if you know that no plant disturbances are caused by this. All output data written by the IO Monitor are transmitted at the bus and have effect on subordinate drives, IO etc.

**IO Monitor**

Columns: 10 Display mode: Decimal

Input data

Offset: 0 Go

	0	1	2	3	4	5	6	7	8	9
0	227	207	0	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0	0
50	0	0	0	0	0	0	0	0	0	0
60	n	n	n	n	n	n	n	n	n	n

Output data

Offset: 0 Go

	0	1	2	3	4	5	6	7	8	9
0	0	0	0	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0	0	0
20	0	0	0	0	0	0	0	0	0	0
30	0	0	0	0	0	0	0	0	0	0
40	0	0	0	0	0	0	0	0	0	0
50	0	0	0	0	0	0	0	0	0	0
60	n	n	n	n	n	n	n	n	n	n

Update

Figure 86: IO Monitor

**Columns** switches the number of columns.

**Display mode** switches the representation of the input and output data between decimal and hexadecimal.

**Offset / Go** moves the indication of the data to the entered offset value.

➤ Enter the output value and select **Update**.

➤ Always the data of the process image are displayed, also when these Bytes have not been reserved by the configuration.

## 9.4 Process Image Monitor

The window **Process Image Monitor** lists the Slave devices connected to the Master, as well as the configured modules or input or output signals of the devices. This makes visible the fieldbus structure and the data structure of the device's input and output data transmitted at the bus. Furthermore the values of the signal data provided to the OPC server are displayed here.

➤ Open **Tools > Process Image Monitor**.




Figure 87: Window 'Process Image Monitor'

Parameter	Meaning	Range of Value / Value
<b>Display Mode</b>	Display of the values in the column <b>Value</b> in decimal or hexadecimal mode.	Decimal (Default), Hexadecimal
	The tree shows the structure of the devices (1), modules (2) and the input data (3) and output data (4).	
	Display when the input and output data are not completely read and analyzed.	
	Display when the input and output data are not valid.	
	Display when the input and output data are valid.	
<b>Typ</b>	Device labeling provided by the hardware: Also description of the modules or input or output signals configured to the device.	

Parameter	Meaning	Range of Value / Value
<b>TAG</b>	Device name provided by the hardware (not changeable in the FDT container) or symbolic name for the modules configured to the device or for the input or output signals (changeable in the window <b>Configuration &gt; Process Data</b> ).	
<b>Value</b>	Display of the valid input and output data values.	
<b>Last Error</b>	Last occurred error (Description see appropriate Application Programming Manual)	

*Table 53: Notes to the Window 'Process Image Monitor'*



## 10 Error Codes

### 10.1 Error Code Definition

For COM based application, like the ODM Server and ODM drivers, a common error definition is used, similar to the Microsoft Windows® HRESULT definition.

Error Code Structure:

COM Errors are HRESULTs, which are 32 bit values using the following layout:

```

3 3 2 2 2 2 2 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1
1 0 9 8 7 6 5 4 3 2 1 0 9 8 7 6 5 4 3 2 1 0
+---+---+---+---+---+---+---+---+---+---+
|Sev|C|R|      Facility      |      Code      |
+---+---+---+---+---+---+---+---+---+---+

```

where

*Sev* - is the severity code:

00 - Success

01 - Informational

10 - Warning

11 - Error

*C* - is the Customer code flag

*R* - is a reserved bit

*Facility* - is the facility code

*Code* - is the facility's status code

In this common error definition, several error code regions are already reserved by Windows® itself, the ODM and some other modules.

## 10.2 Overview Error Codes

Overview Error Codes	Range
General Hardware Errors RCX Operating System	<i>RCX General Task:</i> 0xC02B0001 to 0xC02B4D52
	<i>RCX Common Status &amp; Errors Codes:</i> 0x00000000 to 0xC002000C
	<i>RCX Status &amp; Error Codes:</i> 0x00000000 to 0xC0000008
ODM Server	<i>General ODM Error Codes:</i> 0x8004C700 to 0x8004C761
	<i>General ODM Driver Error Codes:</i> 0x8004C7A0 to 0x8004C7C2
ODM Drivers	<i>cifX Driver Specific ODM Error:</i> 0x8004C001 to 0x8004C0A4
cifX Device Driver and netX Driver	<i>Generic Error:</i> 0x800A0001 bis 0x800A0017
	<i>Generic Driver Error:</i> 0x800B0001 bis 0x800B0042
	<i>Generic Device Error:</i> 0x800C0010 bis 0x800C0041
netX Driver	<i>CIFX API Transport:</i> 0x800D0001 bis 0x800D0013
	<i>CIFX API Transport Header State Error:</i> 0x800E0001 bis 0x800E000B
DBM	<i>ODM Error Codes:</i> 0xC004C810 to 0xC004C878

Table 54: Overview Error Codes and Ranges



The fieldbus specific error codes are described in the manuals of the corresponding protocol tasks.

## 10.3 General Hardware Error Codes

### 10.3.1 RCX General Task Errors

Error Code (Definition)	Value	Description
RCX_E_QUE_UNKNOWN	0xC02B0001	Unknown Queue
RCX_E_QUE_INDEX_UNKNOWN	0xC02B0002	Unknown Queue Index
RCX_E_TASK_UNKNOWN	0xC02B0003	Unknown Task
RCX_E_TASK_INDEX_UNKNOWN	0xC02B0004	Unknown Task Index
RCX_E_TASK_HANDLE_INVALID	0xC02B0005	Invalid Task Handle
RCX_E_TASK_INFO_IDX_UNKNOWN	0xC02B0006	Unknown Index
RCX_E_FILE_XFR_TYPE_INVALID	0xC02B0007	Invalid Transfer Type
RCX_E_FILE_REQUEST_INCORRECT	0xC02B0008	Invalid File Request
RCX_E_TASK_INVALID	0xC02B000E	Invalid Task
RCX_E_SEC_FAILED	0xC02B001D	Security EEPROM Access Failed
RCX_E_EEPROM_DISABLED	0xC02B001E	EEPROM Disabled
RCX_E_INVALID_EXT	0xC02B001F	Invalid Extension
RCX_E_SIZE_OUT_OF_RANGE	0xC02B0020	Block Size Out Of Range
RCX_E_INVALID_CHANNEL	0xC02B0021	Invalid Channel
RCX_E_INVALID_FILE_LEN	0xC02B0022	Invalid File Length
RCX_E_INVALID_CHAR_FOUND	0xC02B0023	Invalid Character Found
RCX_E_PACKET_OUT_OF_SEQ	0xC02B0024	Packet Out Of Sequence
RCX_E_SEC_NOT_ALLOWED	0xC02B0025	Not Allowed In Current State
RCX_E_SEC_INVALID_ZONE	0xC02B0026	Security EEPROM Invalid Zone
RCX_E_SEC_EEPROM_NOT_AVAIL	0xC02B0028	Security EEPROM Eeprom Not Available
RCX_E_SEC_INVALID_CHECKSUM	0xC02B0029	Security EEPROM Invalid Checksum
RCX_E_SEC_ZONE_NOT_WRITEABLE	0xC02B002A	Security EEPROM Zone Not Writeable
RCX_E_SEC_READ_FAILED	0xC02B002B	Security EEPROM Read Failed
RCX_E_SEC_WRITE_FAILED	0xC02B002C	Security EEPROM Write Failed
RCX_E_SEC_ACCESS_DENIED	0xC02B002D	Security EEPROM Access Denied
RCX_E_SEC_EEPROM_EMULATED	0xC02B002E	Security EEPROM Emulated
RCX_E_INVALID_BLOCK	0xC02B0038	Invalid Block
RCX_E_INVALID_STRUCT_NUMBER	0xC02B0039	Invalid Structure Number
RCX_E_INVALID_CHECKSUM	0xC02B4352	Invalid Checksum
RCX_E_CONFIG_LOCKED	0xC02B4B54	Configuration Locked
RCX_E_SEC_ZONE_NOT_READABLE	0xC02B4D52	Security EEPROM Zone Not Readable

Table 55: RCX General Task Errors

### 10.3.2 RCX Common Status & Errors Codes

Error Code (Definition)	Value	Description
RCX_S_OK	0x00000000	Success, Status Okay
RCX_E_FAIL	0xC0000001	Fail
RCX_E_UNEXPECTED	0xC0000002	Unexpected
RCX_E_OUTOFMEMORY	0xC0000003	Out Of Memory
RCX_E_UNKNOWN_COMMAND	0xC0000004	Unknown Command
RCX_E_UNKNOWN_DESTINATION	0xC0000005	Unknown Destination
RCX_E_UNKNOWN_DESTINATION_ID	0xC0000006	Unknown Destination ID
RCX_E_INVALID_PACKET_LEN	0xC0000007	Invalid Packet Length
RCX_E_INVALID_EXTENSION	0xC0000008	Invalid Extension
RCX_E_INVALID_PARAMETER	0xC0000009	Invalid Parameter
RCX_E_WATCHDOG_TIMEOUT	0xC000000C	Watchdog Timeout
RCX_E_INVALID_LIST_TYPE	0xC000000D	Invalid List Type
RCX_E_UNKNOWN_HANDLE	0xC000000E	Unknown Handle
RCX_E_PACKET_OUT_OF_SEQ	0xC000000F	Out Of Sequence
RCX_E_PACKET_OUT_OF_MEMORY	0xC0000010	Out Of Memory
RCX_E_QUE_PACKETDONE	0xC0000011	Queue Packet Done
RCX_E_QUE_SENDPACKET	0xC0000012	Queue Send Packet
RCX_E_POOL_PACKET_GET	0xC0000013	Pool Packet Get
RCX_E_POOL_GET_LOAD	0xC0000015	Pool Get Load
RCX_E_REQUEST_RUNNING	0xC000001A	Request Already Running
RCX_E_INIT_FAULT	0xC0000100	Initialization Fault
RCX_E_DATABASE_ACCESS_FAILED	0xC0000101	Database Access Failed
RCX_E_NOT_CONFIGURED	0xC0000119	Not Configured
RCX_E_CONFIGURATION_FAULT	0xC0000120	Configuration Fault
RCX_E_INCONSISTENT_DATA_SET	0xC0000121	Inconsistent Data Set
RCX_E_DATA_SET_MISMATCH	0xC0000122	Data Set Mismatch
RCX_E_INSUFFICIENT_LICENSE	0xC0000123	Insufficient License
RCX_E_PARAMETER_ERROR	0xC0000124	Parameter Error
RCX_E_INVALID_NETWORK_ADDRESS	0xC0000125	Invalid Network Address
RCX_E_NO_SECURITY_MEMORY	0xC0000126	No Security Memory
RCX_E_NETWORK_FAULT	0xC0000140	Network Fault
RCX_E_CONNECTION_CLOSED	0xC0000141	Connection Closed
RCX_E_CONNECTION_TIMEOUT	0xC0000142	Connection Timeout
RCX_E_LONELY_NETWORK	0xC0000143	Lonely Network
RCX_E_DUPLICATE_NODE	0xC0000144	Duplicate Node
RCX_E_CABLE_DISCONNECT	0xC0000145	Cable Disconnected
RCX_E_BUS_OFF	0xC0000180	Network Node Bus Off
RCX_E_CONFIG_LOCKED	0xC0000181	Configuration Locked
RCX_E_APPLICATION_NOT_READY	0xC0000182	Application Not Ready
RCX_E_TIMER_APPL_PACKET_SENT	0xC002000C	Timer App Packet Sent

Table 56: RCX Common Status & Errors Codes

### 10.3.3 RCX Status & Error Codes

Error Code (Definition)	Value	Description
RCX_S_OK	0x00000000	SUCCESS, STATUS OKAY
RCX_S_QUE_UNKNOWN	0xC02B0001	UNKNOWN QUEUE
RCX_S_QUE_INDEX_UNKNOWN	0xC02B0002	UNKNOWN QUEUE INDEX
RCX_S_TASK_UNKNOWN	0xC02B0003	UNKNOWN TASK
RCX_S_TASK_INDEX_UNKNOWN	0xC02B0004	UNKNOWN TASK INDEX
RCX_S_TASK_HANDLE_INVALID	0xC02B0005	INVALID TASK HANDLE
RCX_S_TASK_INFO_IDX_UNKNOWN	0xC02B0006	UNKNOWN INDEX
RCX_S_FILE_XFR_TYPE_INVALID	0xC02B0007	INVALID TRANSFER TYPE
RCX_S_FILE_REQUEST_INCORRECT	0xC02B0008	INVALID FILE REQUEST
RCX_S_UNKNOWN_DESTINATION	0xC0000005	UNKNOWN DESTINATION
RCX_S_UNKNOWN_DESTINATION_ID	0xC0000006	UNKNOWN DESTINATION ID
RCX_S_INVALID_LENGTH	0xC0000007	INVALID LENGTH
RCX_S_UNKNOWN_COMMAND	0xC0000004	UNKNOWN COMMAND
RCX_S_INVALID_EXTENSION	0xC0000008	INVALID EXTENSION

Table 57: RCX Status & Error Codes

#### 10.3.3.1 RCX Status & Error Codes Slave State

Error Code (Definition)	Value	Description
RCX_SLAVE_STATE_UNDEFINED	0x00000000	UNDEFINED
RCX_SLAVE_STATE_OK	0x00000001	OK
RCX_SLAVE_STATE_FAILED	0x00000002	FAILED (at least one slave)

Table 58: RCX Status & Error Codes Slave State

## 10.4 ODM Error Codes

### 10.4.1 General ODM Error Codes

Error Code (Definition)	Value	Description
CODM3_E_INTERNALERROR	0x8004C700	Internal ODM Error
ODM3_E_DESCRIPTION_NOTFOUND	0x8004C701	Description not found in ODM database
CODM3_E_WRITEREGISTRY	0x8004C710	Error writing to the registry
CODM3_E_BAD_REGULAR_EXPRESSION	0x8004C711	Invalid regular expression
CODM3_E_COMCATEGORIE_MANAGER_FAILED	0x8004C712	Component Category Manager could not be instantiated
CODM3_E_COMCATEGORIE_ENUMERATION_FAILED	0x8004C713	Driver could not be enumerated by the Category Manager
CODM3_E_CREATE_LOCAL_BUFFER	0x8004C714	Error creating local buffers
CODM3_E_UNKNOWNHANDLE	0x8004C715	Unknown handle
CODM3_E_QUEUE_LIMIT_REACHED	0x8004C717	Queue size limit for connection reached
CODM3_E_DATASIZE_ZERO	0x8004C718	Zero data length passed
CODM3_E_INVALID_DATA	0x8004C719	Invalid data content
CODM3_E_INVALID_MODE	0x8004C71A	Invalid mode
CODM3_E_DATABASE_READ	0x8004C71B	Error reading database
CODM3_E_CREATE_DEVICE_THREAD	0x8004C750	Error creating device thread
CODM3_E_CREATE_DEVICE_THREAD_STOP_EVENT	0x8004C751	Error creating device thread stop event
CODM3_E_CLIENT_NOT_REGISTERED	0x8004C752	Client is not registered at the ODM
CODM3_E_NO_MORE_CLIENTS	0x8004C753	Maximum number of clients reached
CODM3_E_MAX_CLIENT_CONNECTIONS_REACHED	0x8004C754	Maximum number of client connections reached
CODM3_E_ENTRY_NOT_FOUND	0x8004C755	Driver/device not found
CODM3_E_DRIVER_NOT_FOUND	0x8004C757	The requested driver is unknown to the ODM
CODM3_E_DEVICE_ALREADY_LOCKED	0x8004C758	Device is locked by another process
CODM3_E_DEVICE_UNLOCKED_FAILED	0x8004C759	Device could not be unlocked, lock was set by another process
CODM3_E_DEVICE_LOCK_NECESSARY	0x8004C75A	Operation requires a device lock to be set
CODM3_E_DEVICE_SUBSCRIPTIONLIMIT	0x8004C75B	Maximum number of servers registered for this device reached
CODM3_E_DEVICE_NOTSUBSCRIBED	0x8004C75C	Process is not registered as a server on this device
CODM3_E_DEVICE_NO_MESSAGE	0x8004C75D	No message available
CODM3_E_TRANSFERTIMEOUT	0x8004C760	Message transfer timeout
CODM3_E_MESSAGE_INSERVICE	0x8004C761	Message in service

Table 59: ODM Error Codes - General ODM Error Codes

## 10.4.2 General ODM Driver Error Codes

Error Code (Definition)	Value	Description
CODM3_E_DRV_OPEN_DEVICE	0x8004C7A0	Packet type unsupported by driver
CODM3_E_DRV_INVALID_IDENTIFIER	0x8004C7A1	Invalid device identifier
CODM3_E_DRV_DEVICE_PARAMETERS_MISMATCH	0x8004C7A3	Parameters differ from requested device
CODM3_E_DRV_BROWSE_NO_DEVICES	0x8004C7A4	No devices found
CODM3_E_DRV_CREATE_DEVICE_INST	0x8004C7A5	Device instance could not be created
CODM3_E_DRV_DEVICE_NOMORE_TX	0x8004C7A6	Device connection limit reached
CODM3_E_DRV_DEVICE_DUPLICATE_TX	0x8004C7A7	Duplicate transmitter ID
CODM3_E_DRV_DEVICE_NOT_CONFIGURED	0x8004C7A8	Device is not configured
CODM3_E_DRV_DEVICE_COMMUNICATION	0x8004C7A9	Device communication error
CODM3_E_DRV_DEVICE_NO_MESSAGE	0x8004C7AA	No message available
CODM3_E_DRV_DEVICE_NOT_READY	0x8004C7AB	Device not ready
CODM3_E_DRV_INVALIDCONFIGURATION	0x8004C7AC	Invalid driver configuration
CODM3_E_DRV_DLINVALIDMODE	0x8004C7C0	Invalid download mode
CODM3_E_DRV_DLINPROGRESS	0x8004C7C1	Download is active
CODM3_E_DRV_ULINPROGRESS	0x8004C7C2	Upload is active

Table 60: ODM Error Codes - General ODM Driver Error Codes

### 10.4.3 cifX Driver Specific ODM Error Codes

cifX Driver Specific ODM Error Codes		
Error Code (Definition)	Value	Description
DRV_E_BOARD_NOT_INITIALIZED	0x8004C001	DRIVER Board not initialized
DRV_E_INIT_STATE_ERROR	0x8004C002	DRIVER Error in internal init state
DRV_E_READ_STATE_ERROR	0x8004C003	DRIVER Error in internal read state
DRV_E_CMD_ACTIVE	0x8004C004	DRIVER Command on this channel is active
DRV_E_PARAMETER_UNKNOWN	0x8004C005	DRIVER Unknown parameter in function
DRV_E_WRONG_DRIVER_VERSION	0x8004C006	DRIVER Version is incompatible with DLL
DRV_E_PCI_SET_CONFIG_MODE	0x8004C007	DRIVER Error during PCI set configuration mode
DRV_E_PCI_READ_DPM_LENGTH	0x8004C008	DRIVER Could not read PCI dual port memory length
DRV_E_PCI_SET_RUN_MODE	0x8004C009	DRIVER Error during PCI set run mode
DRV_E_DEV_DPM_ACCESS_ERROR	0x8004C00A	DEVICE Dual port ram not accessible(board not found)
DRV_E_DEV_NOT_READY	0x8004C00B	DEVICE Not ready (ready flag failed)
DRV_E_DEV_NOT_RUNNING	0x8004C00C	DEVICE Not running (running flag failed)
DRV_E_DEV_WATCHDOG_FAILED	0x8004C00D	DEVICE Watchdog test failed
DRV_E_DEV_OS_VERSION_ERROR	0x8004C00E	DEVICE Signals wrong OS version
DRV_E_DEV_SYSERR	0x8004C00F	DEVICE Error in dual port flags
DRV_E_DEV_MAILBOX_FULL	0x8004C010	DEVICE Send mailbox is full
DRV_E_DEV_PUT_TIMEOUT	0x8004C011	DEVICE PutMessage timeout
DRV_E_DEV_GET_TIMEOUT	0x8004C012	DEVICE GetMessage timeout
DRV_E_DEV_GET_NO_MESSAGE	0x8004C013	DEVICE No message available
DRV_E_DEV_RESET_TIMEOUT	0x8004C014	DEVICE RESET command timeout
DRV_E_DEV_NO_COM_FLAG	0x8004C015	DEVICE COM-flag not set. Check if Bus is running
DRV_E_DEV_EXCHANGE_FAILED	0x8004C016	DEVICE I/O data exchange failed
DRV_E_DEV_EXCHANGE_TIMEOUT	0x8004C017	DEVICE I/O data exchange timeout
DRV_E_DEV_COM_MODE_UNKNOWN	0x8004C018	DEVICE I/O data mode unknown
DRV_E_DEV_FUNCTION_FAILED	0x8004C019	DEVICE Function call failed
DRV_E_DEV_DPMSIZE_MISMATCH	0x8004C01A	DEVICE DPM size differs from configuration
DRV_E_DEV_STATE_MODE_UNKNOWN	0x8004C01B	DEVICE State mode unknown
DRV_E_DEV_HW_PORT_IS_USED	0x8004C01C	DEVICE Output port already in use
DRV_E_USR_OPEN_ERROR	0x8004C01E	USER Driver not opened (device driver not loaded)
DRV_E_USR_INIT_DRV_ERROR	0x8004C01F	USER Can't connect to device
DRV_E_USR_NOT_INITIALIZED	0x8004C020	USER Board not initialized (DevInitBoard not called)
DRV_E_USR_COMM_ERR	0x8004C021	USER IOCTL function failed
DRV_E_USR_DEV_NUMBER_INVALID	0x8004C022	USER Parameter DeviceNumber invalid
DRV_E_USR_INFO_AREA_INVALID	0x8004C023	USER Parameter InfoArea unknown
DRV_E_USR_NUMBER_INVALID	0x8004C024	USER Parameter Number invalid
DRV_E_USR_MODE_INVALID	0x8004C025	USER Parameter Mode invalid
DRV_E_USR_MSG_BUF_NULL_PTR	0x8004C026	USER NULL pointer assignment
DRV_E_USR_MSG_BUF_TOO_SHORT	0x8004C027	USER Message buffer too small



cifX Driver Specific ODM Error Codes		
Error Code (Definition)	Value	Description
DRV_E_USR_SIZE_INVALID	0x8004C028	USER Parameter Size invalid
DRV_E_USR_SIZE_ZERO	0x8004C02A	USER Parameter Size with zero length
DRV_E_USR_SIZE_TOO_LONG	0x8004C02B	USER Parameter Size too long
DRV_E_USR_DEV_PTR_NULL	0x8004C02C	USER Device address null pointer
DRV_E_USR_BUF_PTR_NULL	0x8004C02D	USER Pointer to buffer is a null pointer
DRV_E_USR_SENDSIZE_TOO_LONG	0x8004C02E	USER Parameter SendSize too large
DRV_E_USR_RECVSIZE_TOO_LONG	0x8004C02F	USER Parameter ReceiveSize too large
DRV_E_USR_SENDBUF_PTR_NULL	0x8004C030	USER Pointer to send buffer is a null pointer
DRV_E_USR_RECVBUF_PTR_NULL	0x8004C031	USER Pointer to receive buffer is a null pointer
DRV_E_DMA_INSUFF_MEM	0x8004C032	DMA Memory allocation error
DRV_E_DMA_TIMEOUT_CH4	0x8004C033	DMA Read I/O timeout
DRV_E_DMA_TIMEOUT_CH5	0x8004C034	DMA Write I/O timeout
DRV_E_DMA_TIMEOUT_CH6	0x8004C035	DMA PCI transfer timeout
DRV_E_DMA_TIMEOUT_CH7	0x8004C036	DMA Download timeout
DRV_E_DMA_DB_DOWN_FAIL	0x8004C037	DMA Database download failed
DRV_E_DMA_FW_DOWN_FAIL	0x8004C038	DMA Firmware download failed
DRV_E_CLEAR_DB_FAIL	0x8004C039	DMA Clear database on the device failed
DRV_E_DEV_NO_VIRTUAL_MEM	0x8004C03C	DMA USER Virtual memory not available
DRV_E_DEV_UNMAP_VIRTUAL_MEM	0x8004C03D	DMA USER Unmap virtual memory failed
DRV_E_GENERAL_ERROR	0x8004C046	DRIVER General error
DRV_E_DMA_ERROR	0x8004C047	DRIVER General DMA error
DRV_E_WDG_IO_ERROR	0x8004C048	DRIVER I/O WatchDog failed
DRV_E_WDG_DEV_ERROR	0x8004C049	DRIVER Device Watchdog failed
DRV_E_USR_DRIVER_UNKNOWN	0x8004C050	USER Driver unknown
DRV_E_USR_DEVICE_NAME_INVALID	0x8004C051	USER Device name invalid
DRV_E_USR_DEVICE_NAME_UNKNOWN	0x8004C052	USER Device name unknown
DRV_E_USR_DEVICE_FUNC_NOTIMPL	0x8004C053	USER Device function not implemented
DRV_E_USR_FILE_OPEN_FAILED	0x8004C064	USER File could not be opened
DRV_E_USR_FILE_SIZE_ZERO	0x8004C065	USER File size zero
DRV_E_USR_FILE_NO_MEMORY	0x8004C066	USER Not enough memory to load file
DRV_E_USR_FILE_READ_FAILED	0x8004C067	USER File read failed
DRV_E_USR_INVALID_FILETYPE	0x8004C068	USER File type invalid
DRV_E_USR_FILENAME_INVALID	0x8004C069	USER Invalid filename
DRV_E_FW_FILE_OPEN_FAILED	0x8004C06E	USER Firmware file could not be opened
DRV_E_FW_FILE_SIZE_ZERO	0x8004C06F	USER Not enough memory to load firmware file
DRV_E_FW_FILE_NO_MEMORY	0x8004C070	USER Not enough memory to load firmware file
DRV_E_FW_FILE_READ_FAILED	0x8004C071	USER Firmware file read failed
DRV_E_FW_INVALID_FILETYPE	0x8004C072	USER Firmware file type invalid
DRV_E_FW_FILENAME_INVALID	0x8004C073	USER Firmware file name not valid
DRV_E_FW_DOWNLOAD_ERROR	0x8004C074	USER Firmware file download error
DRV_E_FW_FILENAME_NOT_FOUND	0x8004C075	USER Firmware file not found in the internal table
DRV_E_FW_BOOTLOADER_ACTIVE	0x8004C076	USER Firmware file BOOTLOADER active

cifX Driver Specific ODM Error Codes		
Error Code (Definition)	Value	Description
DRV_E_FW_NO_FILE_PATH	0x8004C077	USER Firmware file no file path
DRV_E_CF_FILE_OPEN_FAILED	0x8004C078	USER Configuration file could not be opened
DRV_E_CF_FILE_SIZE_ZERO	0x8004C079	USER Configuration file size zero
DRV_E_CF_FILE_NO_MEMORY	0x8004C07A	USER Not enough memory to load configuration file
DRV_E_CF_FILE_READ_FAILED	0x8004C07B	USER Configuration file read failed
DRV_E_CF_INVALID_FILETYPE	0x8004C07C	USER Configuration file type invalid
DRV_E_CF_FILENAME_INVALID	0x8004C07D	USER Configuration file name not valid
DRV_E_CF_DOWNLOAD_ERROR	0x8004C07E	USER Configuration file download error
DRV_E_CF_FILE_NO_SEGMENT	0x8004C07F	USER No flash segment in the configuration file
DRV_E_CF_DIFFERS_FROM_DBM	0x8004C080	USER Configuration file differs from database
DRV_E_DBM_SIZE_ZERO	0x8004C083	USER Database size zero
DRV_E_DBM_NO_MEMORY	0x8004C084	USER Not enough memory to upload database
DRV_E_DBM_READ_FAILED	0x8004C085	USER Database read failed
DRV_E_DBM_NO_FLASH_SEGMENT	0x8004C086	USER Database segment unknown
DEV_E_CF_INVALID_DESCRIPTOR_VERSION	0x8004C096	CONFIG Version of the descriptor table invalid
DEV_E_CF_INVALID_INPUT_OFFSET	0x8004C097	CONFIG Input offset is invalid
DEV_E_CF_NO_INPUT_SIZE	0x8004C098	CONFIG Input size is 0
DEV_E_CF_MISMATCH_INPUT_SIZE	0x8004C099	CONFIG Input size does not match configuration
DEV_E_CF_INVALID_OUTPUT_OFFSET	0x8004C09A	CONFIG Invalid output offset
DEV_E_CF_NO_OUTPUT_SIZE	0x8004C09B	CONFIG Output size is 0
DEV_E_CF_MISMATCH_OUTPUT_SIZE	0x8004C09C	CONFIG Output size does not match configuration
DEV_E_CF_STN_NOT_CONFIGURED	0x8004C09D	CONFIG Station not configured
DEV_E_CF_CANNOT_GET_STN_CONFIG	0x8004C09E	CONFIG Cannot get the Station configuration
DEV_E_CF_MODULE_DEF_MISSING	0x8004C09F	CONFIG Module definition is missing
DEV_E_CF_MISMATCH_EMPTY_SLOT	0x8004C0A0	CONFIG Empty slot mismatch
DEV_E_CF_MISMATCH_INPUT_OFFSET	0x8004C0A1	CONFIG Input offset mismatch
DEV_E_CF_MISMATCH_OUTPUT_OFFSET	0x8004C0A2	CONFIG Output offset mismatch
DEV_E_CF_MISMATCH_DATA_TYPE	0x8004C0A3	CONFIG Data type mismatch
DEV_E_CF_MODULE_DEF_MISSING_NO_SI	0x8004C0A4	CONFIG Module definition is missing,(no Slot/Idx)

Table 61: cifX Driver Specific ODM Error Codes

## 10.5 Error Codes cifX Device Driver and netX Driver

### 10.5.1 Generic Error Codes

Error Code (Definition)	Value	Description
CIFX_INVALID_POINTER	0x800A0001L	Invalid pointer (NULL) passed to driver
CIFX_INVALID_BOARD	0x800A0002L	No board with the given nameindex available
CIFX_INVALID_CHANNEL	0x800A0003L	No channel with the given index available
CIFX_INVALID_HANDLE	0x800A0004L	Invalid handle passed to driver
CIFX_INVALID_PARAMETER	0x800A0005L	Invalid parameter
CIFX_INVALID_COMMAND	0x800A0006L	Invalid command
CIFX_INVALID_BUFFERSIZE	0x800A0007L	Invalid buffer size
CIFX_INVALID_ACCESS_SIZE	0x800A0008L	Invalid access size
CIFX_FUNCTION_FAILED	0x800A0009L	Function failed
CIFX_FILE_OPEN_FAILED	0x800A000AL	File could not be opened
CIFX_FILE_SIZE_ZERO	0x800A000BL	File size is zero
CIFX_FILE_LOAD_INSUFF_MEM	0x800A000CL	Insufficient memory to load file
CIFX_FILE_CHECKSUM_ERROR	0x800A000DL	File checksum compare failed
CIFX_FILE_READ_ERROR	0x800A000EL	Error reading from file
CIFX_FILE_TYPE_INVALID	0x800A000FL	Invalid file type
CIFX_FILE_NAME_INVALID	0x800A0010L	Invalid file name
CIFX_FUNCTION_NOT_AVAILABLE	0x800A0011L	Driver function not available
CIFX_BUFFER_TOO_SHORT	0x800A0012L	Given buffer is too short
CIFX_MEMORY_MAPPING_FAILED	0x800A0013L	Failed to map the memory
CIFX_NO_MORE_ENTRIES	0x800A0014L	No more entries available
CIFX_CALLBACK_MODE_UNKNOWN	0x800A0015L	Unkown callback handling mode
CIFX_CALLBACK_CREATE_EVENT_FAILED	0x800A0016L	Failed to create callback events
CIFX_CALLBACK_CREATE_RECV_BUFFER	0x800A0017L	Failed to create callback receive buffer

Table 62: Generic Error Codes

## 10.5.2 Generic Driver Error Codes

Error Code (Definition)	Value	Description
CIFX_DRV_NOT_INITIALIZED	0x800B0001L	Driver not initialized
CIFX_DRV_INIT_STATE_ERROR	0x800B0002L	Driver init state error
CIFX_DRV_READ_STATE_ERROR	0x800B0003L	Driver read state error
CIFX_DRV_CMD_ACTIVE	0x800B0004L	Command is active on device
CIFX_DRV_DOWNLOAD_FAILED	0x800B0005L	General error during download
CIFX_DRV_WRONG_DRIVER_VERSION	0x800B0006L	Wrong driver version
CIFX_DRV_DRIVER_NOT_LOADED	0x800B0030L	CIFx driver is not running
CIFX_DRV_INIT_ERROR	0x800B0031L	Failed to initialize the device
CIFX_DRV_CHANNEL_NOT_INITIALIZED	0x800B0032L	Channel not initialized (xOpenChannel not called)
CIFX_DRV_IO_CONTROL_FAILED	0x800B0033L	IOControl call failed
CIFX_DRV_NOT_OPENED(	0x800B0034L	Driver was not opened
CIFX_DRV_DOWNLOAD_STORAGE_UNKN OWN	0x800B0040L	Unknown download storage type (RAMFLASH based) found
CIFX_DRV_DOWNLOAD_FW_WRONG_CHA NNEL	0x800B0041L	Channel number for a firmware download not supported
CIFX_DRV_DOWNLOAD_MODULE_NO_BAS EOS	0x800B0042L	Modules are not allowed without a Base OS firmware

Table 63: Generic Driver Error Codes

### 10.5.3 Generic Device Error Codes

Error Code (Definition)	Value	Description
CIFX_DEV_DPM_ACCESS_ERROR	0x800C0010L	Dual port memory not accessible (board not found)
CIFX_DEV_NOT_READY	0x800C0011L	Device not ready (ready flag failed)
CIFX_DEV_NOT_RUNNING	0x800C0012L	Device not running (running flag failed)
CIFX_DEV_WATCHDOG_FAILED	0x800C0013L	Watchdog test failed
CIFX_DEV_SYSERR	0x800C0015L	Error in handshake flags
CIFX_DEV_MAILBOX_FULL	0x800C0016L	Send mailbox is full
CIFX_DEV_PUT_TIMEOUT	0x800C0017L	Send packet timeout
CIFX_DEV_GET_TIMEOUT	0x800C0018L	Receive packet timeout
CIFX_DEV_GET_NO_PACKET	0x800C0019L	No packet available
CIFX_DEV_MAILBOX_TOO_SHORT	0x800C001AL	Mailbox too short
CIFX_DEV_RESET_TIMEOUT	0x800C0020L	Reset command timeout
CIFX_DEV_NO_COM_FLAG	0x800C0021L	COM-flag not set
CIFX_DEV_EXCHANGE_FAILED	0x800C0022L	IO data exchange failed
CIFX_DEV_EXCHANGE_TIMEOUT	0x800C0023L	IO data exchange timeout
CIFX_DEV_COM_MODE_UNKNOWN	0x800C0024L	Unknown IO exchange mode
CIFX_DEV_FUNCTION_FAILED	0x800C0025L	Device function failed
CIFX_DEV_DPMSIZE_MISMATCH	0x800C0026L	DPM size differs from configuration
CIFX_DEV_STATE_MODE_UNKNOWN	0x800C0027L	Unknown state mode
CIFX_DEV_HW_PORT_IS_USED	0x800C0028L	Device is still accessed
CIFX_DEV_CONFIG_LOCK_TIMEOUT	0x800C0029L	Configuration locking timeout
CIFX_DEV_CONFIG_UNLOCK_TIMEOUT	0x800C002AL	Configuration unlocking timeout
CIFX_DEV_HOST_STATE_SET_TIMEOUT	0x800C002BL	Set HOST state timeout
CIFX_DEV_HOST_STATE_CLEAR_TIMEOUT	0x800C002CL	Clear HOST state timeout
CIFX_DEV_INITIALIZATION_TIMEOUT	0x800C002DL	Timeout during channel initialization
CIFX_DEV_BUS_STATE_ON_TIMEOUT	0x800C002EL	Set Bus ON Timeout
CIFX_DEV_BUS_STATE_OFF_TIMEOUT	0x800C002FL	Set Bus OFF Timeout
CIFX_DEV_MODULE_ALREADY_RUNNING	0x800C0040L	Module already running
CIFX_DEV_MODULE_ALREADY_EXISTS	0x800C0041L	Module already exists

Table 64: Generic Device Error Codes

## 10.6 Error Codes netX Driver

### 10.6.1 CIFS API Transport Error Codes

Error Code (Definition)	Value	Description
CIFS_TRANSPORT_SEND_TIMEOUT	0x800D0001L	Time out while sending data
CIFS_TRANSPORT_RECV_TIMEOUT	0x800D0002L	Time out waiting for incoming data
CIFS_TRANSPORT_CONNECT	0x800D0003L	Unable to communicate to the device no answer
CIFS_TRANSPORT_ABORTED	0x800D0004L	Transfer has been aborted due to keep alive timeout or interface detachment
CIFS_CONNECTOR_FUNCTIONS_READ_ERROR	0x800D0010L	Error reading the connector functions from the DLL
CIFS_CONNECTOR_IDENTIFIER_TOO_LONG	0x800D0011L	Connector delivers an identifier longer than 6 characters
CIFS_CONNECTOR_IDENTIFIER_EMPTY	0x800D0012L	Connector delivers an empty identifier
CIFS_CONNECTOR_DUPLICATE_IDENTIFIER	0x800D0013L	Connector identifier already used

Table 65: CIFS API Transport Error Codes

### 10.6.2 CIFS API Transport Header State Error Codes

Error Code (Definition)	Value	Description
CIFS_TRANSPORT_ERROR_UNKNOWN	0x800E0001L	Unknown error code in transport header
CIFS_TRANSPORT_CHECKSUM_ERROR	0x800E0002L	CRC16 checksum failed
CIFS_TRANSPORT_LENGTH_INCOMPLETE	0x800E0003L	Transaction with incomplete length detected
CIFS_TRANSPORT_DATA_TYPE_UNKNOWN	0x800E0004L	Device does not support requested data type
CIFS_TRANSPORT_DEVICE_UNKNOWN	0x800E0005L	Device not available unknown
CIFS_TRANSPORT_CHANNEL_UNKNOWN	0x800E0006L	Channel not available unknown
CIFS_TRANSPORT_SEQUENCE	0x800E0007L	Sequence error detected
CIFS_TRANSPORT_BUFFER_OVERFLOW	0x800E0008L	Buffer overflow detected
CIFS_TRANSPORT_RESOURCE	0x800E0009L	Device signals out of resources
CIFS_TRANSPORT_KEEPA_LIVE	0x800E000AL	Device connection monitoring error (Keep alive)
CIFS_TRANSPORT_DATA_TOO_SHORT	0x800E000BL	Received transaction data too short

Table 66: CIFS API Transport Header State Error Codes

## 10.7 ODM Error Codes DBM V4

ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_MD5_INVALID	0XC004C810	Checksum invalid
CDBM_E_INTERNALERROR	0XC004C811	Internal Error
CDBM_W_WRITEREGISTRY	0X8004C812	Error writing to the registry
CDBM_E_UNEXPECTED_VALUE_IN_OLD_HEADER_FORMAT	0XC004C813	Error in a file containing the old DBM Header format.
CDBM_E_CHECKSUM_INVALID	0XC004C814	The Checksum of the old Header is invalid
CDBM_E_DB_ALREADY_LOADED_FORMAT	0XC004C815	A database is already loaded
CDBM_E_NO_VALID_TRANSACTION	0XC004C816	No valid transaction handle given
CDBM_E_STD_STRUCT_ERROR	0XC004C817	An error occurred during validation of data
CDBM_E_UNSUPPORTED_DATA_TYPE_FORMAT	0XC004C818	Unsupported DataType
CDBM_W_CLASS_DELETED_FORMAT	0X8004C819 (Warning)	Using an Object which is marked as deleted
CDBM_W_CLIENT_DISCONNECTED	0X8004C81A (Warning)	A Client has already an outstanding connection to a Table. The connection is now destroyed.
CDBM_E_STRUCTURE_DEFINITION_INVALID	0XC004C81B	A structure definition of an Element in a Table is invalid
CDBM_E_NO_DATA_AVAILABLE	0XC004C81C	No data available for this operation
CDBM_E_NO_VALID_STRUCTURE	0XC004C81D	No valid structure available for this operation
CDBM_E_NO_TOGGLE_STRING_FOUND	0XC004C81E	No Toggle string found for this number
CDBM_E_ELEMENT_OUT_OF_RANGE	0XC004C81F	An element wasn't found in the Record of a Table
CDBM_E_ELEMENT_NOT_IN_TABLE	0XC004C820	The element is not part of the Table
CDBM_E_CANNOT_CONVERT_INTO_CLIENT_TYPE	0XC004C821	The data can't be converted into the Client type
CDBM_E_TRANSACTION_ALREADY_OPEN	0XC004C822	A transaction is already open. Please close this one first before opening a new one.
CDBM_I_OLD_WITHOUT_HEADER	0X4004C823 (Informational)	Use of an old DBM file Format without Header
CDBM_E_HR_FROM	0XC004C824	An HRESULT was received from a Subroutine
CDBM_E_PARAMETER	0XC004C825	A Parameter is invalid
CDBM_E_NOTIMPL	0XC004C826	Method is currently not implemented
CDBM_E_OUTOFMEMORY	0XC004C827	Out of memory
CDBM_E_NO_OPEN_TRANSACTION	0XC004C828	No transaction open
CDBM_E_NO_CONTENTS	0XC004C829	No contents available
CDBM_REC_NO_NOT_FOUND	0XC004C82A	Record not found
CDBM_STRUCTURE_ELEMENT_NOT_FOUND	0XC004C82B	Element of the Structure not found
CDBM_E_NO_MORE_RECORDS_IN_TABTYPE	0XC004C82C	Table type 3 can contain only one record
CDBM_E_WRITE	0XC004C82D	The data in the VARIANT must be given in a SafeArray
CDBM_E_WRITE_NO_PARRAY	0XC004C82E	The VARIANT contains no valid [parray] element

ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_WRITE_CANT_ACCESS_DATA	0XC004C82F	Unable to access SafeArray Data in the VARIANT
CDBM_E_WRITE_DATA	0XC004C830	To write the data of this Element it must be given as a BSTR, or as an Array of VT_UI1/VT_I1
CDBM_E_WRITE_BSTR_E1	0XC004C831	The BSTR string must have an even length.
CDBM_E_WRITE_BSTR_E2	0XC004C832	The BSTR string must contain only hex digits (0..9 and a/A..f/F).
CDBM_E_WRITE_CANT_INTERPRET_ARRAY	0XC004C833	Unable to interpret data in the SafeArray.
CDBM_E_WRITE_VT_ERROR	0XC004C834	Data type in the SafeArray is not VT_UI1 or VT_I1.
CDBM_E_WRITE_LENGTH	0XC004C835	Data length is invalid for write operation of this type.
CDBM_WRITE_ELEMENT	0XC004C836	Element not found in the Record of the Table
CDBM_MIN_MAX_ERROR	0XC004C837	Can't write data because of min underflow or max overflow
CDBM_TABLE_EXIST	0XC004C838	Table already exist in the database
CDBM_MIN_MAX_INVALID	0XC004C839	The Min value is greater than the Max Value
CDBM_DEF_MIN_MAX_INVALID	0XC004C83A	The Default Value is not in the range between the Min value and the Max Value
CDBM_CANT_CHANGE_STRUCTURE_WHILE_RECORDS_EXIST	0XC004C83B	It's not allowed to change the structure while Records exist in the Table
CDBM_NEW_STRUCT_NEEDS_TYPE	0XC004C83C	In a newly added structure the data type must be set also
CDBM_VALUE_ERROR	0XC004C83D	Range error while validating a value
CDBM_DATATYPE_UNSUPPORTED_IN_RCS	0XC004C83E	The data type is unsupported in the RCS file format
CDBM_I_COUNT_OF_TABLES_EXCEEDS_RCS_RANGE	0X4004C83F (Informational)	The count of Tables exceeds the RCS range of Tables. This can cause problems if the file is downloaded to RCS Systems
CDBM_I_COUNT_OF_TABLES_EXCEEDS_OLDDBM_RANGE	0X4004C840 (Informational)	The count of Tables exceeds the DBM32.DLL range of Tables. This can cause problems if the file is used with older Tools using the DBM32.DLL
CDBM_UNSUPPORTED_DATATYPE_IN_RCS_MODE	0XC004C841	The Data type is not compatible with the old database format
CDBM_WRITE_UNSTRUCTURED_1	0XC004C842	The data of an unstructured record can only be written with the 'Write' Method not with 'WriteElement'.
CDBM_READ_UNSTRUCTURED_1	0XC004C843	The data of an unstructured record can only be read with the 'Read' Method not with 'ReadElement'
CDBM_WRITE_DATA_LENGTH_INVALID	0XC004C844	The given data length doesn't correspond with the expected data length.
CDBM_UNKNOWN_VIEW_MODE	0XC004C845	The View Mode is unknown.
CDBM_E_DIAG_TABLE	0XC004C846	It doesn't make much sense to add or delete records from a diagnostic table because those changes are never saved.



ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_ADR_STRING_ERROR	0XC004C847	The given Address string doesn't fit the required format of this type where all address bytes must be in the range between 0 and FF
CDBM_ERROR_FROM_VAR_CHANGE_TYPE	0XC004C848	Function VariantChangeType return an error when trying to convert the Parameter
CDBM_E_MINERROR	0XC004C849	Error while comparing the Value with the lower range
CDBM_E_MAXERROR	0XC004C84A	Error while comparing the Value with the upper range
CDBM_E_RANGE_ERROR	0XC004C84B	Value out of Range
CDBM_E_TABLE_TYPE1	0XC004C84C	Table type 1 doesn't have a unique record length over all records
CDBM_E_TABLE_TYPE3_ADDREC	0XC004C84D	Table type 3 doesn't allow to insert more than one Record
CDBM_E_TABTYPE1	0XC004C84E	It's not allowed to insert more Records than structure definitions in Table Type 1
CDBM_E_TOGGLE_NOT_FOUND	0XC004C84F	Could not find the string for this value in the list of valid toggle strings
CDBM_E_TOGGLE_VALUE_IS_EMPTY_STRING	0XC004C850	The toggle string for this value is empty.
CDBM_VARIANT2BYTEARRAY_ERROR	0XC004C851	Error during conversion of Variant to byte array
CDBM_E_SET_ELEM_PROP_DEPENDENCY	0XC004C852	The Toggle Type needs also the additional string and the additional number entries in the Method
CDBM_E_TABTYPE1_REC_DOESNT_CORRESPOND_WITH_ELEMENT	0XC004C853	When reading the records of Table type 1 elementwise the record number must correspond with the element number
CDBM_TABTYPE1_NO_DATA_FOUND_FOR_RECORD	0XC004C854	When reading the records of Table type 1 and structure definitions are present it's assumed that for each structure element a corresponding record must exist
CDBM_E_TABTYPE1_WRITE_ELEMENT_NE_RECORD	0XC004C855	When writing the records of Table type 1 elementwise and structure definitions are present it's only allowed to write the corresponding element number in each record
CDBM_E_TABTYPE1_WRITE_ELEMENT_NOT_FOUND	0XC004C856	When writing the records of Table type 1 with an array and structure definitions are present it's assumed that a corresponding element number of this record exist
CDBM_I_TABLE_NAME_EXCEEDS_RCS_RANGE	0X4004C857 (Informational)	The Table name exceeds the maximum length of RCS compatible Table names
CDBM_W_CUT_STRING	0X8004C858 (Warning)	The string exceeds the maximum length and will be limited to the maximum length
CDBM_I_STRING_TOO_SHORT	0X4004C859 (Informational)	The string is below the minimum length. The minimum length will be reduced.
CDBM_I_STRING_TOO_LONG	0X4004C85A (Informational)	The string is exceeding the maximum. The maximum length will be extended.
CDBM_E_STRING_TOO_SHORT	0XC004C85B (Error)	The string is below the minimum length.
CDBM_E_STRING_TOO_LONG	0XC004C85C (Error)	The string is exceeding the maximum length

ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_WRONG_TYPE_FOR_WRITE	0XC004C85D	Writing on the Element type with the given Data type is not implemented
CDBM_E_NO_APPEND_IN_STRUCTURED_RECORDS	0XC004C85E	Method IDbmRecord::AppendData is not allowed for structured records
CDBM_E_DATA_UNAVAILABLE	0XC004C85F	No data available
CDBM_E_CANT_CONVERT_INTO	0XC004C860	Unable to convert the value into the Element type
CDBM_E_DBM_FILE_OVERFLOW	0XC004C861	You try to write a RCS like database which needs too much bytes
CDBM_E_PW_ERROR	0XC004C862	Password not correct
CDBM_E_FILELENGTH_CORRUPT	0XC004C863	The file length doesn't correspond to the length given in the Header.
CDBM_E_STRUCT_TYPE	0XC004C864	Error in the file.
CDBM_E_MD5SUM_INVALID	0XC004C865	MD5 sum invalid
CDBM_E_STRUCT_LENGTH	0XC004C866	Error in the expected and given structure length at a specific offset in the file.
CDBM_E_APPEND	0XC004C867	Append of data is only allowed if the Record contains only one data field and the field type will support this
CDBM_APPEND_NOT_SUPPORTED	0XC004C868	Append of Data not supported by this filed type
CDBM_DATA_TYPE_APPEND_ERROR	0XC004C869	Can't append Data of this type.
CDBM_E_UNSTRUCTURED_TABLE_DOESNT_SUPPORT_LENGTH	0XC004C86A	A Table without structure information doesn't support a record length
CDBM_E_DISABLED_WHILE_TRANSACTION_IS_OPEN	0XC004C86B	The Method is disabled while a transaction is open. Please close this one first and call the Method again.
CDBM_E_UNABLE_TO_CALL_READ_ON_LINKED_LIST	0XC004C86C	The Method is disabled on a LinkedList type. Please use the IRecordCollection on this type.
CDBM_E_ELEMENT_HAS_NO_SUBSTRUCTURE	0XC004C86D	An Element from a Table has no substructure
CDBM_STRUCT_ERROR_FROM_VAR_CHANGE_TYPE	0XC004C86E	Error from calling VariantChangeType
CDBM_E_FOREIGNKEY_DEF	0XC004C86F	The definition of a FOREIGNKEY must contain the name of the related Table in the description and this Table must exist at this time
CDBM_E_FOREIGNKEY_REF_TAB	0XC004C870	The description of a FOREIGNKEY must refer to a Table of type 'eDbmTableTypeLinkedList'
CDBM_E_KEY	0XC004C871	To create a Record Collection with a KEY it's necessary to have the data type KEY at the first position in all Records of the searched Table
CDBM_E_KEY_TABLE_TYPE	0XC004C872	This Method needs a Table of type 'eDbmTableTypeLinkedList'
CDBM_DATATYPE_NOT_IMPLEMENTED	0XC004C873	This data type is currently not implemented
CDBM_INSERT_POS_NOT_FOUND	0XC004C874	The position of the Record where the new one should be inserted wasn't found
CDBM_E_INSERT_REC_QI	0XC004C875	Error during insertion of a Record
CDBM_E_TAB_PROP	0XC004C876	Invalid Property in Table
CDBM_E_KEY_NOT_FOUND	0XC004C877	The KEY wasn't found in the Table

ODM Error Codes DBM V4		
Error Code (Definition)	Value	Description
CDBM_E_KEY_INVALID	0XC004C878	The KEY is invalid for this operation

*Table 67: ODM Error Codes DBM V4*

# 11 Appendix

## 11.1 User Rights

User-rights are set within the FDT-container. Depending on the level the configuration is accessible by the user or read-only.

To access the **Settings**, **Configuration** and **Diagnosis** panes of the AS-Interface Master DTM you do not need special user rights. Also all users can select the decimal or hexadecimal Display mode or sort table entries.



**Note:** To edit, set or configure the parameters of the **Settings** and **Configuration** panes, you need user rights for *Maintenance*, for *Planning Engineer* or for *Administrator*.

The following tables give an overview of the user right groups and which user rights you need to configure the single parameters.

### 11.1.1 Settings

	Observer	Operator	Maintenance	Planning Engineer	Administrator
<i>Driver</i>	D	D	X	X	X
<i>Verify or adapt Driver Settings</i>	-	-	X	X	X
<i>Configuring netX Driver</i>	-	-	X	X	X
<i>Device Assignment</i>	D	D	X	X	X
<i>Scanning for Devices</i>	-	-	X	X	X
<i>Selecting the Device (with or without firmware)</i>	-	-	X	X	X
<i>Selecting the Device once more (with Firmware)</i>	-	-	X	X	X
<i>Firmware Download</i>	D	D	X	X	X

Table 68: Settings (D = Displaying, X = Editing, Configuring)

### 11.1.2 Configuration

	Observer	Operator	Maintenance	Planning Engineer	Administrator
<i>Process Data</i>	D	D	X	X	X
<i>Address Table</i>	D	D	X	X	X
<i>Station Table</i>	D	D	X	X	X
<i>Master Settings</i>	D	D	X	X	X
<i>Bus Parameters</i>	D	D	X	X	X

Table 69: Configuration (D = Displaying, X = Editing, Configuring)

## 11.2 References

- [1] Device Type Manager (DTM) Style Guide, Version 1.0 ; FDT-JIG - Order No. <0001-0008-000>
- [2] Complete Specification of the Actuator-Sensor-Interface, presently Version 3, Revision 2, dated July 9, 2008
- [3] AS-Interface Master Protocol API Manual, Revision 4, Hilscher GmbH 2012

## 11.3 List of Figures

Figure 1: Dialog Structure of the AS-Interface Master DTM	14
Figure 2: Navigation Area	15
Figure 3: Status Bar – Status Fields 1 to 6	18
Figure 4: Status Bar Display Examples	18
Figure 5: Default Driver ‚cifX Device Driver’ for PC cards cifX	32
Figure 6: Default Driver ‚cifX Device Driver’ for PC cards cifX (example)	32
Figure 7: Default Driver ‚netX Driver’ for Hilscher devices except for PC cards cifX (example)	32
Figure 8: Manual Selection of multiple drivers (Example)	33
Figure 9: netX Driver > USB/RS232 Connection	36
Figure 10: netX Driver > TCP Connection	39
Figure 11: Device Assignment - detected Devices (* The name of the device class is displayed.) – Example for a device without firmware	41
Figure 12: Device Assignment - detected Devices (* The name of the device class is displayed.) Example for Devices without Firmware	43
Figure 13: Device Assignment - Selecting the Device (* The name of the device class is displayed.) – Example for a device without firmware / one Device is selected	44
Figure 14: Device Assignment - Selecting the Device (* The name of the device class is displayed.) – Example for Devices with and without Firmware / one Device is selected	45
Figure 15: Device Assignment - Selecting the Device (* The name of the device class is displayed.) – Example for a device with firmware / one Device is selected	46
Figure 16: Firmware Download	47
Figure 17: Error Message ‘The device is not assigned to the hardware!’	48
Figure 18: Window ‘Select Firmware File’ (Example CIFX)	49
Figure 19: Request Select Firmware File - Example Invalid Firmware	51
Figure 20: Request - Do you really want to download the firmware?	52
Figure 21: Firmware Download - Progress Bar	53
Figure 22: Clock Symbol and Hook Symbol green	53
Figure 23: Firmware Download – Download	53
Figure 24: Licensing	54
Figure 25: Process Data (Example)	58
Figure 26: Configuration > Address Table (Example)	59
Figure 27: Configuration > Address Table - Auto Addressing	60
Figure 28: Configuration > Address Table - Display Mode	60
Figure 29: Station Table (Example)	61
Figure 30: Configuration > Master Settings	62
Figure 31: Master Settings > Start of Bus Communication	63
Figure 32: Master Settings > Application Monitoring	63
Figure 33: Master Settings > Process Image Storage Format	64
Figure 34: Master Settings > Module Alignment	64
Figure 35: Master Settings > Process Data Handshake	65
Figure 36: Bus Parameters	66
Figure 37: Example Debug Mode with pending Diagnosis, (Master and Slave)	71
Network View of a Project with one Network	

Figure 38: Set Station Address	74
Figure 39: Change Extended ID1 Code	75
Figure 40: Live List	76
Figure 41: Live List > Slaves	77
Figure 42: Live List > Additional Information	78
Figure 43: Starting 'Network Scan' (Example)	80
Figure 44: Scan Response dialog of the Master DTM (Example)	81
Figure 45: Scan Response dialog of the Master DTM (Example)	82
Figure 46: Creating the DTM devices (Example)	85
Figure 47: Created Slave Devices in the Network (Example)	85
Figure 48: 'Download' current Configuration to AS-Interface Master (Example)	86
Figure 49: netDevice Message: Download	88
Figure 50: License Pane	91
Figure 51: License Pane - License Type	92
Figure 52: License Pane – License Type / Master protocols	92
Figure 53: License Pane – License Type / Utilities	92
Figure 54: License Pane - Request Form, please fill out / Device Information	95
Figure 55: License Pane - Request Form, please fill out / License Type	96
Figure 56: License Pane - Request Form, please fill out / Mandatory data	96
Figure 57: License Pane – Selecting the Subsidiary / Ordering / Contacts	97
Figure 58: License Pane – placing the order by E-mail	98
Figure 59: Example: Order E-Mail License request	98
Figure 60: License Pane - placing the order by Fax or by Telephone	99
Figure 61: Example: Order Data Form PrintOrderRequest	99
Figure 62: License Pane – Fax Number of the selected Subsidiary	100
Figure 63: License Pane – Telephone Number of the selected Subsidiary	100
Figure 64: License Pane - Ordering by exported File and E-Mail	101
Figure 65: License Pane - Download License	102
Figure 66: General Diagnosis	104
Figure 67: Master Diagnosis	106
Figure 68: Station Diagnosis - Station Status	107
Figure 69: Interface Diagnosis > Interface flags	108
Figure 70: Interface Diagnosis > Periphery Errors	109
Figure 71: Firmware Diagnosis (Example)	110
Figure 72: Extended Diagnosis > [Folder Name] > Task Information Example Display	112
Figure 73: Extended Diagnosis > [Folder Name] > IniBatch Status Example Display	113
Figure 74: Extended Diagnosis > ASI_MASTER > Commands	114
Figure 75: Extended Diagnosis > ASI_MASTER > Interrupts	115
Figure 76: Extended Diagnosis > ASI_MASTER > xC managment area	116
Figure 77: Extended Diagnosis > ASI_MASTER > xC Slave config area	117
Figure 78: Extended Diagnosis > ASI_MASTER > xC configuration area	117
Figure 79: Extended Diagnosis > ASI_APM > Master Configuration	118
Figure 80: Extended Diagnosis > ASI_APM > Commands	119
Figure 81: Extended Diagnosis > ASI_APM > DPM data exchange	120
Figure 82: Extended Diagnosis > ASI_APM > IO Status	121
Figure 83: Packet Monitor	123
Figure 84: Send > Packet Header and Send Data	124
Figure 85: Packet Header and Receive Data	125
Figure 86: IO Monitor	126
Figure 87: Window 'Process Image Monitor'	127

## 11.4 List of Tables

Table 1: Descriptions Dialog Pages	6
Table 2: List of Revisions	7
Table 3: General Device Information	15
Table 4: Overview Dialog Panes	16
Table 5: OK, Cancel, Apply and Help	17
Table 6: Selecting, inserting, deleting Table Line	17
Table 7: Status Bar Icons [1]	18
Table 8: Signal Words in Safety Messages on Personal Injury	22
Table 9: Signal Words in Safety Messages on Property Damage	22
Table 10: Getting started - Configuration Steps	26
Table 11: Descriptions of the Dialog Panes Settings	29
Table 12: Driver Selection List Parameters	32
Table 13: Parameters netX Driver > USB/RS232 Connection	37
Table 14: Parameters netX Driver > TCP Connection	40
Table 15: Parameters of the Device Assignment	42
Table 16: Parameter Firmware Download	47
Table 17: Parameters Select Firmware File	50
Table 18: Descriptions of the Dialog Panes Configuration	55
Table 19: Process Data	58
Table 20: Parameters Address Table Pane - Inputs / Outputs	59
Table 21: Station Table	61
Table 22: Range of Value / Value for the Watchdog time	63
Table 23: Master Settings Pane Parameters - Process Image Storage Format	64
Table 24: Parameters Master Settings > Module Alignment	64
Table 25: Bus Parameters	66
Table 26: Debug Mode Busline Colors and Debug Icons	72
Table 27: Legend Live List > Slaves	77
Table 28: Live List > Additional Information	78
Table 29: Description on the Scan Response dialog of the Master DTM	84
Table 30: Descriptions of the Diagnosis Panes	103
Table 31: Indication General Diagnosis	105
Table 32: Parameter General Diagnosis	105
Table 33: Parameter Master Diagnosis	106
Table 34: Station Diagnosis - Station Status	107
Table 35: Interface Diagnosis > Interface flags	109
Table 36: Legend Interface Diagnosis > Periphery Errors	109
Table 37: Description Table Task Information	110
Table 38: Descriptions of the Dialog Panes Extended Diagnosis	111
Table 39: Extended Diagnosis > [Folder Name] > Task Information	112
Table 40: Extended Diagnosis > [Folder Name] > IniBatch Status	113
Table 41: Extended Diagnosis > ASI_MASTER > Commands	114
Table 42: Extended Diagnosis > ASI_MASTER > Interrupts	115
Table 43: Extended Diagnosis > ASI_MASTER > xC management area	116
Table 44: Extended Diagnosis > ASI_MASTER > xC Slave config area	117
Table 45: Extended Diagnosis > ASI_MASTER > xC configuration area	117
Table 46: Extended Diagnosis > ASI_APM > Master Configuration	118
Table 47: Extended Diagnosis > ASI_APM > Commands	119
Table 48: Extended Diagnosis > ASI_APM > DPM data exchange	120
Table 49: Extended Diagnosis > ASI_APM > IO Status	121
Table 50: Descriptions of the Diagnosis Panes	122
Table 51: Descriptions Packet Header	124

Table 52: Descriptions Packet Header	125
Table 53: Notes to the Window 'Process Image Monitor'	128
Table 54: Overview Error Codes and Ranges	130
Table 55: RCX General Task Errors	131
Table 56: RCX Common Status & Errors Codes	132
Table 57: RCX Status & Error Codes	133
Table 58: RCX Status & Error Codes Slave State	133
Table 59: ODM Error Codes - General ODM Error Codes	134
Table 60: ODM Error Codes - General ODM Driver Error Codes	135
Table 61: cifX Driver Specific ODM Error Codes	138
Table 62: Generic Error Codes	139
Table 63: Generic Driver Error Codes	140
Table 64: Generic Device Error Codes	141
Table 65: CIFX API Transport Error Codes	142
Table 66: CIFX API Transport Header State Error Codes	142
Table 67: ODM Error Codes DBM V4	147
Table 68: Settings (D = Displaying, X = Editing, Configuring)	148
Table 69: Configuration (D = Displaying, X = Editing, Configuring)	148



## 11.5 Glossary

### AS-Interface

Actuator Sensor Interface, AS-I: A standard for field bus communication for connecting actuators and sensors according to EN 50295 and IEC 62026-2. It is an industrial networking solution (physical layer, data access method and protocol) used in PLC, DCS and PC-based automation systems. It is designed for connecting simple field I/O devices (e.g. binary ON/OFF devices such as actuators, sensors, rotary encoders, analog inputs and outputs, push buttons, and valve position sensors) in discrete manufacturing and process applications using a single 2-conductor cable.

### DTM

Device Type Manager

The Device Type Manager (DTM) is a software module with graphical user interface for the configuration and/or for diagnosis of devices.

### FDT

Field Device Tool

FDT specifies an interface, in order to be able to use DTM (Device Type Manager) in different applications of different manufacturers.

### Master

AS-Interface Master devices initiate the data traffic on the bus. In the AS-Interface protocol Master devices are called active participants. A master may send messages without external request.

### ODMV3

The Online-Data-Manager Version 3 (ODMV3) is an application interface. The ODMV3 works as a server, which can be run as an out-proc server or system service. Its task is to provide different applications (e. g. SYCON.net), access to multiple devices and even share one device amongst several applications.

### Slave

Slave devices are peripheral devices, like for example I/O devices or drives. Slave devices are also called passive participants. They do not receive the bus access authorization. That means, they may only accept received messages from the Master or send a message to the Master after enquiry of the Master.

## 11.6 Contacts

### Headquarters

#### Germany

Hilscher Gesellschaft für  
Systemautomation mbH  
Rheinstrasse 15  
65795 Hattersheim  
Phone: +49 (0) 6190 9907-0  
Fax: +49 (0) 6190 9907-50  
E-Mail: [info@hilscher.com](mailto:info@hilscher.com)

#### Support

Phone: +49 (0) 6190 9907-99  
E-Mail: [de.support@hilscher.com](mailto:de.support@hilscher.com)

### Subsidiaries

#### China

Hilscher Systemautomation (Shanghai) Co. Ltd.  
200010 Shanghai  
Phone: +86 (0) 21-6355-5161  
E-Mail: [info@hilscher.cn](mailto:info@hilscher.cn)

#### Support

Phone: +86 (0) 21-6355-5161  
E-Mail: [cn.support@hilscher.com](mailto:cn.support@hilscher.com)

#### France

Hilscher France S.a.r.l.  
69500 Bron  
Phone: +33 (0) 4 72 37 98 40  
E-Mail: [info@hilscher.fr](mailto:info@hilscher.fr)

#### Support

Phone: +33 (0) 4 72 37 98 40  
E-Mail: [fr.support@hilscher.com](mailto:fr.support@hilscher.com)

#### India

Hilscher India Pvt. Ltd.  
Pune, Delhi, Mumbai  
Phone: +91 8888 750 777  
E-Mail: [info@hilscher.in](mailto:info@hilscher.in)

#### Italy

Hilscher Italia S.r.l.  
20090 Vimodrone (MI)  
Phone: +39 02 25007068  
E-Mail: [info@hilscher.it](mailto:info@hilscher.it)

#### Support

Phone: +39 02 25007068  
E-Mail: [it.support@hilscher.com](mailto:it.support@hilscher.com)

#### Japan

Hilscher Japan KK  
Tokyo, 160-0022  
Phone: +81 (0) 3-5362-0521  
E-Mail: [info@hilscher.jp](mailto:info@hilscher.jp)

#### Support

Phone: +81 (0) 3-5362-0521  
E-Mail: [jp.support@hilscher.com](mailto:jp.support@hilscher.com)

#### Korea

Hilscher Korea Inc.  
Seongnam, Gyeonggi, 463-400  
Phone: +82 (0) 31-789-3715  
E-Mail: [info@hilscher.kr](mailto:info@hilscher.kr)

#### Switzerland

Hilscher Swiss GmbH  
4500 Solothurn  
Phone: +41 (0) 32 623 6633  
E-Mail: [info@hilscher.ch](mailto:info@hilscher.ch)

#### Support

Phone: +49 (0) 6190 9907-99  
E-Mail: [ch.support@hilscher.com](mailto:ch.support@hilscher.com)

#### USA

Hilscher North America, Inc.  
Lisle, IL 60532  
Phone: +1 630-505-5301  
E-Mail: [info@hilscher.us](mailto:info@hilscher.us)

#### Support

Phone: +1 630-505-5301  
E-Mail: [us.support@hilscher.com](mailto:us.support@hilscher.com)