

# アロー 電子音警報器

【型式】 ST-25CB、ST-25CJ、ST-25CP、ST-25CS、ST-25CJM

## 取扱説明書

このたびはお買い上げいただき、誠にありがとうございます。  
ご使用に際してはこの取扱説明書をよく読みのうえ、正しくお使いください。  
お読みになったあとは大切に保管し、必要なときにお読みください。

### 1 安全上のご注意

表示内容を無視して誤った使い方をしたときに生じる危害や損害を説明しています。

本機のご使用前に以下の「注意事項」をよくお読みいただき、理解し遵守してください。

**警告** 取扱いを誤った場合、使用者が死亡又は重症を負うことが想定される危害の程度をいう。

- 製品は取扱説明書に記載された範囲内でご使用ください。  
**感電、火災のおそれがあります。**
- 結線するときは、必ず電源を切ってから行なってください。  
**感電するおそれがあります。**
- 取扱説明書に記載された部品の交換、組み替え及び調整を行なうときは、必ず電源を切ってから行なってください。  
**感電するおそれがあります。**
- 本機の分解や改造は行なわないでください。  
**感電するおそれがあります。**


**注意** 取扱いを誤った場合、使用者が傷害を負うことが想定されるか、又は物的損害の発生が想定される危害、損害の程度をいう。

- 使用しない引出し線の先端は、必ず絶縁テープ等で絶縁処理をしてください。  
**感電、漏電、故障の原因となります。**
- 【おねがい】
- スピーカ開口部に雨水が入らないよう取り付けてください。
- 電源回路および内部回路保護のため、外部に必ずヒューズを接続してください。
- 電圧変動の激しい電源（変動率10%を超える電源）や、ノイズ、サージを多く含む電源（±1000V、1μsを超えるもの）でのご使用は避けてください。
- 引出し線を強く引っ張らないでください。
- IC・LSIを使用しているため、電磁波の強い場所での使用は避けてください。
- 信号線は複数台並列接続したり、他の機器と並列接続しないでください。（ST-25CJMのみ）
- 配線の余分な引き回しや他の電源線などとの併設は避けてください。
- 信号線には絶対に電圧を印加しないでください。
- 電源のON、OFFはチャタリング的に短時間で行なわないでください。  
OFF後は少なくとも2秒以上後にONになるようにしてください。（ST-25CB、ST-25CS以外）
- 供給電源の投入については、電圧が徐々に上昇して定格電圧になるような投入は避けてください。（ST-25CB、ST-25CS以外）
- ボリュームを強く押ししたり、無理に回さないでください。
- 取扱説明書に記載された部品の交換、組み替え及び調整を行なうときは、防水Oリング等のみ出しにご注意ください。
- 複数台使用される場合、音色を同時にスタートしても再生音は同期しません。

### 2 【型式の説明】 例) ST-25CP-DCW-E

製品の型式	製品の電源電圧	ボディ色	メロディの種類
ST-25CB シングルタイプ、アラーム	DC:DC12V	W:白	ST-25CPのみ記載
ST-25CS シングルタイプ、アラーム	DC24V	R:赤	-D:メロディDタイプ
ST-25CJ シングルタイプ、アラーム・メロディ	48:DC48V	Y:黄	-E:メロディEタイプ
ST-25CP シングルタイプ、メロディ	AC:AC110V		
ST-25CJM:マルチタイプ、アラーム・メロディ	AC220V		


### 3 【各部の名称】



### 4 【電源電圧の設定変更】


- 本機の電源電圧設定は以下の通りです。  
DCタイプ:DC24V  
ACタイプ:AC220V  
DCタイプでDC12V電源を使用される場合、またはACタイプでAC110V電源を使用される場合は、本機の電源電圧の設定変更が必要です。

電源電圧の設定変更方法  
●後蓋をはずし、電源電圧スイッチを切替えてください。



### 5 【取付方法】


- 取付けは、振動の少ない十分強度のある平らな面を選んでください。
- 必要に応じて本体取付アングルを本体から取外して、アングルを取付板に固定してください。アングルは取付穴3ヶ所で確実に固定してください。  
推奨ねじ:M8  
推奨トルク:6N・m
- 本体をアングル固定ボルトでアングルに取付けてください。  
推奨締付トルク:4N・m



取付穴加工図


### 6 【結線方法】

ST-25CB、ST-25CJ、ST-25CP、ST-25CSの場合




ST-25CJMの場合

外部接続回路にはリレーやスイッチなどの無電圧接点またはオープンコレクタ(NPN)をご使用ください。  
本機がDC12V/24Vタイプ及びDC48Vタイプの場合、外部接点の共通側を本機のCOM線の代わりに電源のマイナス線に接続してもご使用いただけます。  
複数の信号をONさせた場合、チャンネル番号の若い音が吹鳴します。



	ACタイプ	DCタイプ
最大使用電圧	DC24V以上	電源電圧以上
最大使用電流	50mA以上	
漏れ電流	0.1mA以下	
ON電圧	1V以下	1V以下(DC12V時は0.5V以下)

### 7 【使用方法】



ST-25CBの音色一覧(出荷時はGに設定)

SOUND SELECT	音色	音程	周期
A	非常ベル音	標準	標準
B	発車ベル音	標準	標準
C	警鐘音	標準	遅い
D	ピンポン音	標準	標準
E	非常ベル音	標準	標準
F	非常ベル音	高い	標準
G	警鐘音	標準	標準
H	ビュービュー音	標準	標準

ST-25CP-Dの音色一覧(出荷時はAに設定)

SOUND SELECT	音色
A	チャイム音
B	ビビビ音
C	禁じられた遊び
D	カチューシャ
E	メリーさんの羊
F	草競馬
G	アマリリス
H	モーツァルト40番
I	ピラ音
J	ダウン音
K	明日があるさ
L	エレクトリカルパレード
M	サザエさん
N	タッチ
O	非常ベル音
P	フリッカー音

ST-25CSの音色一覧(出荷時はAに設定)

SOUND SELECT	音色	音程	周期
A	フリッカー音	標準	標準
B	フリッカー音	高い	標準
C	ビーボー音	標準	標準
D	ビーボー音	高い	標準
E	フリッカー音	標準	速い
F	フリッカー音	高い	速い
G	ビーボー音	標準	速い
H	ビーボー音	高い	速い
I	電鈴音	標準	標準
J	電鈴音	高い	標準

ST-25CJの音色一覧(出荷時はDに設定)

SOUND SELECT	音色
A	ビーボー音
B	ビーボー音
C	チャイム音
D	フルル音
E	リング音
F	トレモロ音
G	大きな栗の木の下で(曲)
H	静かな湖畔(曲)

ST-25CJMの音色一覧

SOUND SELECT	音色
1	ビーボー音
2	ビーボー音
3	チャイム音
4	フルル音
5	リング音
6	トレモロ音
7	大きな栗の木の下で(曲)
8	静かな湖畔(曲)


### 8 【定格】

型式	電源電圧	消費電力	突入電流	製品質量
ST-25CB-DC*	DC12V	3W	12A	1kg
	DC24V	6W	0.4A	
ST-25CB-AC*	AC110V	8W	0.4A	1.2kg
	AC220V	8W	0.2A	
ST-25CJ-DCW	DC12V	3W	12A	1kg
	DC24V	6W	0.4A	
ST-25CJ-48W	DC48V	7.2W	5A	1.2kg
ST-25CJ-AC*	AC110V	8W	0.4A	1.2kg
	AC220V	8W	0.2A	
ST-25CP-DC*-D	DC12V	3W	3.5A	1kg
	DC24V	7W	1A	
ST-25CP-48W-D	DC48V	5.5W	5.5A	1.2kg
ST-25CP-AC*-D	AC110V	6.5W	0.3A	1.2kg
	AC220V	6.5W	0.15A	
ST-25CP-DC*-E	DC12V	3W	3.5A	1kg
	DC24V	7W	1A	
ST-25CP-48W-E	DC48V	5.5W	5.5A	1.2kg
ST-25CP-AC*-E	AC110V	6.5W	0.3A	1.2kg
	AC220V	6.5W	0.15A	
ST-25CS-DC*	DC12V	3W	12A	1kg
	DC24V	6W	0.4A	
ST-25CS-48W	DC48V	7.2W	5A	1.2kg
ST-25CS-AC*	AC110V	8W	0.4A	1.2kg
	AC220V	8W	0.2A	
ST-25CJM-DC*	DC12V	3W	12A	1kg
	DC24V	6W	0.4A	
ST-25CJM-AC*	AC110V	8W	0.4A	1.2kg
	AC220V	8W	0.2A	

音圧	最大102dB(1m前方)
定格出力	2W
定格時間	連続
使用周囲温度	-20℃～50℃
使用周囲湿度	35%～85%RH(結露のないこと)
使用雰囲気	腐食性ガスのないこと
保護特性	IP53(正方向取付時)

表記の音圧は最大値を表します。音色や電圧変動により音圧が低くなる場合があります。

### 9 【外観図】



[単位:mm]

## シュナイダーエレクトリックホールディングス株式会社

お問い合わせ

本製品でお困りのこと、ご質問など、いつでも解決のお手伝いをさせていただきます。  
弊社サポートサイトへアクセスしてください。

<http://www.pro-face.com/trans/ja/manual/1001.html>

PHA23527\_00



Schneider Electric

# ARROW ALARM

[MODEL] ST-25CB, ST-25CJ, ST-25CP, ST-25CS, ST-25CJM

**Instruction Manual** Thank you for purchasing. Please read this instruction manual carefully before installation. Please keep it carefully after having read, and please read when it is necessary.

## 1 [Precaution] Injury or damage by failure to follow these instructions.

Read and comprehend and follow the instructions below before installing.

**Warning** Failure to follow these instructions will result in death or serious injury.

- Do not use the product outside instructions in this manual.
- HAZARD OF ELECTRIC SHOCK OR BURN**
- Turn off power supply before wiring.
- HAZARD OF ELECTRIC SHOCK**
- Turn off power supply before replacing accessories, rearrangement of LED units or other operations following instructions in this manual.
- HAZARD OF ELECTRIC SHOCK**
- Do not disassemble or modify the product outside instructions in this manual.
- HAZARD OF ELECTRIC SHOCK**

**Caution** Failure to follow these instructions will result in serious injury or equipment damage.

- Provide any unused cord or wire with insulation.
- DESTRUCTION OR MALFUNCTION OF DEVICE, DESTRUCTION ELECTRIC SHOCK**


### [Other usage considerations]

- Install the product properly with the cone aimed at a downward direction so water will not invade.
- Install a fuse to protect power supply circuit and other internal circuit.
- Do not supply voltage with large fluctuation (more than 10% of the rated voltage) or with noises or surge (more than  $\pm 1000V$ ,  $1 \mu s$ ).
- Do not pull out the cables or wires.
- Do not install the product with strong electromagnetic waves to avoid malfunction of IC or LSI inside.
- Do not supply power from one power supply to plural products.
- And do not supply power from one power supply to other plural devices. (ST-25CJM only)
- Do not supply power from one power supply to plural products or other devices.
- Do not keep any cord or wire too loose.
- Do not supply voltage to contact input wires.
- Do not control power supply in a short time of less than 2 seconds by means of ON-OFF. When turning power supply off, wait for a delay of more than 500ms at least before turning power ON again. (Excluding ST-25CB, ST-25CS)
- Do not supply voltage as it comes up to the rated voltage gradually. (Excluding ST-25CB, ST-25CS)
- Do not rotate or push the volume dial or knob.
- Set O-ring between the main body and the back cover properly after replacing accessories, rearrangement of LED units or other operations following instructions in this manual.
- The melodies by each product do not always synchronize even they start at the same time.

## 2 [Model No.] Example: ST-25CP-DCW-E


Model No.	Voltage	Melody
ST-25CB :Single type,Alarm	DC:DC12V	ST-25CP only
ST-25CS :Single type,Alarm	DC24V	-D:Melody D type
ST-25CJ :Single type,Alarm+Melody	48:DC48V	W:White
ST-25CP :Single type,Melody	AC:AC110V	R:Red
ST-25CJM:Multi type,Alarm+Melody	AC220V	Y:Yellow

## 3 [Parts name]




## 4 [Equipment Installation]

- For AC and DC power sources, the source voltage is changeable. The AC source can be selected for AC 110 or 220 Volts and the DC source can be selected for DC 12 or 24 Volts.
- Note: When shipping, the source voltage is selected for the value designated on the label. Follow the steps to change the source voltage to the alternate voltage range.
- ① Take off the back cover by unscrewing the back cover screw.
- ② For AC, change the switch from AC 110 to AC220, or vice-versa.
- ③ For DC, change the switch from DC 12 to DC 24, or vice-versa.
- ④ Re-install the back cover and ensure the 'O' ring or packing is still intact before screwing the back cover screw back in. Adding silicone grease to the 'O' ring will ensure waterproofing.




## 5 [Source Voltage Selection]

- Detach the bracket from the main body. After securing the bracket to a firm position, place the resin washers in-between the bracket and the main body.
- Install the bracket with the bolts supplied and use a torque of 4N·m to secure the body to the bracket.




## 6 [Wiring method]

For ST-25CB, ST-25CJ, ST-25CP, ST-25CS




For ST-25CJM



## 7 [How to use]

Adjustment of volume  
 ● It is possible to adjust it by the volume behind the main body. (When shipping it, set it in the maximum.)

Setting of sound (ST-25CB, ST-25CJ, ST-25CP, ST-25CS)  
 ● It is possible to adjust it by the sound select switch behind the main body.



Sound for ST-25CB Sound select for [A] upon Shipment				Sound for ST-25CP-D Sound select for [A] upon Shipment			
SOUND SELECT	Sound	Interval	Period	SOUND SELECT	Sound	Interval	Period
A	Emergency Bell	Standard	Standard	A	Doorbell Chime		
B	Starting Bell	Standard	Standard	B	Intermittent Beep		
C	Gong Sound	Standard	Slow	C	Forbidden Play		
D	Pin Pon Sound	Standard	Standard	D	Katuiha		
E	Emergency Bell	Standard	Standard	E	Mary's Lamb		
F	Emergency Bell	High	Standard	F	Camp Town Races		
G	Gong Sound	Standard	Standard	G	Amaryllis		
H	Door Chime	Standard	Standard	H	Mozart #40		
				I	Timpani Melody		
				J	Arcade Sound		
				K	Ashita ga aru sa		
				L	Electrical Parade		
				M	Sazae-san		
				N	Touch		
				O	Emergency Bell		
				P	Flicker Chime		

Sound for ST-25CS Sound select for [A] upon Shipment				Sound for ST-25CP-E Sound select for [A] upon Shipment			
SOUND SELECT	Sound	Interval	Period	SOUND SELECT	Sound	Interval	Period
A	Flicker Sound	Standard	Standard	A	Doorbell Chime		
B	Flicker Sound	High	Standard	B	Intermittent Beep		
C	Pee Poo Sound	Standard	Standard	C	Good wine with Coffee		
D	Pee Poo Sound	High	Standard	D	Flower		
E	Flicker Sound	Standard	Rapid	E	Ground Star		
F	Flicker Sound	High	Rapid	F	Such a Life with a Tear		
G	Pee Poo Sound	Standard	Rapid	G	RAIDERS OF THE LOST ARK		
H	Pee Poo Sound	High	Rapid	H	ET Theme		
I	Electric Bell	Standard	Standard	I	Ambulance		
J	Electric Bell	High	Standard	J	Steam Whistle		

Sound for ST-25CJ Sound select for [D] upon Shipment	
SOUND SELECT	Sound
A	Pee Poo Sound
B	Pi Pi Pi Sound
C	Chime Sound
D	Electric Bell
E	Ring Tone
F	Tremolo
G	Under the Spreading
H	Quiet Lakeside

Sound for ST-25CJM	
SOUND SELECT	Sound
1	Pee Poo Sound
2	Pi Pi Pi Sound
3	Chime Sound
4	Electric Bell
5	Ring Tone
6	Tremolo
7	Under the Spreading
8	Quiet Lakeside


## 8 [Ratings]

Model	Voltage	Power Consumption	Inrush Current	Product Mass
ST-25CB-DC*	DC12V DC24V	3W 6W	12A 0.4A	1kg
ST-25CB-AC*	AC110V AC220V	8W	0.4A 0.2A	1.2kg
ST-25CJ-DCW	DC12V DC24V	3W 6W	12A 0.4A	1kg
ST-25CJ-48W	DC48V	7.2W	5A	1.2kg
ST-25CJ-AC*	AC110V AC220V	8W	0.4A 0.2A	1.2kg
ST-25CP-DC*-D	DC12V DC24V	3W 7W	3.5A 1A	1kg
ST-25CP-48W-D	DC48V	5.5W	5.5A	1.2kg
ST-25CP-AC*-D	AC110V AC220V	6.5W	0.3A 0.15A	1.2kg
ST-25CP-DC*-E	DC12V DC24V	3W 7W	3.5A 1A	1kg
ST-25CP-48W-E	DC48V	5.5W	5.5A	1.2kg
ST-25CP-AC*-E	AC110V AC220V	6.5W	0.3A 0.15A	1.2kg
ST-25CS-DC*	DC12V DC24V	3W 6W	12A 0.4A	1kg
ST-25CS-48W	DC48V	7.2W	5A	1.2kg
ST-25CS-AC*	AC110V AC220V	8W	0.4A 0.2A	1.2kg
ST-25CJM-DC*	DC12V DC24V	3W 6W	12A 0.4A	1kg
ST-25CJM-AC*	AC110V AC220V	8W	0.4A 0.2A	1.2kg

\* In the model shows the body color.

Sound Pressure	Max. 102dB
Rated Time	Continuous
Operating Temperature Range	-20°C~50°C
Operating Humidity Range	35%~85%RH
Operating Atmosphere	Non corrosive gas
Protection Characteristics	IP53

## 9 [Dimensions]



**Schneider Electric Japan Holdings Ltd.**

Inquiry

Do you have any questions about difficulties with your unit?  
 Please contact it willingly.  
[support@proface.co.jp](mailto:support@proface.co.jp)

PHA23527\_00