

## System Device for Basic Model

<b>Title</b>	System Device for Basic model
<b>Supported OS</b>	Windows 10 64bit (Build version is 21H2 or more.)
<b>Description</b>	After installing these drivers, your product can use PSEIO, SD Card slot, and Serial IO appropriately.

## How to Install

1. Right-Click on “PSE\_HECI\_xxx¥ISH.inf”.
2. Click “Install”.
3. Right-Click on “4557\_RC01¥ GeneStor.inf”
4. Click “Install”.
5. Right-Click on “iaLPSS2\_GPIO2¥iaLPSS\_GPIO2.inf”.
6. Click “Install”.
7. Right-Click on “iaLPSS2\_I2C¥iaLPSS\_I2C.inf”.
8. Click “Install”.
9. Right-Click on “iaLPSS2\_UART2¥iaLPSS\_UART2.inf”.
10. Click “Install”.