

How to install Utility

Title	FP6000 Series Utility
Supported OS	Windows 10 32bit (Build version is 1809 or more.)
Description	<p>When this utility is installed on a product, the product can use the following features.</p> <p>*For details of each function, refer to the User Manual.</p> <p>Utility Name</p> <ul style="list-style-type: none">● Application Launcher● Brightness● Buzzer● Calibration● Front USB● Touch Mode● FP6 System
Limitation	<ul style="list-style-type: none">● User cannot use this utility installer at the same time as FP6000 Series and Multi Display Adapter for SP5000 Series.● The Application Launcher layout will be partially reset when you use this installer.● Utilities are not supported on 2 units of FP6000 Series displays operating on Windows 10 32bit version.

How to Install

1. Download the following data from download page of “Microsoft Visual C++ Redistributable Package” and execute it. File name may be changed by Microsoft.

Installation of this module may fail if your product status doesn't require it to be installed.

Microsoft Visual C++ Redistributable Package

<https://learn.microsoft.com/en-US/cpp/windows/latest-supported-vc-redist?view=msvc-170>

vc_regist.x86.exe

2. Execute the “dpinst.exe” in Display Communication USB Driver for FP6.zip.
3. Execute Setup.exe.
4. Restart your product.