

STM6000 Series Edge Box HMI

Firmware Version 1.3.6

Release Notes

STM6EBH-RN.01

12/2024

Legal Information

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Pro-face brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.

Table of Contents

Safety Information.....	4
About the Book.....	5
Product Information	6
What's New.....	6
Installation Instructions	6
Limitations	6
Release History.....	6

Safety Information

Important Information

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

Please Note

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

About the Book

Document Scope

This document contains important information about the delivery of STM6000 Series Edge Box HMI firmware version 1.3.6, and the history of previous releases. Read this document completely before using the product or products described.

Validity Note

This document is valid for STM6000 Series Edge Box HMI firmware version 1.3.6.

The characteristics of the products described in this document are intended to match the characteristics that are available on www.pro-face.com. As part of our corporate strategy for constant improvement, we may revise the content over time to enhance clarity and accuracy. If you see a difference between the characteristics in this document and the characteristics on www.pro-face.com, consider www.pro-face.com to contain the latest information.

Related Documents

You can download the manuals related to this product from the Pro-face download page (www.pro-face.com/trans/en/manual/1085.html).

Information on Non-Inclusive or Insensitive Terminology

As a responsible, inclusive company, Schneider Electric is constantly updating its communications and products that contain non-inclusive or insensitive terminology. However, despite these efforts, our content may still contain terms that are deemed inappropriate by some customers.

Trademarks

Schneider Electric has made every effort to supply trademark information about company names, products, and services mentioned in this manual.

All other brands and products referenced in this document are acknowledged to be the trademarks or registered trademarks of their respective holders.

Product Information

What's New

No new features

Installation Instructions

For how to install and update the firmware, please refer to our website:
<https://origin-faq.pro-face.com/support/ww/en/faqs/FAQ000247806>

The following products are subject to update:

Reference	Description
Target product number	PFXSTM6B00DIOT
Update target firmware	Versions before 1.3.2

Limitations

- You cannot connect to this product from BLUE Open Studio version 2020 Service Pack 3 or earlier, as it does not support TLS connections during download.
- On first booting up after enabling download, this product creates a certificate file for TLS connections. Consequently, it may take several minutes for the connection to be established.
- When connecting to the Remote Agent with firmware version V1.3.2 or later, the "Use TLS" checkbox in the Remote Management Tool must be enabled.

Release History

Firmware Version	Release Date	Description
V1.0.0	Jan. 10, 2023	Initial version
V1.1.0	Feb. 20, 2023	Fixed license activation issue
V1.1.1	Feb. 23, 2023	Fixed small bugs

Firmware Version	Release Date	Description
V1.3.2	Apr. 26, 2024	<ul style="list-style-type: none">• Updated the Remote Agent.<ul style="list-style-type: none">◦ Improved the download speed.◦ Added support for TLS connections for project download with user name and password.*1• Added support for uppercase letters in the filename of Custom Widgets.• Added support for Remote Agent updates with the BLUE Open Studio runtime installer.*2• Improved the upgrade mechanism of Remote Agent.• Fixed factory setup issues.• Optimized BSP update.• Fixed security vulnerabilities.
V1.3.6	Nov. 21, 2024	Fixed an issue where Project/Runtime Transfer failed after transferring a project that contained custom widgets.

*1 Requires BLUE Open Studio version 2023 or later.

*2 With previous firmware versions, even if the Remote Agent was updated from BLUE Open Studio, rebooting would restore the originally installed firmware.

Schneider Electric Japan Holdings Ltd.

4-4-9 Kitahama, Chuo-ku, Osaka
Osaka, 541-0041, JAPAN

+ 81 (0) 50 4561 4800

www.pro-face.com

As standards, specifications, and design change from time to time,
please ask for confirmation of the information given in this publication.

© 2024 – Schneider Electric Japan Holdings Ltd. All rights reserved.

STM6EBH-RN.01