

Bitmap Font Register/Setting

1. Extract the downloaded Picture Font compressed file.
2. Copy the font folder from Extracted folder to the blow path.
C:\ProgramData\Pro-face\GP-Pro EX *.**\PictureFont(or BitmapFont)
("*.**" is a version number. It's possible to use Version 2.50 later.)
3. Launch the GP-Pro EX version that copied the folder.
4. Set numeric display to the Base Screen.
5. Open the [Display]tab, and Select [Bitmap Font] form [Font Type].
6. Select added font form [Model].

Important Notes

- When opening a project file on a PC, you cannot edit Bitmp Font if the Bitmap Font Settings have not been added. When you want to edit Bitmap Font other PC, add to Bitmap Font to using PC. However, it is possible to use not setup Bitmap Font on PC, if you won't edit Bitmap Font.
- Display on Screen
- simulation
- Transfer to Hardware