


Sample Templates Document: GPS_Selector04.blu



Document copyright policy:

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric, given in writing. You also agree not to establish any hypertext links to this document or its content.

Schneider Electric does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a "Danger" or "Warning" safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

About the Book



At a Glance

Document Scope

This manual describes how to use this product.

Validity Note

This documentation is valid for this product.

The technical characteristics of the device(s) described in this manual also appear online at <http://www.pro-face.com>.

The characteristics presented in the present document should be the same as those that appear online. In line with our policy of constant improvement we may revise content over time to improve clarity and accuracy. In the event that you see a difference between the document and online information, use the online information as your reference.

Registered Trademarks

Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Product names used in this manual may be the registered trademarks owned by the respective proprietors.

Related Documents

You can download the manuals related to this product, such as the software manual, from our support site at <http://www.pro-face.com/trans/en/manual/1001.html>.

Product Related Information

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In the event this product does not run properly due to whatever reason, it may be difficult or impossible to identify a function. Functions that may present a hazard if not immediately executed, such as a fuel shut-off, must be provided independently of this product. The machine's control system design must take into account the operator being unable to control the machine or making mistakes in the control of the machine.

WARNING

UNINTENDED EQUIPMENT OPERATION

The application of this product requires expertise in the design and programming of control systems. Only persons with such expertise should be allowed to program, install, alter, and apply this product.

- Follow all local and national safety standards.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems" or their equivalent governing your particular location.

Table of Content

Safety Information	3
About the Book	4
Template Overview	6
Project structure	6
Run Time Behavior	7
How to copy the objects to your project file	8
How to change GPS Selector variables	12
How to change variable input range	15
How to Resize GPS Selector	16
How to Move the Grid Parts	17

Target: ST-6500WAD

Driver: None

BLUE version 3.4.100 or later


Template Overview

This template has 14 different medium and large size selectors.

Project structure

- On Simple_Demo screen, 2 Content displays (Layout Object) of different sizes are placed. GPS_Selector4 content is called in Simple_Demo screen.

Screen			
Simple_Demo	ContentDisplay1 (Contents ID: 4)	GPS_Selector04	It has 14 contents of different numbers of points for both medium and large selectors Size:512 x 512 Size:256 x 256
	ContentDisplay2 (Contents ID: 4)		




Run Time Behavior

Runtime/Simulation of This template has circular Selector with Large and Medium Size, Input given in Numeric Display and Value shows in Selectors.


Enter the Input in Numeric Display and Selector Rotates to entered Value Maximum Value is 8.

How to copy the objects to your project file

1. Open your project file and downloaded project file simultaneously.




2. Open the downloaded project file and select the Grid object.
 - Click the Content from “Contents” and select the Grid parts by dragging the mouse




Or


- In Object List, select GPS_Selector04 object.



3. Copy the selected Grid object in content using  copy icon in global Toolbar.


4. Open your project file.

Select the desired Screen/Content and click the paste  icon in global Toolbar.




You can resize the Composite gauge. For more details, refer [How to Resize GPS Selector](#).

- Open the downloaded project file and select “All variables”. Select the displayed variables and click the copy icon from global Toolbar.




- Open your project file and select “All Variables”. Click an existing variable or a blank Variable and click paste icon in global toolbar.




The copied variable is pasted in your project.

Note1: You can also create your own variables to display in Selector. For more details, refer [How to change Selector variable](#)

7. Open the downloaded project file, select “User-Defined Converters”. Select the displayed converter and click the copy icon from the global Toolbar.




8. Open your project file, select “User-Defined Converters”. Click on the Converter screen and click paste icon from the global Toolbar.




How to change GPS Selector variables


1. Open your project, in screen click on object list and select NumericDisplay1.




2. In Properties tab, Select **Function > Basic > Current Value** and bind the desired variable from variable selector and click ok.




- Open your project, in Content click on object list and select Images2.




- In Properties tab, Select **Shape > Size/Location > Rotation Angle** and bind the desired variable from variable selector and click ok



- Open your project, in Content click on object list and select Switch1.



- In Properties tab, Select **Function > Touch > Destination** and bind the desired variable from variable selector and click ok.




- Repeat the step 5 and 6 for the remaining Switches

Note: Make sure to configure the input range same as source. For more details, refer [How to change variable input range](#).

8. In Project Explorer, select “User-Defined Converters”. Then Select GPS_Selector04_3

In Properties, Click  to open Expression Editor.


9. In Expression Editor, select the desired variable and its expression and click ok.




10. Repeat above step for GPS_Selector04_4 to GPS_Selector04_9.

How to change variable input range

1. Open your project, click on ‘All Variables’, and select the variable binded to GPS_Selector.
2. In Properties tab, change the ‘Minimum’ and ‘Maximum’ value for the input range.




3. In Project Explorer, select Screen/Content where GPS Selector is placed.
4. In Object List, select CircleScale1. In Properties tab, select **Shape > Text > Label Attribute > Minimum, Maximum** and change the value to input range used in variable.



5. Repeat step 4 for remaining Content in Project Explorer.

How to Resize GPS Selector

1. Select Screen (where GPS Selector is placed) and then select the Grid object.
2. In properties tab, change the Width and Height of the Grid object.



How to Move the Grid Parts

To move the Grid Parts, select the Grid Parts by dragging a mouse and click the outside frame (within 8 pixels) and move it. Else, the form of the Grid Parts will not be kept.

